ORIGINALE ARCHIVIO

CARLO GAVAZZI SPACE SpA

AMS02-PDS

Tipo Doc.: *Doc.Type:*	REPORT			N° DRD: *DRD N°:*	DEL 103
N° Doc.: *Doc. N°:*	**PDS-RP-CGS-116**	Ediz.: *Issue:* **1**	Data: *Date:* **27/07/2009**	Pagina *Page* **1**	Di *Of* **142**
Titolo : *Title :*	AMS02-PDS PFM REDUCED FUNCTIONAL TEST REPORT				

	Nome & Funzione *Name & Function*	Firma *Signature*	Data *Date*
Preparato da: *Prepared by:*	Albertin A. (DT/EE/)		27/7/09
Approvato da: *Approved by:*	Grossi R. (DT/EE) Alia S. (SYS) Francini E. (PA/QA) Cinquepalmi C. (PA/CC)		27/7/09 27-7-09 27/07/09 27/07/09
Applicazione autorizzata da: *Application authorized by:*	Olivier M. (PM)		27/07/09
Customer / Higher Level Contractor			
Accettato da: *Accepted by:*	ASI		
Approvato da: *Approved by:*	ASI		

LISTA DI DISTRIBUZIONE *DISTRIBUTION LIST*	N	A	I
Interna / *Internal*			
Albertin A.	1	X	
Alia s.	1	X	
Francini E.	1		X
Olivier M.	1		X
Esterna / *External*			
E. Russo (ASI)	1		X

N=Numero di copie A=Applicazione I=Informazione
N=Number of copy A=Application I=Information

Gestione documenti: *Data Management:* Firma / *Signature* 27/07/09 Data / *Date*

File: PDS-RP-CGS-116_Is1.doc

Questo documento contiene informazioni di proprietà di CARLO GAVAZZI SPACE SpA: Tutti i diritti sono riservati
All information contained in this document are property of CARLO GAVAZZI SPACE SpA. All right reserved.

REGISTRAZIONE DELLE MODIFICHE / *CHANGE RECORD*			
EDIZIONE *ISSUE*	DATA *DATE*	AUTORIZZAZIONE *CHANGE AUTHORITY*	OGGETTO DELLA MODIFICA E SEZIONI AFFETTE *REASON FOR CHANGE AND AFFECTED SECTIONS*
1	27/07/2009	-	First issue

Questo documento contiene informazioni di proprietà di CARLO GAVAZZI SPACE SpA. Tutti i diritti sono riservati.
All information contained in this document are property of CARLO GAVAZZI SPACE SpA. All right reserved.

LISTA DELLE PAGINE VALIDE / *LIST OF VALID PAGES*

PAGINA *PAGE*	EDIZIONE *ISSUE*	PAGINA *PAGE*	EDIZIONE *ISSUE*	PAGINA *PAGE*	EDIZIONE *ISSUE*	PAGINA *PAGE*	EDIZIONE *ISSUE*	PAGINA *PAGE*	EDIZIONE *ISSUE*
1 - 142	1								

Questo documento contiene informazioni di proprietà di CARLO GAVAZZI SPACE SpA. Tutti i diritti sono riservati.
All information contained in this document are property of CARLO GAVAZZI SPACE SpA. All right reserved.

TABLE OF CONTENT

1 SCOPE 7

2 DOCUMENTS 7

2.1 APPLICABLE DOCUMENTS 7
2.2 REFERENCE DOCUMENTS 7

3 ACRONYMS 8

4 PARTICIPANTS REQUIRED 9

4.1 GENERAL 9
4.2 RESPONSIBILITY 9
4.3 QA WITNESS OF TEST AND SIGN-OFF 9
4.4 NON CONFORMANCE AND FAILURES 9
4.5 CALIBRATION REQUIREMENTS 9

5 TEST ARTICLE 9

6 TEST CONFIGURATION 9

7 INSTRUMENTATION AND TEST EQUIPMENT 11

8 TEST CONDITION 12

9 TEST PROCEDURE VARIATION SHEET 12

10 TEST DATA SHEETS 14

10.1 DATA SHEETS FILLING UP 14
10.2 ELECTRICAL CONNECTIONS 15
10.2.1 ISOLATION 15
10.3 FUNCTIONAL VERIFICATION 16
10.3.1 A SECTION 16
10.3.1.1 SETUP 16
10.3.1.2 POWER ON WITH ISS MAIN BUS 16
10.3.1.2.1 CAN BUS COMMUNICATION LINE CHECK board 30 17
10.3.1.2.2 CAN BUS COMMUNICATION LINE CHECK board 31 17
10.3.1.2.3 PDS INTERNAL SERIAL COMMUNICATION CHECK BOARD 30 18
10.3.1.2.4 PDS INTERNAL SERIAL COMMUNICATION CHECK BOARD 31 19
10.3.1.2.5 CAN BUS BOARDS CROSS CMD OFF/ON AND SUICIDE TEST 20
10.3.1.3 POWER VIDEO GRAPPLE FIXTURE 1 POWER SUPPLY VERIFICATION (1P) 25
10.3.1.4 T0 POWER SUPPLY TEST 27
10.3.1.5 UNIT CHECK 29
10.3.1.5.1 INPUT STAGE A VERIFICATION 30
10.3.1.5.2 ESEM 1-A SIDE A 30
10.3.1.5.2.1 ESEM 1-A side A UNDER VOLTAGE TEST 32
10.3.1.5.2.2 ESEM 1-A side A OVER VOLTAGE TEST 33
10.3.1.5.2.3 ESEM 1-A side A Global ON/OFF test 35
10.3.1.5.3 PB2-1 SIDE A 36
10.3.1.5.4 ESEM 3A-1 SIDE A 39
10.3.1.5.5 PB2-2 SIDE A 42
10.3.1.5.6 ESEM 3A-2 SIDE A 45
10.3.1.5.7 PB2-3 SIDE A 48
10.3.1.5.8 ESEM 3A-3 SIDE A 51
10.3.1.5.9 PB2-4 SIDE A 54
ESEM 3A-4 SIDE A 57

Questo documento contiene informazioni di proprietà di CARLO GAVAZZI SPACE SpA. Tutti i diritti sono riservati.
All information contained in this document are property of CARLO GAVAZZI SPACE SpA. All right reserved.

10.3.1.5.10 ESEM 3-B SIDE A 61
10.3.1.5.10.1 CCS load verification 68
10.3.1.6 SIDE A TELEMETRY VERIFICATION 69
10.3.1.6.1 INPUT STAGE CURRENT MONITOR 69
10.3.1.6.2 INPUT STAGE – ESEM1A TELEMETRY 73
10.3.2 B SECTION 76
10.3.2.1 SETUP 76
10.3.2.2 POWER ON WITH ISS MAIN BUS 76
10.3.2.2.1 CAN BUS COMMUNICATION LINE CHECK board 30 77
10.3.2.2.2 CAN BUS COMMUNICATION LINE CHECK board 31 77
10.3.2.2.3 PDS INTERNAL SERIAL COMMUNICATION CHECK BOARD 30 78
10.3.2.2.4 PDS INTERNAL SERIAL COMMUNICATION CHECK BOARD 31 79
10.3.2.2.5 CAN BUS BOARDS CROSS CMD OFF/ON AND SIUCIDE TEST 80
10.3.2.3 POWER VIDEO GRAPPLE FIXTURE 2 POWER SUPPLY VERIFICATION (2p) 84
10.3.2.4 APCU POWER SUPPLY TEST 85
10.3.2.5 UNIT CHECK 87
10.3.2.5.1 INPUT STAGE B VERIFICATION 88
10.3.2.5.2 ESEM 1-A SIDE B 89
10.3.2.5.2.1 ESEM 1-A side B UNDER VOLTAGE TEST 90
10.3.2.5.2.2 ESEM 1-A side B OVER VOLTAGE TEST 91
10.3.2.5.2.3 ESEM 1-A side B Global ON/OFF test 93
10.3.2.5.3 PB2-1 SIDE B 94
10.3.2.5.4 ESEM 3A-1 SIDE B 97
10.3.2.5.5 PB2-2 SIDE B 101
10.3.2.5.6 ESEM 3A-2 SIDE B 104
10.3.2.5.7 PB2-3 SIDE B 107
10.3.2.5.8 ESEM 3A-3 SIDE B 110
10.3.2.5.9 PB2-4 SIDE B 113
10.3.2.5.10 ESEM 3A-4 SIDE B 116
10.3.2.5.11 ESEM 3-B SIDE B 120
10.3.2.6 SIDE B TELEMETRY VERIFICATION 126
10.3.2.6.1 INPUT STAGE CURRENT MONITOR 126
10.3.2.6.2 INPUT STAGE – ESEM1A TELEMETRY 130

11. ANNEX PVS 133

12. CONCLUSION 142

Questo documento contiene informazioni di proprietà di CARLO GAVAZZI SPACE SpA. Tutti i diritti sono riservati.
All information contained in this document are property of CARLO GAVAZZI SPACE SpA. All right reserved.

LIST OF TABLES

Tab. 1: Accuracy value 10
Tab. 2: INSTRUMENT LIST 11
Tab. 3: Side A Input Stage current monitors 72
Tab. 4: Side A Input Stage - ESEM 1-A telemetry 75
Tab. 5: Side B Input Stage current monitors 129
Tab. 6: Side B Input Stage - ESEM 1-A telemetry 132

Questo documento contiene informazioni di proprietà di CARLO GAVAZZI SPACE SpA. Tutti i diritti sono riservati.
All information contained in this document are property of CARLO GAVAZZI SPACE SpA. All right reserved.

1 SCOPE

This document describes the reduced test report, to demonstrate the AMS-02 Power Distribution System Proto Flight Model (PDS-PFM) functionality after closure box as indicated in MoM TRR PDS opening DC-IPC-2009-081 dated 04+05/06/2009.

The unit under test is:
AMS02-PDS
Model: PFM
Part number: 10-AMS02PDS-000.00
Serial number: FM01

The document corresponds to contract deliverable DEL 103.

2 DOCUMENTS

2.1 APPLICABLE DOCUMENTS

AD	Doc. Number	Issue / Date	Rev	Title / Applicability	Remarks
1	*AMS-RQ-CGS-002*	*1 / April 2007*	*N.A.*	*PDS Specification*	
2	*PDS-PL-CGS-003*	*1 / 11-05-2009*	*N.A.*	*AMS02 PDS DESIGN DEVELOPMENT AND QUALIFICATION PLAN*	
3	*PDS-PR-CGS-020*	*1 / 10/07/2009*	*N.A.*	*AMS02-PDS PFM Reduced Functional Test Procedure*	

2.2 REFERENCE DOCUMENTS

RD	Doc. Number	Issue / Date	Rev	Title / Applicability	Remarks
1	*10-AMS02PDS-000.00*	*28/07/2008*	*/*	*AMS02 Power Distribution System Assembly*	
2	*10-AMS02PDS-000.01*	*28/07/2008*	*/*	*AMS02 Power Distribution System Assembly Parts List*	
3	*10-AMS02PDS-000.02*	*08/06/2009*	*A*	*AMS02 Power Distribution System ICD*	
4	*PDS-IC-CGS-001*	*2 / 08-06-2009*	*N.A.*	*PDS FM electrical/functional, mechanical ICD*	

Questo documento contiene informazioni di proprietà di CARLO GAVAZZI SPACE SpA. Tutti i diritti sono riservati.
All information contained in this document are property of CARLO GAVAZZI SPACE SpA. All right reserved.

3 ACRONYMS

C.I.	Configuration Item. Also called Part Number (P/N)
CGS	Carlo Gavazzi Space
FM	Flight Model
NA	Not Applicable
P/N	Part Number. Also called Configuration Item C.I.
PA	Product Assurance
PDS	Power Distribution System
PVS	Procedure Variation Sheet
QA	Quality Assurance
S/N	Serial Number
TE	Test Equipment
UUT	Unit Under Test

Questo documento contiene informazioni di proprietà di CARLO GAVAZZI SPACE SpA. Tutti i diritti sono riservati.
All information contained in this document are property of CARLO GAVAZZI SPACE SpA. All right reserved.

4 PARTICIPANTS REQUIRED

4.1 GENERAL

All test will be performed under QA surveillance in accordance with, and following detailed procedure of applicable PA Plan.

4.2 RESPONSIBILITY

The technical responsibility for testing and test results is up to the Engineering department.

QA is responsible for ensuring that all the agreed procedures are carefully observed, that test equipment and instrumentation used during testing is calibrated and within validity date: that the test data sheets are recorded in the Test Report and signed by the operators and QA witnesses, that all non conforming condition and test results are properly documented and notified to the Prime Contractor, and that all requirements of applicable PA Plan, specification and Statement of Work pertaining to the acceptance tests, are fully satisfied.

4.3 QA WITNESS OF TEST AND SIGN-OFF

QA inspector, or its delegate, shall witness the tests described in this procedure in accordance to the requirement specified in the applicable PA Plans.

4.4 NON CONFORMANCE AND FAILURES

Any malfunction/defect which occurs during the test will be processed along the Non Conformance Procedure described in the applicable PA Plans.

4.5 CALIBRATION REQUIREMENTS

All instruments used for testing shall be calibrated.

Evidence of certification shall be provided by a label attached to the instruments itself, showing the calibration date, the expiring date and the signature of the operator.

5 TEST ARTICLE

The test article consists of: (see Par. 1).

Before starting the test, the model, P/N and SN of the test article to be tested shall be recorded on the step-by-step procedure sheets under the table cell "UNIT UNDER TEST".

6 TEST CONFIGURATION

Before the beginning of the test, be sure that all the cables between AMS02-PDS box and test setup are connected.

Follows a list of the needed instruments:

- 1 oscilloscope: it is recommended to connect the oscilloscope to PC in order to acquire the measurements (acquisition software required)
- 2 multimeters

Questo documento contiene informazioni di proprietà di CARLO GAVAZZI SPACE SpA. Tutti i diritti sono riservati.
All information contained in this document are property of CARLO GAVAZZI SPACE SpA. All right reserved.

- 1 short circuit generator
- 1 current probe to connect to oscilloscope
- EPP can box (interface between PC and PDS)
- 1 milliohmeter
- 1 personal computer with LINUX operative system
- Test racks

The needed interface software is the following:

- PDS-4
- USCM

During test, it's suggested the use of a fan applied to PDS dissipator.

The accuracy of the telemetry are resumed in the following table

	Signals	Monitored Range	Accuracy
Input Stage	Main Power Voltage	0V ÷ 190V	5%
	Main Power Current	-5A ÷ 33A	20% F.S. see RFW PDS-WV-CGS-002
	Analog Reference Voltage	~4V	±250mV
ESEM1-A	Main Power Voltage	0V ÷ 150V	3%
	Temperature	-40°C ÷ +90°C	±2°C
PB2	+28V Output Voltage	0V ÷ 36.76V	3%
	Analog Reference Voltage	~2V	±250mV
	Temperature	-40°C ÷ +90°C	±2°C
Esem3-A	Outlet #1 to #7 Current (rated 5A)	0A ÷ 7.5A	3%
	Outlet #8 Current (rated 10A)	0A ÷ 15A	3%
	Analog Reference Voltage	~3V	±250mV
	Temperature	-40°C ÷ +90°C	±2°C
ESEM3-B	Outlet #12 Current (rated 10A)	0A ÷ 15A	3%
	Analog Reference Voltage	~2.5V	±250mV
	Temperature	-40°C ÷ +90°C	±2°C

Tab. 1: Accuracy value

Questo documento contiene informazioni di proprietà di CARLO GAVAZZI SPACE SpA. Tutti i diritti sono riservati.
All information contained in this document are property of CARLO GAVAZZI SPACE SpA. All right reserved.

7 INSTRUMENTATION AND TEST EQUIPMENT

The complete list of the instrumentation used during the test shall be recorded in next table.

The list shall be filled up during tests and reported in Test Report.

N.	EQUIPMENT	MANUFACTURER	P/N	S/N	ACCURACY (*)	NEXT CAL. DATE	REMARKS
1	Multimeter	Fluke	45	ENG-LAB-103		23-may-2010	
2	Current probe amplifier	Tektronix	TCPA300	ENG-LAB-300		25-may-2010	
3	Current probe	Tektronix	TCP305	ENG-LAB-300-1		25-may-2010	
4	Multimeter	HP	34401	ENG-LAB-301		Nov-2009	
5	Multimeter	Fluke	45	ENG-LAB-104		23-may-2010	

Tab. 2: INSTRUMENT LIST

(*) Where not specified the accuracy is as stated on the instrument manufacturer data sheet

Questo documento contiene informazioni di proprietà di CARLO GAVAZZI SPACE SpA. Tutti i diritti sono riservati.
All information contained in this document are property of CARLO GAVAZZI SPACE SpA. All right reserved.

8 TEST CONDITION

- The CI shall be tested in its defined configuration: it shall properly closed, all electrical loads shall be present and the CI interface function(s) shall be simulated.

- Unless otherwise specified, all measurements are to be performed at the following ambient condition:

Temperature	25 °C +/- 3°C
Relative humidity	between 30 % and 60 % RH
Pressure	Ambient
Cleanliness	100000 class

- All tests, unless otherwise specified, shall be performed internally to CGS laboratories in a proper area. General disposition shall be applied to maximize personnel safety from potential hazards

- Connectors savers shall be used on PFM model as applicable to protect the UUT interface connectors.

- Skilled personnel shall be employed

- All used instruments shall meet the necessary accuracy and shall not degrade the UUT performances.

9 TEST PROCEDURE VARIATION SHEET

In case that for any reason the test procedure has to be changed, the change shall be described in a Procedure Variation Sheet (PVS) as shown in the next page.

The PVS shall contain:

- Reference to the test procedure to be changed
- Reference to the relevant test, procedure page and paragraph
- Description of the change, possibly in the form was....is.....
- Reason for change
- Test Engineer, QA, Test conductor signatures and dates
- Customer signature and date (when required).

Each PVS shall be identified by a reference number provided in sequential order.

All the generated PVS shall be collected in a dedicated section of the Test Report.

Questo documento contiene informazioni di proprietà di CARLO GAVAZZI SPACE SpA. Tutti i diritti sono riservati.
All information contained in this document are property of CARLO GAVAZZI SPACE SpA. All right reserved.

PROCEDURE VARIATION SHEET ref. N°:		
Test Procedure Ref.:	Page Revised:	Paragraph Revised:
Description of Change:		
Reason for Change:		

CONCURRENCE				
Test Cond.	QA	System Eng.		Customer
Date	Date	Date		Date

Questo documento contiene informazioni di proprietà di CARLO GAVAZZI SPACE SpA. Tutti i diritti sono riservati.
All information contained in this document are property of CARLO GAVAZZI SPACE SpA. All right reserved.

10 TEST DATA SHEETS

The step-by-step procedure sheets are provided in the following pages.

10.1 DATA SHEETS FILLING UP

The following fields of the data sheets:

- UUT DATA (including Model, Item, C.I., S/N)
- Measured value

shall be filled up during the test performances and shall be part of the Test Report together with photographs, sketches, etc. eventually useful to document the test execution/result.
Remarks field shall be used as a minimum to provide, where appropriate, reference to NCRs and PVS.
Test Report reference data shall be added in the relevant field.
Each data sheet (including the attachments) shall be certified by QA stamp and signature together with the Test conductor signature and date.

Questo documento contiene informazioni di proprietà di CARLO GAVAZZI SPACE SpA. Tutti i diritti sono riservati.
All information contained in this document are property of CARLO GAVAZZI SPACE SpA. All right reserved.

10.2 ELECTRICAL CONNECTIONS

10.2.1 ISOLATION

STEP n°	TEST SEQUENCE	EXPECTED VALUE	MEASURED VALUE	REMARKS
2.1	The PDS shall be in OFF condition, disconnected from any cable or test equipment and placed on an insulated table.			
2.2	To verify the power isolation, measure the DC resistance:			OBJECTIVE: Verify the power isolation using the DC resistance measurements
2.3	To verify the power isolation between bus A positive line and BONDING			
2.4	J100 pin E Vs BONDING	>1MΩ	OK (OL)	
2.5	J100 pin A Vs BONDING	>1MΩ	OK (OL)	
2.6	J101 pin A Vs BONDING	>1MΩ	OK (OL)	
2.7	To verify the power isolation between bus A return line and BONDING			
2.8	J100 pin D Vs BONDING	>1MΩ	OK (OL)	
2.9	J100 pin B Vs BONDING	>1MΩ	OK (OL)	
2.10	J101 pin G Vs BONDING	>1MΩ	OK (OL)	
2.11	To verify the power isolation between bus B positive line and BONDING			
2.12	J200 pin E Vs BONDING	>1MΩ	OK (OL)	
2.13	J200 pin A Vs BONDING	>1MΩ	OK (OL)	
2.14	J201 pin D Vs BONDING	>1MΩ	OK (OL)	
2.15	To verify the power isolation between bus B return line and BONDING			
2.16	J200 pin D Vs BONDING	>1MΩ	OK (OL)	
2.17	J200 pin B Vs BONDING	>1MΩ	OK (OL)	
2.18	J201 pin E Vs BONDING	>1MΩ	OK (OL)	

Questo documento contiene informazioni di proprietà di CARLO GAVAZZI SPACE SpA. Tutti i diritti sono riservati.

All information contained in this document are property of CARLO GAVAZZI SPACE SpA. All right reserved.

10.3 FUNCTIONAL VERIFICATION

10.3.1 A SECTION

10.3.1.1 SETUP

STEP n°	TEST SEQUENCE	EXPECTED VALUE	MEASURED VALUE	REMARKS
3.1.1.1	Verify that the **"power switch box"** is connected between power supply alim and PDS cables	Connected	Connected	
3.1.1.2	Verify that the **"power switch"** of the **"power switch box"** is set in OFF position	OFF	OFF	
3.1.1.3	Verify that all load are connected except for external heaters	Connected	Connected	
3.1.1.4	Set all the loads to 0A current absorption (external heaters included)	0A absorbtion set	OK	
3.1.1.5	Launch the PDS controller software and select FM in the Model window	Program open	OK	
3.1.1.6	Launch the USCM controller software: Open the file **"USCM"**	File open	OK	

10.3.1.2 POWER ON WITH ISS MAIN BUS

3.1.2.1	Connect main power supply between AI_120V (positive) and AI_120V_RTN (negative)	J100 connected	Connected	
3.1.2.2	Set Power supply alim to 120V	120,00V±1,00V	120V	
3.1.2.3	Set output current limitation to 3A	3A±0,5A	3A	
3.1.2.4	Enable power supply output	enabled	Enable	
3.1.2.5	Verify that green led of **"power switch box"** is lighted	Green led ligthed	Green	
3.1.2.6	Switch ON the **"power switch "of "power switch box"**	Switch ON	ON	
3.1.2.7	Verify that red led of **"power switch box"** is lighted	Red led ligthed	Red	
3.1.2.8	Verify the current absorption from Main Bus	1,10A±0,20A	1,08 A	Note: this current can be read from power supply display or amperometer. In case of power supply reading, verify the correctness of measurements.
3.1.2.9	**Unmated connectoros verification**			
3.1.2.10	Measure with multimeter the voltage between 1P_120V (positive) and 1P_120V_RTN (negative)	<5V	0,005V	
3.1.2.11	Measure with multimeter the voltage between T0_120V (positive) and T0_120V_RTN (negative)	<5V	0,005V	

Questo documento contiene informazioni di proprietà di CARLO GAVAZZI SPACE SpA. Tutti i diritti sono riservati.
All information contained in this document are property of CARLO GAVAZZI SPACE SpA. All right reserved.

10.3.1.2.1 CAN BUS COMMUNICATION LINE CHECK BOARD 30

STEP n°	TEST SEQUENCE	EXPECTED VALUE	MEASURED VALUE	REMARKS
3.1.2.12	Objective: to verify the external CAN BUS lines communication			
3.1.2.13	Select USCM controller software	USCM selected	USCM selected	
3.1.2.14	set the CAN BUS board address to 30 in the command widow	30	30	
3.1.2.15	Select JMDC = 0	0	0	
3.1.2.16	Select TX = A	A	A	
3.1.2.17	Select RX = A	A	A	
3.1.2.18	press button READ and verify on the command status window	Command execute OK	Command execute OK	
3.1.2.19	Verify MODE window	PDS_PROM	PDS_PROM	
3.1.2.20	Verify Version window	26-Jan-09 17:06	26-Jan-09 17:06	
3.1.2.21	Verify History window	POWER ON 0	POWER ON 0	
3.1.2.22	select Select TX = B	B	B	
3.1.2.23	Select RX = B	B	B	
3.1.2.24	press button READ and verify on the command status window	Command execute OK	Command execute OK	
3.1.2.25	Verify MODE window	PDS_PROM	PDS_PROM	
3.1.2.26	Verify Version window	26-Jan-09 17:06	26-Jan-09 17:06	
3.1.2.27	Verify History	POWER ON 0	POWER ON 0	

10.3.1.2.2 CAN BUS COMMUNICATION LINE CHECK BOARD 31

3.1.2.28	Objective: To verify the external CAN BUS lines communication			
3.1.2.29	Set the CAN BUS board address to 31 in the command widow	31	31	
3.1.2.30	Select JMDC = 0	0	0	
3.1.2.31	Select TX = A	A	A	
3.1.2.32	Select RX = A	A	A	
3.1.2.33	press button READ and verify on the command status window	Command execute OK	Command execute OK	
3.1.2.34	Verify MODE window	PDS_PROM	PDS_PROM	
3.1.2.35	Verify Version window	26-Jan-09 17:06	26-Jan-09 17:06	
3.1.2.36	Verify History window	POWER ON 0	POWER ON 0	
3.1.2.37	select Select TX = B	B	B	

DATE:	TEST CONDUCTOR	QA	CUSTOMER
22/07/2009	Albertin A.	Francini E.	

Questo documento contiene informazioni di proprietà di CARLO GAVAZZI SPACE SpA. Tutti i diritti sono riservati.

All information contained in this document are property of CARLO GAVAZZI SPACE SpA. All right reserved.

UUT DATA : Model PFM Item AMS02 POWER DISTRIBUTION SYSTEM C.I. PDS 18 S/N FM01

STEP n°	TEST SEQUENCE	EXPECTED VALUE	MEASURED VALUE	REMARKS
3.1.2.38	Select RX = B	B	B	
3.1.2.39	press button READ and verify on the command status window	Command execute OK	Command execute OK	
3.1.2.40	Verify MODE window	PDS_PROM	PDS_PROM	
3.1.2.41	Verify Version window	26-Jan-09 17:06	26-Jan-09 17:06	
3.1.2.42	Verify History	POWER ON 0	POWER ON 0	

10.3.1.2.3 PDS INTERNAL SERIAL COMMUNICATION CHECK BOARD 30

3.1.2.43	**Objective: To verify the internal communication of the CAN BUS boards 30 with the PDS A side boards**			
3.1.2.44	set the CAN BUS board address to 30	30	30	
3.1.2.45	select JMDC = 0	0	0	
3.1.2.46	select TX = A	A	A	
3.1.2.47	select RX = A	A	A	
3.1.2.48	Press button "RUN Flash" and verify on the command status window	Command execute OK	Command execute OK	
3.1.2.49	press button READ and verify on the command status window	Command execute OK	Command execute OK	
3.1.2.50	Verify MODE window	PDS_FLASH	PDS_FLASH	
3.1.2.51	Verify Version window	26-Jan-09 17:07	26-Jan-09 17:07	
3.1.2.52	Verify History	PROM 3	PROM 3	
3.1.2.53	Select PDS controller software	program open	program open	
3.1.2.54	set the CAN BUS board address to 30	30	30	
3.1.2.55	select JMDC = 0	0	0	
3.1.2.56	select TX = A	A	A	
3.1.2.57	select RX = A	A	A	
3.1.2.58	Select "CAN BUS I/F Side" to A	A	A	
3.1.2.59	Select "PDS Side" to A	A	A	
3.1.2.60	Press button "READ INPUT" button and verify on the command status window	Command execute OK	Command execute OK	
3.1.2.61	Verify Input Stage A Voltage (V)monitor	120V ± 9.5V	119,4V	
3.1.2.62	Verify Input stage A Current (A) monitor	1,1A ± 20%	0,7 A	20% Full Scale value
3.1.2.63	Press button "READ" to verify all board status	Command execute OK	Command execute OK	
3.1.2.64	Verify "Sta" column values	All boards OK	All boards OK	

DATE:	TEST CONDUCTOR	QA	CUSTOMER
22 /07/2009	Albertin A.	Francini E.	

Questo documento contiene informazioni di proprietà di CARLO GAVAZZI SPACE SpA. Tutti i diritti sono riservati.
All information contained in this document are property of CARLO GAVAZZI SPACE SpA. All right reserved.

UUT DATA : Model PFM Item AMS02 POWER DISTRIBUTION SYSTEM C.I. PDS 18 S/N FM01

STEP n°	TEST SEQUENCE	EXPECTED VALUE	MEASURED VALUE	REMARKS
3.1.2.65	Verify "OVT" column values	All boards OK	All boards OK	With the exception of ESEM1-A board: OVT flag not present
3.1.2.66	Verify "Temp" column values	-20°C to +80°C	OK	No full scale values must be present All temperatures must be inside unit temp limits
3.1.2.67	Verify "Ref" colum values	2,5V ± 0,25V 2,0V ± 0,25V 3,0V ± 0,25V 2,0V ± 0,25V 3,0V ± 0,25V 2,0V ± 0,25V 3,0V ± 0,25V 2,0V ± 0,25V 3,0V ± 0,25V 4,0V ± 0,25V	2,50V 2,19V 2,99V 2,14V 2,99V 2,16V 3,00V 2,17V 2,98V 4,04V	All

10.3.1.2.4 PDS INTERNAL SERIAL COMMUNICATION CHECK BOARD 31

3.1.2.68	Select USCM controller software	USCM selcted	USCM selcted	
3.1.2.69	Set the CAN BUS board address to 31	31	31	
3.1.2.70	select JMDC = 0	0	0	
3.1.2.71	select TX = A	A	A	
3.1.2.72	select RX = A	A	A	
3.1.2.73	Press button "RUN Flash" and verify on the command status window	Command execute OK	Command execute OK	
3.1.2.74	press button READ and verify on the command status window	Command execute OK	Command execute OK	
3.1.2.75	Verify MODE window	PDS_FLASH	PDS_FLASH	
3.1.2.76	Verify Version window	26-Jan-09 17:07	26-Jan-09 17:07	
3.1.2.77	Verify History	PROM 3	PROM 3	
3.1.2.78	Select PDS controller software	program open	program open	
3.1.2.79	Set the CAN BUS board address to 31	31	31	
3.1.2.80	select JMDC = 0	0	0	
3.1.2.81	select TX = A	A	A	
3.1.2.82	select RX = A	A	A	
3.1.2.83	Select "CAN BUS I/F Side" to B	B	B	
3.1.2.84	Select "PDS Side" to A	A	A	

DATE:	TEST CONDUCTOR	QA	CUSTOMER
22/07/2009	Albertin A.	Francini E.	

Questo documento contiene informazioni di proprietà di CARLO GAVAZZI SPACE SpA. Tutti i diritti sono riservati.

All information contained in this document are property of CARLO GAVAZZI SPACE SpA. All right reserved.

UUT DATA : Model PFM Item AMS02 POWER DISTRIBUTION SYSTEM C.I. PDS 18 S/N FM01

STEP n°	TEST SEQUENCE	EXPECTED VALUE	MEASURED VALUE	REMARKS
3.1.2.85	Click on Run flash button	OK	OK	
3.1.2.86	Press button "READ INPUT" button and verify on the command status window	Command execute OK	Command execute OK	
3.1.2.87	Verify "Input Stage A" Voltage (V)monitor	120V ± 9.5V	120,5V	
3.1.2.88	Verify "Input stage A" Current (A) monitor	1,1A ± 20%	0,959 A	20% Full Scale value
3.1.2.89	Press button "READ" to verify all board status	Command execute OK	Command execute OK	
3.1.2.90	Verify "Sta" column values	All boards OK	All boards OK	
3.1.2.91	Verify "OVT" column values	All boards OK	All boards OK	With the exception of ESEM1-A board: OVT flag not present
3.1.2.92	Verify "Temp" column values	-20°C to +80°C	OK	No full scale values must be present All temperatures must be inside unit temp limits Some difference can be present due to different board power dissipation
3.1.2.93	Verify "Ref" colum values	2,5V ± 0,25V 2,0V ± 0,25V 3,0V ± 0,25V 2,0V ± 0,25V 3,0V ± 0,25V 2,0V ± 0,25V 3,0V ± 0,25V 2,0V ± 0,25V 3,0V ± 0,25V 4,0V ± 0,25V	2,50V 2,20V 3,02V 2,11V 3,00V 2,18V 3,01V 2,20V 2,94V 4,01V	
3.1.2.94	Switch OFF 120V main bus	OK	OK	

10.3.1.2.5 CAN BUS BOARDS CROSS CMD OFF/ON AND SUICIDE TEST

3.1.2.95	Objective: to verify the possibility to command OFF and ON one board from the other			
3.1.2.96	Verify that the **"power switch box"** is connected between power supply alim and PDS cables	Connected	Connected	
3.1.2.97	Verify that the **"power switch"** of the **"power switch box"** is set in OFF position	OFF	OFF	
3.1.2.98	Lunch the PDS controller software	Program open	Program open	
3.1.2.99	Launch the USCM controller software	File open	File open	
3.1.2.100	Set to "FM" the window Model	FM	FM	
3.1.2.101	Connect "J300 test box" to the unit J300 connector	OK	OK	
3.1.2.102	Connect main power supply between AI_120V (positive) and AI_120V_RTN (negative)	J100 connected	J100 connected	

DATE:	TEST CONDUCTOR	QA	CUSTOMER
22/07/2009	Albertin A.	Francini E.	

Questo documento contiene informazioni di proprietà di CARLO GAVAZZI SPACE SpA. Tutti i diritti sono riservati.
All information contained in this document are property of CARLO GAVAZZI SPACE SpA. All right reserved.

UUT DATA : Model PFM Item AMS02 POWER DISTRIBUTION SYSTEM C.I. PDS 18 S/N FM01

STEP n°	TEST SEQUENCE	EXPECTED VALUE	MEASURED VALUE	REMARKS
3.1.2.103	Set Power supply alim to 120V	120,00V±1,00V	120,V	V1
3.1.2.104	Set output current limitation to 3A	3A±0,5A	3A	
3.1.2.105	Enable power supply output	enabled	enabled	
3.1.2.106	Verify that green led of **"power switch box"** is lighted	Green led ligthed	Green led ligthed	
3.1.2.107	Switch ON the **"power switch "of "power switch box"**	Switch ON	Switch ON	
3.1.2.108	Verify that red led of **"power switch box"** is lighted	Red led ligthed	Red led ligthed	
3.1.2.109	Verify the current absorption from Main Bus	1,10A±0,20A	1,06 A	Note: this current can be read from power supply display or amperometer. In case of power supply reading, verify the correctness of measurements.
3.1.2.110	Select USCM controller software	USCM selcted	USCM selcted	
3.1.2.111	set the CAN BUS board address to 30 in the command window	30	30	
3.1.2.112	Select JMDC = 0	0	0	
3.1.2.113	Select TX = A	A	A	
3.1.2.114	Select RX = A	A	A	
3.1.2.115	press button READ and verify on the command status window	Command execute OK	Command execute OK	
3.1.2.116	Verify MODE window	PDS_PROM	PDS_PROM	
3.1.2.117	Verify Version window	26-Jan-09 17:06	26-Jan-09 17:06	
3.1.2.118	Verify History window	POWER ON 0	POWER ON 0	
3.1.2.119	Measure the CAN BUS internal power supply: connect a multimeter between PIN Vcc (positive) and SEC_GND (negative) on side A of the J300 test box	5.3V ± 0.1V	5,305V	
3.1.2.120	Set the CAN BUS board address to 31 in the command window	31	31	
3.1.2.121	Select JMDC = 0	0	0	
3.1.2.122	Select TX = A	A	A	
3.1.2.123	Select RX = A	A	A	
3.1.2.124	press button READ and verify on the command status window	Command execute OK	Command execute OK	
3.1.2.125	Verify MODE window	PDS_PROM	PDS_PROM	
3.1.2.126	Verify Version window	26-Jan-09 17:06	26-Jan-09 17:06	
3.1.2.127	Verify History window	POWER ON 0	POWER ON 0	
3.1.2.128	Measure the CAN BUS internal power supply: connect a multimeter between PIN Vcc (positive) and SEC_GND (negative) on side B of the J300 test box	5.30 ± 0.1V	5,285V	
3.1.2.129	set the CAN BUS board address to 30 in the command window	30	30	
3.1.2.130	press button SOFF and verify on the command status window	Command execute OK	Command execute OK	
3.1.2.131	Set the CAN BUS board address to 31 in the command window	31	31	

DATE:	TEST CONDUCTOR	QA	CUSTOMER
22 /07/2009	Albertin A.	Francini E.	

Questo documento contiene informazioni di proprietà di CARLO GAVAZZI SPACE SpA. Tutti i diritti sono riservati.

All information contained in this document are property of CARLO GAVAZZI SPACE SpA. All right reserved.

UUT DATA : Model PFM Item AMS02 POWER DISTRIBUTION SYSTEM C.I. PDS 18 S/N FM01

STEP n°	TEST SEQUENCE	EXPECTED VALUE	MEASURED VALUE	REMARKS
3.1.2.132	press button READ and verify on the command status window	Command execute failed	Command execute failed	
3.1.2.133	Measure the CAN BUS 31 internal power supply: connect a multimeter between PIN Vcc (positive) and SEC_GND (negative) on side B of the J300 test box	0.5V ± 0.1V	0,5V	
3.1.2.134	Measure the CAN BUS 30 internal power supply: connect a multimeter between PIN Vcc (positive) and SEC_GND (negative) on side A of the J300 test box	5.3V ± 0.1V	5,304V	
3.1.2.135	set the CAN BUS board address to 30 in the command window	30	30	
3.1.2.136	press button SON and verify on the command status window	Command execute OK	Command execute OK	
3.1.2.137	Set the CAN BUS board address to 31 in the command window	31	31	
3.1.2.138	press button READ and verify on the command status window	Command execute OK	Command execute OK	
3.1.2.139	Measure the CAN BUS internal power supply: connect a multimeter between PIN Vcc (positive) and SEC_GND (negative) on side B of the J300 test box	5.3V ± 0.1V	5,29V	
3.1.2.140	Verify MODE window	PDS_PROM	PDS_PROM	
3.1.2.141	Verify Version window	26-Jan-09 17:06	26-Jan-09 17:06	
3.1.2.142	Verify History window	POWER ON 0	POWER ON 0	
3.1.2.143	Set the CAN BUS board address to 31 in the command window	31	31	
3.1.2.144	press button SOFF and verify on the command status window	Command execute OK	Command execute OK	
3.1.2.145	set the CAN BUS board address to 30 in the command window	30	30	
3.1.2.146	press button READ and verify on the command status window	Command execute failed	Command execute failed	
3.1.2.147	Measure the CAN BUS internal power supply: connect a multimeter between PIN Vcc (positive) and SEC_GND (negative) on side A of the J300 test box	0,5V ± 0.1V	0,52V	
3.1.2.148	Measure the CAN BUS internal power supply: connect a multimeter between PIN Vcc (positive) and SEC_GND (negative) on side B of the J300 test box	5.3V ± 0.1V	5,28V	
3.1.2.149	Set the CAN BUS board address to 31 in the command window	31	31	
3.1.2.150	press button SON and verify on the command status window	Command execute OK	Command execute OK	
3.1.2.151	set the CAN BUS board address to 30 in the command window	30	30	
3.1.2.152	press button READ and verify on the command status window	Command execute OK	Command execute OK	
3.1.2.153	Measure the CAN BUS internal power supply: connect a multimeter between PIN Vcc (positive) and SEC_GND (negative) on side A of the J300 test box	5.3V ± 0.1V	5,31V	
3.1.2.154	Verify MODE window	PDS_PROM	PDS_PROM	
3.1.2.155	Verify Version window	26-Jan-09 17:06	26-Jan-09 17:06	

DATE:	TEST CONDUCTOR	QA	CUSTOMER
22/07/2009	Albertin A.	Francini E.	

Questo documento contiene informazioni di proprietà di CARLO GAVAZZI SPACE SpA. Tutti i diritti sono riservati.

All information contained in this document are property of CARLO GAVAZZI SPACE SpA. All right reserved.

UUT DATA : Model PFM Item AMS02 POWER DISTRIBUTION SYSTEM C.I. PDS 18 S/N FM01

STEP n°	TEST SEQUENCE	EXPECTED VALUE	MEASURED VALUE	REMARKS
3.1.2.156	Verify History window	POWER ON 0	POWER ON 0	
3.1.2.157	**SUICIDE BOARD 30 COMMAND TEST**			
3.1.2.158	set the CAN BUS board address to 30 in the command window	30	30	
3.1.2.159	press button SUIC and verify on the command status window	Command execute failed	Command execute failed	
3.1.2.160	Measure the CAN BUS internal power supply: connect a multimeter between PIN Vcc (positive) and SEC_GND (negative) on side A of the J300 test box	0.50V ±0.1V	0,51V	
3.1.2.161	press button READ and verify on the command status window	Command execute failed	Command execute failed	
3.1.2.162	Set the CAN BUS board address to 31 in the command window	31	31	
3.1.2.163	press button SON and verify on the command status window	Command execute OK	Command execute OK	
3.1.2.164	set the CAN BUS board address to 30 in the command window	30	30	
3.1.2.165	press button READ and verify on the command status window	Command execute OK	Command execute OK	
3.1.2.166	Measure the CAN BUS internal power supply: connect a multimeter between PIN Vcc (positive) and SEC_GND (negative) on side 30 of the J300 test box	5.30 ± 0.1V	5,304V	
3.1.2.167	Verify MODE window	PDS_PROM	PDS_PROM	
3.1.2.168	Verify Version window	26-Jan-09 17:06	26-Jan-09 17:06	
3.1.2.169	Verify History window	POWER ON 0	POWER ON 0	
3.1.2.170	**SUICIDE BOARD 31 COMMAND TEST**			
3.1.2.171	Set the CAN BUS board address to 31 in the command window	31	31	
3.1.2.172	press button SUIC and verify on the command status window	Command execute failed	Command execute failed	
3.1.2.173	Measure the CAN BUS internal power supply: connect a multimeter between PIN Vcc (positive) and SEC_GND (negative) on side B of the J300 test box	0.50V ± 0.1V	0,52V	
3.1.2.174	press button READ and verify on the command status window	Command execute failed	Command execute failed	
3.1.2.175	set the CAN BUS board address to 30 in the command window	30	30	
3.1.2.176	press button SON and verify on the command status window	Command execute OK	Command execute OK	
3.1.2.177	Set the CAN BUS board address to 31 in the command window	31	31	
3.1.2.178	press button READ and verify on the command status window	Command execute OK	Command execute OK	
3.1.2.179	Measure the CAN BUS internal power supply: connect a multimeter between PIN Vcc (positive) and SEC_GND (negative) on side B of the J300 test box	5.30V ± 0.1V	5,28V	
3.1.2.180	Verify MODE window	PDS_PROM	PDS_PROM	

DATE:	TEST CONDUCTOR	QA	CUSTOMER
22/07/2009	Albertin A.	Francini E.	

Questo documento contiene informazioni di proprietà di CARLO GAVAZZI SPACE SpA. Tutti i diritti sono riservati.

All information contained in this document are property of CARLO GAVAZZI SPACE SpA. All right reserved.

UUT DATA :	Model	PFM	Item	AMS02 POWER DISTRIBUTION SYSTEM	C.I.	PDS 18	S/N	FM01

STEP n°	TEST SEQUENCE	EXPECTED VALUE	MEASURED VALUE	REMARKS
3.1.2.181	Verify Version window	26-Jan-09 17:06	26-Jan-09 17:06	
3.1.2.182	Verify History window	POWER ON 0	POWER ON 0	
3.1.2.183	Switch OFF the "power switch "of "power switch box"	OFF	OFF	
3.1.2.184	Disable power supply output	DISABLED	DISABLED	

DATE:	TEST CONDUCTOR	QA	CUSTOMER
22 /07/2009	Albertin A.	Francini E.	

Questo documento contiene informazioni di proprietà di CARLO GAVAZZI SPACE SpA. Tutti i diritti sono riservati.

All information contained in this document are property of CARLO GAVAZZI SPACE SpA. All right reserved.

UUT DATA :	Model	PFM	Item	AMS02 POWER DISTRIBUTION SYSTEM	C.I.	PDS 18	S/N	FM01

10.3.1.3 POWER VIDEO GRAPPLE FIXTURE 1 POWER SUPPLY VERIFICATION (1P)

STEP n°	TEST SEQUENCE	EXPECTED VALUE	MEASURED VALUE	REMARKS
3.1.2.185	Connect main power supply between 1P_120V (positive) and 1P_120V_RTN (negative)	CONNECTED	CONNECTED	
3.1.2.186	Connect ESEM 3-B outlet 1 to load	CONNECTED	CONNECTED	Default on: current absorptioN = 1,200A±100mA
3.1.2.187	Set Power supply alim to 120V	120,00V±1,00V	120V	
3.1.2.188	Set output current limitation to 5A	5A±0,5A	5 A	
3.1.2.189	Enable power supply output	Enabled	Enabled	
3.1.2.190	Verify that green led of "power switch box" is lighted	Green led ligthed	Green led ligthed	
3.1.2.191	Switch ON the "power switch "of "power switch box"	Switch ON	Switch ON	
3.1.2.192	Verify that red led of "power switch box" is lighted	Red led ligthed	Red led ligthed	
3.1.2.193	Measure the PDS input voltage: connect a multimeter between PIN "bypass thermal interlock" (positive) and "PRI_GND"(negative) on side A of the J300 test box	118,50V±1,00V	119,5V	
3.1.2.194	Verify the current absorption from Main Bus	2,30A±0,20A	2,29 A	Note: this current can be read from power supply display or amperometer. In case of power supply reading, verify the correctness of measurements.
3.1.2.195	Select PDS controller software	OPEN	OPEN	
3.1.2.196	Set to "FM" the window Model	FM	FM	
3.1.2.197	Set the CAN BUS board address to 30	30	30	
3.1.2.198	Select "CAN BUS I/F Side" to A	A	A	
3.1.2.199	Select "PDS Side" to A	A	A	
3.1.2.200	select JMDC = 0	0	0	
3.1.2.201	select TX = A	A	A	
3.1.2.202	select RX = A	A	A	
3.1.2.203	Press button "RUN Flash" and verify on the command status window	Command execute OK	Command execute OK	
3.1.2.204	Press button "READ" to verify all board status	Command execute OK	Command execute OK	
3.1.2.205	Verify the status of the flags indicated on "Sta" column. All flags must be "OK"	OK	OK	Click on READ command under Sta column This column resumes the status of al the boards
3.1.2.206	Set the CAN BUS board address to 31	31	31	
3.1.2.207	Select "CAN BUS I/F Side" to B	B	B	
3.1.2.208	Select "PDS Side" to A	A	A	
3.1.2.209	Click on Run flash button	Command execute OK	Command execute OK	Command located on up-left

DATE:	TEST CONDUCTOR	QA	CUSTOMER
23/07/2009	Albertin A.	Francini E.	

Questo documento contiene informazioni di proprietà di CARLO GAVAZZI SPACE SpA. Tutti i diritti sono riservati.
All information contained in this document are property of CARLO GAVAZZI SPACE SpA. All right reserved.

UUT DATA : Model PFM Item AMS02 POWER DISTRIBUTION SYSTEM C.I. PDS 18 S/N FM01

STEP n°	TEST SEQUENCE	EXPECTED VALUE	MEASURED VALUE	REMARKS
3.1.2.210	Press button "READ" to verify all board status	Command execute OK	Command execute OK	
3.1.2.211	Verify the status of the flags indicated on "Sta" column. All flags must be "OK"	OK	OK	Click on READ command under Sta column This column resumes the status of al the boards
3.1.2.212	Measure with multimeter the voltage on ESEM 3-B outlet 1	117,00V<V<120,00V	118,3V	This test is used to verify that input diode located in input stage board is not damaged
3.1.2.213	Switch OFF main power bus	OK	OK	
3.1.2.214	disconnect ESEM 3-B outlet 1 to default load	OK	OK	

DATE:	TEST CONDUCTOR	QA	CUSTOMER
23 /07/2009	Albertin A.	Francini E.	

Questo documento contiene informazioni di proprietà di CARLO GAVAZZI SPACE SpA. Tutti i diritti sono riservati.
All information contained in this document are property of CARLO GAVAZZI SPACE SpA. All right reserved.

UUT DATA :	Model	PFM	Item	AMS02 POWER DISTRIBUTION SYSTEM	C.I.	PDS 18	S/N	FM01

10.3.1.4 T0 POWER SUPPLY TEST

STEP n°	TEST SEQUENCE	EXPECTED VALUE	MEASURED VALUE	REMARKS
3.1.2.215	Connect main power supply between T0_120V (positive) and T0_120V_RTN (negative)	Connected	Connected	
3.1.2.216	Connect ESEM 3-B outlet 1 to load	CONNECTED	CONNECTED	Default on: current absorptioN = 1,200A±100mA
3.1.2.217	Set Power supply alim to 120V	120,00V±1,00V	120 V	
3.1.2.218	Set output current limitation to 5A	5A±0,5A	5 A	
3.1.2.219	Enable power supply output	Enabled	Enabled	
3.1.2.220	Verify that green led of "power switch box" is lighted	Green led ligthed	Green led ligthed	
3.1.2.221	Switch ON the "power switch "of "power switch box"	Switch ON	Switch ON	
3.1.2.222	Verify that red led of "power switch box" is lighted	Red led ligthed	Red led ligthed	
3.1.2.223	Measure the PDS input voltage: connect a multimeter between PIN "bypass thermal interlock" (positive) and "PRI_GND"(negative) on side A of the J300 test box	118,50V±1,00V	119.5V	
3.1.2.224	Verify the current absorption from Main Bus	2,30A±0,20A	2,3A	Note: this current can be read from power supply display or amperometer. In case of power supply reading, verify the correctness of measurements.
3.1.2.225	Select PDS controller software	OPEN	OPEN	
3.1.2.226	Set to "FM" the window Model	FM	FM	
3.1.2.227	Set the CAN BUS board address to 30	30	30	
3.1.2.228	Select "CAN BUS I/F Side" to A	A	A	
3.1.2.229	Select "PDS Side" to A	A	A	
3.1.2.230	select JMDC = 0	0	0	
3.1.2.231	select TX = A	A	A	
3.1.2.232	select RX = A	A	A	
3.1.2.233	Press button "RUN Flash" and verify on the command status window	Command execute OK	Command execute OK	
3.1.2.234	Press button "READ" to verify all board status	Command execute OK	Command execute OK	
3.1.2.235	Verify the status of the flags indicated on "Sta" column. All flags must be "OK"	OK	OK	Click on READ command under Sta column This column resumes the status of al the boards
3.1.2.236	Set the CAN BUS board address to 31	31	31	
3.1.2.237	Select "CAN BUS I/F Side" to B	B	B	
3.1.2.238	Select "PDS Side" to A	A	A	
3.1.2.239	Click on Run flash button	Command execute OK	Command execute OK	Command located on up-left

DATE:	TEST CONDUCTOR	QA	CUSTOMER
23/07/2009	Albertin A.	Francini E.	

Questo documento contiene informazioni di proprietà di CARLO GAVAZZI SPACE SpA. Tutti i diritti sono riservati.

All information contained in this document are property of CARLO GAVAZZI SPACE SpA. All right reserved.

UUT DATA : Model PFM Item AMS02 POWER DISTRIBUTION SYSTEM C.I. PDS 18 S/N FM01

STEP n°	TEST SEQUENCE	EXPECTED VALUE	MEASURED VALUE	REMARKS
3.1.2.240	Press button "READ" to verify all board status	Command execute OK	Command execute OK	
3.1.2.241	Verify the status of the flags indicated on "Sta" column. All flags must be "OK"	OK	OK	Click on READ command under Sta column This column resumes the status of al the boards
3.1.2.242	Measure with multimeter the voltage on ESEM 3-B outlet 1	117,00V<V<120,00V	118,3V	This test is used to verify that input diode located in input stage board is not damaged
3.1.2.243	Switch OFF main power bus	OK	OK	
3.1.2.244	disconnect ESEM 3-B outlet 1 to default load	OK	OK	

DATE:	TEST CONDUCTOR	QA	CUSTOMER
23/07/2009	Albertin A.	Francini E.	

Questo documento contiene informazioni di proprietà di CARLO GAVAZZI SPACE SpA. Tutti i diritti sono riservati.

All information contained in this document are property of CARLO GAVAZZI SPACE SpA. All right reserved.

UUT DATA :	Model	PFM	Item	AMS02 POWER DISTRIBUTION SYSTEM	C.I.	PDS 18	S/N	FM01

10.3.1.5 UNIT CHECK

STEP n°	TEST SEQUENCE	EXPECTED VALUE	MEASURED VALUE	REMARKS
3.1.5.1	Connect AI_120V and AI_120V_RTN power supply signals	Connected	Connected	
3.1.5.2	Verify that all the cables of the section are connected AND ALL LOADS ARE SET TO ØA	OK	OK	See PVS-01
3.1.5.3	Launch the PDS controller software	Program open	Program open	
3.1.5.4	Set to "FM" the window Model	OK	OK	
3.1.5.5	Select "PDS Side" to A	A	A	
3.1.5.6	Set the CAN BUS board address to 30	30	30	
3.1.5.7	Select JMDC = 0	0	0	
3.1.5.8	Select TX = A	A	A	
3.1.5.9	Select RX = A	A	A	
3.1.5.10	Select "CAN BUS I/F Side" to A	A	A	
3.1.5.11	Set input bus voltage to 120V	120V±1V	120V	V1
3.1.5.12	Set input bus current limitation to 27,5 A	27,5 A±1A	27,5A	
3.1.5.13	Enable power supply output	Enabled	Enabled	
3.1.5.14	Verify that green led of "power switch box" is lighted	Green led ligthed	Green led ligthed	
3.1.5.15	Switch ON the "power switch "of "power switch box"	Switch ON	Switch ON	
3.1.5.16	Verify that red led of "power switch box" is lighted	Red led ligthed	Red led ligthed	
3.1.5.17	Take note of power supply output current	1,1A±0,5A	1,1A	I1
3.1.5.18	Press button "RUN Flash" and verify on the command status window	Command execute OK	Command execute OK	

DATE:	TEST CONDUCTOR	QA	CUSTOMER
23/07/2009	Albertin A.	Francini E.	

Questo documento contiene informazioni di proprietà di CARLO GAVAZZI SPACE SpA. Tutti i diritti sono riservati.
All information contained in this document are property of CARLO GAVAZZI SPACE SpA. All right reserved.

STEP n°	TEST SEQUENCE	EXPECTED VALUE	MEASURED VALUE	REMARKS

10.3.1.5.1 INPUT STAGE A VERIFICATION

3.1.5.19	Push the command "Read input" located in the bottom left of the software window	OK	OK	
3.1.5.20	Take note of the value "V" indicated in Input Stage A window	V1±9,50V	119.5V	
3.1.5.21	Take note of the value "I" indicated in Input Stage A window	I1± 20%	0,71A	20% Full Scale value
3.1.5.22	Set the CAN BUS board address to 31	31	31	
3.1.5.23	Select "CAN BUS I/F Side" to B	B	B	
3.1.5.24	Press button "RUN Flash" and verify on the command status window	Command execute OK	Command execute OK	
3.1.5.25	Push the command "Read input" located in the bottom left of the software window	OK	OK	
3.1.5.26	Take note of the value "V" indicated in Input Stage B window	V1±9,50V	118,3V	
3.1.5.27	Take note of the value "I" indicated in Input Stage B window	I1± 20%	1,03A	
3.1.5.28	Switch OFF main power bus	OFF	OFF	
3.1.5.29	Connect external heaters	Connected	Connected	
3.1.5.30	Switch ON main bus	ON	ON	
3.1.5.31	Verify the current absorption from Main Bus	7,80A±0,50A	7,75A	verify that heater lines are working
3.1.5.32	Switch OFF main power bus	OFF	OFF	
3.1.5.33	Disconnect external heaters	Disconnected	Disconnected	

10.3.1.5.2 ESEM 1-A SIDE A

1A-A.1	Set input bus voltage to 120V	120V±1V	120V	V1
1A-A.2	Set input bus current limitation to 27,5 A	27,5A	27,5A	
1A-A.3	Switch ON main bus	ON	ON	
1A-A.4	Take note of power supply output current	1,1A±0,5A	1,1 A	I1
1A-A.5	Set the CAN BUS board address to 30	30	30	
1A-A.6	Select "CAN BUS I/F Side" to A	A	A	
1A-A.7	Press button "RUN Flash" and verify on the command status window	Command execute OK	Command execute OK	
1A-A.8	Click on ESEM 1-A button	OK	OK	
1A-A.9	Set Digital I/F Test logic value = 1 in "Commanding" column	1	1	
1A-A.10	Click on letter "W" on the right of the "1" value	OK	OK	
1A-A.11	Click on the command READ ALL under the column Digital Readout	OK	OK	

DATE:	TEST CONDUCTOR	QA	CUSTOMER
23/07/2009	Albertin A.	Francini E.	

Questo documento contiene informazioni di proprietà di CARLO GAVAZZI SPACE SpA. Tutti i diritti sono riservati.

All information contained in this document are property of CARLO GAVAZZI SPACE SpA. All right reserved.

UUT DATA : Model PFM Item AMS02 POWER DISTRIBUTION SYSTEM C.I. PDS 18 S/N FM01

STEP n°	TEST SEQUENCE	EXPECTED VALUE	MEASURED VALUE	REMARKS
1A-A.12	Verify that in the column Digital Readout under the voice Digital I/F Test appears "1"	1	1	
1A-A.13	Set Digital I/F Test logic value = 0 in "Commanding" column	0	0	
1A-A.14	Click on letter "W" on the right of the "0" value	OK	OK	
1A-A.15	Click on the command READ ALL under the column Digital Readout	OK	OK	
1A-A.16	Verify that in the column Digital Readout under the voice Digital I/F Test appears "0"	0	0	
1A-A.17	Verify the status of the following flags: BOARD STATUS DCDC 1 OVC DCDC 2 OVC DCDC 1 STATUS DCDC 2 STATUS MAIN POWER STATUS	 OK OK OK ON ON ON	 OK OK OK ON ON ON	Flags located in Digital readout column
1A-A.18	Click on PB2-1 button	OK	OK	
1A-A.19	Set to "ON" the line "DCDC OFF/ON CMD" in the "commanding" column"	ON	ON	
1A-A.20	Press "W" button" in the line "DCDC OFF/ON CMD" in the "commanding" column	Command execute OK	Command execute OK	
1A-A.21	Verify that in the column Digital Readout under the voice DCDC ON/OFF appears "ON"	ON	ON	
1A-A.22	Click on PB2-2 button	OK	OK	
1A-A.23	Set to "ON" the line "DCDC OFF/ON CMD" in the "commanding" column"	ON	ON	
1A-A.24	Press "W" button" in the line "DCDC OFF/ON CMD" in the "commanding" column	Command execute OK	Command execute OK	
1A-A.25	Verify that in the column Digital Readout under the voice DCDC ON/OFF appears "ON"	ON	ON	
1A-A.26	Click on PB2-3 button	OK	OK	
1A-A.27	Set to "ON" the line "DCDC OFF/ON CMD" in the "commanding" column"	ON	ON	
1A-A.28	Press "W" button" in the line "DCDC OFF/ON CMD" in the "commanding" column	Command execute OK	Command execute OK	
1A-A.29	Verify that in the column Digital Readout under the voice DCDC ON/OFF appears "ON"	ON	ON	
1A-A.30	Click on PB2-4 button	OK	OK	
1A-A.31	Set to "ON" the line "DCDC OFF/ON CMD" in the "commanding" column"	ON	ON	
1A-A.32	Press "W" button" in the line "DCDC OFF/ON CMD" in the "commanding" column	Command execute OK	Command execute OK	
1A-A.33	Verify that in the column Digital Readout under the voice DCDC ON/OFF appears "ON"	ON	ON	
1A-A.34	Take note of power supply output current	1,6A±0,5A	1,57 A	All the PB2 DC/DC are ON

DATE:	TEST CONDUCTOR	QA	CUSTOMER
23/07/2009	Albertin A.	Francini E.	

Questo documento contiene informazioni di proprietà di CARLO GAVAZZI SPACE SpA. Tutti i diritti sono riservati.

All information contained in this document are property of CARLO GAVAZZI SPACE SpA. All right reserved.

UUT DATA :	Model	PFM	Item	AMS02 POWER DISTRIBUTION SYSTEM	C.I.	PDS 18	S/N	FM01

10.3.1.5.2.1 ESEM 1-A SIDE A UNDER VOLTAGE TEST

STEP n°	TEST SEQUENCE	EXPECTED VALUE	MEASURED VALUE	REMARKS
1A-A.35	Click on ESEM 1-A button	OK	OK	
1A-A.36	Press "READ ALL" button in the column "ANALOG READOUT"	Command execute OK	Command execute OK	
1A-A.37	Verify the "Analog ref. 4.0V" telemetry	4,0V ± 0,15V	4,06 V	
1A-A.38	Measure the input voltage with a multimeter	120V ± 0.2V	120,2 V	
1A-A.39	In the column "ANALOG READOUT" press R Button near Main Power Volt.	120V ± 4.5V	121,0 V	
1A-A.40	Decrease the input voltage to 113V	113V ± 0.2V	113,0 V	
1A-A.41	In the column "ANALOG READOUT" press R Button near Main Power Volt.	113V ± 4.5V	113,3 V	
1A-A.42	Decrease the input voltage to 85V (below threshold and accuracy)	85V ± 0,2V	85,0 V	Threshold = 88V ± 2V
1A-A.43	Verify current absorption from Main Bus	0,000A±200mA	0,07 A	
1A-A.44	In the column "ANALOG READOUT" press R Button near Main Power Volt.	Command execute Failed	Command execute Failed	
1A-A.45	Set the CAN BUS board address to 31	31	31	
1A-A.46	Select "CAN BUS I/F Side" to B	B	B	
1A-A.47	In the column "ANALOG READOUT" press R Button near Main Power Volt.	Command execute Failed	Command execute Failed	
1A-A.48	Increase the input voltage to 113V	113V ± 0.2V	113,0 V	
1A-A.49	Take note of power supply output current	1,3A±0,5A	1,26 A	
1A-A.50	Set power supply to 120V	120V ± 0.2V	120,0 V	
1A-A.51	Take note of power supply output current	1,1A±0,5A	1,07 A	
1A-A.52	Press button "RUN Flash" and verify on the command status window	Command execute OK	Command execute OK	
1A-A.53	Set the CAN BUS board address to 30	30	30	
1A-A.54	Select "CAN BUS I/F Side" to A	A	A	
1A-A.55	Press button "RUN Flash" and verify on the command status window	Command execute OK	Command execute OK	
1A-A.56	Click on ESEM1-A button	OK	OK	
1A-A.57	Press "READ ALL" button in the column "DIGITAL READOUT"	Command execute OK	Command execute OK	
1A-A.58	Verify the following parameter: Board status DCDC 1 OVC DCDC 2 OVC	 0 (OK) 0 (OK) 0 (OK)	 0 (OK) 0 (OK) 0 (OK)	

DATE:	TEST CONDUCTOR	QA	CUSTOMER
23/07/2009	Albertin A.	Francini E.	

Questo documento contiene informazioni di proprietà di CARLO GAVAZZI SPACE SpA. Tutti i diritti sono riservati.

All information contained in this document are property of CARLO GAVAZZI SPACE SpA. All right reserved.

UUT DATA : Model PFM Item AMS02 POWER DISTRIBUTION SYSTEM C.I. PDS 18 S/N FM01

STEP n°	TEST SEQUENCE	EXPECTED VALUE	MEASURED VALUE	REMARKS
	DCDC 1 STATUS DCDC 2 STATUS MAIN POWER STATUS	1 (ON) 1 (ON) 1 (ON)	1 (ON) 1 (ON) 1 (ON)	
1A-A.59	Click on Read All command in the column Analog Readout	OK	OK	
1A-A.60	Verify the value of the following telemetries: Temperature Main Power Volt. Analog Ref. 4.0V	 -40°C<T<80C° 120,00V±7,50V 4,000V±150mV	 28,37 °C 119,0 V 4,13 V	

10.3.1.5.2.2 ESEM 1-A SIDE A OVER VOLTAGE TEST

1A-A.61	Click on PB2-1 button	OK	OK	
1A-A.62	Set to "ON" the line "DCDC OFF/ON CMD" in the "commanding" column"	ON	ON	
1A-A.63	Press "W" button in the line "DCDC OFF/ON CMD" in the "commanding" column	W	W	
1A-A.64	Verify that in the column Digital Readout under the voice DCDC ON/OFF appears "ON"	ON	ON	
1A-A.65	Click on PB2-2 button	OK	OK	
1A-A.66	Set to "ON" the line "DCDC OFF/ON CMD" in the "commanding" column"	ON	ON	
1A-A.67	Press "W" button in the line "DCDC OFF/ON CMD" in the "commanding" column	W	W	
1A-A.68	Verify that in the column Digital Readout under the voice DCDC ON/OFF appears "ON"	ON	ON	
1A-A.69	Click on PB2-3 button	OK	OK	
1A-A.70	Set to "ON" the line "DCDC OFF/ON CMD" in the "commanding" column"	ON	ON	
1A-A.71	Press "W" button in the line "DCDC OFF/ON CMD" in the "commanding" column	W	W	
1A-A.72	Verify that in the column Digital Readout under the voice DCDC ON/OFF appears "ON"	ON	ON	
1A-A.73	Click on PB2-4 button	OK	OK	
1A-A.74	Set to "ON" the line "DCDC OFF/ON CMD" in the "commanding" column"	ON	ON	
1A-A.75	Press "W" button in the line "DCDC OFF/ON CMD" in the "commanding" column	W	W	
1A-A.76	Verify that in the column Digital Readout under the voice DCDC ON/OFF appears "ON"	ON	ON	
1A-A.77	Take note of power supply output current	1,6A±0,5A	1,6 A	All the PB2 DC/DC are ON
1A-A.78	Increase the input voltage to 126V	126V ± 0.2V	126,0 V	
1A-A.79	Click on ESEM1-A button	OK	OK	
1A-A.80	In the column "ANALOG READOUT" press R Button near Main Power Volt	126V ± 4.5V	127,0 V	
1A-A.81	Increase the input voltage to 130V	130V ± 0.2V	130,2 V	
1A-A.82	In the column "ANALOG READOUT" press R Button near Main Power Volt.	130V ± 4.5V	132,2 V	
1A-A.83	Set the input voltage to 153V (up the threshold and accuracy)	153V ± 0,2V	153,2 V	Threshold = 150V ± 2V
1A-A.84	Verify current absorption from Main Bus	0,000A±200mA	0,1 A	
1A-A.85	In the column "ANALOG READOUT" press R Button near Main Power Volt.	Command execute	Command execute	

DATE:	TEST CONDUCTOR	QA	CUSTOMER
23/07/2009	Albertin A.	Francini E.	

Questo documento contiene informazioni di proprietà di CARLO GAVAZZI SPACE SpA. Tutti i diritti sono riservati.

All information contained in this document are property of CARLO GAVAZZI SPACE SpA. All right reserved.

UUT DATA : Model PFM Item AMS02 POWER DISTRIBUTION SYSTEM C.I. PDS 18 S/N FM01

STEP n°	TEST SEQUENCE	EXPECTED VALUE	MEASURED VALUE	REMARKS
		Failed	Failed	
1A-A.86	Set the CAN BUS board address to 31	31	31	
1A-A.87	Select "CAN BUS I/F Side" to B	B	B	
1A-A.88	In the column "ANALOG READOUT" press R Button near Main Power Volt.	Command execute Failed	Command execute Failed	
1A-A.89	Set the input voltage to 126V	126V ± 0.2V	126,2V	
1A-A.90	Take note of power supply output current	1,0A±0,5A	1,0 A	
1A-A.91	Press button "RUN Flash" and verify on the command status window	Command execute OK	Command execute OK	
1A-A.92	Set power supply to 120V	120V ± 0.2V	120,2 V	
1A-A.93	Take note of power supply output current	1,1A±0,5A	1,07 A	
1A-A.94	Set the CAN BUS board address to 30	30	30	
1A-A.95	Select "CAN BUS I/F Side" to A	A	A	
1A-A.96	Press button "RUN Flash" and verify on the command status window	Command execute OK	Command execute OK	
1A-A.97	Click on ESEM1-A button	OK	OK	
1A-A.98	Press "READ ALL" button in the column "DIGITAL READOUT"	OK	OK	
1A-A.99	Verify the following parameter:			
1A-A.100	Board status	0 (OK)	0 (OK)	
1A-A.101	DCDC 1 OVC	0 (OK)	0 (OK)	
1A-A.102	DCDC 2 OVC	0 (OK)	0 (OK)	
1A-A.103	DCDC 1 STATUS	1 (ON)	1 (ON)	
1A-A.104	DCDC 2 STATUS	1 (ON)	1 (ON)	
1A-A.105	MAIN POWER STATUS	1 (ON)	1 (ON)	
1A-A.106	Verify the value of the following telemetries: Temperature Main Power Volt. Analog Ref. 4.0V	 -40°C<T<80C° 120,00V±7,50V 4,000V±150mV	 26,97 °C 121,2 V 4,04 V	

DATE:	TEST CONDUCTOR	QA	CUSTOMER
23/07/2009	Albertin A.	Francini E.	

Questo documento contiene informazioni di proprietà di CARLO GAVAZZI SPACE SpA. Tutti i diritti sono riservati.

All information contained in this document are property of CARLO GAVAZZI SPACE SpA. All right reserved.

UUT DATA :	Model	PFM	Item	AMS02 POWER DISTRIBUTION SYSTEM	C.I.	PDS 18	S/N	FM01

10.3.1.5.2.3 ESEM 1-A SIDE A GLOBAL ON/OFF TEST

STEP n°	TEST SEQUENCE	EXPECTED VALUE	MEASURED VALUE	REMARKS
1A-A.107	Set OFF in the Global ON/OFF window and click on relative "W" command	OFF	OFF	
1A-A.108	Verify current absorption from Main Bus	0,000A±200mA	0,1 A	
1A-A.109	Press "READ ALL" button in the column "DIGITAL READOUT"	OK	OK	
1A-A.110	Verify that appears the message "Command execution failed!"	Command execution failed!	Command execution failed!	
1A-A.111	Perform a power cycle OFF/ON on the main bus	OK	OK	
1A-A.112	Click on Run flash button	OK	OK	
1A-A.113	Click on Read all command under Digital Readout column and verify that appears the message "Command executed O.K."	Command executed OK	Command executed OK	
1A-A.114	Verify that the value of Board status in Digital Readout column in "OK"	OK	OK	
1A-A.115	Set the CAN BUS board address to 31	31	31	
1A-A.116	Select "CAN BUS I/F Side" to B	B	B	
1A-A.117	Click on Run flash button	OK	OK	
1A-A.118	Click on Read all command under Digital Readout column and verify that appears the message "Command executed O.K."	Command executed OK	Command executed OK	
1A-A.119	Verify that the value of Board status in Digital Readout column in "OK"	OK	OK	
1A-A.120	Set OFF in the Global ON/OFF window and click on relative "W" command	OK	OK	
1A-A.121	Verify current absorption from Main Bus	0,000A±200mA	0,1 A	
1A-A.122	Press "READ ALL" button in the column "DIGITAL READOUT"	OK	OK	
1A-A.123	Verify that appears the message "Command execution failed!"	Command execution failed!	Command execution failed!	
1A-A.124	Perform a power cycle OFF/ON on the main bus	OK	OK	
1A-A.125	Set the CAN BUS board address to 30	30	30	
1A-A.126	Select "CAN BUS I/F Side" to A	A	A	
1A-A.127	Click on Run flash button	OK	OK	
1A-A.128	Click on Read all command under Digital Readout column and verify that appears the message "Command executed O.K."	Command executed OK	Command executed OK	
1A-A.129	Verify that the value of Board status in Digital Readout column in "OK"	OK	OK	
1A-A.130	Switch OFF main power bus	OFF	OFF	

DATE:	TEST CONDUCTOR	QA	CUSTOMER
26/07/2009	Albertin A.	Francini E.	

Questo documento contiene informazioni di proprietà di CARLO GAVAZZI SPACE SpA. Tutti i diritti sono riservati.
All information contained in this document are property of CARLO GAVAZZI SPACE SpA. All right reserved.

UUT DATA :	Model	PFM	Item	AMS02 POWER DISTRIBUTION SYSTEM	C.I.	PDS 18	S/N	FM01

10.3.1.5.3 PB2-1 SIDE A

STEP n°	TEST SEQUENCE	EXPECTED VALUE	MEASURED VALUE	REMARKS
PB2-4-A.1	Connect AI_120V and AI_120V_RTN power supply signals	OK	OK	
PB2-4-A.2	Verify that all the cables of the section are connected	OK	OK	
PB2-4-A.3	Launch the PDS controller software	Program open	Program open	
PB2-4-A.4	Set to "FM" the window Model	FM	FM	
PB2-4-A.5	set the CAN BUS board address to 30	30	30	
PB2-4-A.6	select JMDC = 0	0	0	
PB2-4-A.7	select TX = A	A	A	
PB2-4-A.8	select RX = A	A	A	
PB2-4-A.9	Select "CAN BUS I/F Side" to A	A	A	
PB2-4-A.10	Select "PDS Side" to A	A	A	
PB2-4-A.11	Set input bus voltage to 120V	120V±1V	120V	
PB2-4-A.12	Set input bus current limitation to 27,5 A	27,5A	27,5A	
PB2-4-A.13	Enable power supply output	enabled	enabled	
PB2-4-A.14	Verify that green led of "power switch box" is lighted	Green led ligthed	Green led ligthed	
PB2-4-A.15	Switch ON the "power switch "of "power switch box"	Switch ON	Switch ON	
PB2-4-A.16	Verify that red led of "power switch box" is lighted	Red led ligthed	Red led ligthed	
PB2-4-A.17	Take note of power supply output current	1,1A±0,5A	1,07 A	
PB2-4-A.18	Click on Run flash button	OK	OK	
PB2-4-A.19	Set the CAN BUS board address to 31	31	31	
PB2-4-A.20	Select "CAN BUS I/F Side" to B	B	B	
PB2-4-A.21	Click on Run flash button	OK	OK	
PB2-4-A.22	Set the CAN BUS board address to 30	30	30	
PB2-4-A.23	Select "CAN BUS I/F Side" to A	A	A	
PB2-4-A.24	Click on PB2-1 button	OK	OK	This board is default ON
PB2-4-A.25	Set Digital I/F Test logic value = 1 in "Commanding" column	1	1	Button located on left side of software window
PB2-4-A.26	Click on letter "W" on the right of the "1" value	OK	OK	
PB2-4-A.27	Click on the command READ ALL under the column Digital Readout	OK	OK	
PB2-4-A.28	Verify that in the column Digital Readout under the voice Digital I/F Test appears "1"	1	1	
PB2-4-A.29	Set Digital I/F Test logic value = 0 in "Commanding" column	0	0	
PB2-4-A.30	Click on letter "W" on the right of the "0" value	OK	OK	
PB2-4-A.31	Click on the command READ ALL under the column Digital Readout	OK	OK	
PB2-4-A.32	Verify that in the column Digital Readout under the voice Digital I/F Test appears "0"	0	0	
PB2-4-A.33	Verify the status of the following flags: BOARD STATUS	OK	OK	

DATE:	TEST CONDUCTOR	QA	CUSTOMER
26/07/2009	Albertin A.	Francini E.	

Questo documento contiene informazioni di proprietà di CARLO GAVAZZI SPACE SpA. Tutti i diritti sono riservati.

All information contained in this document are property of CARLO GAVAZZI SPACE SpA. All right reserved.

UUT DATA : Model PFM Item AMS02 POWER DISTRIBUTION SYSTEM C.I. PDS 18 S/N FM01

STEP n°	TEST SEQUENCE	EXPECTED VALUE	MEASURED VALUE	REMARKS
	OVT ALARM	OK	OK	
	Input OVC Alarm	OK	OK	
	DCDC ON/OFF	ON	ON	
	27V UV	OK	OK	
	29V Trip	OK	OK	
	DCDC OFF/ON CMD	ON	ON	
PB2-4-A.34	Measure with multimeter the voltage on ESEM 3A-1 out 3 (Check that load is not connected)	28,00V±1,00V	28,15 V	V1
PB2-4-A.35	Verify the value of the following telemetry: Output Voltage	V1±1.092V	28,20 V	Click on relative Rbutton
PB2-4-A.36	Set OFF on DCDC ON /OFF command window and send the command	OK	OK	Power cell OFF
PB2-4-A.37	Click on the command READ ALL under the column Digital Readout	OK	OK	
PB2-4-A.38	Verify the status of the following flags:			
	BOARD STATUS	OK	OK	
	OVT ALARM	OK	OK	
	Input OVC Alarm	OK	OK	
	DCDC ON/OFF	OFF	OFF	
	27V UNV	OK	OK	
	29V Trip	OK	OK	
	DCDC OFF/ON CMD	OFF	OFF	
PB2-4-A.39	Click on the command READ ALL under the column Analog Readout	OK	OK	
PB2-4-A.40	Verify the value of the following telemetries:			
	Temperature	-40°C<T<80C°	31,73 °C	
	Analog Ref. 2.0V	2,000V±150mV	2,02 V	
PB2-4-A.41	Verify the following analog monitor: Output Voltage	0,00V±1.092V	-0,06 V	Click on relative Rbutton
PB2-4-A.42	Measure with multimeter the voltage on ESEM 3-A 1 out 3 (Check that load is not connected)	0,00V±0,10V	0,015 V	
PB2-4-A.43	Set the CAN BUS board address to 31	31	31	
PB2-4-A.44	Select "CAN BUS I/F Side" to B	B	B	
PB2-4-A.45	Click on the command READ ALL under the column Digital Readout	OK	OK	
PB2-4-A.46	Verify the status of the following flags:			
	BOARD STATUS	OK	OK	
	OVT ALARM	OK	OK	
	Input OVC Alarm	OK	OK	
	DCDC ON/OFF	OFF	OFF	
	27V UNV	OK	OK	
	29V Trip	OK	OK	
	DCDC OFF/ON CMD	OFF	OFF	
PB2-4-A.47	Set ON on DCDC OFF/ON command window and send the command	OK	OK	Power cell ON

DATE:	TEST CONDUCTOR	QA	CUSTOMER
24 /07/2009	Albertin A.	Francini E.	

Questo documento contiene informazioni di proprietà di CARLO GAVAZZI SPACE SpA. Tutti i diritti sono riservati.

All information contained in this document are property of CARLO GAVAZZI SPACE SpA. All right reserved.

UUT DATA : Model PFM Item AMS02 POWER DISTRIBUTION SYSTEM C.I. PDS 18 S/N FM01

STEP n°	TEST SEQUENCE	EXPECTED VALUE	MEASURED VALUE	REMARKS
PB2-4-A.48	Click on the command READ ALL under the column Digital Readout	OK	OK	
PB2-4-A.49	Verify the status of the following flags:			
	BOARD STATUS	OK	OK	
	OVT ALARM	OK	OK	
	Input OVC Alarm	OK	OK	
	DCDC ON/OFF	ON	ON	
	27V UNV	OK	OK	
	29V Trip	OK	OK	
	DCDC OFF/ON CMD	ON	ON	
PB2-4-A.50	Set the CAN BUS board address to 30	30	30	
PB2-4-A.51	Select "CAN BUS I/F Side" to A	A	A	
PB2-4-A.52	Click on the command READ ALL under the column Digital Readout	OK	OK	
PB2-4-A.53	Verify the status of the following flags:			
	BOARD STATUS	OK	OK	
	OVT ALARM	OK	OK	
	Input OVC Alarm	OK	OK	
	DCDC ON/OFF	ON	ON	
	27V UNV	OK	OK	
	29V Trip	OK	OK	
	DCDC OFF/ON CMD	ON	ON	

DATE:	TEST CONDUCTOR	QA	CUSTOMER
24/07/2009	Albertin A.	Francini E.	

Questo documento contiene informazioni di proprietà di CARLO GAVAZZI SPACE SpA. Tutti i diritti sono riservati.

All information contained in this document are property of CARLO GAVAZZI SPACE SpA. All right reserved.

UUT DATA :	Model	PFM	Item	AMS02 POWER DISTRIBUTION SYSTEM	C.I.	PDS 18	S/N	FM01

10.3.1.5.4 ESEM 3A-1 SIDE A

STEP n°	TEST SEQUENCE	EXPECTED VALUE	MEASURED VALUE	REMARKS
3A-1-A.1	Click on ESEM 3A-1 button	OK	OK	Button located on left side of software window
3A-1-A.2	Connect to active loads outlet 1, 2, 3, 4, 5, 6, 7 and 8.	OK	OK	
3A-1-A.3	Verify that loads are set to 0A current absorption	OK	OK	
3A-1-A.4	Set Digital I/F Test logic value = 1 in "Commanding" column	1	1	
3A-1-A.5	Click on letter "W" on the right of the "1" value	OK	OK	
3A-1-A.6	Click on the command READ ALL under the column Digital Readout	OK	OK	
3A-1-A.7	Verify that in the column Digital Readout under the voice Digital I/F Test appears "1"	1	1	
3A-1-A.8	Set Digital I/F Test logic value = 0 in "Commanding" column	0	0	
3A-1-A.9	Click on letter "W" on the right of the "0" value	OK	OK	
3A-1-A.10	Click on the command READ ALL under the column Digital Readout	OK	OK	
3A-1-A.11	Verify that in the column Digital Readout under the voice Digital I/F Test appears "0"	0	0	
3A-1-A.12	Set ON in the window All Outlets ON/OFF and push the relative "W" command	OK	OK	
3A-1-A.13	Read on display the voltage on this ESEM 3-A loads: O_1: TPD3 O_2: TPD7 O_3: JPD_N O_4: SPD1_N O_5: UGPD_N O_6:SPD0_R O_7: TPD1 O_8:TTPD_R	 28,00V±1,00V 28,00V±1,00V 28,00V±1,00V 28,00V±1,00V 28,00V±1,00V 28,00V±1,00V 28,00V±1,00V 28,00V±1,00V	28,15 V (ALL)	
3A-1-A.14	Click on Read All command in Digital Readout column	OK	OK	
3A-1-A.15	Verify the status of the following flags: BOARD STATUS OVT Alarm From O_1 CMD: TPD3 to O_8 CMD: TTPD_R From O_1 Status: TPD3 to O_8 Status: TTPD_R	 OK OK ON ON	 OK OK ON ON	
3A-1-A.16	Set the CAN BUS board address to 31	31	31	
3A-1-A.17	Select "CAN BUS I/F Side" to B	B	B	
3A-1-A.18	Click on Read All command in Digital Readout column	OK	OK	
3A-1-A.19	Verify the status of the following flags: BOARD STATUS OVT Alarm From O_1 CMD: TPD3 to O_8 CMD: TTPD_R From O_1 Status: TPD3 to O_8 Status: TTPD_R	 OK OK ON ON	 OK OK ON ON	

DATE:	TEST CONDUCTOR	QA	CUSTOMER
27/07/2009	Albertin A.	Francini E.	

Questo documento contiene informazioni di proprietà di CARLO GAVAZZI SPACE SpA. Tutti i diritti sono riservati.

All information contained in this document are property of CARLO GAVAZZI SPACE SpA. All right reserved.

UUT DATA : Model PFM Item AMS02 POWER DISTRIBUTION SYSTEM C.I. PDS 18 S/N FM01

STEP n°	TEST SEQUENCE	EXPECTED VALUE	MEASURED VALUE	REMARKS
3A-1-A.20	Generate a short circuit on the passive load keyboards: From O_1: TPD3 to O_8: TTPD_R	OK	OK	
3A-1-A.21	Read on display the voltage on this ESEM 3-A loads: O_1: TPD3 O_2: TPD7 O_3: JPD_N O_4: SPD1_N O_5: UGPD_N O_6:SPD0_R O_7: TPD1 O_8:TTPD_R	0,00V<V<1,00V 0,00V<V<1,00V 0,00V<V<1,00V 0,00V<V<1,00V 0,00V<V<1,00V 0,00V<V<1,00V 0,00V<V<1,00V 0,00V<V<1,00V	0,020 V (ALL)	
3A-1-A.22	Click on Read All command in Digital Readout column	OK	OK	
3A-1-A.23	Verify the status of the following flags: BOARD STATUS OVT Alarm From O_1 CMD: TPD3 to O_8 CMD: TTPD_R From O_1 Status: TPD3 to O_8 Status: TTPD_R	**NOK** OK ON **OFF**	**NOK** OK ON **OFF**	
3A-1-A.24	Set the CAN BUS board address to 30	30	30	
3A-1-A.25	Select "CAN BUS I/F Side" to A	A	A	
3A-1-A.26	Click on Read All command in Digital Readout column	OK	OK	
3A-1-A.27	Verify the status of the following flags: BOARD STATUS OVT Alarm From O_1 CMD: TPD3 to O_8 CMD: TTPD_R From O_1 Status: TPD3 to O_8 Status: TTPD_R	**NOK** OK ON **OFF**	**NOK** OK ON **OFF**	
3A-1-A.28	Set OFF in the window All Outlets ON/OFF and push the relative "W" command	OK	OK	
3A-1-A.29	Set ON in the window All Outlets ON/OFF and push the relative "W" command	OK	OK	
3A-1-A.30	Click on Read All command in Digital Readout column	OK	OK	
3A-1-A.31	Verify the status of the following flags: BOARD STATUS OVT Alarm From O_1 CMD: TPD3 to O_8 CMD: TTPD_R From O_1 Status: TPD3 to O_8 Status: TTPD_R	**OK** OK ON **ON**	**OK** OK ON **ON**	
3A-1-A.32	Set the CAN BUS board address to 31	31	31	
3A-1-A.33	Select "CAN BUS I/F Side" to B	B	B	
3A-1-A.34	Click on Read All command in Digital Readout column	OK	OK	
3A-1-A.35	Verify the status of the following flags: BOARD STATUS	**OK**	**OK**	

DATE:	TEST CONDUCTOR	QA	CUSTOMER
26/07/2009	Albertin A.	Francini E.	

Questo documento contiene informazioni di proprietà di CARLO GAVAZZI SPACE SpA. Tutti i diritti sono riservati.

All information contained in this document are property of CARLO GAVAZZI SPACE SpA. All right reserved.

UUT DATA : Model PFM Item AMS02 POWER DISTRIBUTION SYSTEM C.I. PDS 18 S/N FM01

STEP n°	TEST SEQUENCE	EXPECTED VALUE	MEASURED VALUE	REMARKS
	OVT Alarm From O_1 CMD: TPD3 to O_8 CMD: TTPD_R From O_1 Status: TPD3 to O_8 Status: TTPD_R	OK ON ON	OK ON ON	
3A-1-A.36	Using board telemetries set to 2A current absorption all the outlets: From O_1: TPD3 to O_8: TTPD_R	OK	OK	Set active loads to constant current mode. Set current on display with 100mA above the desired value with the exception of out8 that is correct.
3A-1-A.37	Push on Read All button in Analog Readout column	OK	OK	
3A-1-A.38	Verify the telemetries: O_1 Current: TPD3 O_2 Current: TPD3 O_3 Current: JPD_N O_4 Current: SPD1_N O_5 Current: UGPD_N O_6 Current: SPD0_R O_7 Current: TPD1 O_8 Current: TTPD_R Temperature Analog Ref. 3.0V	 2,000A±0,225A 2,000A±0,225A 2,000A±0,225A 2,000A±0,225A 2,000A±0,225A 2,000A±0,225A 2,000A±0,225A 2,00A±0,45A -40°C<T<80C° 3,000V±250mV	 2,05 A 2,10 A 2,02 A 2,07 A 2,05 A 2,04 A 2,08 A 2,13 A 26,7 °C 2,97 V	
3A-1-A.39	Set the CAN BUS board address to 30	30	30	
3A-1-A.40	Select "CAN BUS I/F Side" to A	A	A	
3A-1-A.41	Push on Read All button in Analog Readout column	OK	OK	
3A-1-A.42	Verify the telemetries: O_1 Current: TPD3 O_2 Current: TPD3 O_3 Current: JPD_N O_4 Current: SPD1_N O_5 Current: UGPD_N O_6 Current: SPD0_R O_7 Current: TPD1 O_8 Current: TTPD_R Temperature Analog Ref. 3.0V	 2,000A±0,225A 2,000A±0,225A 2,000A±0,225A 2,000A±0,225A 2,000A±0,225A 2,000A±0,225A 2,000A±0,225A 2,00A±0,45A -40°C<T<80C° 3,000V±250mV	 2,05 A 2,07 A 2,05 A 2,05 A 2,05 A 2,07 A 2,08 A 2,09 A 30,0 °C 2,99 V	
3A-1-A.43	Set to 0A current absorption all the outlets: From O_1: TPD3 to O_8: TTPD_R	OK	OK	
3A-1-A.44	Set OFF in the window All Outlets ON/OFF and push the relative "W" command	OK	OK	
3A-1-A.45	Click on Raed all to in Digital readout column	OK	OK	
3A-1-A.46	Verify from digital readout column that all outlets are OFF	OK	OK	

DATE:	TEST CONDUCTOR	QA	CUSTOMER
24/07/2009	Albertin A.	Francini E.	

Questo documento contiene informazioni di proprietà di CARLO GAVAZZI SPACE SpA. Tutti i diritti sono riservati.

All information contained in this document are property of CARLO GAVAZZI SPACE SpA. All right reserved.

UUT DATA :	Model	PFM	Item	AMS02 POWER DISTRIBUTION SYSTEM	C.I.	PDS 18	S/N	FM01

10.3.1.5.5 PB2-2 SIDE A

STEP n°	TEST SEQUENCE	EXPECTED VALUE	MEASURED VALUE	REMARKS
PB2-2-A.1	Connect AI_120V and AI_120V_RTN power supply signals	OK	OK	
PB2-2-A.2	Verify that all the cables of the section are connected	OK	OK	
PB2-2-A.3	Launch the PDS controller software	Program open	Program open	
PB2-2-A.4	Set to "FM" the window Model	OK	OK	
PB2-2-A.5	Select "PDS Side" to A	A	A	
PB2-2-A.6	Set the CAN BUS board address to 30	30	30	
PB2-2-A.7	Select JMDC = 0	0	0	
PB2-2-A.8	Select TX = A	A	A	
PB2-2-A.9	Select RX = A	A	A	
PB2-2-A.10	Select "CAN BUS I/F Side" to A	A	A	
PB2-2-A.11	Set input bus voltage to 120V	120V±1V	120,0 V	
PB2-2-A.12	Set input bus current limitation to ~~15A~~ 27,5A	27,5A ~~15A~~±1A	27,5 A	See PVS-02
PB2-2-A.13	Enable power supply output	enabled	enabled	
PB2-2-A.14	Verify that green led of "power switch box" is lighted	Green led ligthed	Green led ligthed	
PB2-2-A.15	Switch ON the "power switch "of "power switch box"	Switch ON	Switch ON	
PB2-2-A.16	Verify that red led of "power switch box" is lighted	Red led ligthed	Red led ligthed	
PB2-2-A.17	Take note of power supply output current	1,1A±0,5A	1,1 A	
PB2-2-A.18	Click on Run flash button	OK	OK	
PB2-2-A.19	Set the CAN BUS board address to 31	31	31	
PB2-2-A.20	Select "CAN BUS I/F Side" to B	B	B	
PB2-2-A.21	Click on Run flash button	OK	OK	
PB2-2-A.22	Set the CAN BUS board address to 30	30	30	
PB2-2-A.23	Select "CAN BUS I/F Side" to A	A	A	
PB2-2-A.24	Click on PB2-2 button	OK	OK	This board is default OFF
PB2-2-A.25	Set Digital I/F Test logic value = 1 in "Commanding" column	1	1	Button located on left side of software window
PB2-2-A.26	Click on letter "W" on the right of the "1" value	OK	OK	
PB2-2-A.27	Click on the command READ ALL under the column Digital Readout	OK	OK	
PB2-2-A.28	Verify that in the column Digital Readout under the voice Digital I/F Test appears "1"	1	1	
PB2-2-A.29	Set Digital I/F Test logic value = 0 in "Commanding" column	0	0	
PB2-2-A.30	Click on letter "W" on the right of the "0" value	OK	OK	
PB2-2-A.31	Click on the command READ ALL under the column Digital Readout	OK	OK	
PB2-2-A.32	Verify that in the column Digital Readout under the voice Digital I/F Test appears "0"	0	0	
PB2-2-A.33	Click on the command READ ALL under the column Digital Readout	OK	OK	
PB2-2-A.34	Verify the status of the following flags:			

DATE:	TEST CONDUCTOR	QA	CUSTOMER
24/07/2009	Albertin A.	Francini E.	

Questo documento contiene informazioni di proprietà di CARLO GAVAZZI SPACE SpA. Tutti i diritti sono riservati.

All information contained in this document are property of CARLO GAVAZZI SPACE SpA. All right reserved.

UUT DATA : Model PFM Item AMS02 POWER DISTRIBUTION SYSTEM C.I. PDS 18 S/N FM01

STEP n°	TEST SEQUENCE	EXPECTED VALUE	MEASURED VALUE	REMARKS
	BOARD STATUS	OK	OK	
	OVT ALARM	OK	OK	
	Input OVC Alarm	OK	OK	
	DCDC ON/OFF	OFF	OFF	
	27V UV	OK	OK	
	29V Trip	OK	OK	
	DCDC OFF/ON CMD	OFF	OFF	
PB2-2-A.35	Click on the command READ ALL under the column Analog Readout	OK	OK	
PB2-2-A.36	Verify the value of the following telemetries:			
	Temperature	-40°C<T<80C°	25,4 °C	
	Analog Ref. 2.0V	2,000V±150mV	1,94 V	
PB2-2-A.37	Set the CAN BUS board address to 31	31	31	
PB2-2-A.38	Select "CAN BUS I/F Side" to B	B	B	
PB2-2-A.39	Click on the command READ ALL under the column Digital Readout	OK	OK	
PB2-2-A.40	Verify the status of the following flags:			
	BOARD STATUS	OK	OK	
	OVT ALARM	OK	OK	
	Input OVC Alarm	OK	OK	
	DCDC ON/OFF	OFF	OFF	
	27V UNV	OK	OK	
	29V Trip	OK	OK	
	DCDC OFF/ON CMD	OFF	OFF	
PB2-2-A.41	Set ON on DCDC OFF/ON command window and send the command	OK	OK	Power cell ON
PB2-2-A.42	Click on the command READ ALL under the column Digital Readout	OK	OK	
PB2-2-A.43	Verify the status of the following flags:			
	BOARD STATUS	OK	OK	
	OVT ALARM	OK	OK	
	Input OVC Alarm	OK	OK	
	DCDC ON/OFF	ON	ON	
	27V UNV	OK	OK	
	29V Trip	OK	OK	
	DCDC OFF/ON CMD	ON	ON	
PB2-2-A.44	Click on ESEM 3A-2 button	OK	OK	
PB2-2-A.45	Set ON in the window "O_1: ER1_N" and push the relative "W" command	OK	OK	
PB2-2-A.46	Read on display the voltage on ESEM 3-A 2 out 1 (Check that load is not connected)	28,00V±1,00V	28,17 V	V1
PB2-2-A.47	Click on PB2-2 button	OK	OK	
PB2-2-A.48	Click on the command READ ALL under the column Analog Readout	OK	OK	

DATE:	TEST CONDUCTOR	QA	CUSTOMER
26/07/2009	Albertin A.	Francini E.	

Questo documento contiene informazioni di proprietà di CARLO GAVAZZI SPACE SpA. Tutti i diritti sono riservati.

All information contained in this document are property of CARLO GAVAZZI SPACE SpA. All right reserved.

UUT DATA : Model PFM Item AMS02 POWER DISTRIBUTION SYSTEM C.I. PDS 18 S/N FM01

STEP n°	TEST SEQUENCE	EXPECTED VALUE	MEASURED VALUE	REMARKS
PB2-2-A.49	Verify the value of the following telemetry: Output Voltage	V1±1.092V	28,5 V	Click on relative Rbutton
PB2-2-A.50	Set the CAN BUS board address to 30	30	30	
PB2-2-A.51	Select "CAN BUS I/F Side" to A	A	A	
PB2-2-A.52	Click on the command READ ALL under the column Digital Readout	OK	OK	
PB2-2-A.53	Verify the status of the following flags: BOARD STATUS OVT ALARM Input OVC Alarm DCDC ON/OFF 27V UNV 29V Trip DCDC OFF/ON CMD	 OK OK OK ON OK OK ON	 OK OK OK ON OK OK ON	

DATE:	TEST CONDUCTOR	QA	CUSTOMER
26/07/2009	Albertin A.	Francini E.	

Questo documento contiene informazioni di proprietà di CARLO GAVAZZI SPACE SpA. Tutti i diritti sono riservati.

All information contained in this document are property of CARLO GAVAZZI SPACE SpA. All right reserved.

UUT DATA :	Model	PFM	Item	AMS02 POWER DISTRIBUTION SYSTEM	C.I.	PDS 18	S/N	FM01

10.3.1.5.6 ESEM 3A-2 SIDE A

STEP n°	TEST SEQUENCE	EXPECTED VALUE	MEASURED VALUE	REMARKS
3A-2-A.1	Click on ESEM3-A-2 button	OK	OK	Button located on left side of software window
3A-2-A.2	Connect to active loads outlet 1, 2, 3, 4, 5, 6, 7 and 8.	OK	OK	
3A-2-A.3	Verify that loads are set to 0A current absorption	OK	OK	
3A-2-A.4	Set Digital I/F Test logic value = 1 in "Commanding" column	1	1	
3A-2-A.5	Click on letter "W" on the right of the "1" value	OK	OK	
3A-2-A.6	Click on the command READ ALL under the column Digital Readout	OK	OK	
3A-2-A.7	Verify that in the column Digital Readout under the voice Digital I/F Test appears "1"	1	1	
3A-2-A.8	Set Digital I/F Test logic value = 0 in "Commanding" column	0	0	
3A-2-A.9	Click on letter "W" on the right of the "0" value	OK	OK	
3A-2-A.10	Click on the command READ ALL under the column Digital Readout	OK	OK	
3A-2-A.11	Verify that in the column Digital Readout under the voice Digital I/F Test appears "0"	0	0	
3A-2-A.12	Set ON in the window All Outlets ON/OFF and push the relative "W" command	OK	OK	
3A-2-A.13	Read on display the voltage on this ESEM 3-A loads: O_1: ER1_N O_2: TPD2 O_3: TPD6 O_4: SPD3_N O_5: MPD_N O_6: UPD1 O_7: SPD2_N O_8: CAB_R	 28,00V±1,00V 28,00V±1,00V 28,00V±1,00V 28,00V±1,00V 28,00V±1,00V 28,00V±1,00V 28,00V±1,00V 28,00V±1,00V	28,05 V (ALL)	
3A-2-A.14	Click on Read All command in Digital Readout column	OK	OK	
3A-2-A.15	Verify the status of the following flags: BOARD STATUS OVT Alarm From O_1 CMD: ER1_N to O_8 CMD: CAB_R From O_1 Status: ER1_N to O_8 Status: CAB_R	 OK OK ON ON	 OK OK ON ON	
3A-2-A.16	Set the CAN BUS board address to 31	31	31	
3A-2-A.17	Select "CAN BUS I/F Side" to B	B	B	
3A-2-A.18	Click on Read All command in Digital Readout column	OK	OK	
3A-2-A.19	Verify the status of the following flags: BOARD STATUS OVT Alarm From O_1 CMD: ER1_N to O_8 CMD: CAB_R From O_1 Status: ER1_N to O_8 Status: CAB_R	 OK OK ON ON	 OK OK ON ON	

DATE:	TEST CONDUCTOR	QA	CUSTOMER
24 /07/2009	Albertin A.	Francini E.	

Questo documento contiene informazioni di proprietà di CARLO GAVAZZI SPACE SpA. Tutti i diritti sono riservati.

All information contained in this document are property of CARLO GAVAZZI SPACE SpA. All right reserved.

UUT DATA : Model PFM Item AMS02 POWER DISTRIBUTION SYSTEM C.I. PDS 18 S/N FM01

STEP n°	TEST SEQUENCE	EXPECTED VALUE	MEASURED VALUE	REMARKS
3A-2-A.20	Generate a short circuit on the passive load keyboards: From O_1: ER1_N to O_8: CAB_R	OK	OK	
3A-2-A.21	Read on display the voltage on this ESEM 3-A loads: O_1: ER1_N O_2: TPD2 O_3: TPD6 O_4: SPD3_N O_5: MPD_N O_6: UPD1 O_7: SPD2_N O_8: CAB_R	 0,00V<V<1,00V 0,00V<V<1,00V 0,00V<V<1,00V 0,00V<V<1,00V 0,00V<V<1,00V 0,00V<V<1,00V 0,00V<V<1,00V 0,00V<V<1,00V	0,0 V (ALL)	
3A-2-A.22	Click on Read All command in Digital Readout column	OK	OK	
3A-2-A.23	Verify the status of the following flags: BOARD STATUS OVT Alarm From O_1 CMD: ER1_N to O_8 CMD: CAB_R From O_1 Status: ER1_N to O_8 Status: CAB_R	 NOK OK ON OFF	 NOK OK ON OFF	
3A-2-A.24	Set the CAN BUS board address to 30	30	30	
3A-2-A.25	Select "CAN BUS I/F Side" to A	A	A	
3A-2-A.26	Click on Read All command in Digital Readout column	OK	OK	
3A-2-A.27	Verify the status of the following flags: BOARD STATUS OVT Alarm From O_1 CMD: ER1_N to O_8 CMD: CAB_R From O_1 Status: ER1_N to O_8 Status: CAB_R	 NOK OK ON OFF	 NOK OK ON OFF	
3A-2-A.28	Set OFF in the window All Outlets ON/OFF and push the relative "W" command	OK	OK	
3A-2-A.29	Set ON in the window All Outlets ON/OFF and push the relative "W" command	OK	OK	
3A-2-A.30	Click on Read All command in Digital Readout column	OK	OK	
3A-2-A.31	Verify the status of the following flags: BOARD STATUS OVT Alarm From O_1 CMD: ER1_N to O_8 CMD: CAB_R From O_1 Status: ER1_N to O_8 Status: CAB_R	 OK OK ON ON	 OK OK ON ON	
3A-2-A.32	Set the CAN BUS board address to 31	31	31	
3A-2-A.33	Select "CAN BUS I/F Side" to B	B	B	
3A-2-A.34	Click on Read All command in Digital Readout column	OK	OK	
3A-2-A.35	Verify the status of the following flags: BOARD STATUS	OK	OK	

DATE:	TEST CONDUCTOR	QA	CUSTOMER
24/07/2009	Albertin A.	Francini E.	

Questo documento contiene informazioni di proprietà di CARLO GAVAZZI SPACE SpA. Tutti i diritti sono riservati.

All information contained in this document are property of CARLO GAVAZZI SPACE SpA. All right reserved.

UUT DATA : Model PFM Item AMS02 POWER DISTRIBUTION SYSTEM C.I. PDS 18 S/N FM01

STEP n°	TEST SEQUENCE	EXPECTED VALUE	MEASURED VALUE	REMARKS
	OVT Alarm From O_1 CMD: ER1_N to O_8 CMD: CAB_R From O_1 Status: ER1_N to O_8 Status: CAB_R	OK ON ON	OK ON ON	
3A-2-A.36	Using board telemetries set to 2A current absorption all the outlets: From O_1: ER1_N to O_8: CAB_R	OK	OK	Set active loads to constant current mode. Set current on display with 100mA above the desired value with the exception of out8 that is correct.
3A-2-A.37	Push on Read All button in Analog Readout column	OK	OK	
3A-2-A.38	Verify the telemetries: O_1 Current: ER1_N O_2 Current: TPD2 O_3 Current: TPD6 O_4 Current: SPD3_N O_5 Current: MPD_N O_6 Current: UPD1 O_7 Current: SPD2_N O_8 Current: CAB_R Temperature Analog Ref. 3.0V	2,000A±0,225A 2,000A±0,225A 2,000A±0,225A 2,000A±0,225A 2,000A±0,225A 2,000A±0,225A 2,000A±0,225A 2,00A±0,45A -40°C<T<80C° 3,000V±250mV	2,16 A 2,10 A 2,05 A 2,06 A 2,10 A 2,17 A 2,13 A 2,22 A 29,0 °C 2,98 V	
3A-2-A.39	Set the CAN BUS board address to 30	30	30	
3A-2-A.40	Select "CAN BUS I/F Side" to A	A	A	
3A-2-A.41	Push on Read All button in Analog Readout column	OK	OK	
3A-2-A.42	Verify the telemetries: O_1 Current: ER1_N O_2 Current: TPD2 O_3 Current: TPD6 O_4 Current: SPD3_N O_5 Current: MPD_N O_6 Current: UPD1 O_7 Current: SPD2_N O_8 Current: CAB_R Temperature Analog Ref. 3.0V	2,000A±0,225A 2,000A±0,225A 2,000A±0,225A 2,000A±0,225A 2,000A±0,225A 2,000A±0,225A 2,000A±0,225A 2,00A±0,45A -40°C<T<80C° 3,000V±250mV	2,13 A 2,07 A 2,04 A 2,08 A 2,12 A 2,16 A 2,16 A 2,23 A 31 °C 2,97 V	
3A-2-A.43	Set to 0A current absorption all the outlets: From O_1: TPD3 to O_8: TTPD_R	OK	OK	
3A-2-A.44	Set OFF in the window All Outlets ON/OFF and push the relative "W" command	OK	OK	
3A-2-A.45	Click on Raed all to in Digital readout column	OK	OK	
3A-2-A.46	Verify from digital readout column that all outlets are OFF	OK	OK	

DATE:	TEST CONDUCTOR	QA	CUSTOMER
27/07/2009	Albertin A.	Francini E.	

Questo documento contiene informazioni di proprietà di CARLO GAVAZZI SPACE SpA. Tutti i diritti sono riservati.

All information contained in this document are property of CARLO GAVAZZI SPACE SpA. All right reserved.

UUT DATA :	Model	PFM	Item	AMS02 POWER DISTRIBUTION SYSTEM	C.I.	PDS 18	S/N	FM01

10.3.1.5.7 PB2-3 SIDE A

STEP n°	TEST SEQUENCE	EXPECTED VALUE	MEASURED VALUE	REMARKS
PB2-3-A.1	Connect AI_120V and AI_120V_RTN power supply signals	OK	OK	
PB2-3-A.2	Verify that all the cables of the section are connected	OK	OK	
PB2-3-A.3	Launch the PDS controller software	Program open	Program open	
PB2-3-A.4	Set to "FM" the window Model	OK	OK	
PB2-3-A.5	Select "PDS Side" to A	A	A	
PB2-3-A.6	Set the CAN BUS board address to 30	30	30	
PB2-3-A.7	Select JMDC = 0	0	0	
PB2-3-A.8	Select TX = A	A	A	
PB2-3-A.9	Select RX = A	A	A	
PB2-3-A.10	Select "CAN BUS I/F Side" to A	A	A	
PB2-3-A.11	Set input bus voltage to 120V	120V±1V	120,0 V	
PB2-3-A.12	Set input bus current limitation to ~~15A~~ 27,5A	27,5A ~~15A~~±1A	27,5 A	See PVS-02
PB2-3-A.13	Enable power supply output	enabled	enabled	
PB2-3-A.14	Verify that green led of "power switch box" is lighted	Green led ligthed	Green led ligthed	
PB2-3-A.15	Switch ON the "power switch "of "power switch box"	Switch ON	Switch ON	
PB2-3-A.16	Verify that red led of "power switch box" is lighted	Red led ligthed	Red led ligthed	
PB2-3-A.17	Take note of power supply output current	1,1A±0,5A	1,1 A	
PB2-3-A.18	Click on Run flash button	OK	OK	
PB2-3-A.19	Set the CAN BUS board address to 31	31	31	
PB2-3-A.20	Select "CAN BUS I/F Side" to B	B	B	
PB2-3-A.21	Click on Run flash button	OK	OK	
PB2-3-A.22	Set the CAN BUS board address to 30	30	30	
PB2-3-A.23	Select "CAN BUS I/F Side" to A	A	A	
PB2-3-A.24	Click on PB2-3 button	OK	OK	This board is default OFF
PB2-3-A.25	Set Digital I/F Test logic value = 1 in "Commanding" column	1	1	Button located on left side of software window
PB2-3-A.26	Click on letter "W" on the right of the "1" value	OK	OK	
PB2-3-A.27	Click on the command READ ALL under the column Digital Readout	OK	OK	
PB2-3-A.28	Verify that in the column Digital Readout under the voice Digital I/F Test appears "1"	1	1	
PB2-3-A.29	Set Digital I/F Test logic value = 0 in "Commanding" column	0	0	
PB2-3-A.30	Click on letter "W" on the right of the "0" value	OK	OK	
PB2-3-A.31	Click on the command READ ALL under the column Digital Readout	OK	OK	
PB2-3-A.32	Verify that in the column Digital Readout under the voice Digital I/F Test appears "0"	0	0	
PB2-3-A.33	Click on the command READ ALL under the column Digital Readout	OK	OK	
PB2-3-A.34	Verify the status of the following flags:			

DATE:	TEST CONDUCTOR	QA	CUSTOMER
24/07/2009	Albertin A.	Francini E.	

Questo documento contiene informazioni di proprietà di CARLO GAVAZZI SPACE SpA. Tutti i diritti sono riservati.

All information contained in this document are property of CARLO GAVAZZI SPACE SpA. All right reserved.

UUT DATA : Model PFM Item AMS02 POWER DISTRIBUTION SYSTEM C.I. PDS 18 S/N FM01

STEP n°	TEST SEQUENCE	EXPECTED VALUE	MEASURED VALUE	REMARKS
	BOARD STATUS	OK	OK	
	OVT ALARM	OK	OK	
	Input OVC Alarm	OK	OK	
	DCDC ON/OFF	OFF	OFF	
	27V UV	OK	OK	
	29V Trip	OK	OK	
	DCDC OFF/ON CMD	OFF	OFF	
PB2-3-A.35	Click on the command READ ALL under the column Analog Readout	OK	OK	
PB2-3-A.36	Verify the value of the following telemetries:			
	Temperature	-40°C<T<80C°	26,0 °C	
	Analog Ref. 2.0V	2,000V±150mV	2,00 V	
PB2-3-A.37	Set the CAN BUS board address to 31	31	31	
PB2-3-A.38	Select "CAN BUS I/F Side" to B	B	B	
PB2-3-A.39	Click on the command READ ALL under the column Digital Readout	OK	OK	
PB2-3-A.40	Verify the status of the following flags:			
	BOARD STATUS	OK	OK	
	OVT ALARM	OK	OK	
	Input OVC Alarm	OK	OK	
	DCDC ON/OFF	OFF	OFF	
	27V UNV	OK	OK	
	29V Trip	OK	OK	
	DCDC OFF/ON CMD	OFF	OFF	
PB2-3-A.41	Set ON on DCDC OFF/ON command window and send the command	OK	OK	Power cell ON
PB2-3-A.42	Click on the command READ ALL under the column Digital Readout	OK	OK	
PB2-3-A.43	Verify the status of the following flags:			
	BOARD STATUS	OK	OK	
	OVT ALARM	OK	OK	
	Input OVC Alarm	OK	OK	
	DCDC ON/OFF	ON	ON	
	27V UNV	OK	OK	
	29V Trip	OK	OK	
	DCDC OFF/ON CMD	ON	ON	
PB2-3-A.44	Click on ESEM 3A-3 button	OK	OK	
PB2-3-A.45	Set ON in the window "O_1: TPD0" and push the relative "W" command	OK	OK	
PB2-3-A.46	Read on display the voltage on ESEM 3-A 3 out 1 (Check that load is not connected)	28,00V±1,00V	28,17 V	V1
PB2-3-A.47	Click on PB2-3 button	OK	OK	
PB2-3-A.48	Click on the command READ ALL under the column Analog Readout	OK	OK	
PB2-3-A.49	Verify the value of the following telemetry:			Click on relative Rbutton

DATE:	TEST CONDUCTOR	QA	CUSTOMER
24/07/2009	Albertin A.	Francini E.	

Questo documento contiene informazioni di proprietà di CARLO GAVAZZI SPACE SpA. Tutti i diritti sono riservati.

All information contained in this document are property of CARLO GAVAZZI SPACE SpA. All right reserved.

UUT DATA : Model PFM Item AMS02 POWER DISTRIBUTION SYSTEM C.I. PDS 18 S/N FM01

STEP n°	TEST SEQUENCE	EXPECTED VALUE	MEASURED VALUE	REMARKS
	Output Voltage	V1±1.092V	28,17 V	
PB2-3-A.50	Set the CAN BUS board address to 30	30	30	
PB2-3-A.51	Select "CAN BUS I/F Side" to A	A	A	
PB2-3-A.52	Click on the command READ ALL under the column Digital Readout	OK	OK	
PB2-3-A.53	Verify the status of the following flags:			
	BOARD STATUS	OK	OK	
	OVT ALARM	OK	OK	
	Input OVC Alarm	OK	OK	
	DCDC ON/OFF	ON	ON	
	27V UNV	OK	OK	
	29V Trip	OK	OK	
	DCDC OFF/ON CMD	ON	ON	

DATE:	TEST CONDUCTOR	QA	CUSTOMER
26/07/2009	Albertin A.	Francini E.	

Questo documento contiene informazioni di proprietà di CARLO GAVAZZI SPACE SpA. Tutti i diritti sono riservati.

All information contained in this document are property of CARLO GAVAZZI SPACE SpA. All right reserved.

UUT DATA :	Model	PFM	Item	AMS02 POWER DISTRIBUTION SYSTEM	C.I.	PDS 18	S/N	FM01

10.3.1.5.8 ESEM 3A-3 SIDE A

STEP n°	TEST SEQUENCE	EXPECTED VALUE	MEASURED VALUE	REMARKS
3A-3-A.1	Click on ESEM3-A-3 button	OK	OK	Button located on left side of software window
3A-3-A.2	Connect to active loads outlet 1, 2, 3, 4, 5, 6, 7 and 8.	OK	OK	
3A-3-A.3	Verify that loads are set to 0A current absorption	OK	OK	
3A-3-A.4	Set Digital I/F Test logic value = 1 in "Commanding" column	1	1	
3A-3-A.5	Click on letter "W" on the right of the "1" value	OK	OK	
3A-3-A.6	Click on the command READ ALL under the column Digital Readout	OK	OK	
3A-3-A.7	Verify that in the column Digital Readout under the voice Digital I/F Test appears "1"	1	1	
3A-3-A.8	Set Digital I/F Test logic value = 0 in "Commanding" column	0	0	
3A-3-A.9	Click on letter "W" on the right of the "0" value	OK	OK	
3A-3-A.10	Click on the command READ ALL under the column Digital Readout	OK	OK	
3A-3-A.11	Verify that in the column Digital Readout under the voice Digital I/F Test appears "0"	0	0	
3A-3-A.12	Set ON in the window All Outlets ON/OFF and push the relative "W" command	OK	OK	
3A-3-A.13	Read on display the voltage on this ESEM 3-A loads: O_1: TPD0 O_2: TPD4 O_3: ER0_N O_4: MPD_R O_5: SPD3_R O_6: UGPD_R O_7: SPD2_R O_8: CAB_N	 28,00V±1,00V 28,00V±1,00V 28,00V±1,00V 28,00V±1,00V 28,00V±1,00V 28,00V±1,00V 28,00V±1,00V 28,00V±1,00V	28,0 V (ALL)	
3A-3-A.14	Click on Read All command in Digital Readout column	OK	OK	
3A-3-A.15	Verify the status of the following flags: BOARD STATUS OVT Alarm From O_1 CMD: TPD0 to O_8 CMD: CAB_N From O_1 Status: TPD0 to O_8 Status: CAB_N	 OK OK ON ON	 OK OK ON ON	
3A-3-A.16	Set the CAN BUS board address to 31	31	31	
3A-3-A.17	Select "CAN BUS I/F Side" to B	B	B	
3A-3-A.18	Click on Read All command in Digital Readout column	OK	OK	
3A-3-A.19	Verify the status of the following flags: BOARD STATUS OVT Alarm From O_1 CMD: TPD0 to O_8 CMD: CAB_N From O_1 Status: TPD0 to O_8 Status: CAB_N	 OK OK ON ON	 OK OK ON ON	

DATE:	TEST CONDUCTOR	QA	CUSTOMER
26 /07/2009	Albertin A.	Francini E.	

Questo documento contiene informazioni di proprietà di CARLO GAVAZZI SPACE SpA. Tutti i diritti sono riservati.

All information contained in this document are property of CARLO GAVAZZI SPACE SpA. All right reserved.

UUT DATA : Model PFM Item AMS02 POWER DISTRIBUTION SYSTEM C.I. PDS 18 S/N FM01

STEP n°	TEST SEQUENCE	EXPECTED VALUE	MEASURED VALUE	REMARKS
3A-3-A.20	Generate a short circuit on the passive load keyboards: From O_1: TPD0 to O_8: CAB_N	OK	OK	
3A-3-A.21	Read on display the voltage on this ESEM 3-A loads: O_1: TPD0 O_2: TPD4 O_3: ER0_N O_4: MPD_R O_5: SPD3_R O_6: UGPD_R O_7: SPD2_R O_8: CAB_N	0,00V<V<1,00V 0,00V<V<1,00V 0,00V<V<1,00V 0,00V<V<1,00V 0,00V<V<1,00V 0,00V<V<1,00V 0,00V<V<1,00V 0,00V<V<1,00V	0,00 V (ALL)	
3A-3-A.22	Click on Read All command in Digital Readout column	OK	OK	
3A-3-A.23	Verify the status of the following flags: BOARD STATUS OVT Alarm From O_1 CMD: TPD0 to O_8 CMD: CAB_N From O_1 Status: TPD0 to O_8 Status: CAB_N	NOK OK ON OFF	NOK OK ON OFF	
3A-3-A.24	Set the CAN BUS board address to 30	30	30	
3A-3-A.25	Select "CAN BUS I/F Side" to A	A	A	
3A-3-A.26	Click on Read All command in Digital Readout column	OK	OK	
3A-3-A.27	Verify the status of the following flags: BOARD STATUS OVT Alarm From O_1 CMD: TPD0 to O_8 CMD: CAB_N From O_1 Status: TPD0 to O_8 Status: CAB_N	NOK OK ON OFF	NOK OK ON OFF	
3A-3-A.28	Set OFF in the window All Outlets ON/OFF and push the relative "W" command	OK	OK	
3A-3-A.29	Set ON in the window All Outlets ON/OFF and push the relative "W" command	OK	OK	
3A-3-A.30	Click on Read All command in Digital Readout column	OK	OK	
3A-3-A.31	Verify the status of the following flags: BOARD STATUS OVT Alarm From O_1 CMD: TPD0 to O_8 CMD: CAB_N From O_1 Status: TPD0 to O_8 Status: CAB_N	OK OK ON ON	OK OK ON ON	
3A-3-A.32	Set the CAN BUS board address to 31	31	31	
3A-3-A.33	Select "CAN BUS I/F Side" to B	B	B	
3A-3-A.34	Click on Read All command in Digital Readout column	OK	OK	
3A-3-A.35	Verify the status of the following flags: BOARD STATUS	OK	OK	

DATE:	TEST CONDUCTOR	QA	CUSTOMER
24/07/2009	Albertin A.	Francini E.	

Questo documento contiene informazioni di proprietà di CARLO GAVAZZI SPACE SpA. Tutti i diritti sono riservati.

All information contained in this document are property of CARLO GAVAZZI SPACE SpA. All right reserved.

UUT DATA : Model PFM Item AMS02 POWER DISTRIBUTION SYSTEM C.I. PDS 18 S/N FM01

STEP n°	TEST SEQUENCE	EXPECTED VALUE	MEASURED VALUE	REMARKS
	OVT Alarm From O_1 CMD: TPD0 to O_8 CMD: CAB_N From O_1 Status: TPD0 to O_8 Status: CAB_N	OK ON ON	OK ON ON	
3A-3-A.36	Using board telemetries set to 2A current absorption all the outlets: From O_1: TPD0 to O_8: CAB_N	OK	OK	Set active loads to constant current mode. Set current on display with 100mA above the desired value with the exception of out8 that is correct.
3A-3-A.37	Push on Read All button in Analog Readout column	OK	OK	
3A-3-A.38	Verify the telemetries: O_1 Current: TPD0 O_2 Current: TPD4 O_3 Current: ER0_N O_4 Current: MPD_R O_5 Current: SPD3_R O_6 Current: UGPD_R O_7 Current: SPD2_R O_8 Current: CAB_N Temperature Analog Ref. 3.0V	 2,000A±0,225A 2,000A±0,225A 2,000A±0,225A 2,000A±0,225A 2,000A±0,225A 2,000A±0,225A 2,000A±0,225A 2,00A±0,45A -40°C<T<80C° 3,000V±250mV	 2,10 A 2,10 A 2,11 A 2,09 A 2,12 A 2,18 A 2,11 A 2,12 A 30,0 °C 2,98 V	
3A-3-A.39	Set the CAN BUS board address to 30	30	30	
3A-3-A.40	Select "CAN BUS I/F Side" to A	A	A	
3A-3-A.41	Push on Read All button in Analog Readout column	OK	OK	
3A-3-A.42	Verify the telemetries: O_1 Current: TPD0 O_2 Current: TPD4 O_3 Current: ER0_N O_4 Current: MPD_R O_5 Current: SPD3_R O_6 Current: UGPD_R O_7 Current: SPD2_R O_8 Current: CAB_N Temperature Analog Ref. 3.0V	 2,000A±0,225A 2,000A±0,225A 2,000A±0,225A 2,000A±0,225A 2,000A±0,225A 2,000A±0,225A 2,000A±0,225A 2,00A±0,45A -40°C<T<80C° 3,000V±250mV	 2,08 A 2,09 A 2,11 A 2,08 A 2,13 A 2,21 A 2,11 A 2,18 A 33°C 3,02 V	
3A-3-A.43	Set to 0A current absorption all the outlets: From O_1: TPD0 to O_8: CAB_N	OK	OK	
3A-3-A.44	Set OFF in the window All Outlets ON/OFF and push the relative "W" command	OK	OK	
3A-3-A.45	Click on Raed all to in Digital readout column	OK	OK	
3A-3-A.46	Verify from digital readout column that all outlets are OFF	OK	OK	

DATE:	TEST CONDUCTOR	QA	CUSTOMER
24/07/2009	Albertin A.	Francini E.	

Questo documento contiene informazioni di proprietà di CARLO GAVAZZI SPACE SpA. Tutti i diritti sono riservati.

All information contained in this document are property of CARLO GAVAZZI SPACE SpA. All right reserved.

UUT DATA :	Model	PFM	Item	AMS02 POWER DISTRIBUTION SYSTEM	C.I.	PDS 18	S/N	FM01

10.3.1.5.9 PB2-4 SIDE A

STEP n°	TEST SEQUENCE	EXPECTED VALUE	MEASURED VALUE	REMARKS
PB2-4-A.1	Connect AI_120V and AI_120V_RTN power supply signals	OK	OK	
PB2-4-A.2	Verify that all the cables of the section are connected	OK	OK	
PB2-4-A.3	Launch the PDS controller software	Program open	Program open	
PB2-4-A.4	Set to "FM" the window Model	OK	OK	
PB2-4-A.5	Select "PDS Side" to A	A	A	
PB2-4-A.6	Set the CAN BUS board address to 30	30	30	
PB2-4-A.7	Select JMDC = 0	0	0	
PB2-4-A.8	Select TX = A	A	A	
PB2-4-A.9	Select RX = A	A	A	
PB2-4-A.10	Select "CAN BUS I/F Side" to A	A	A	
PB2-4-A.11	Set input bus voltage to 120V	120V±1V	120,0 V	
PB2-4-A.12	Set input bus current limitation to ~~15A~~ 27,5A	27,5A ~~15A~~±1A	27,5 A	See PVS-02
PB2-4-A.13	Enable power supply output	enabled	enabled	
PB2-4-A.14	Verify that green led of "power switch box" is lighted	Green led ligthed	Green led ligthed	
PB2-4-A.15	Switch ON the "power switch "of "power switch box"	Switch ON	Switch ON	
PB2-4-A.16	Verify that red led of "power switch box" is lighted	Red led ligthed	Red led ligthed	
PB2-4-A.17	Take note of power supply output current	1,1A±0,5A	1,1 A	
PB2-4-A.18	Click on Run flash button	OK	OK	
PB2-4-A.19	Set the CAN BUS board address to 31	31	31	
PB2-4-A.20	Select "CAN BUS I/F Side" to B	B	B	
PB2-4-A.21	Click on Run flash button	OK	OK	
PB2-4-A.22	Set the CAN BUS board address to 30	31	31	
PB2-4-A.23	Select "CAN BUS I/F Side" to A	A	A	
PB2-4-A.24	Click on PB2-4 button	OK	OK	This board is default ON
PB2-4-A.25	Set Digital I/F Test logic value = 1 in "Commanding" column	1	1	Button located on left side of software window
PB2-4-A.26	Click on letter "W" on the right of the "1" value	OK	OK	
PB2-4-A.27	Click on the command READ ALL under the column Digital Readout	OK	OK	
PB2-4-A.28	Verify that in the column Digital Readout under the voice Digital I/F Test appears "1"	1	1	
PB2-4-A.29	Set Digital I/F Test logic value = 0 in "Commanding" column	0	0	
PB2-4-A.30	Click on letter "W" on the right of the "0" value	OK	OK	
PB2-4-A.31	Click on the command READ ALL under the column Digital Readout	OK	OK	
PB2-4-A.32	Verify that in the column Digital Readout under the voice Digital I/F Test appears "0"	0	0	
PB2-4-A.33	Click on the command READ ALL under the column Analog Readout	OK	OK	

DATE:	TEST CONDUCTOR	QA	CUSTOMER
26/07/2009	Albertin A.	Francini E.	

Questo documento contiene informazioni di proprietà di CARLO GAVAZZI SPACE SpA. Tutti i diritti sono riservati.

All information contained in this document are property of CARLO GAVAZZI SPACE SpA. All right reserved.

UUT DATA : Model PFM Item AMS02 POWER DISTRIBUTION SYSTEM C.I. PDS 18 S/N FM01

STEP n°	TEST SEQUENCE	EXPECTED VALUE	MEASURED VALUE	REMARKS
PB2-4-A.34	Verify the status of the following flags: BOARD STATUS OVT ALARM Input OVC Alarm DCDC ON/OFF 27V UV 29V Trip DCDC OFF/ON CMD	 OK OK OK ON OK OK ON	 OK OK OK ON OK OK ON	
PB2-4-A.35	Click on the command READ ALL under the column Analog Readout	OK	OK	
PB2-4-A.36	Verify the value of the following telemetries: Temperature Analog Ref. 2.0V	 N.A. ~~-40°C<T<80C°~~ N.A. ~~2,000V±150mV~~	 N.A. N.A.	See PVS-05
PB2-4-A.37	Read on display the voltage on ESEM 3A-4 out 1 (Check that load is not connected)	28,00V±1,00V	28,17 V	
PB2-4-A.38	Verify the value of the following telemetry: Output Voltage	V1±1.092V	28,08 V	
PB2-4-A.39	Set OFF on DCDC ON /OFF command window and send the command	OK	OK	
PB2-4-A.40	Click on the command READ ALL under the column Digital Readout	OK	OK	
PB2-4-A.41	Verify the status of the following flags: BOARD STATUS OVT ALARM Input OVC Alarm DCDC ON/OFF 27V UNV 29V Trip DCDC OFF/ON CMD	 OK OK OK OFF OK OK OFF	 OK OK OK OFF OK OK OFF	
PB2-4-A.42	Click on the command READ ALL under the column Analog Readout	OK		
PB2-4-A.43	Verify the value of the following telemetries: Temperature Analog Ref. 2.0V	 -40°C<T<80C° 2,000V±150mV	 36,77 °C 2,05 V	
PB2-4-A.44	Verify the following analog monitor: Output Voltage	0,00V±1.092V	0,02 V	
PB2-4-A.45	Read on display the voltage on ESEM 3A-4 out 1 (Check that load is not connected)	0,00V±0,10V	-0,06 V	
PB2-4-A.46	Set the CAN BUS board address to 30	30	30	
PB2-4-A.47	Select "CAN BUS I/F Side" to A	A	A	
PB2-4-A.48	Click on the command READ ALL under the column Digital Readout	OK	OK	
PB2-4-A.49	Verify the status of the following flags: BOARD STATUS OVT ALARM	 OK OK	 OK OK	

DATE:	TEST CONDUCTOR	QA	CUSTOMER
26 /07/2009	Albertin A.	Francini E.	

Questo documento contiene informazioni di proprietà di CARLO GAVAZZI SPACE SpA. Tutti i diritti sono riservati.

All information contained in this document are property of CARLO GAVAZZI SPACE SpA. All right reserved.

UUT DATA : Model PFM Item AMS02 POWER DISTRIBUTION SYSTEM C.I. PDS 18 S/N FM01

STEP n°	TEST SEQUENCE	EXPECTED VALUE	MEASURED VALUE	REMARKS
	Input OVC Alarm	OK	OK	
	DCDC ON/OFF	OFF	OFF	
	27V UNV	OK	OK	
	29V Trip	OK	OK	
	DCDC OFF/ON CMD	OFF	OFF	
PB2-4-A.50	Set ON on DCDC OFF/ON command window and send the command	OK	OK	
PB2-4-A.51	Click on the command READ ALL under the column Digital Readout	OK	OK	
PB2-4-A.52	Verify the status of the following flags:			
	BOARD STATUS	OK	OK	
	OVT ALARM	OK	OK	
	Input OVC Alarm	OK	OK	
	DCDC ON/OFF	ON	ON	
	27V UNV	OK	OK	
	29V Trip	OK	OK	
	DCDC OFF/ON CMD	ON	ON	
PB2-4-A.53	Read on display the voltage on ESEM 3A-4 out 1 (Check that load is not connected)	28,00V±1,00V	28,1 V	
PB2-4-A.54	Set the CAN BUS board address to 31	31	31	
PB2-4-A.55	Select "CAN BUS I/F Side" to B	B	B	
PB2-4-A.56	Click on the command READ ALL under the column Digital Readout	OK	OK	
PB2-4-A.57	Verify the status of the following flags:			
	BOARD STATUS	OK	OK	
	OVT ALARM	OK	OK	
	Input OVC Alarm	OK	OK	
	DCDC ON/OFF	ON	ON	
	27V UNV	OK	OK	
	29V Trip	OK	OK	
	DCDC OFF/ON CMD	ON	ON	

DATE:	TEST CONDUCTOR	QA	CUSTOMER
24/07/2009	Albertin A.	Francini E.	

Questo documento contiene informazioni di proprietà di CARLO GAVAZZI SPACE SpA. Tutti i diritti sono riservati.

All information contained in this document are property of CARLO GAVAZZI SPACE SpA. All right reserved.

UUT DATA :	Model	PFM	Item	AMS02 POWER DISTRIBUTION SYSTEM	C.I.	PDS 18	S/N	FM01

ESEM 3A-4 SIDE A

STEP n°	TEST SEQUENCE	EXPECTED VALUE	MEASURED VALUE	REMARKS
3A-4-A.1	Click on ESEM 3A-4 button	OK	OK	Button located on left side of software window
3A-4-A.2	Connect to active loads outlet 1, 2, 3, 4, 5, 6, 7 and 8.	OK	OK	
3A-4-A.3	Verify that loads are set to 0A current absorption	OK	OK	
3A-4-A.4	Set Digital I/F Test logic value = 1 in "Commanding" column	1	1	
3A-4-A.5	Click on letter "W" on the right of the "1" value	OK	OK	
3A-4-A.6	Click on the command READ ALL under the column Digital Readout	OK	OK	
3A-4-A.7	Verify that in the column Digital Readout under the voice Digital I/F Test appears "1"	1	1	
3A-4-A.8	Set Digital I/F Test logic value = 0 in "Commanding" column	0	0	
3A-4-A.9	Click on letter "W" on the right of the "0" value	OK	OK	
3A-4-A.10	Click on the command READ ALL under the column Digital Readout	OK	OK	
3A-4-A.11	Verify that in the column Digital Readout under the voice Digital I/F Test appears "0"	0	0	
3A-4-A.12	Set ON in the window All Outlets ON/OFF and push the relative "W" command	OK	OK	
3A-4-A.13	Read on display the voltage on this ESEM 3-A loads: O_1: JPD_R O_2: ER1_R O_3: SPD1_R O_4: ER0_R O_5: UPD0 O_6: SPD0_N O_7: TPD5 O_8: TTPD_N	 28,00V±1,00V 28,00V±1,00V 28,00V±1,00V 28,00V±1,00V 28,00V±1,00V 28,00V±1,00V 28,00V±1,00V 28,00V±1,00V	28,0 V (ALL)	
3A-4-A.14	Click on Read All command in Digital Readout column	OK	OK	
3A-4-A.15	Verify the status of the following flags: BOARD STATUS OVT Alarm From O_1 CMD: JPD_R to O_8 CMD: TTPD_N From O_1 Status: JPD_R to O_8 Status: TTPD_N	 OK OK ON ON	 OK OK ON ON	
3A-4-A.16	Set the CAN BUS board address to 31	31	31	
3A-4-A.17	Select "CAN BUS I/F Side" to B	B	B	
3A-4-A.18	Click on Read All command in Digital Readout column	OK	OK	
3A-4-A.19	Verify the status of the following flags: BOARD STATUS OVT Alarm From O_1 CMD: JPD_R to O_8 CMD: TTPD_N From O_1 Status: JPD_R to O_8 Status: TTPD_N	 OK OK ON ON	 OK OK ON ON	

DATE:	TEST CONDUCTOR	QA	CUSTOMER
27/07/2009	Albertin A.	Francini E.	

Questo documento contiene informazioni di proprietà di CARLO GAVAZZI SPACE SpA. Tutti i diritti sono riservati.

All information contained in this document are property of CARLO GAVAZZI SPACE SpA. All right reserved.

UUT DATA : Model PFM Item AMS02 POWER DISTRIBUTION SYSTEM C.I. PDS 18 S/N FM01

STEP n°	TEST SEQUENCE	EXPECTED VALUE	MEASURED VALUE	REMARKS
3A-4-A.20	Generate a short circuit on the passive load keyboards: From O_1: JPD_R to O_8: TTPD_N	OK	OK	
3A-4-A.21	Read on display the voltage on this ESEM 3-A loads: O_1: TPD0 O_2: TPD4 O_3: ER0_N O_4: MPD_R O_5: SPD3_R O_6: UGPD_R O_7: SPD2_R O_8: CAB_N	 0,00V<V<1,00V 0,00V<V<1,00V 0,00V<V<1,00V 0,00V<V<1,00V 0,00V<V<1,00V 0,00V<V<1,00V 0,00V<V<1,00V 0,00V<V<1,00V	 0,00 V (ALL)	
3A-4-A.22	Click on Read All command in Digital Readout column	OK	OK	
3A-4-A.23	Verify the status of the following flags: BOARD STATUS OVT Alarm From O_1 CMD: JPD_R to O_8 CMD: TTPD_N From O_1 Status: JPD_R to O_8 Status: TTPD_N	 **NOK** OK ON **OFF**	 **NOK** OK ON **OFF**	
3A-4-A.24	Set the CAN BUS board address to 30	30	30	
3A-4-A.25	Select "CAN BUS I/F Side" to A	A	A	
3A-4-A.26	Click on Read All command in Digital Readout column	OK	OK	
3A-4-A.27	Verify the status of the following flags: BOARD STATUS OVT Alarm From O_1 CMD: JPD_R to O_8 CMD: TTPD_N From O_1 Status: JPD_R to O_8 Status: TTPD_N	 **NOK** OK ON **OFF**	 **NOK** OK ON **OFF**	
3A-4-A.28	Set OFF in the window All Outlets ON/OFF and push the relative "W" command	OK	OK	
3A-4-A.29	Set ON in the window All Outlets ON/OFF and push the relative "W" command	OK	OK	
3A-4-A.30	Click on Read All command in Digital Readout column	OK	OK	
3A-4-A.31	Verify the status of the following flags: BOARD STATUS OVT Alarm From O_1 CMD: JPD_R to O_8 CMD: TTPD_N From O_1 Status: JPD_R to O_8 Status: TTPD_N	 **OK** OK ON **ON**	 **OK** OK ON **ON**	
3A-4-A.32	Set the CAN BUS board address to 31	31	31	
3A-4-A.33	Select "CAN BUS I/F Side" to B	B	B	
3A-4-A.34	Click on Read All command in Digital Readout column	OK	OK	
3A-4-A.35	Verify the status of the following flags: BOARD STATUS	**OK**	**OK**	

DATE:	TEST CONDUCTOR	QA	CUSTOMER
24/07/2009	Albertin A.	Francini E.	

Questo documento contiene informazioni di proprietà di CARLO GAVAZZI SPACE SpA. Tutti i diritti sono riservati.

All information contained in this document are property of CARLO GAVAZZI SPACE SpA. All right reserved.

UUT DATA : Model PFM Item AMS02 POWER DISTRIBUTION SYSTEM C.I. PDS 18 S/N FM01

STEP n°	TEST SEQUENCE	EXPECTED VALUE	MEASURED VALUE	REMARKS
	OVT Alarm From O_1 CMD: JPD_R to O_8 CMD: TTPD_N From O_1 Status: JPD_R to O_8 Status: TTPD_N	OK ON ON	OK ON ON	
3A-4-A.36	Using board telemetries set to 2A current absorption all the outlets: From O_1: JPD_R to O_8: TTPD_N	OK	OK	Set active loads to constant current mode. Set current on display with 100mA above the desired value with the exception of out8 that is correct.
3A-4-A.37	Push on Read All button in Analog Readout column	OK	OK	
3A-4-A.38	Verify the telemetries: O_1 Current: JPD_R O_2 Current: ER1_R O_3 Current: SPD1_R O_4 Current: ER0_R O_5 Current: UPD0 O_6 Current: SPD0_N O_7 Current: TPD5 O_8 Current: TTPD_N Temperature Analog Ref. 3.0VTemperature Analog Ref. 3.0V	 2,000A±0,225A 2,000A±0,225A 2,000A±0,225A 2,000A±0,225A 2,000A±0,225A 2,000A±0,225A 2,000A±0,225A 2,00A±0,45A -40°C<T<80C° 3,000V±250mV	 2,05 A 2,08 A 2,10 A 2,06 A 2,10 A 2,11 A 2,11 A 2,15 A 31,0 °C 2,93 V	
3A-4-A.39	Set the CAN BUS board address to 30	30	30	
3A-4-A.40	Select "CAN BUS I/F Side" to A	A	A	
3A-4-A.41	Push on Read All button in Analog Readout column	OK	OK	
3A-4-A.42	Verify the current telemetries: O_1 Current: JPD_R O_2 Current: ER1_R O_3 Current: SPD1_R O_4 Current: ER0_R O_5 Current: UPD0 O_6 Current: SPD0_N O_7 Current: TPD5 O_8 Current: TTPD_N Temperature Analog Ref. 3.0V	 2,000A±0,225A 2,000A±0,225A 2,000A±0,225A 2,000A±0,225A 2,000A±0,225A 2,000A±0,225A 2,000A±0,225A 2,00A±0,45A -40°C<T<80C° 3,000V±250mV	2,03 A 2,08 A 2,10 A 2,09 A 2,15 A 2,10 A 2,11 A 2,13 A 32,0 °C 3,04 V	
3A-4-A.43	Set to 0A current absorption all the outlets: From O_1: JPD_R to O_8: TTPD_N	OK	OK	
3A-4-A.44	Set OFF in the window All Outlets ON/OFF and push the relative "W" command	OK	OK	
3A-4-A.45	Click on Raed all to in Digital readout column	OK	OK	

DATE:	TEST CONDUCTOR	QA	CUSTOMER
24/07/2009	Albertin A.	Francini E.	

Questo documento contiene informazioni di proprietà di CARLO GAVAZZI SPACE SpA. Tutti i diritti sono riservati.

All information contained in this document are property of CARLO GAVAZZI SPACE SpA. All right reserved.

UUT DATA : Model PFM Item AMS02 POWER DISTRIBUTION SYSTEM C.I. PDS 18 S/N FM01

STEP n°	TEST SEQUENCE	EXPECTED VALUE	MEASURED VALUE	REMARKS
3A-4-A.46	Verify from digital readout column that all outlets are OFF	OK	OK	
3A-4-A.47	Switch OFF the "power switch "of "power switch box"	OFF	OFF	See PVS-06

Questo documento contiene informazioni di proprietà di CARLO GAVAZZI SPACE SpA. Tutti i diritti sono riservati.

All information contained in this document are property of CARLO GAVAZZI SPACE SpA. All right reserved.

STEP n°	TEST SEQUENCE	EXPECTED VALUE	MEASURED VALUE	REMARKS

10.3.1.5.10 ESEM 3-B SIDE A

3B-A.1	Connect all the loads. The following column resumes the currents (with Main bus equal to 120V): OUTLET / CURRENT [A] SET 1 / 1,200±100mA 2 / 3,200±100mA 3 / 1,200±100mA 4 / 1,200±100mA 5 / 2,400±100mA 6 / 1,200±100mA 7 / 1,200±100mA 8 / 1,200±100mA 9 / 1,200±100mA 10 / 1,200±100mA 11 / 1,200±100mA 12 / 3,520±100mA	OK	OK	There is no need to check the current absorption of the loads. CCS load not connected
3B-A.2	Set all the loads of the other boards to 0A	OK	OK	
3B-A.3	Set power supply voltage to 120V	120V ± 0.2V	120,0 V	
3B-A.4	Set power supply current limitation to 27.5A	27.5A±0.5A	27,5 A	
3B-A.5	Switch ON the "power switch "of "power switch box"	OK	OK	
3B-A.6	Take note of input current	7,9A±0,5A	7,75 A	
3B-A.7	Select PDS controller software	program open	program open	
3B-A.8	Set the CAN BUS board address to 30	30	30	
3B-A.9	Select JMDC = 0	0	0	
3B-A.10	Select TX = A	A	A	
3B-A.11	Select RX = A	A	A	
3B-A.12	Select "CAN BUS I/F Side" to A	A	A	
3B-A.13	Select "PDS Side" to A	A	A	
3B-A.14	Click on Run flash command	OK	OK	
3B-A.15	Click on ESEM3-B button	OK	OK	Button located on left side of PDS controller software window
3B-A.16	Set Digital I/F Test logic value = 1 in "Commanding" column	1	1	
3B-A.17	Click on letter "W" on the right of the "1" value	OK	OK	

DATE:	TEST CONDUCTOR	QA	CUSTOMER
24 /07/2009	Albertin A.	Francini E.	

Questo documento contiene informazioni di proprietà di CARLO GAVAZZI SPACE SpA. Tutti i diritti sono riservati.

All information contained in this document are property of CARLO GAVAZZI SPACE SpA. All right reserved.

UUT DATA : Model PFM Item AMS02 POWER DISTRIBUTION SYSTEM C.I. PDS 18 S/N FM01

STEP n°	TEST SEQUENCE	EXPECTED VALUE	MEASURED VALUE	REMARKS
3B-A.18	Click on the command READ ALL under the column Digital Readout	OK	OK	
3B-A.19	Verify that in the column Digital Readout under the voice Digital I/F Test appears "1"	1	1	
3B-A.20	Set Digital I/F Test logic value = 0 in "Commanding" column	0	0	
3B-A.21	Click on letter "W" on the right of the "0" value	OK	OK	
3B-A.22	Click on the command READ ALL under the column Digital Readout	OK	OK	
3B-A.23	Verify that in the column Digital Readout under the voice Digital I/F Test appears "0"	0	0	
3B-A.24	Verify the status of the following flags: BOARD STATUS OVT Alarm O__1 CMD: AH_OUT1 O__2 CMD: AH_OUT2 O__3 CMD: AH_OUT3 O__4 CMD: AH_OUT4 O__5 CMD: AH_OUT5 O__6 CMD: AH_OUT6 O__7 CMD: AH_OUT7 O__8 CMD: AH_OUT8 O__9 CMD: AH_OUT9 O_10 CMD: AH_OUT10 O_11 CMD: AH_OUT11 O_12 CMD: AO_CCEB O__1 Status: AH_OUT1 O__2 Status: AH_OUT2 O__3 Status: AH_OUT3 O__4 Status: AH_OUT4 O__5 Status : AH_OUT5 O__6 Status: AH_OUT6 O__7 Status: AH_OUT7 O__8 Status: AH_OUT8 O__9 Status: AH_OUT9 O_10 Status: AH_OUT10 O_11 Status: AH_OUT11 O_12 Status: AO_CCEB O_12 Trip: AO_CCEB	OK OK ON ON ON ON OFF OFF ON OFF OFF OFF OFF OFF OFF ON ON ON OFF OFF ON OFF OFF OFF OFF OFF OFF OK	OK OK ON ON ON OFF OFF ON OFF OFF OFF OFF OFF OFF ON ON ON OFF OFF ON OFF OFF OFF OFF OFF OFF OK	
3B-A.25	Push on Read All button in Analog Readout column	OK	OK	
3B-A.26	Take note of the following values in "Analog readout" column: Temperature	-40°C<T<80C°	30,0 °C	

DATE:	TEST CONDUCTOR	QA	CUSTOMER
24/07/2009	Albertin A.	Francini E.	

Questo documento contiene informazioni di proprietà di CARLO GAVAZZI SPACE SpA. Tutti i diritti sono riservati.

All information contained in this document are property of CARLO GAVAZZI SPACE SpA. All right reserved.

UUT DATA : Model PFM Item AMS02 POWER DISTRIBUTION SYSTEM C.I. PDS 18 S/N FM01

STEP n°	TEST SEQUENCE	EXPECTED VALUE	MEASURED VALUE	REMARKS
	O_12 Current: AO_CCEB Analog Ref. 2.5V	0,00A±0,45A 2,500V±150mV	0,11 A 2,50 V	
3B-A.27	Set the CAN BUS board address to 31	31	31	
3B-A.28	Select "CAN BUS I/F Side" to B	B	B	
3B-A.29	Click on Run flash button	OK	OK	
3B-A.30	Click on Read All command in Digital Readout column	OK	OK	
3B-A.31	Verify the status of the following flags:			
	BOARD STATUS	OK	OK	
	OVT Alarm	OK	OK	
	O__1 CMD: AH_OUT1	ON	ON	
	O__2 CMD: AH_OUT2	ON	ON	
	O__3 CMD: AH_OUT3	ON	ON	
	O__4 CMD: AH_OUT4	OFF	OFF	
	O__5 CMD: AH_OUT5	OFF	OFF	
	O__6 CMD: AH_OUT6	ON	ON	
	O__7 CMD: AH_OUT7	OFF	OFF	
	O__8 CMD: AH_OUT8	OFF	OFF	
	O__9 CMD: AH_OUT9	OFF	OFF	
	O_10 CMD: AH_OUT10	OFF	OFF	
	O_11 CMD: AH_OUT11	OFF	OFF	
	O_12 CMD: AO_CCEB	OFF	OFF	
	O__1 Status: AH_OUT1	ON	ON	
	O__2 Status: AH_OUT2	ON	ON	
	O__3 Status: AH_OUT3	ON	ON	
	O__4 Status: AH_OUT4	OFF	OFF	
	O__5 Status : AH_OUT5	OFF	OFF	
	O__6 Status: AH_OUT6	ON	ON	
	O__7 Status: AH_OUT7	OFF	OFF	
	O__8 Status: AH_OUT8	OFF	OFF	
	O__9 Status: AH_OUT9	OFF	OFF	
	O_10 Status: AH_OUT10	OFF	OFF	
	O_11 Status: AH_OUT11	OFF	OFF	
	O_12 Status: AO_CCEB	OFF	OFF	
	O_12 Trip: AO_CCEB	OK	OK	
3B-A.32	Push on Read All button in Analog Readout column	OK	OK	
3B-A.33	Take note of the following values in "Analog readout" column: Temperature O_12 Current: AO_CCEB	 -40°C<T<80C° 0,00A±0,45A	 30,0 °C 0,12 A	

DATE:	TEST CONDUCTOR	QA	CUSTOMER
26 /07/2009	Albertin A.	Francini E.	

Questo documento contiene informazioni di proprietà di CARLO GAVAZZI SPACE SpA. Tutti i diritti sono riservati.

All information contained in this document are property of CARLO GAVAZZI SPACE SpA. All right reserved.

UUT DATA : Model PFM Item AMS02 POWER DISTRIBUTION SYSTEM C.I. PDS 18 S/N FM01

STEP n°	TEST SEQUENCE	EXPECTED VALUE	MEASURED VALUE	REMARKS
	Analog Ref. 2.5V	2,500V±150mV	2,49 V	
3B-A.34	Set OFF in the window All Outlets ON/OFF and push the relative "W" command	OK	OK	
3B-A.35	Click on the command READ ALL under the column Digital Readout	OK	OK	
3B-A.36	Verify the status of the following flags: BOARD STATUS OVT Alarm From O__1 CMD: AH_OUT1 to O_11 CMD: AH_OUT11 O_12 CMD: AO_CCEB From O__1 Status: AH_OUT1 to O_11 Status: AH_OUT11 O_12 Status: AO_CCEB O_12 Trip: AO_CCEB	 OK OK OFF OFF OFF OFF OK	 OK OK OFF OFF OFF OFF OK	
3B-A.37	Set the CAN BUS board address to 30	30	30	
3B-A.38	Select "CAN BUS I/F Side" to A	A	A	
3B-A.39	Click on the command READ ALL under the column Digital Readout	OK	OK	
3B-A.40	Verify the status of the following flags: BOARD STATUS OVT Alarm From O__1 CMD: AH_OUT1 to O_11 CMD: AH_OUT11 O_12 CMD: AO_CCEB From O__1 Status: AH_OUT1 to O_11 Status: AH_OUT11 O_12 Status: AO_CCEB O_12 Trip: AO_CCEB	 OK OK OFF OFF OFF OFF OK	 OK OK OFF OFF OFF OFF OK	
3B-A.41	Verify with a multimeter the voltage of the outlets: AH_OUT1 AH_OUT2 AH_OUT3 AH_OUT4 AH_OUT5 AH_OUT6 AH_OUT7 AH_OUT8 AH_OUT9 AH_OUT10 AH_OUT11 AO_CCEB	 V<5,00V V<5,00V V<5,00V V<5,00V V<5,00V V<5,00V V<5,00V V<5,00V V<5,00V V<5,00V V<5,00V V<5,00V	 0,00 V (ALL)	
3B-A.42	Set ON in the window All Outlets ON/OFF and push the relative "W" command	OK	OK	
3B-A.43	Take note of input current	21A±1A	20,02 A	
3B-A.44	Click on the command READ ALL under the column Digital Readout	OK	OK	

DATE:	TEST CONDUCTOR	QA	CUSTOMER
26/07/2009	Albertin A.	Francini E.	

Questo documento contiene informazioni di proprietà di CARLO GAVAZZI SPACE SpA. Tutti i diritti sono riservati.

All information contained in this document are property of CARLO GAVAZZI SPACE SpA. All right reserved.

UUT DATA : Model PFM Item AMS02 POWER DISTRIBUTION SYSTEM C.I. PDS 18 S/N FM01

STEP n°	TEST SEQUENCE	EXPECTED VALUE	MEASURED VALUE	REMARKS
3B-A.45	Verify the status of the following flags: BOARD STATUS OVT Alarm From O__1 CMD: AH_OUT1 to O_11 CMD: AH_OUT11 O_12 CMD: AO_CCEB From O__1 Status: AH_OUT1 to O_11 Status: AH_OUT11 O_12 Status: AO_CCEB O_12 Trip: AO_CCEB	 OK OK ON ON ON ON OK	 OK OK ON ON ON ON OK	
3B-A.46	Set the CAN BUS board address to 31	31	31	
3B-A.47	Select "CAN BUS I/F Side" to B	B	B	
3B-A.48	Click on the command READ ALL under the column Digital Readout	OK	OK	
3B-A.49	Verify the status of the following flags: BOARD STATUS OVT Alarm From O__1 CMD: AH_OUT1 to O_11 CMD: AH_OUT11 O_12 CMD: AO_CCEB From O__1 Status: AH_OUT1 to O_11 Status: AH_OUT11 O_12 Status: AO_CCEB O_12 Trip: AO_CCEB	 OK OK ON ON ON ON OK	 OK OK ON ON ON ON OK	
3B-A.50	Set the CAN BUS board address to 30	30	30	
3B-A.51	Select "CAN BUS I/F Side" to A	A	A	
3B-A.52	Measure the PDS input voltage: connect a multimeter between PIN "bypass thermal interlock" (positive) and "PRI_GND"(negative) on side A of the J300 test box	117,50V±1,00V	117,4 V	See PVS-07
3B-A.53	Verify with a multimeter the voltage of the outlets: AH_OUT1 AH_OUT2 AH_OUT3 AH_OUT4 AH_OUT5 AH_OUT6 AH_OUT7 AH_OUT8 AH_OUT9 AH_OUT10 AH_OUT11 AO_CCEB	 115V ~~117V~~<V<120,00V 115V ~~117V~~<V<120,00V 115V ~~117V~~<V<120,00V 115V ~~117V~~<V<120,00V 115V ~~117V~~<V<120,00V 115V ~~117V~~<V<120,00V 115V ~~117V~~<V<120,00V 115V ~~117V~~<V<120,00V 115V ~~117V~~<V<120,00V 115V ~~117V~~<V<120,00V 115V ~~117V~~<V<120,00V 115V ~~117V~~<V<120,00V	 115,6 V 115,7 V 115,6 V 115,6 V 115,6 V 115,6 V 115,6 V 115,6 V 115,6 V 115,6 V 115,6 V 116,4 V	Measurement on the load See PVS-09
3B-A.54	Set OFF the command All Outlets ON/OFF in commanding column and click on relative "W"	OK	OK	
3B-A.55	Connect the short circuit simulator in parallel to outlet 12	OK	OK	

DATE:	TEST CONDUCTOR	QA	CUSTOMER
26/07/2009	Albertin A.	Francini E.	

Questo documento contiene informazioni di proprietà di CARLO GAVAZZI SPACE SpA. Tutti i diritti sono riservati.

All information contained in this document are property of CARLO GAVAZZI SPACE SpA. All right reserved.

UUT DATA : Model PFM Item AMS02 POWER DISTRIBUTION SYSTEM C.I. PDS 18 S/N FM01

STEP n°	TEST SEQUENCE	EXPECTED VALUE	MEASURED VALUE	REMARKS
3B-A.56	Set the short circuit simulator to 10ms short circuit duration	OK	OK	
3B-A.57	Set "ON" in the window "O_12:AO_CCEB" and push the relative "W" command	OK	OK	
3B-A.58	Create the short circuit	OK	OK	
3B-A.59	Click on the command READ ALL under the column Digital Readout	OK	OK	
3B-A.60	Verify the status of the following flags: BOARD STATUS OVT Alarm From O__1 Status: AH_OUT1 to O_11 Status: AH_OUT11 O_12 Status: AO_CCEB O_12 Trip: AO_CCEB	NOK OK ON ON OFF TRIP	NOK OK ON ON OFF TRIP	
3B-A.61	Set the CAN BUS board address to 31	31	31	
3B-A.62	Select "CAN BUS I/F Side" to B	B	B	
3B-A.63	Click on the command READ ALL under the column Digital Readout	OK	OK	
3B-A.64	Verify the status of the following flags: BOARD STATUS OVT Alarm From O__1 Status: AH_OUT1 to O_11 Status: AH_OUT11 O_12 Status: AO_CCEB O_12 Trip: AO_CCEB	NOK OK ON ON OFF TRIP	NOK OK ON ON OFF TRIP	
3B-A.65	Set the CAN BUS board address to 30	30	30	
3B-A.66	Select "CAN BUS I/F Side" to A	A	A	
3B-A.67	Disconnect short circuit simulator	OK	OK	
3B-A.68	Set OFF the command O_12:AO_CCEB in commanding column and click on relative "W"	OK	OK	Protection reset
3B-A.69	Set ON the command O_12:AO_CCEB in commanding column and click on relative "W"	OK	OK	
3B-A.70	Click on the command READ ALL under the column Digital Readout	OK	OK	
3B-A.71	Verify the status of the following flags: BOARD STATUS O_12 Status: AO_CCEB O_12 Trip: AO_CCEB	OK ON OK	OK ON OK	
3B-A.72	Set the CAN BUS board address to 31	31	31	
3B-A.73	Select "CAN BUS I/F Side" to B	B	B	
3B-A.74	Click on the command READ ALL under the column Digital Readout	OK	OK	
3B-A.75	Verify the status of the following flags: BOARD STATUS O_12 Status: AO_CCEB O_12 Trip: AO_CCEB	OK ON OK	OK ON OK	
3B-A.76	Set the CAN BUS board address to 30	30	30	

DATE:	TEST CONDUCTOR	QA	CUSTOMER
24 /07/2009	Albertin A.	Francini E.	

Questo documento contiene informazioni di proprietà di CARLO GAVAZZI SPACE SpA. Tutti i diritti sono riservati.

All information contained in this document are property of CARLO GAVAZZI SPACE SpA. All right reserved.

UUT DATA :	Model	PFM	Item	AMS02 POWER DISTRIBUTION SYSTEM	C.I.	PDS 18	S/N	FM01

STEP n°	TEST SEQUENCE	EXPECTED VALUE	MEASURED VALUE	REMARKS
3B-A.77	Select "CAN BUS I/F Side" to A	A	A	
3B-A.78	Set OFF the command All Outlets ON/OFF in commanding column and click on relative "W"	OK	OK	
3B-A.79	Switch OFF main power bus	OK	OK	
3B-A.80	Disconnect current probe	OK	OK	
3B-A.81	Switch OFF the "power switch "of "power switch box"	Switch OFF	Switch OFF	

DATE:	TEST CONDUCTOR	QA	CUSTOMER
24/07/2009	Albertin A.	Francini E.	

Questo documento contiene informazioni di proprietà di CARLO GAVAZZI SPACE SpA. Tutti i diritti sono riservati.

All information contained in this document are property of CARLO GAVAZZI SPACE SpA. All right reserved.

UUT DATA :	Model	PFM	Item	AMS02 POWER DISTRIBUTION SYSTEM	C.I.	PDS 18	S/N	FM01

10.3.1.5.10.1 CCS LOAD VERIFICATION

STEP n°	TEST SEQUENCE	EXPECTED VALUE	MEASURED VALUE	REMARKS
CCS.1	Connect AI_120V and AI_120V_RTN power supply signals	OK	OK	CCS load is connected only to A bus. During this test the unit is supplied from Main bus.
CCS.2	Set all the loads to 0A current absorption (external heaters included)	0A absorbtion set	OK	
CCS.3	Set power supply voltage to 120V	120V ± 0.2V	120,0 V	
CCS.4	Set power supply current limitation to 27.5A	27.5A±0.5A	27,5 A	
CCS.5	Insert an amperometer in serie to CCS load	OK	OK	
CCS.6	Switch ON the "power switch "of "power switch box"	OK	OK	
CCS.7	Take note of input current	1,1A±0,5A	1,1 A	
CCS.8	Select PDS controller software	program open	OPEN	
CCS.9	Set the CAN BUS board address to 30	30	30	
CCS.10	Select JMDC = 0	0	0	
CCS.11	Select TX = A	A	A	
CCS.12	Select RX = A	A	A	
CCS.13	Select "CAN BUS I/F Side" to A	A	A	
CCS.14	Select "PDS Side" to A	A	A	
CCS.15	Click on Run flash command	OK	OK	
CCS.16	Click on **ESEM3-B** icon	OK	OK	
CCS.17	Set OFF in All Outlets ON/OFF window and send the command	OFF	OFF	
CCS.18	Click on **ESEM3-A 1** icon	OK	OK	
CCS.19	Using the telemetry regulate the current of ESEM3-A 1 outlet 3	1,80A±100mA	1,82 A	Default ON load
CCS.20	Command ON the outlet 5 (UGPD_N)	ON	ON	
CCS.21	Using the telemetry regulate the current of ESEM3-A 1 outlet 5	1,20A ±100mA	1,20 A	
CCS.22	Click on **PB2-2** icon	OK	OK	
CCS.23	Set ON to DCDC OFF/ON command and send the command	ON	ON	
CCS.24	Click on **ESEM3-A-2** icon	OK	OK	
CCS.25	Command ON the outlet 5 (MPD_N)	1,80A ±100mA	1,84 A	
CCS.26	Command ON the outlet 8 (CAB_R)	0,70A±100mA	0,78 A	
CCS.27	Click on **PB2-3** icon	OK	OK	
CCS.28	Set ON to DCDC OFF/ON command and send the command	ON	ON	
CCS.29	Click on **ESEM3-A-3** icon	OK	OK	
CCS.30	Command ON the outlet 8 (O_8:CAB_N)	2,50A±100mA	2,58 A	
CCS.31	Click on **ESEM3-A-4** icon	OK	OK	
CCS.32	Command ON the outlet 1 (JPD_R)	1,80A ±100mA	1,82 A	
CCS.33	Take note of input current	3,70A±0,50A	3,85 A	

DATE:	TEST CONDUCTOR	QA	CUSTOMER
24 /07/2009	Albertin A.	Francini E.	

Questo documento contiene informazioni di proprietà di CARLO GAVAZZI SPACE SpA. Tutti i diritti sono riservati.

All information contained in this document are property of CARLO GAVAZZI SPACE SpA. All right reserved.

UUT DATA :	Model	PFM	Item	AMS02 POWER DISTRIBUTION SYSTEM	C.I.	PDS 18	S/N	FM01

STEP n°	TEST SEQUENCE	EXPECTED VALUE	MEASURED VALUE	REMARKS
CCS.34	Set ON the CCS load switch	ON	ON	
CCS.35	Take note of CCS current reading by amperometer	5,00A±0,50A	4,68 A	
CCS.36	Take note of input current from main bus	8,40A±0,50A	8,55 A	
CCS.37	Set OFF the CCS load switch	OFF	OFF	
CCS.38	Switch OFF the "power switch "of "power switch box"	Switch OFF	OFF	
CCS.39	Disconnect amperometer	OK	DISCONNECTED	

10.3.1.6 SIDE A TELEMETRY VERIFICATION

10.3.1.6.1 INPUT STAGE CURRENT MONITOR

IBUS-A.1	Connect all the ESEM3B loads. The following column resumes the currents (with Main bus equal to 120V):	OK	OK	There is no need to check the current absorption of the loads. CCS load not connected

OUTLET	CURRENT [A] SET
1	1,200±100mA
2	3,200±100mA
3	1,200±100mA
4	1,200±100mA
5	2,400±100mA
6	1,200±100mA
7	1,200±100mA
8	1,200±100mA
9	1,200±100mA
10	1,200±100mA
11	1,200±100mA
12	3,520±100mA

IBUS-A.2	Set all the loads of the other boards to 0A	OK	OK	
IBUS-A.3	Set power supply voltage to 120V	120V ± 0.2V	120,0 V	
IBUS-A.4	Set power supply current limitation to 27.5A	27.5A±0.5A	27,5 A	
IBUS-A.5	Switch ON the "power switch "of "power switch box"	OK	OK	
IBUS-A.6	Take note of input current	7,9A±0,5A	7,78 A	
IBUS-A.7	Select PDS controller software	program open	OPEN	
IBUS-A.8	Set the CAN BUS board address to 30	30	30	

DATE:	TEST CONDUCTOR	QA	CUSTOMER
26/07/2009	Albertin A.	Francini E.	

Questo documento contiene informazioni di proprietà di CARLO GAVAZZI SPACE SpA. Tutti i diritti sono riservati.
All information contained in this document are property of CARLO GAVAZZI SPACE SpA. All right reserved.

UUT DATA : Model PFM Item AMS02 POWER DISTRIBUTION SYSTEM C.I. PDS 18 S/N FM01

STEP n°	TEST SEQUENCE	EXPECTED VALUE	MEASURED VALUE	REMARKS
IBUS-A.9	Select JMDC = 0	0	0	
IBUS-A.10	Select TX = A	A	A	
IBUS-A.11	Select RX = A	A	A	
IBUS-A.12	Select "CAN BUS I/F Side" to A	A	A	
IBUS-A.13	Select "PDS Side" to A	A	A	
IBUS-A.14	Click on Run flash command	OK	OK	
IBUS-A.15	Set the CAN BUS board address to 31	31	31	
IBUS-A.16	Select "CAN BUS I/F Side" to B	B	B	
IBUS-A.17	Click on Run flash command	OK	OK	
IBUS-A.18	Set the CAN BUS board address to 30	30	30	
IBUS-A.19	Select "CAN BUS I/F Side" to A	A	A	
IBUS-A.20	Click on ESEM3-B button	OK	OK	Button located on left side of PDS controller software window
IBUS-A.21	Verify the status of the following flags:			
	BOARD STATUS	OK	OK	
	OVT Alarm	OK	OK	
	O__1 CMD: AH_OUT1	ON	ON	
	O__2 CMD: AH_OUT2	ON	ON	
	O__3 CMD: AH_OUT3	ON	ON	
	O__4 CMD: AH_OUT4	OFF	OFF	
	O__5 CMD: AH_OUT5	OFF	OFF	
	O__6 CMD: AH_OUT6	ON	ON	
	O__7 CMD: AH_OUT7	OFF	OFF	
	O__8 CMD: AH_OUT8	OFF	OFF	
	O__9 CMD: AH_OUT9	OFF	OFF	
	O_10 CMD: AH_OUT10	OFF	OFF	
	O_11 CMD: AH_OUT11	OFF	OFF	
	O_12 CMD: AO_CCEB	OFF	OFF	
	O__1 Status: AH_OUT1	ON	ON	
	O__2 Status: AH_OUT2	ON	ON	
	O__3 Status: AH_OUT3	ON	ON	
	O__4 Status: AH_OUT4	OFF	OFF	
	O__5 Status : AH_OUT5	OFF	OFF	
	O__6 Status: AH_OUT6	ON	ON	
	O__7 Status: AH_OUT7	OFF	OFF	
	O__8 Status: AH_OUT8	OFF	OFF	
	O__9 Status: AH_OUT9	OFF	OFF	
	O_10 Status: AH_OUT10	OFF	OFF	

DATE:	TEST CONDUCTOR	QA	CUSTOMER
26/07/2009	Albertin A.	Francini E.	

Questo documento contiene informazioni di proprietà di CARLO GAVAZZI SPACE SpA. Tutti i diritti sono riservati.

All information contained in this document are property of CARLO GAVAZZI SPACE SpA. All right reserved.

UUT DATA : Model PFM Item AMS02 POWER DISTRIBUTION SYSTEM C.I. PDS 18 S/N FM01

STEP n°	TEST SEQUENCE	EXPECTED VALUE	MEASURED VALUE	REMARKS
	O_11 Status: AH_OUT11 O_12 Status: AO_CCEB O_12 Trip: AO_CCEB	OFF OFF OK	OFF OFF OK	
IBUS-A.22	Push on Read All button in Analog Readout column	OK	OK	
IBUS-A.23	Take note of the following values in "Analog readout" column: Temperature O_12 Current: AO_CCEB Analog Ref. 2.5V	 -40°C<T<80C° 0,00A±0,45A 2,500V±150mV	 26,33 °C 0,11 A 2,5 V	
IBUS-A.24	Set OFF in the window All Outlets ON/OFF and push the relative "W" command	OK	OK	
IBUS-A.25	Take note of input current	1.1A±0.2A	1,1 A	
IBUS-A.26	Click on the command READ ALL under the column Digital Readout	OK	OK	
IBUS-A.27	Verify the status of the following flags: BOARD STATUS OVT Alarm From O__1 CMD: AH_OUT1 to O_11 CMD: AH_OUT11 O_12 CMD: AO_CCEB From O__1 Status: AH_OUT1 to O_11 Status: AH_OUT11 O_12 Status: AO_CCEB O_12 Trip: AO_CCEB	 OK OK OFF OFF OFF OFF OK	 OK OK OFF OFF OFF OFF OK	
IBUS-A.28	Fill the table at the end of paragraph	OK	OK	
IBUS-A.29	To switch ON the loads Set "ON" in the window "O_x: AH_OUTx" and push the relative "W" command	OK	OK	
IBUS-A.30	To read telemetries change from CAN BUS 30 to CAN BUS 31 using the following parameters: *CAN BUS 30 verification* Set the CAN BUS board address to 30 Select "CAN BUS I/F Side" to A *CAN BUS 31 verification* Set the CAN BUS board address to 31 Select "CAN BUS I/F Side" to B	OK	OK	
IBUS-A.31	Using the table at the end of paragraph verify that Iload-Itlm is lower than 7,6A	OK	OK	Verify that all telemetries are in line with tolerance 20% F.S. see RFW PDS-WV-CGS-002
IBUS-A.32	Set OFF in the window All Outlets ON/OFF and push the relative "W" command	OK	OK	
IBUS-A.33	Switch OFF the "power switch "of "power switch box"	Switch OFF	OFF	
IBUS-A.34	Disconnect all Loads	OK	OK	

DATE:	TEST CONDUCTOR	QA	CUSTOMER
27/07/2009	Albertin A.	Francini E.	

Questo documento contiene informazioni di proprietà di CARLO GAVAZZI SPACE SpA. Tutti i diritti sono riservati.

All information contained in this document are property of CARLO GAVAZZI SPACE SpA. All right reserved.

Side A Input Stage - current monitors

	INPUT STAGE	
	CAN BUS 30	CAN BUS 31
Iload ~1,1A [A] – Loads OFF	1,05	1,05
Itlm ~1,1A [A] – Loads OFF	0,44	0,73
Itlm - Iload < 7,6A	-0,610	-0,320
Iload ~4,7A [A] – Switch ON out 1, 5	4,55	4,55
Itlm ~4,7A [A] – Switch ON out 1, 5	4,51	4,91
Itlm - Iload < 7,6A	-0,040	0,360
Iload ~10,3A [A] – Switch ON out 2, 3 ,4	10,07	10,07
Itlm ~10,3A [A] – Switch ON out 2, 3, 4	10,25	10,85
Itlm - Iload < 7,6A	0,180	0,780
Iload ~15,1A [A] – Switch ON out 6, 7, 8 ,9	14,7	14,7
Itlm ~15,1A [A] – Switch ON out 6, 7, 8 ,9	14,88	15,6
Itlm - Iload < 7,6A	0,180	0,900
Iload ~21,1A [A] – Switch ON out 10, 11, 12	20,3	20,3
Itlm ~21,1A [A] – Switch ON out 10, 11, 12	20,18	21,06
Itlm - Iload < 7,6A	-0,120	0,760

Tab. 3: Side A Input Stage current monitors

Questo documento contiene informazioni di proprietà di CARLO GAVAZZI SPACE SpA. Tutti i diritti sono riservati.
All information contained in this document are property of CARLO GAVAZZI SPACE SpA. All right reserved.

UUT DATA :	Model	PFM	Item	AMS02 POWER DISTRIBUTION SYSTEM	C.I.	PDS 18	S/N	FM01

10.3.1.6.2 INPUT STAGE – ESEM1A TELEMETRY

STEP n°	TEST SEQUENCE	EXPECTED VALUE	MEASURED VALUE	REMARKS
VBUS-A.1	Connect main power supply between AI_120V (positive) and AI_120V_RTN (negative)	J100 connected	J100	
VBUS-A.2	Set Power supply alim to 120V	120,00V±1,00V	120,0 V	
VBUS-A.3	Set output current limitation to 3A	3A±0,5A	3,0 A	
VBUS-A.4	Enable power supply output	enabled	enabled	
VBUS-A.5	Verify that green led of **"power switch box"** is lighted	Green led ligthed	Green led ligthed	
VBUS-A.6	Switch ON the **"power switch "of "power switch box"**	Switch ON	Switch ON	
VBUS-A.7	Verify that red led of **"power switch box"** is lighted	Red led ligthed	Red led ligthed	
VBUS-A.8	Verify the current absorption from Main Bus	1,10A±0,20A	1,1 A	Note: this current can be read from power supply display or amperometer. In case of power supply reading, verify the correctness of measurements.
VBUS-A.9	Select PDS controller software	program open	program open	
VBUS-A.10	Set the CAN BUS board address to 30	30	30	
VBUS-A.11	Select JMDC = 0	0	0	
VBUS-A.12	Select TX = A	A	A	
VBUS-A.13	Select RX = A	A	A	
VBUS-A.14	Select "CAN BUS I/F Side" to A	A	A	
VBUS-A.15	Select "PDS Side" to A	A	A	
VBUS-A.16	Click on Run flash command	OK	OK	
VBUS-A.17	Set the CAN BUS board address to 31	31	31	
VBUS-A.18	Select "CAN BUS I/F Side" to B	B	B	
VBUS-A.19	Click on Run flash command	OK	OK	
VBUS-A.20	Set the CAN BUS board address to 30	30	30	
VBUS-A.21	Select "CAN BUS I/F Side" to A	A	A	
VBUS-A.22	Fill the table at the end of paragraph	OK	OK	
VBUS-A.23	Connect a multimeter between PIN "bypass thermal interlock" (positive) and "PRI_GND"(negative) on side A of the J300 test box	OK	OK	
VBUS-A.24	To set the Voltage value use the multimeter connected on J300 test box	OK	OK	
VBUS-A.25	To read the telemetry of the ESEM1A board *Click on ESEM1A button and Press button "READ"*	OK	OK	Button located on left side of software window
VBUS-A.26	To read the telemetry of the INPUT STAGE *Click on button "READ" relevant to INPUT STAGE*	OK	OK	Button located on left side of software window
VBUS-A.27	To read telemetries change from CAN BUS 30 to CAN BUS 31 using the following parameters:	OK	OK	

DATE:	TEST CONDUCTOR	QA	CUSTOMER
26/07/2009	Albertin A.	Francini E.	

Questo documento contiene informazioni di proprietà di CARLO GAVAZZI SPACE SpA. Tutti i diritti sono riservati.

All information contained in this document are property of CARLO GAVAZZI SPACE SpA. All right reserved.

UUT DATA : **Model** **PFM** **Item** **AMS02 POWER DISTRIBUTION SYSTEM** **C.I.** **PDS 18** **S/N** **FM01**

STEP n°	TEST SEQUENCE	EXPECTED VALUE	MEASURED VALUE	REMARKS
	CAN BUS 30 verification Set the CAN BUS board address to 30 Select "CAN BUS I/F Side" to A *CAN BUS 31 verification* Set the CAN BUS board address to 31 Select "CAN BUS I/F Side" to B			
VBUS-A.28	Using the table at the end of paragraph verify that Iload-Itlm is lower than 9.5V	OK	OK	Verify that all telemetries are in line with tolerance 5% F.S.
VBUS-A.29	Set Power supply alim to 120V	120,00V±1,00V	120,0 V	
VBUS-A.30	Switch OFF the "power switch "of "power switch box"	Switch OFF	OFF	
VBUS-A.31	Switch OFF main power bus	OK	OK	

DATE:	TEST CONDUCTOR	QA	CUSTOMER
24/07/2009	Albertin A.	Francini E.	

Questo documento contiene informazioni di proprietà di CARLO GAVAZZI SPACE SpA. Tutti i diritti sono riservati.
All information contained in this document are property of CARLO GAVAZZI SPACE SpA. All right reserved.

STEP n°	TEST SEQUENCE	EXPECTED VALUE	MEASURED VALUE	REMARKS

Side A Input Stage – Esem1A telemetry

	INPUT STAGE		ESEM1A	
	CAN BUS 30	CAN BUS 31	CAN BUS 30	CAN BUS 31
Vbus 90V [V]	90,06	90,06	90,06	90,06
Vtel 90 [V]	91,6	96,0	89,4	89,8
Vtlm - Vbus < 9,5V	1,540	5,940	-0,660	-0,260
Vbus 110V [V]	110,3	110,3	110,3	110,3
Vtel 110 [V]	110,9	116,0	111,0	110,4
Vtlm - Vbus < 9,5V	0,600	5,700	0,700	0,100
Vbus 120V [V]	120,3	120,3	120,3	120,3
Vtel 120 [V]	120,7	125,3	121,0	120,7
Vtlm - Vbus < 9,5V	0,400	5,000	0,700	0,400
Vbus 130V [V]	130,4	130,4	130,4	130,4
Vtel 130 [V]	130,7	135,1	132,1	131,4
Vtlm - Vbus < 9,5V	0,300	4,700	1,700	1,000
Vbus 145V [V]	145,5	145,5	145,5	145,5
Vtel 145 [V]	147,3	149,0	147,3	146,5
Vtlm - Vbus < 9,5V	1,800	3,500	1,800	1,000

Tab. 4: Side A Input Stage - ESEM 1-A telemetry

Questo documento contiene informazioni di proprietà di CARLO GAVAZZI SPACE SpA. Tutti i diritti sono riservati.
All information contained in this document are property of CARLO GAVAZZI SPACE SpA. All right reserved.

UUT DATA :	Model	PFM	Item	AMS02 POWER DISTRIBUTION SYSTEM	C.I.	PDS 18	S/N	FM01

STEP n°	TEST SEQUENCE	EXPECTED VALUE	MEASURED VALUE	REMARKS

10.3.2 B SECTION

10.3.2.1 SETUP

3.2.1.1	Verify that the **"power switch box"** is connected between power supply alim and PDS cables	Connected	Connected	
3.2.1.2	Verify that the **"power switch"** of the **"power switch box"** is set in OFF position	OFF	OFF	
3.2.1.3	Verify that all load are connected except for external heaters	Connected	Connected	
3.2.1.4	Set all the loads to 0A current absorption (external heaters included)	0A absorbtion set	0A absorbtion set	
3.2.1.5	Launch the PDS controller software and select FM in the Model window	Program open	Program open	
3.2.1.6	Launch the USCM controller software: Open the file **"USCM"**	File open	File open	

10.3.2.2 POWER ON WITH ISS MAIN BUS

3.2.2.1	Connect main power supply between BI_120V (positive) and BI_120V_RTN (negative)	J200 ~~J100~~ connected	Connected	**See PVS-03**
3.2.2.2	Set Power supply to 120V	120,00V±1,00V	120V	
3.2.2.3	Set output current limitation to 3A	3A±0,5A	3A	
3.2.2.4	Enable power supply output	enabled	enabled	
3.2.2.5	Verify that green led of **"power switch box"** is lighted	Green led ligthed	Green led ligthed	
3.2.2.6	Switch ON the **"power switch "**of **"power switch box"**	Switch ON	Switch ON	
3.2.2.7	Verify that red led of **"power switch box"** is lighted	Red led ligthed	Red led ligthed	
3.2.2.8	Verify the current absorption from Main Bus	1,10A±0,20A	0,99A	Note: this current can be read from power supply display or amperometer. In case of power supply reading, verify the correctness of measurements.
3.2.2.9	**Unmated connectors verfication**			
3.2.2.10	Measure with multimeter the volrtage between 2P_120V (positive) and 2P_120V_RTN (negative)	<5V	0,008V	Power bus isolation verification
3.2.2.11	Measure with multimeter the volrtage between AP_120V (positive) and AP_120V_RTN (negative)	<5V	0,006V	Power bus isolation verification

DATE:	TEST CONDUCTOR	QA	CUSTOMER
24/07/2009	Albertin A.	Francini E.	

Questo documento contiene informazioni di proprietà di CARLO GAVAZZI SPACE SpA. Tutti i diritti sono riservati.
All information contained in this document are property of CARLO GAVAZZI SPACE SpA. All right reserved.

UUT DATA :	Model	PFM	Item	AMS02 POWER DISTRIBUTION SYSTEM	C.I.	PDS 18	S/N	FM01

10.3.2.2.1 CAN BUS COMMUNICATION LINE CHECK BOARD 30

STEP n°	TEST SEQUENCE	EXPECTED VALUE	MEASURED VALUE	REMARKS
3.2.2.12	Objective: to verify the external CAN BUS lines communication			
3.2.2.13	Select USCM controller software	USCM selcted	USCM selcted	
3.2.2.14	set the CAN BUS board address to 30 in the command widow	30	30	
3.2.2.15	Select JMDC = 0	0	0	
3.2.2.16	Select TX = A	A	A	
3.2.2.17	Select RX = A	A	A	
3.2.2.18	press button READ and verify on the command status window	Command execute OK	Command execute OK	
3.2.2.19	Verify MODE window	PDS_PROM	PDS_PROM	
3.2.2.20	Verify Version window	26-Jan-09 17:06	26-Jan-09 17:06	
3.2.2.21	Verify History window	POWER ON 0	POWER ON 0	
3.2.2.22	select Select TX = B	B	B	
3.2.2.23	Select RX = B	B	B	
3.2.2.24	press button READ and verify on the command status window	Command execute OK	Command execute OK	
3.2.2.25	Verify MODE window	PDS_PROM	PDS_PROM	
3.2.2.26	Verify Version window	26-Jan-09 17:06	26-Jan-09 17:06	
3.2.2.27	Verify History	POWER ON 0	POWER ON 0	

10.3.2.2.2 CAN BUS COMMUNICATION LINE CHECK BOARD 31

3.2.2.28	Objective: To verify the external CAN BUS lines communication			
3.2.2.29	Set the CAN BUS board address to 31 in the command widow	31	31	
3.2.2.30	Select JMDC = 0	0	0	
3.2.2.31	Select TX = A	A	A	
3.2.2.32	Select RX = A	A	A	
3.2.2.33	press button READ and verify on the command status window	Command execute OK	Command execute OK	
3.2.2.34	Verify MODE window	PDS_PROM	PDS_PROM	
3.2.2.35	Verify Version window	26-Jan-09 17:06	26-Jan-09 17:06	
3.2.2.36	Verify History window	POWER ON 0	POWER ON 0	

DATE: 26/07/2009	TEST CONDUCTOR Albertin A.	QA Francini E.	CUSTOMER

Questo documento contiene informazioni di proprietà di CARLO GAVAZZI SPACE SpA. Tutti i diritti sono riservati.
All information contained in this document are property of CARLO GAVAZZI SPACE SpA. All right reserved.

UUT DATA : Model PFM Item AMS02 POWER DISTRIBUTION SYSTEM C.I. PDS 18 S/N FM01

STEP n°	TEST SEQUENCE	EXPECTED VALUE	MEASURED VALUE	REMARKS
3.2.2.37	select Select TX = B	B	B	
3.2.2.38	Select RX = B	B	B	
3.2.2.39	press button READ and verify on the command status window	Command execute OK	Command execute OK	
3.2.2.40	Verify MODE window	PDS_PROM	PDS_PROM	
3.2.2.41	Verify Version window	26-Jan-09 17:06	26-Jan-09 17:06	
3.2.2.42	Verify History	POWER ON 0	POWER ON 0	

10.3.2.2.3 PDS INTERNAL SERIAL COMMUNICATION CHECK BOARD 30

3.2.2.43	**Objective: To verify the internal communication of the CAN BUS boards 30 with the PDS B side boards**			
3.2.2.44	set the CAN BUS board address to 30	30	30	
3.2.2.45	select JMDC = 0	0	0	
3.2.2.46	select TX = A	A	A	
3.2.2.47	select RX = A	A	A	
3.2.2.48	Press button "RUN Flash" and verify on the command status window	Command execute OK	Command execute OK	
3.2.2.49	press button READ and verify on the command status window	Command execute OK	Command execute OK	
3.2.2.50	Verify MODE window	PDS_FLASH	PDS_FLASH	
3.2.2.51	Verify Version window	26-Jan-09 17:07	26-Jan-09 17:07	
3.2.2.52	Verify History	PROM 3	PROM 3	
3.2.2.53	Select PDS controller software	program open	program open	
3.2.2.54	set the CAN BUS board address to 30	30	30	
3.2.2.55	select JMDC = 0	0	0	
3.2.2.56	select TX = A	A	A	
3.2.2.57	select RX = A	A	A	
3.2.2.58	Select "CAN BUS I/F Side" to A	A	A	
3.2.2.59	Select "PDS Side" to B	B	B	
3.2.2.60	Press button "READ INPUT" button and verify on the command status window	Command execute OK	Command execute OK	
3.2.2.61	Verify Input Stage B Voltage (V)monitor	120V ± 9.5V	120V	
3.2.2.62	Verify Input stage B Current (A) monitor	1,1A ± 20%	1,04A	
3.2.2.63	Press button "READ" to verify all board status			
3.2.2.64	Verify "Sta" column values	All boards OK	OK	

DATE:	TEST CONDUCTOR	QA	CUSTOMER
24 /07/2009	Albertin A.	Francini E.	

Questo documento contiene informazioni di proprietà di CARLO GAVAZZI SPACE SpA. Tutti i diritti sono riservati.

All information contained in this document are property of CARLO GAVAZZI SPACE SpA. All right reserved.

UUT DATA : Model PFM Item AMS02 POWER DISTRIBUTION SYSTEM C.I. PDS 18 S/N FM01

STEP n°	TEST SEQUENCE	EXPECTED VALUE	MEASURED VALUE	REMARKS
3.2.2.65	Verify "OVT" column values	All boards OK	OK	With the exception of ESEM1-A board: OVT flag not present
3.2.2.66	Verify "Temp" column values	-20°C to +80°C	OK	No full scale values must be present All temperatures must be inside unit temp limits
3.2.2.67	Verify "Ref" colum values	2,5V ± 0,25V 2,0V ± 0,25V 3,0V ± 0,25V 2,0V ± 0,25V 3,0V ± 0,25V 2,0V ± 0,25V 3,0V ± 0,25V 2,0V ± 0,25V 3,0V ± 0,25V 4,0V ± 0,25V	2,52V 2,18V 2,97V 2,25V 2,95V 2,18V 2,98V 2,20V 2,96V 4,04V	All

10.3.2.2.4 PDS INTERNAL SERIAL COMMUNICATION CHECK BOARD 31

3.2.2.68	Select USCM controller software	USCM selcted	USCM selcted	
3.2.2.69	Set the CAN BUS board address to 31	31	31	
3.2.2.70	select JMDC = 0	0	0	
3.2.2.71	select TX = A	A	A	
3.2.2.72	select RX = A	A	A	
3.2.2.73	Press button "RUN Flash" and verify on the command status window	Command execute OK	Command execute OK	
3.2.2.74	press button READ and verify on the command status window	Command execute OK	Command execute OK	
3.2.2.75	Verify MODE window	PDS_FLASH	PDS_FLASH	
3.2.2.76	Verify Version window	26-Jan-09 17:07	26-Jan-09 17:07	
3.2.2.77	Verify History	PROM 3	PROM 3	
3.2.2.78	Select PDS controller software	program open	program open	
3.2.2.79	Set the CAN BUS board address to 31	31	31	
3.2.2.80	select JMDC = 0	0	0	
3.2.2.81	select TX = A	A	A	
3.2.2.82	select RX = A	A	A	
3.2.2.83	Select "CAN BUS I/F Side" to B	B	B	
3.2.2.84	Select "PDS Side" to B	B	B	

DATE:	TEST CONDUCTOR	QA	CUSTOMER
24 /07/2009	Albertin A.	Francini E.	

Questo documento contiene informazioni di proprietà di CARLO GAVAZZI SPACE SpA. Tutti i diritti sono riservati.

All information contained in this document are property of CARLO GAVAZZI SPACE SpA. All right reserved.

UUT DATA : Model PFM Item AMS02 POWER DISTRIBUTION SYSTEM C.I. PDS 18 S/N FM01

STEP n°	TEST SEQUENCE	EXPECTED VALUE	MEASURED VALUE	REMARKS
3.2.2.85	Click on Run flash button	OK	OK	
3.2.2.86	Press button "READ INPUT" button and verify on the command status window	Command execute OK	Command execute OK	
3.2.2.87	Verify "Input Stage B" Voltage (V)monitor	120V ± 9.5V	119,7V	
3.2.2.88	Verify "Input stage B" Current (A) monitor	1,1A ± 20%	0,71A	20% Full Scale value
3.2.2.89	Press button "READ" to verify all board status	Command execute OK	Command execute OK	
3.2.2.90	Verify "Sta" column values	All boards OK	OK	
3.2.2.91	Verify "OVT" column values	All boards OK	OK	With the exception of ESEM1-A board: OVT flag not present
3.2.2.92	Verify "Temp" column values	-20°C to +80°C	OK	No full scale values must be present All temperatures must be inside unit temp limits Some difference can be present due to different board power dissipation
3.2.2.93	Verify "Ref" colum values	2,5V ± 0,25V 2,0V ± 0,25V 3,0V ± 0,25V 2,0V ± 0,25V 3,0V ± 0,25V 2,0V ± 0,25V 3,0V ± 0,25V 2,0V ± 0,25V 3,0V ± 0,25V 4,0V ± 0,25V	2,51V 2,20V 2,98V 2,25V 2,98V 2,18V 2,95V 2,22V 2,98V 3,98V	
3.2.2.94	Switch OFF 120V main bus		OFF	

10.3.2.2.5 CAN BUS BOARDS CROSS CMD OFF/ON AND SIUCIDE TEST

3.2.2.95	Objective: to verify the possibility to command OFF and ON one board from the other			
3.2.2.96	Verify that the **"power switch box"** is connected between power supply alim and PDS cables	Connected	Connected	
3.2.2.97	Verify that the **"power switch"** of the **"power switch box"** is set in OFF position	OFF	OFF	
3.2.2.98	Lunch the PDS controller software	Program open	Program open	
3.2.2.99	Launch the USCM controller software	File open	File open	
3.2.2.100	Set to "FM" the window Model	FM	FM	
3.2.2.101	Connect "J300 test box" to the unit J300 connector	OK	OK	
3.2.2.102	Connect main power supply between BI_120V (positive) and BI_120V_RTN (negative)	J200 connected	OK	

DATE:	TEST CONDUCTOR	QA	CUSTOMER
24 /07/2009	Albertin A.	Francini E.	

Questo documento contiene informazioni di proprietà di CARLO GAVAZZI SPACE SpA. Tutti i diritti sono riservati.
All information contained in this document are property of CARLO GAVAZZI SPACE SpA. All right reserved.

UUT DATA : Model PFM Item AMS02 POWER DISTRIBUTION SYSTEM C.I. PDS 18 S/N FM01

STEP n°	TEST SEQUENCE	EXPECTED VALUE	MEASURED VALUE	REMARKS
3.2.2.103	Set Power supply alim to 120V	120,00V±1,00V	120V	V1
3.2.2.104	Set output current limitation to 3A	3A±0,5A	3A	
3.2.2.105	Enable power supply output	enabled	enabled	
3.2.2.106	Verify that green led of **"power switch box"** is lighted	Green led ligthed	GREEN	
3.2.2.107	Switch ON the **"power switch "of "power switch box"**	Switch ON	ON	
3.2.2.108	Verify that red led of **"power switch box"** is lighted	Red led ligthed	RED	
3.2.2.109	Verify the current absorption from Main Bus	1,10A±0,20A	1,1A	Note: this current can be read from power supply display or amperometer. In case of power supply reading, verify the correctness of measurements.
3.2.2.110	Select USCM controller software	USCM selcted	USCM selcted	
3.2.2.111	set the CAN BUS board address to 30 in the command window	30	30	
3.2.2.112	Select JMDC = 0	0	0	
3.2.2.113	Select TX = A	A	A	
3.2.2.114	Select RX = A	A	A	
3.2.2.115	press button READ and verify on the command status window	Command execute OK	Command execute OK	
3.2.2.116	Verify MODE window	PDS_PROM	PDS_PROM	
3.2.2.117	Verify Version window	26-Jan-09 17:06	26-Jan-09 17:06	
3.2.2.118	Verify History window	POWER ON 0	POWER ON 0	
3.2.2.119	Measure the CAN BUS internal power supply: connect a multimeter between PIN Vcc (positive) and SEC_GND (negative) on side A of the J300 test box	5.3V ± 0.1V	5,31V	
3.2.2.120	Set the CAN BUS board address to 31 in the command window	31	31	
3.2.2.121	Select JMDC = 0	0	0	
3.2.2.122	Select TX = A	A	A	
3.2.2.123	Select RX = A	A	A	
3.2.2.124	press button READ and verify on the command status window	Command execute OK	Command execute OK	
3.2.2.125	Verify MODE window	PDS_PROM	PDS_PROM	
3.2.2.126	Verify Version window	26-Jan-09 17:06	26-Jan-09 17:06	
3.2.2.127	Verify History window	POWER ON 0	POWER ON 0	
3.2.2.128	Measure the CAN BUS internal power supply: connect a multimeter between PIN Vcc (positive) and SEC_GND (negative) on side B of the J300 test box	5.30 ± 0.1V	5,28V	
3.2.2.129	set the CAN BUS board address to 30 in the command window	30	30	
3.2.2.130	press button SOFF and verify on the command status window	Command execute OK	Command execute OK	
3.2.2.131	Set the CAN BUS board address to 31 in the command window	31	31	

DATE:	TEST CONDUCTOR	QA	CUSTOMER
24 /07/2009	Albertin A.	Francini E.	

Questo documento contiene informazioni di proprietà di CARLO GAVAZZI SPACE SpA. Tutti i diritti sono riservati.

All information contained in this document are property of CARLO GAVAZZI SPACE SpA. All right reserved.

UUT DATA : Model PFM Item AMS02 POWER DISTRIBUTION SYSTEM C.I. PDS 18 S/N FM01

STEP n°	TEST SEQUENCE	EXPECTED VALUE	MEASURED VALUE	REMARKS
3.2.2.132	press button READ and verify on the command status window	Command execute failed	Command execute failed	
3.2.2.133	Measure the CAN BUS 31 internal power supply: connect a multimeter between PIN Vcc (positive) and SEC_GND (negative) on side B of the J300 test box	0.50 ± 0.1V	0,51V	
3.2.2.134	Measure the CAN BUS 30 internal power supply: connect a multimeter between PIN Vcc (positive) and SEC_GND (negative) on side A of the J300 test box	5.30 ± 0.1V	5,30V	
3.2.2.135	set the CAN BUS board address to 30 in the command window	30	30	
3.2.2.136	press button SON and verify on the command status window	Command execute OK	Command execute OK	
3.2.2.137	Set the CAN BUS board address to 31 in the command window	31	31	
3.2.2.138	press button READ and verify on the command status window	Command execute OK	Command execute OK	
3.2.2.139	Measure the CAN BUS internal power supply: connect a multimeter between PIN Vcc (positive) and SEC_GND (negative) on side B of the J300 test box	5.3V ± 0.1V	5,28V	
3.2.2.140	Verify MODE window	PDS_PROM	PDS_PROM	
3.2.2.141	Verify Version window	26-Jan-09 17:06	26-Jan-09 17:06	
3.2.2.142	Verify History window	POWER ON 0	POWER ON 0	
3.2.2.143	Set the CAN BUS board address to 31 in the command window	31	31	
3.2.2.144	press button SOFF and verify on the command status window	Command execute OK	Command execute OK	
3.2.2.145	set the CAN BUS board address to 30 in the command window	30	30	
3.2.2.146	press button READ and verify on the command status window	Command execute failed	Command execute failed	
3.2.2.147	Measure the CAN BUS internal power supply: connect a multimeter between PIN Vcc (positive) and SEC_GND (negative) on side A of the J300 test box	0,5V ± 0.1V	0,52V	
3.2.2.148	Measure the CAN BUS internal power supply: connect a multimeter between PIN Vcc (positive) and SEC_GND (negative) on side B of the J300 test box	5.3V ± 0.1V	5,28V	
3.2.2.149	Set the CAN BUS board address to 31 in the command window	31	31	
3.2.2.150	press button SON and verify on the command status window	Command execute OK	Command execute OK	
3.2.2.151	set the CAN BUS board address to 30 in the command window	30	30	
3.2.2.152	press button READ and verify on the command status window	Command execute OK	Command execute OK	
3.2.2.153	Measure the CAN BUS internal power supply: connect a multimeter between PIN Vcc (positive) and SEC_GND (negative) on side B of the J300 test box	5.3V ± 0.1V	5,31V	
3.2.2.154	Verify MODE window	PDS_PROM	PDS_PROM	
3.2.2.155	Verify Version window	26-Jan-09 17:06	26-Jan-09 17:06	

DATE:	TEST CONDUCTOR	QA	CUSTOMER
22/07/2009	Albertin A.	Francini E.	

Questo documento contiene informazioni di proprietà di CARLO GAVAZZI SPACE SpA. Tutti i diritti sono riservati.

All information contained in this document are property of CARLO GAVAZZI SPACE SpA. All right reserved.

UUT DATA : Model PFM Item AMS02 POWER DISTRIBUTION SYSTEM C.I. PDS 18 S/N FM01

STEP n°	TEST SEQUENCE	EXPECTED VALUE	MEASURED VALUE	REMARKS
3.2.2.156	Verify History window	POWER ON 0	POWER ON 0	
3.2.2.157	**SUICIDE BOARD 30 COMMAND TEST**			
3.2.2.158	set the CAN BUS board address to 30 in the command window	30	30	
3.2.2.159	press button SUIC and verify on the command status window	Command execute failed	Command execute failed	
3.2.2.160	Measure the CAN BUS internal power supply: connect a multimeter between PIN Vcc (positive) and SEC_GND (negative) on side A of the J300 test box	0.50 ± 0.1V	0,52V	
3.2.2.161	press button READ and verify on the command status window	Command execute failed	Command execute failed	
3.2.2.162	Set the CAN BUS board address to 31 in the command window	31	31	
3.2.2.163	press button SON and verify on the command status window	Command execute OK	Command execute OK	
3.2.2.164	set the CAN BUS board address to 30 in the command window	30	30	
3.2.2.165	press button READ and verify on the command status window	Command execute OK	Command execute OK	
3.2.2.166	Measure the CAN BUS internal power supply: connect a multimeter between PIN Vcc (positive) and SEC_GND (negative) on side 30 of the J300 test box	5.3V ± 0.1V	5,30V	
3.2.2.167	Verify MODE window	PDS_PROM	PDS_PROM	
3.2.2.168	Verify Version window	26-Jan-09 17:06	26-Jan-09 17:06	
3.2.2.169	Verify History window	POWER ON 0	POWER ON 0	
3.2.2.170	**SUICIDE BOARD 31 COMMAND TEST**			
3.2.2.171	Set the CAN BUS board address to 31 in the command window	31	31	
3.2.2.172	press button SUIC and verify on the command status window	Command execute failed	Command execute failed	
3.2.2.173	Measure the CAN BUS internal power supply: connect a multimeter between PIN Vcc (positive) and SEC_GND (negative) on side B of the J300 test box	0.5V ± 0.1V	0,51V	
3.2.2.174	press button READ and verify on the command status window	Command execute failed	Command execute failed	
3.2.2.175	set the CAN BUS board address to 30 in the command window	30	30	
3.2.2.176	press button SON and verify on the command status window	Command execute OK	Command execute OK	
3.2.2.177	Set the CAN BUS board address to 31 in the command window	31	31	
3.2.2.178	press button READ and verify on the command status window	Command execute OK	Command execute OK	
3.2.2.179	Measure the CAN BUS internal power supply: connect a multimeter between PIN Vcc (positive) and SEC_GND (negative) on side B of the J300 test box	5.30V ± 0.1V	5,28V	
3.2.2.180	Verify MODE window	PDS_PROM	PDS_PROM	

DATE:	TEST CONDUCTOR	QA	CUSTOMER
26 /07/2009	Albertin A.	Francini E.	

Questo documento contiene informazioni di proprietà di CARLO GAVAZZI SPACE SpA. Tutti i diritti sono riservati.

All information contained in this document are property of CARLO GAVAZZI SPACE SpA. All right reserved.

UUT DATA : Model PFM Item AMS02 POWER DISTRIBUTION SYSTEM C.I. PDS 18 S/N FM01

STEP n°	TEST SEQUENCE	EXPECTED VALUE	MEASURED VALUE	REMARKS
3.2.2.181	Verify Version window	26-Jan-09 17:06	26-Jan-09 17:06	
3.2.2.182	Verify History window	POWER ON 0	POWER ON 0	
3.2.2.183	Switch OFF the "power switch "of "power switch box"	OFF	OFF	
3.2.2.184	Disable power supply output	Disable	Disable	

10.3.2.3 POWER VIDEO GRAPPLE FIXTURE 2 POWER SUPPLY VERIFICATION (2P)

3.2.2.185	Connect main power supply between 2P_120V (positive) and 2P_120V_RTN (negative)	CONNECTED	CONNECTED	
3.2.2.186	Connect ESEM 3-B outlet 1 to default load	CONNECTED	CONNECTED	Default current absorption equal to 1,200A±100mA
3.2.2.187	Set Power supply alim to 120V	120,00V±1,00V	120V	
3.2.2.188	Set output current limitation to 5A	5A±0,5A	5A	
3.2.2.189	Enable power supply output	Enabled	enabled	
3.2.2.190	Verify that green led of **"power switch box"** is lighted	Green led ligthed	green	
3.2.2.191	Switch ON the **"power switch "of "power switch box"**	Switch ON	ON	
3.2.2.192	Verify that red led of **"power switch box"** is lighted	Red led ligthed	red	
3.2.2.193	Verify the current absorption from Main Bus	2,30A±0,20A	2,23A	Note: this current can be read from power supply display or amperometer. In case of power supply reading, verify the correctness of measurements.
3.2.2.194	Launch the PDS controller software	OPEN	OPEN	
3.2.2.195	Set to "FM" the window Model	FM	FM	
3.2.2.196	Set the CAN BUS board address to 31	31	31	
3.2.2.197	select JMDC = 0	0	0	
3.2.2.198	select TX = A	A	A	
3.2.2.199	select RX = A	A	A	
3.2.2.200	Select "CAN BUS I/F Side" to B	B	B	
3.2.2.201	Select "PDS Side" to B	B	B	
3.2.2.202	Press button "RUN Flash" and verify on the command status window	Command execute OK	Command execute OK	
3.2.2.203	Press button "READ" to verify all board status	Command execute OK	Command execute OK	
3.2.2.204	Verify the status of the flags indicated on "Sta" column. All flags must be "OK"	OK	OK	Click on READ command under Sta column This column resumes the status of al the boards
3.2.2.205	Set the CAN BUS board address to 31	30	30	
3.2.2.206	Set to "B" the window PDS Side	B	B	
3.2.2.207	Set the window CAN BUS I/F Side to "A" configuration	A	A	
3.2.2.208	Click on Run flash button			Command located on up-left

DATE:	TEST CONDUCTOR	QA	CUSTOMER
26 /07/2009	Albertin A.	Francini E.	

Questo documento contiene informazioni di proprietà di CARLO GAVAZZI SPACE SpA. Tutti i diritti sono riservati.

All information contained in this document are property of CARLO GAVAZZI SPACE SpA. All right reserved.

UUT DATA : Model PFM Item AMS02 POWER DISTRIBUTION SYSTEM C.I. PDS 18 S/N FM01

STEP n°	TEST SEQUENCE	EXPECTED VALUE	MEASURED VALUE	REMARKS
3.2.2.209	Press button "READ" to verify all board status	Command execute OK	Command execute OK	
3.2.2.210	Verify the status of the flags indicated on "Sta" column. All flags must be "OK"	OK	OK	Click on READ command under Sta column This column resumes the status of al the boards
3.2.2.211	Measure with multimeter the voltage on ESEM 3-B outlet 1	117,00V<V<120,00V	118,5V	This test is used to verify that input diode located in input stage board is not damaged
3.2.2.212	Switch OFF main power bus	OK	OK	
3.2.2.213	Disconnect ESEM 3-B outlet 1 to default load	OK	OK	

10.3.2.4 APCU POWER SUPPLY TEST

3.2.2.214	Connect main power supply between AP_120V (positive) and AP_120V_RTN (negative)	CONNECTED	CONNECTED	
3.2.2.215	Connect ESEM 3-B outlet 1 to default load	CONNECTED	CONNECTED	Default current absorption equal to 1,200A±100mA
3.2.2.216	Set Power supply alim to 120V	120,00V±1,00V	120V	
3.2.2.217	Set output current limitation to 5A	5A±0,5A	5A	
3.2.2.218	Enable power supply output	Enabled	enabled	
3.2.2.219	Verify that green led of "power switch box" is lighted	Green led ligthed	GREEN	
3.2.2.220	Switch ON the "power switch "of "power switch box"	Switch ON	ON	
3.2.2.221	Verify that red led of "power switch box" is lighted	Red led ligthed	RED	
3.2.2.222	Verify the current absorption from Main Bus	2,30A±0,20A	2,3A	Note: this current can be read from power supply display or amperometer. In case of power supply reading, verify the correctness of measurements.
3.2.2.223	Launch the PDS controller software	OPEN	OPEN	
3.2.2.224	Set to "FM" the window Model	FM	FM	
3.2.2.225	Set the CAN BUS board address to 31	31	31	
3.2.2.226	select JMDC = 0	0	0	
3.2.2.227	select TX = A	A	A	
3.2.2.228	select RX = A	A	A	
3.2.2.229	Select "CAN BUS I/F Side" to B	B	B	
3.2.2.230	Select "PDS Side" to B	B	B	
3.2.2.231	Press button "RUN Flash" and verify on the command status window	Command execute OK	Command execute OK	
3.2.2.232	Press button "READ" to verify all board status	Command execute OK	Command execute OK	
3.2.2.233	Verify the status of the flags indicated on "Sta" column. All flags must be "OK"	OK	OK	Click on READ command under Sta column This column resumes the status of al the boards

DATE:	TEST CONDUCTOR	QA	CUSTOMER
21 /07/2009	Albertin A.	Francini E.	

Questo documento contiene informazioni di proprietà di CARLO GAVAZZI SPACE SpA. Tutti i diritti sono riservati.

All information contained in this document are property of CARLO GAVAZZI SPACE SpA. All right reserved.

UUT DATA : Model PFM Item AMS02 POWER DISTRIBUTION SYSTEM C.I. PDS 18 S/N FM01

STEP n°	TEST SEQUENCE	EXPECTED VALUE	MEASURED VALUE	REMARKS
3.2.2.234	Set the CAN BUS board address to 31	30	30	
3.2.2.235	Set to "B" the window PDS Side	B	B	
3.2.2.236	Set the window CAN BUS I/F Side to "A" configuration	A	A	
3.2.2.237	Click on Run flash button			Command located on up-left
3.2.2.238	Press button "READ" to verify all board status	Command execute OK	Command execute OK	
3.2.2.239	Verify the status of the flags indicated on "Sta" column. All flags must be "OK"	OK	OK	Click on READ command under Sta column This column resumes the status of al the boards
3.2.2.240	Measure with multimeter the voltage on ESEM 3-B outlet 1	117,00V<V<120,00V	118,7V	This test is used to verify that input diode located in input stage board is not damaged
3.2.2.241	Switch OFF main power bus	OK	OK	
3.2.2.242	Disconnect ESEM 3-B outlet 1 to default load	OK	OK	

DATE:	TEST CONDUCTOR	QA	CUSTOMER
24/07/2009	Albertin A.	Francini E.	

Questo documento contiene informazioni di proprietà di CARLO GAVAZZI SPACE SpA. Tutti i diritti sono riservati.

All information contained in this document are property of CARLO GAVAZZI SPACE SpA. All right reserved.

UUT DATA :	Model	PFM	Item	AMS02 POWER DISTRIBUTION SYSTEM	C.I.	PDS 18	S/N	FM01

10.3.2.5 UNIT CHECK

STEP n°	TEST SEQUENCE	EXPECTED VALUE	MEASURED VALUE	REMARKS
3.2.5.1	Connect BI_120V and BI_120V_RTN power supply signals	OK	OK	
3.2.5.2	Verify that all the cables of the section are connected	OK	OK	
3.2.5.3	Launch the PDS controller software	Program open	Program open	
3.2.5.4	Set to "FM" the window Model	OK	OK	
3.2.5.5	Set the CAN BUS board address to 31	31	31	
3.2.5.6	select JMDC = 0	0	0	
3.2.5.7	select TX = A	A	A	
3.2.5.8	select RX = A	A	A	
3.2.5.9	Select "CAN BUS I/F Side" to B	B	B	
3.2.5.10	Select "PDS Side" to B	B	B	
3.2.5.11	Set input bus voltage to 120V	120V±1V	120V	V1
3.2.5.12	Set input bus current limitation to 27,5 A	27,5 A±1A	27,5 A	
3.2.5.13	Enable power supply output	Enabled	Enabled	
3.2.5.14	Verify that green led of "power switch box" is lighted	Green led ligthed	Green led ligthed	
3.2.5.15	Switch ON the "power switch "of "power switch box"	Switch ON	Switch ON	
3.2.5.16	Verify that red led of "power switch box" is lighted	Red led ligthed	Red led ligthed	
3.2.5.17	Take note of power supply output current	1,1A±0,5A	1A	I1
3.2.5.18	Press button "RUN Flash" and verify on the command status window	Command execute OK	Command execute OK	

DATE:	TEST CONDUCTOR	QA	CUSTOMER
22/07/2009	Albertin A.	Francini E.	

Questo documento contiene informazioni di proprietà di CARLO GAVAZZI SPACE SpA. Tutti i diritti sono riservati.

All information contained in this document are property of CARLO GAVAZZI SPACE SpA. All right reserved.

STEP n°	TEST SEQUENCE	EXPECTED VALUE	MEASURED VALUE	REMARKS

10.3.2.5.1 INPUT STAGE B VERIFICATION

3.2.5.19	Push the command "Read input" located in the bottom left of the software window	OK	OK	
3.2.5.20	Take note of the value "V" indicated in Input Stage B window	V1±9,50V	119.1V	V1 is indicated in step 3.2.5.11
3.2.5.21	Take note of the value "I" indicated in Input Stage B window	I1± 20%	0.76A	20% Full Scale value
3.2.5.22	Set the CAN BUS board address to 30	30	30	
3.2.5.23	Select "CAN BUS I/F Side" to A	A	A	
3.2.5.24	Press button "RUN Flash" and verify on the command status window	Command execute OK	Command execute OK	
3.2.5.25	Push the command "Read input" located in the bottom left of the software window	OK	OK	
3.2.5.26	Take note of the value "V" indicated in Input Stage B window	V1±9,50V	119.9V	
3.2.5.27	Take note of the value "I" indicated in Input Stage B window	I1± 20%	0.94A	
3.2.5.28	Switch OFF main power bus	OFF	OFF	
3.2.5.29	Connect external heaters	Connected	Connected	
3.2.5.30	Switch ON main bus	ON	ON	
3.2.5.31	Verify the current absorption from Main Bus	7,80A±0,50A	7,73 A	verify that heater lines are working
3.2.5.32	Switch OFF main power bus	OFF	OFF	
3.2.5.33	Disconnect external heaters	Disconnected	Disconnected	

Questo documento contiene informazioni di proprietà di CARLO GAVAZZI SPACE SpA. Tutti i diritti sono riservati.

All information contained in this document are property of CARLO GAVAZZI SPACE SpA. All right reserved.

UUT DATA : Model PFM Item AMS02 POWER DISTRIBUTION SYSTEM C.I. PDS 18 S/N FM01

10.3.2.5.2 ESEM 1-A SIDE B

STEP n°	TEST SEQUENCE	EXPECTED VALUE	MEASURED VALUE	REMARKS
1A-B.1	Set input bus voltage to 120V	120V±1V	120,0 V	V1
1A-B.2	Set input bus current limitation to ~~15A~~	~~15A~~ 27,5±1A	27,5 A	See PVS-04
1A-B.3	Switch ON main bus	ON	ON	
1A-B.4	Take note of power supply output current	1,1A±0,5A	1,02 A	I1
1A-B.5	Set the CAN BUS board address to 31	31	31	
1A-B.6	Select "CAN BUS I/F Side" to B	B	B	
1A-B.7	Press button "RUN Flash" and verify on the command status window	Command execute OK	Command execute OK	
1A-B.8	Click on ESEM 1-A button	OK	OK	
1A-B.9	Set Digital I/F Test logic value = 1 in "Commanding" column	1	1	
1A-B.10	Click on letter "W" on the right of the "1" value	OK	OK	
1A-B.11	Click on the command READ ALL under the column Digital Readout	OK	OK	
1A-B.12	Verify that in the column Digital Readout under the voice Digital I/F Test appears "1"	1	1	
1A-B.13	Set Digital I/F Test logic value = 0 in "Commanding" column	0	0	
1A-B.14	Click on letter "W" on the right of the "0" value	OK	OK	
1A-B.15	Click on the command READ ALL under the column Digital Readout	OK	OK	
1A-B.16	Verify that in the column Digital Readout under the voice Digital I/F Test appears "0"	0	0	
1A-B.17	Verify the status of the following flags: BOARD STATUS DCDC 1 OVC DCDC 2 OVC DCDC 1 STATUS DCDC 2 STATUS MAIN POWER STATUS	 OK OK OK ON ON ON	 OK OK OK ON ON ON	Flags located in Digital readout column
1A-B.18	Click on PB2-1 button	OK	OK	
1A-B.19	Set to "ON" the line "DCDC OFF/ON CMD" in the "commanding" column"	ON	ON	
1A-B.20	Press "W" button" in the line "DCDC OFF/ON CMD" in the "commanding" column	Command execute OK	Command execute OK	
1A-B.21	Verify that in the column Digital Readout under the voice DCDC ON/OFF appears "ON"	ON	ON	
1A-B.22	Click on PB2-2 button	OK	OK	
1A-B.23	Set to "ON" the line "DCDC OFF/ON CMD" in the "commanding" column"	ON	ON	
1A-B.24	Press "W" button" in the line "DCDC OFF/ON CMD" in the "commanding" column	Command execute OK	Command execute OK	
1A-B.25	Verify that in the column Digital Readout under the voice DCDC ON/OFF appears "ON"	ON	ON	

DATE:	TEST CONDUCTOR	QA	CUSTOMER
24/07/2009	Albertin A.	Francini E.	

Questo documento contiene informazioni di proprietà di CARLO GAVAZZI SPACE SpA. Tutti i diritti sono riservati.

All information contained in this document are property of CARLO GAVAZZI SPACE SpA. All right reserved.

UUT DATA : Model PFM Item AMS02 POWER DISTRIBUTION SYSTEM C.I. PDS 18 S/N FM01

STEP n°	TEST SEQUENCE	EXPECTED VALUE	MEASURED VALUE	REMARKS
1A-B.26	Click on PB2-3 button	OK	OK	
1A-B.27	Set to "ON" the line "DCDC OFF/ON CMD" in the "commanding" column"	ON	ON	
1A-B.28	Press "W" button" in the line "DCDC OFF/ON CMD" in the "commanding" column	Command execute OK	Command execute OK	
1A-B.29	Verify that in the column Digital Readout under the voice DCDC ON/OFF appears "ON"	ON	ON	
1A-B.30	Click on PB2-4 button	OK	OK	
1A-B.31	Set to "ON" the line "DCDC OFF/ON CMD" in the "commanding" column"	ON	ON	
1A-B.32	Press "W" button" in the line "DCDC OFF/ON CMD" in the "commanding" column	Command execute OK	Command execute OK	
1A-B.33	Verify that in the column Digital Readout under the voice DCDC ON/OFF appears "ON"	ON	ON	
1A-B.34	Take note of power supply output current	1,6A±0,5A	1,44 A	All the PB2 DC/DC are ON

10.3.2.5.2.1 ESEM 1-A SIDE B UNDER VOLTAGE TEST

1A-B.35	Click on ESEM 1-A button	OK	OK	
1A-B.36	Press "READ ALL" button in the column "ANALOG READOUT"	Command execute OK	Command execute OK	
1A-B.37	Verify the "Analog ref. 4.0V" telemetry	4,0V ± 0,15V	4,01 V	
1A-B.38	Measure the input voltage with a multimeter	120V ± 0.2V	120,2 V	
1A-B.39	In the column "ANALOG READOUT" press R Button near Main Power Volt.	120V ± 4.5V	117,3 V	
1A-B.40	Decrease the input voltage to 113V	113V ± 0.2V	113,1 V	
1A-B.41	In the column "ANALOG READOUT" press R Button near Main Power Volt.	113V ± 4.5V	111,0 V	
1A-B.42	Decrease the input voltage to 85V (below threshold and accuracy)	85V ± 0,2V	85,2 V	Threshold = 88V ± 2V
1A-B.43	Verify current absorption from Main Bus	0,000A±200mA	0,07 A	
1A-B.44	In the column "ANALOG READOUT" press R Button near Main Power Volt.	Command execute Failed	Command execute Failed	
1A-B.45	Set the CAN BUS board address to 30	30	30	
1A-B.46	Select "CAN BUS I/F Side" to A	A	A	
1A-B.47	In the column "ANALOG READOUT" press R Button near Main Power Volt.	Command execute Failed	Command execute Failed	
1A-B.48	Increase the input voltage to 113V	113V ± 0.2V	113,0 V	
1A-B.49	Take note of power supply output current	1,3A±0,5A	1,32 A	
1A-B.50	Set power supply to 120V	120V ± 0.2V	120,2 V	
1A-B.51	Take note of power supply output current	1,1A±0,5A	1,0 A	
1A-B.52	Press button "RUN Flash" and verify on the command status window	Command execute OK	OK	

DATE:	TEST CONDUCTOR	QA	CUSTOMER
24/07/2009	Albertin A.	Francini E.	

Questo documento contiene informazioni di proprietà di CARLO GAVAZZI SPACE SpA. Tutti i diritti sono riservati.

All information contained in this document are property of CARLO GAVAZZI SPACE SpA. All right reserved.

UUT DATA : Model PFM Item AMS02 POWER DISTRIBUTION SYSTEM C.I. PDS 18 S/N FM01

STEP n°	TEST SEQUENCE	EXPECTED VALUE	MEASURED VALUE	REMARKS
1A-B.53	Set the CAN BUS board address to 31	31	31	
1A-B.54	Select "CAN BUS I/F Side" to B	B	B	
1A-B.55	Press button "RUN Flash" and verify on the command status window	Command execute OK	OK	
1A-B.56	Click on ESEM1-A button	OK	OK	
1A-B.57	Press "READ ALL" button in the column "DIGITAL READOUT"	Command execute OK	OK	
1A-B.58	Verify the following parameter: Board status DCDC 1 OVC DCDC 2 OVC DCDC 1 STATUS DCDC 2 STATUS MAIN POWER STATUS	 0 (OK) 0 (OK) 0 (OK) 1 (ON) 1 (ON) 1 (ON)	 0 (OK) 0 (OK) 0 (OK) 1 (ON) 1 (ON) 1 (ON)	
1A-B.59	Click on Read All command in the column Analog Readout	OK	OK	
1A-B.60	Verify the value of the following telemetries: Temperature Main Power Volt. Analog Ref. 4.0V	 -40°C<T<80C° 120,00V±7,50V 4,000V±150mV	 26°C 118.1V 4.04V	

10.3.2.5.2.2 ESEM 1-A SIDE B OVER VOLTAGE TEST

1A-B.61	Click on PB2-1 button	OK	OK	
1A-B.62	Set to "ON" the line "DCDC OFF/ON CMD" in the "commanding" column"	ON	ON	
1A-B.63	Press "W" button" in the line "DCDC OFF/ON CMD" in the "commanding" column	W	W	
1A-B.64	Verify that in the column Digital Readout under the voice DCDC ON/OFF appears "ON"	ON	ON	
1A-B.65	Click on PB2-2 button	OK	OK	
1A-B.66	Set to "ON" the line "DCDC OFF/ON CMD" in the "commanding" column"	ON	ON	
1A-B.67	Press "W" button" in the line "DCDC OFF/ON CMD" in the "commanding" column	W	W	
1A-B.68	Verify that in the column Digital Readout under the voice DCDC ON/OFF appears "ON"	ON	ON	
1A-B.69	Click on PB2-3 button	OK	OK	
1A-B.70	Set to "ON" the line "DCDC OFF/ON CMD" in the "commanding" column"	ON	ON	
1A-B.71	Press "W" button" in the line "DCDC OFF/ON CMD" in the "commanding" column	W	W	
1A-B.72	Verify that in the column Digital Readout under the voice DCDC ON/OFF appears "ON"	ON	ON	
1A-B.73	Click on PB2-4 button	OK	OK	

DATE:	TEST CONDUCTOR	QA	CUSTOMER
24 /07/2009	Albertin A.	Francini E.	

Questo documento contiene informazioni di proprietà di CARLO GAVAZZI SPACE SpA. Tutti i diritti sono riservati.

All information contained in this document are property of CARLO GAVAZZI SPACE SpA. All right reserved.

UUT DATA : Model PFM Item AMS02 POWER DISTRIBUTION SYSTEM C.I. PDS 18 S/N FM01

STEP n°	TEST SEQUENCE	EXPECTED VALUE	MEASURED VALUE	REMARKS
1A-B.74	Set to "ON" the line "DCDC OFF/ON CMD" in the "commanding" column"	ON	ON	
1A-B.75	Press "W" button" in the line "DCDC OFF/ON CMD" in the "commanding" column	W	W	
1A-B.76	Verify that in the column Digital Readout under the voice DCDC ON/OFF appears "ON"	ON	ON	
1A-B.77	Take note of power supply output current	1,6A±0,5A	1.45 A	All the PB2 DC/DC are ON
1A-B.78	Increase the input voltage to 126V	126V ± 0.2V	126,14 V	
1A-B.79	Click on ESEM1-A button	OK	OK	
1A-B.80	In the column "ANALOG READOUT" press R Button near Main Power Volt	126V ± 4.5V	125,9 V	
1A-B.81	Increase the input voltage to 130V	130V ± 0.2V	130,1 V	
1A-B.82	In the column "ANALOG READOUT" press R Button near Main Power Volt.	130V ± 4.5V	128,0 V	
1A-B.83	Set the input voltage to 153V (up the threshold and accuracy)	153V ± 0,2V	153,2V	Threshold = 150V ± 2V
1A-B.84	Verify current absorption from Main Bus	0,000A±200mA	0,10 A	
1A-B.85	In the column "ANALOG READOUT" press R Button near Main Power Volt.	Command execute Failed	Command execute Failed	
1A-B.86	Set the CAN BUS board address to 30	30	30	
1A-B.87	Select "CAN BUS I/F Side" to A	A	A	
1A-B.88	In the column "ANALOG READOUT" press R Button near Main Power Volt.	Command execute Failed	Command execute Failed	
1A-B.89	Set the input voltage to 126V	126V ± 0.2V	126,11 V	
1A-B.90	Take note of power supply output current	1,0A±0,5A	0,9 A	
1A-B.91	Press button "RUN Flash" and verify on the command status window	Command execute OK	Command execute OK	
1A-B.92	Set power supply to 120V	120V ± 0.2V	120,0 V	
1A-B.93	Take note of power supply output current	1,1A±0,5A	1,0 A	
1A-B.94	Set the CAN BUS board address to 31	31	31	
1A-B.95	Select "CAN BUS I/F Side" to B	B	B	
1A-B.96	Press button "RUN Flash" and verify on the command status window	Command execute OK	Command execute OK	
1A-B.97	Click on ESEM1-A button	OK	OK	
1A-B.98	Press "READ ALL" button in the column "DIGITAL READOUT"	OK	OK	
1A-B.99	Verify the following parameter:			
1A-B.100	Board status	0 (OK)	0 (OK)	
1A-B.101	DCDC 1 OVC	0 (OK)	0 (OK)	
1A-B.102	DCDC 2 OVC	0 (OK)	0 (OK)	
1A-B.103	DCDC 1 STATUS	1 (ON)	1 (ON)	
1A-B.104	DCDC 2 STATUS	1 (ON)	1 (ON)	
1A-B.105	MAIN POWER STATUS	1 (ON)	1 (ON)	

DATE:	TEST CONDUCTOR	QA	CUSTOMER
24 /07/2009	Albertin A.	Francini E.	

Questo documento contiene informazioni di proprietà di CARLO GAVAZZI SPACE SpA. Tutti i diritti sono riservati.

All information contained in this document are property of CARLO GAVAZZI SPACE SpA. All right reserved.

UUT DATA :	Model	PFM	Item	AMS02 POWER DISTRIBUTION SYSTEM	C.I.	PDS 18	S/N	FM01

STEP n°	TEST SEQUENCE	EXPECTED VALUE	MEASURED VALUE	REMARKS
1A-B.106	Verify the value of the following telemetries: Temperature Main Power Volt. Analog Ref. 4.0V	 -40°C<T<80C° 120,00V±7,50V 4,000V±150mV	 27,3 °C 121,2 V 4,01 V	

10.3.2.5.2.3 ESEM 1-A SIDE B GLOBAL ON/OFF TEST

1A-B.1	Set OFF in the Global ON/OFF window and click on relative "W" command	OFF	OFF	
1A-B.2	Verify current absorption from Main Bus	0,000A±200mA	0,085 A	
1A-B.3	Press "READ ALL" button in the column "DIGITAL READOUT"	OK	OK	
1A-B.4	Verify that appears the message "Command execution failed!"	Command execution failed!	Command execution failed!	
1A-B.5	Perform a power cycle OFF/ON on the main bus	OK	OK	
1A-B.6	Click on Run flash button	OK	OK	
1A-B.7	Click on Read all command under Digital Readout column and verify that appears the message "Command executed O.K."	Command executed OK	Command executed OK	
1A-B.8	Verify that the value of Board status in Digital Readout column in "OK"	OK	OK	
1A-B.9	Set the CAN BUS board address to 30	30	30	
1A-B.10	Select "CAN BUS I/F Side" to A	A	A	
1A-B.11	Click on Run flash button	OK	OK	
1A-B.12	Click on Read all command under Digital Readout column and verify that appears the message "Command executed O.K."	Command executed OK	Command executed OK	
1A-B.13	Verify that the value of Board status in Digital Readout column in "OK"	OK	OK	
1A-B.14	Set OFF in the Global ON/OFF window and click on relative "W" command	OK	OK	
1A-B.15	Verify current absorption from Main Bus	0,000A±200mA	0,070 A	
1A-B.16	Press "READ ALL" button in the column "DIGITAL READOUT"	OK	OK	
1A-B.17	Verify that appears the message "Command execution failed!"	Command execution failed!	Command execution failed!	
1A-B.18	Perform a power cycle OFF/ON on the main bus	OK	OK	
1A-B.19	Set the CAN BUS board address to 31	31	31	
1A-B.20	Select "CAN BUS I/F Side" to B	B	B	
1A-B.21	Click on Run flash button	OK	OK	
1A-B.22	Click on Read all command under Digital Readout column and verify that appears the message "Command executed O.K."	Command executed OK	Command executed OK	
1A-B.23	Verify that the value of Board status in Digital Readout column in "OK"	OK	OK	
1A-B.24	Switch OFF main power bus	OFF	OFF	

DATE:	TEST CONDUCTOR	QA	CUSTOMER
24 /07/2009	Albertin A.	Francini E.	

Questo documento contiene informazioni di proprietà di CARLO GAVAZZI SPACE SpA. Tutti i diritti sono riservati.

All information contained in this document are property of CARLO GAVAZZI SPACE SpA. All right reserved.

UUT DATA : Model PFM Item AMS02 POWER DISTRIBUTION SYSTEM C.I. PDS 18 S/N FM01

10.3.2.5.3 PB2-1 SIDE B

STEP n°	TEST SEQUENCE	EXPECTED VALUE	MEASURED VALUE	REMARKS
PB2-1-B.1	Connect BI_120V and BI_120V_RTN power supply signals	OK	OK	
PB2-1-B.2	Verify that all the cables of the section are connected	OK	OK	
PB2-1-B.3	Launch the PDS controller software	Program open	Program open	
PB2-1-B.4	Set to "FM" the window Model	OK	OK	
PB2-1-B.5	Select "PDS Side" to B	B	B	
PB2-1-B.6	Set the CAN BUS board address to 31	31	31	
PB2-1-B.7	Select JMDC = 0	0	0	
PB2-1-B.8	Select TX = A	A	A	
PB2-1-B.9	Select RX = A	A	A	
PB2-1-B.10	Select "CAN BUS I/F Side" to B	B	B	
PB2-1-B.11	Set input bus voltage to 120V	120V±1V	120,05 V	
PB2-1-B.12	Set input bus current limitation to ~~15A~~ 27.5A	27,5A ~~15A~~±1A	27,5 A	See PVS-02
PB2-1-B.13	Enable power supply output	enabled	enabled	
PB2-1-B.14	Verify that green led of "power switch box" is lighted	Green led ligthed	Green led ligthed	
PB2-1-B.15	Switch ON the "power switch "of "power switch box"	Switch ON	Switch ON	
PB2-1-B.16	Verify that red led of "power switch box" is lighted	Red led ligthed	Red led ligthed	
PB2-1-B.17	Take note of power supply output current	1,1A±0,5A	0,99 A	
PB2-1-B.18	Click on Run flash button	OK	OK	
PB2-1-B.19	Set the CAN BUS board address to 30	30	30	
PB2-1-B.20	Select "CAN BUS I/F Side" to A	A	A	
PB2-1-B.21	Click on Run flash button	OK	OK	
PB2-1-B.22	Set the CAN BUS board address to 31	31	31	
PB2-1-B.23	Select "CAN BUS I/F Side" to B	B	B	
PB2-1-B.24	Click on PB2-4 button	OK	OK	This board is default ON
PB2-1-B.25	Set Digital I/F Test logic value = 1 in "Commanding" column	1	1	Button located on left side of software window
PB2-1-B.26	Click on letter "W" on the right of the "1" value	OK	OK	
PB2-1-B.27	Click on the command READ ALL under the column Digital Readout	OK	OK	
PB2-1-B.28	Verify that in the column Digital Readout under the voice Digital I/F Test appears "1"	1	1	
PB2-1-B.29	Set Digital I/F Test logic value = 0 in "Commanding" column	0	0	
PB2-1-B.30	Click on letter "W" on the right of the "0" value	OK	OK	
PB2-1-B.31	Click on the command READ ALL under the column Digital Readout	OK	OK	
PB2-1-B.32	Verify that in the column Digital Readout under the voice Digital I/F Test appears "0"	0	0	
PB2-1-B.33	Verify the status of the following flags: BOARD STATUS	OK	OK	

DATE:	TEST CONDUCTOR	QA	CUSTOMER
24 /07/2009	Albertin A.	Francini E.	

Questo documento contiene informazioni di proprietà di CARLO GAVAZZI SPACE SpA. Tutti i diritti sono riservati.

All information contained in this document are property of CARLO GAVAZZI SPACE SpA. All right reserved.

UUT DATA : Model PFM Item AMS02 POWER DISTRIBUTION SYSTEM C.I. PDS 18 S/N FM01

STEP n°	TEST SEQUENCE	EXPECTED VALUE	MEASURED VALUE	REMARKS
	OVT ALARM Input OVC Alarm DCDC ON/OFF 27V UV 29V Trip DCDC OFF/ON CMD	OK OK ON OK OK ON	OK OK ON OK OK ON	
PB2-1-B.34	Read on display the voltage on ESEM 3A-1 out 3 (Check that load is not connected)	28,00V±1,00V	28,15 V	V1
PB2-1-B.35	Verify the value of the following telemetry: Output Voltage	V1±1.092V	28,17 V	Click on relative Rbutton
PB2-1-B.36	Set OFF on DCDC ON /OFF command window and send the command	OK	OK	Power cell OFF
PB2-1-B.37	Click on the command READ ALL under the column Digital Readout	OK	OK	
PB2-1-B.38	Verify the status of the following flags: BOARD STATUS OVT ALARM Input OVC Alarm DCDC ON/OFF 27V UNV 29V Trip DCDC OFF/ON CMD	OK OK OK OFF OK OK OFF	OK OK OK OFF OK OK OFF	
PB2-1-B.39	Click on the command READ ALL under the column Analog Readout	OK	OK	
PB2-1-B.40	Verify the value of the following telemetries: Temperature Analog Ref. 2.0V	-40°C<T<80C° 2,000V±150mV	32,92 °C 2,03 V	
PB2-1-B.41	Verify the following analog monitor: Output Voltage	0,00V±1.092V	0,00V	
PB2-1-B.42	Read on display the voltage on ESEM 3-A 1 out 3 (Check that load is not connected)	0,00V±0,10V	-0,02 V	
PB2-1-B.43	Set the CAN BUS board address to 30	30	30	
PB2-1-B.44	Select "CAN BUS I/F Side" to A	A	A	
PB2-1-B.45	Click on the command READ ALL under the column Digital Readout	OK	OK	
PB2-1-B.46	Verify the status of the following flags: BOARD STATUS OVT ALARM Input OVC Alarm DCDC ON/OFF 27V UNV 29V Trip DCDC OFF/ON CMD	OK OK OK OFF OK OK OFF	OK OK OK OFF OK OK OFF	
PB2-1-B.47	Set ON on DCDC OFF/ON command window and send the command	OK	OK	Power cell ON

DATE:	TEST CONDUCTOR	QA	CUSTOMER
26/07/2009	Albertin A.	Francini E.	

Questo documento contiene informazioni di proprietà di CARLO GAVAZZI SPACE SpA. Tutti i diritti sono riservati.

All information contained in this document are property of CARLO GAVAZZI SPACE SpA. All right reserved.

UUT DATA : Model PFM Item AMS02 POWER DISTRIBUTION SYSTEM C.I. PDS 18 S/N FM01

STEP n°	TEST SEQUENCE	EXPECTED VALUE	MEASURED VALUE	REMARKS
PB2-1-B.48	Click on the command READ ALL under the column Digital Readout	OK	OK	
PB2-1-B.49	Verify the status of the following flags:			
	BOARD STATUS	OK	OK	
	OVT ALARM	OK	OK	
	Input OVC Alarm	OK	OK	
	DCDC ON/OFF	ON	ON	
	27V UNV	OK	OK	
	29V Trip	OK	OK	
	DCDC OFF/ON CMD	ON	ON	
PB2-1-B.50	Read on display the voltage on ESEM 3-A 1 out 3 (Check that load is not connected)	28,00V±1,00V	28,1 V	
PB2-1-B.51	Set the CAN BUS board address to 31	31	31	
PB2-1-B.52	Select "CAN BUS I/F Side" to B	B	B	
PB2-1-B.53	Click on the command READ ALL under the column Digital Readout	OK	OK	
PB2-1-B.54	Verify the status of the following flags:			
	BOARD STATUS	OK	OK	
	OVT ALARM	OK	OK	
	Input OVC Alarm	OK	OK	
	DCDC ON/OFF	ON	ON	
	27V UNV	OK	OK	
	29V Trip	OK	OK	
	DCDC OFF/ON CMD	ON	ON	

Questo documento contiene informazioni di proprietà di CARLO GAVAZZI SPACE SpA. Tutti i diritti sono riservati.

All information contained in this document are property of CARLO GAVAZZI SPACE SpA. All right reserved.

UUT DATA :	Model	PFM	Item	AMS02 POWER DISTRIBUTION SYSTEM	C.I.	PDS 18	S/N	FM01

10.3.2.5.4 ESEM 3A-1 SIDE B

STEP n°	TEST SEQUENCE	EXPECTED VALUE	MEASURED VALUE	REMARKS
3A-1-B.1	Click on ESEM 3A-1 button	OK	OK	Button located on left side of software window
3A-1-B.2	Connect to active loads outlet 1, 2, 3, 4, 5, 6, 7 and 8.	OK	OK	
3A-1-B.3	Verify that loads are set to 0A current absorption	OK	OK	
3A-1-B.4	Set Digital I/F Test logic value = 1 in "Commanding" column	1	1	
3A-1-B.5	Click on letter "W" on the right of the "1" value	OK	OK	
3A-1-B.6	Click on the command READ ALL under the column Digital Readout	OK	OK	
3A-1-B.7	Verify that in the column Digital Readout under the voice Digital I/F Test appears "1"	1	1	
3A-1-B.8	Set Digital I/F Test logic value = 0 in "Commanding" column	0	0	
3A-1-B.9	Click on letter "W" on the right of the "0" value	OK	OK	
3A-1-B.10	Click on the command READ ALL under the column Digital Readout	OK	OK	
3A-1-B.11	Verify that in the column Digital Readout under the voice Digital I/F Test appears "0"	0	0	
3A-1-B.12	Set ON in the window All Outlets ON/OFF and push the relative "W" command	OK	OK	
3A-1-B.13	Read on display the voltage on this ESEM 3-A loads: O_1: TPD3 O_2: TPD7 O_3: JPD_N O_4: SPD1_N O_5: UGPD_N O_6:SPD0_R O_7: TPD1 O_8:TTPD_R	 28,00V±1,00V 28,00V±1,00V 28,00V±1,00V 28,00V±1,00V 28,00V±1,00V 28,00V±1,00V 28,00V±1,00V 28,00V±1,00V	28,05 V (ALL)	
3A-1-B.14	Click on Read All command in Digital Readout column	OK	OK	
3A-1-B.15	Verify the status of the following flags: BOARD STATUS OVT Alarm From O_1 CMD: TPD3 to O_8 CMD: TTPD_R From O_1 Status: TPD3 to O_8 Status: TTPD_R	 OK OK ON ON	 OK OK ON ON	
3A-1-B.16	Set the CAN BUS board address to 30	30	30	
3A-1-B.17	Select "CAN BUS I/F Side" to A	A	A	
3A-1-B.18	Click on Read All command in Digital Readout column	OK	OK	
3A-1-B.19	Verify the status of the following flags: BOARD STATUS OVT Alarm From O_1 CMD: TPD3 to O_8 CMD: TTPD_R	 OK OK ON	 OK OK ON	

DATE:	TEST CONDUCTOR	QA	CUSTOMER
24 /07/2009	Albertin A.	Francini E.	

Questo documento contiene informazioni di proprietà di CARLO GAVAZZI SPACE SpA. Tutti i diritti sono riservati.

All information contained in this document are property of CARLO GAVAZZI SPACE SpA. All right reserved.

UUT DATA : Model PFM Item AMS02 POWER DISTRIBUTION SYSTEM C.I. PDS 18 S/N FM01

STEP n°	TEST SEQUENCE	EXPECTED VALUE	MEASURED VALUE	REMARKS
	From O_1 Status: TPD3 to O_8 Status: TTPD_R	ON	ON	
3A-1-B.20	Generate a short circuit on the passive load keyboards: From O_1: TPD3 to O_8: TTPD_R	OK	OK	
3A-1-B.21	Read on display the voltage on this ESEM 3-A loads: O_1: TPD3 O_2: TPD7 O_3: JPD_N O_4: SPD1_N O_5: UGPD_N O_6:SPD0_R O_7: TPD1 O_8:TTPD_R	 0,00V<V<1,00V 0,00V<V<1,00V 0,00V<V<1,00V 0,00V<V<1,00V 0,00V<V<1,00V 0,00V<V<1,00V 0,00V<V<1,00V 0,00V<V<1,00V	 0,00 V (ALL)	
3A-1-B.22	Click on Read All command in Digital Readout column	OK	OK	
3A-1-B.23	Verify the status of the following flags: BOARD STATUS OVT Alarm From O_1 CMD: TPD3 to O_8 CMD: TTPD_R From O_1 Status: TPD3 to O_8 Status: TTPD_R	 **NOK** OK ON **OFF**	 **NOK** OK ON **OFF**	
3A-1-B.24	Set the CAN BUS board address to 31	31	31	
3A-1-B.25	Select "CAN BUS I/F Side" to B	B	B	
3A-1-B.26	Click on Read All command in Digital Readout column	OK	OK	
3A-1-B.27	Verify the status of the following flags: BOARD STATUS OVT Alarm From O_1 CMD: TPD3 to O_8 CMD: TTPD_R From O_1 Status: TPD3 to O_8 Status: TTPD_R	 **NOK** OK ON **OFF**	 **NOK** OK ON **OFF**	
3A-1-B.28	Set OFF in the window All Outlets ON/OFF and push the relative "W" command	OK	OK	
3A-1-B.29	Set ON in the window All Outlets ON/OFF and push the relative "W" command	OK	OK	
3A-1-B.30	Click on Read All command in Digital Readout column	OK	OK	
3A-1-B.31	Verify the status of the following flags: BOARD STATUS OVT Alarm From O_1 CMD: TPD3 to O_8 CMD: TTPD_R From O_1 Status: TPD3 to O_8 Status: TTPD_R	 **OK** OK ON **ON**	 **OK** OK ON **ON**	
3A-1-B.32	Set the CAN BUS board address to 30	30	30	
3A-1-B.33	Select "CAN BUS I/F Side" to A	A	A	
3A-1-B.34	Click on Read All command in Digital Readout column	OK	OK	

DATE:	TEST CONDUCTOR	QA	CUSTOMER
26 /07/2009	Albertin A.	Francini E.	

Questo documento contiene informazioni di proprietà di CARLO GAVAZZI SPACE SpA. Tutti i diritti sono riservati.

All information contained in this document are property of CARLO GAVAZZI SPACE SpA. All right reserved.

UUT DATA : Model PFM Item AMS02 POWER DISTRIBUTION SYSTEM C.I. PDS 18 S/N FM01

STEP n°	TEST SEQUENCE	EXPECTED VALUE	MEASURED VALUE	REMARKS
3A-1-B.35	Verify the status of the following flags: BOARD STATUS OVT Alarm From O_1 CMD: TPD3 to O_8 CMD: TTPD_R From O_1 Status: TPD3 to O_8 Status: TTPD_R	 OK OK ON ON	 OK OK ON ON	
3A-1-B.36	Using board telemetries set to 2A current absorption all the outlets: From O_1: TPD3 to O_8: TTPD_R	OK	OK	Set active loads to constant current mode. Set current on display with 100mA above the desired value with the exception of out8 that is correct.
3A-1-B.37	Push on Read All button in Analog Readout column	OK	OK	
3A-1-B.38	Verify the telemetries: O_1 Current: TPD3 O_2 Current: TPD3 O_3 Current: JPD_N O_4 Current: SPD1_N O_5 Current: UGPD_N O_6 Current: SPD0_R O_7 Current: TPD1 O_8 Current: TTPD_R Temperature Analog Ref. 3.0V	 2,000A±0,225A 2,000A±0,225A 2,000A±0,225A 2,000A±0,225A 2,000A±0,225A 2,000A±0,225A 2,000A±0,225A 2,00A±0,45A -40°C<T<80C° 3,000V±250mV	 2,04 A 2,05 A 2,07 A 2,06 A 2,05 A 2,10 A 2,07 A 2,12 A 27,96 V 2,98 V	
3A-1-B.39	Set the CAN BUS board address to 31	31	31	
3A-1-B.40	Select "CAN BUS I/F Side" to B	B	B	
3A-1-B.41	Push on Read All button in Analog Readout column	OK	OK	
3A-1-B.42	Verify the telemetries: O_1 Current: TPD3 O_2 Current: TPD3 O_3 Current: JPD_N O_4 Current: SPD1_N O_5 Current: UGPD_N O_6 Current: SPD0_R O_7 Current: TPD1 O_8 Current: TTPD_R Temperature Analog Ref. 3.0V	 2,000A±0,225A 2,000A±0,225A 2,000A±0,225A 2,000A±0,225A 2,000A±0,225A 2,000A±0,225A 2,000A±0,225A 2,00A±0,45A -40°C<T<80C° 3,000V±250mV	 2,06 A 2,03 A 2,07 A 2,06 A 2,03 A 2,09 A 2,08 A 2,11 A 30 °C 2,98 V	
3A-1-B.43	Set to 0A current absorption all the outlets: From O_1: TPD3 to O_8: TTPD_R	OK	OK	
3A-1-B.44	Set OFF in the window All Outlets ON/OFF and push the relative "W" command	OK	OK	

DATE:	TEST CONDUCTOR	QA	CUSTOMER
24 /07/2009	Albertin A.	Francini E.	

Questo documento contiene informazioni di proprietà di CARLO GAVAZZI SPACE SpA. Tutti i diritti sono riservati.

All information contained in this document are property of CARLO GAVAZZI SPACE SpA. All right reserved.

UUT DATA :	Model	PFM	Item	AMS02 POWER DISTRIBUTION SYSTEM	C.I.	PDS 18	S/N	FM01

STEP n°	TEST SEQUENCE	EXPECTED VALUE	MEASURED VALUE	REMARKS
3A-1-B.45	Click on Raed all to in Digital readout column	OK	OK	
3A-1-B.46	Verify from digital readout column that all outlets are OFF	OK	OK	

DATE:	TEST CONDUCTOR	QA	CUSTOMER
26 /07/2009	Albertin A.	Francini E.	

Questo documento contiene informazioni di proprietà di CARLO GAVAZZI SPACE SpA. Tutti i diritti sono riservati.

All information contained in this document are property of CARLO GAVAZZI SPACE SpA. All right reserved.

UUT DATA :	Model	PFM	Item	AMS02 POWER DISTRIBUTION SYSTEM	C.I.	PDS 18	S/N	FM01

10.3.2.5.5 PB2-2 SIDE B

STEP n°	TEST SEQUENCE	EXPECTED VALUE	MEASURED VALUE	REMARKS
PB2-2-B.1	Connect BI_120V and BI_120V_RTN power supply signals	OK	OK	
PB2-2-B.2	Verify that all the cables of the section are connected	OK	OK	
PB2-2-B.3	Launch the PDS controller software	Program open	Program open	
PB2-2-B.4	Set to "FM" the window Model	OK	OK	
PB2-2-B.5	Select "PDS Side" to B	B	B	
PB2-2-B.6	Set the CAN BUS board address to 31	31	31	
PB2-2-B.7	Select JMDC = 0	0	0	
PB2-2-B.8	Select TX = A	A	A	
PB2-2-B.9	Select RX = A	A	A	
PB2-2-B.10	Select "CAN BUS I/F Side" to B	B	B	
PB2-2-B.11	Set input bus voltage to 120V	120V±1V	120,05 V	
PB2-2-B.12	Set input bus current limitation to ~~15A~~ 27.5A	27,5A ~~15A~~±1A	27,5 A	See PVS-02
PB2-2-B.13	Enable power supply output	enabled	enabled	
PB2-2-B.14	Verify that green led of "power switch box" is lighted	Green led ligthed	Green led ligthed	
PB2-2-B.15	Switch ON the "power switch "of "power switch box"	Switch ON	Switch ON	
PB2-2-B.16	Verify that red led of "power switch box" is lighted	Red led ligthed	Red led ligthed	
PB2-2-B.17	Take note of power supply output current	1,1A±0,5A	0,98 A	
PB2-2-B.18	Click on Run flash button	OK	OK	
PB2-2-B.19	Set the CAN BUS board address to 30	30	30	
PB2-2-B.20	Select "CAN BUS I/F Side" to A	A	A	
PB2-2-B.21	Click on Run flash button	OK	OK	
PB2-2-B.22	Set the CAN BUS board address to 31	31	31	
PB2-2-B.23	Select "CAN BUS I/F Side" to B	B	B	
PB2-2-B.24	Click on PB2-2 button	OK	OK	This board is default OFF
PB2-2-B.25	Set Digital I/F Test logic value = 1 in "Commanding" column	1	1	Button located on left side of software window
PB2-2-B.26	Click on letter "W" on the right of the "1" value	OK	OK	
PB2-2-B.27	Click on the command READ ALL under the column Digital Readout	OK	OK	
PB2-2-B.28	Verify that in the column Digital Readout under the voice Digital I/F Test appears "1"	1	1	
PB2-2-B.29	Set Digital I/F Test logic value = 0 in "Commanding" column	0	0	
PB2-2-B.30	Click on letter "W" on the right of the "0" value	OK	OK	
PB2-2-B.31	Click on the command READ ALL under the column Digital Readout	OK	OK	
PB2-2-B.32	Verify that in the column Digital Readout under the voice Digital I/F Test appears "0"	0	0	
PB2-2-B.33	Click on the command READ ALL under the column Digital Readout	OK	OK	
PB2-2-B.34	Verify the status of the following flags:			

DATE:	TEST CONDUCTOR	QA	CUSTOMER
24/07/2009	Albertin A.	Francini E.	

Questo documento contiene informazioni di proprietà di CARLO GAVAZZI SPACE SpA. Tutti i diritti sono riservati.

All information contained in this document are property of CARLO GAVAZZI SPACE SpA. All right reserved.

UUT DATA : Model PFM Item AMS02 POWER DISTRIBUTION SYSTEM C.I. PDS 18 S/N FM01

STEP n°	TEST SEQUENCE	EXPECTED VALUE	MEASURED VALUE	REMARKS
	BOARD STATUS	OK	OK	
	OVT ALARM	OK	OK	
	Input OVC Alarm	OK	OK	
	DCDC ON/OFF	OFF	OFF	
	27V UV	OK	OK	
	29V Trip	OK	OK	
	DCDC OFF/ON CMD	OFF	OFF	
PB2-2-B.35	Click on the command READ ALL under the column Analog Readout	OK	OK	
PB2-2-B.36	Verify the value of the following telemetries: Temperature Analog Ref. 2.0V	 -40°C<T<80C° 2,000V±150mV	 25,6 °C 2,03 V	
PB2-2-B.37	Set the CAN BUS board address to 30	30	30	
PB2-2-B.38	Select "CAN BUS I/F Side" to A	A	A	
PB2-2-B.39	Click on the command READ ALL under the column Digital Readout	OK	OK	
PB2-2-B.40	Verify the status of the following flags: BOARD STATUS OVT ALARM Input OVC Alarm DCDC ON/OFF 27V UNV 29V Trip DCDC OFF/ON CMD	 OK OK OK OFF OK OK OFF	 OK OK OK OFF OK OK OFF	
PB2-2-B.41	Set ON on DCDC OFF/ON command window and send the command	OK	OK	Power cell ON
PB2-2-B.42	Click on the command READ ALL under the column Digital Readout	OK	OK	
PB2-2-B.43	Verify the status of the following flags: BOARD STATUS OVT ALARM Input OVC Alarm DCDC ON/OFF 27V UNV 29V Trip DCDC OFF/ON CMD	 OK OK OK ON OK OK ON	 OK OK OK ON OK OK ON	
PB2-2-B.44	Click on ESEM 3A-2 button	OK	OK	
PB2-2-B.45	Set ON in the window "O_1: ER1_N" and push the relative "W" command	OK	OK	
PB2-2-B.46	Read on display the voltage on ESEM 3A 2 out 1 (Check that load is not connected)	28,00V±1,00V	28,11 V	V1
PB2-2-B.47	Click on PB2-2 button	OK	OK	
PB2-2-B.48	Click on the command READ ALL under the column Analog Readout	OK	OK	
PB2-2-B.49	Verify the value of the following telemetry:			Click on relative Rbutton

DATE:	TEST CONDUCTOR	QA	CUSTOMER
24 /07/2009	Albertin A.	Francini E.	

Questo documento contiene informazioni di proprietà di CARLO GAVAZZI SPACE SpA. Tutti i diritti sono riservati.

All information contained in this document are property of CARLO GAVAZZI SPACE SpA. All right reserved.

UUT DATA : Model **PFM** Item **AMS02 POWER DISTRIBUTION SYSTEM** C.I. **PDS 18** S/N **FM01**

STEP n°	TEST SEQUENCE	EXPECTED VALUE	MEASURED VALUE	REMARKS
	Output Voltage	V1±1.092V	28,2 V	V1 indicated on step PB2-2-B.46
PB2-2-B.50	Set the CAN BUS board address to 31	31	31	
PB2-2-B.51	Select "CAN BUS I/F Side" to B	B	B	
PB2-2-B.52	Click on the command READ ALL under the column Digital Readout	OK	OK	
PB2-2-B.53	Verify the status of the following flags:			
	BOARD STATUS	OK	OK	
	OVT ALARM	OK	OK	
	Input OVC Alarm	OK	OK	
	DCDC ON/OFF	ON	ON	
	27V UNV	OK	OK	
	29V Trip	OK	OK	
	DCDC OFF/ON CMD	ON	ON	

DATE:	TEST CONDUCTOR	QA	CUSTOMER
24 /07/2009	Albertin A.	Francini E.	

Questo documento contiene informazioni di proprietà di CARLO GAVAZZI SPACE SpA. Tutti i diritti sono riservati.

All information contained in this document are property of CARLO GAVAZZI SPACE SpA. All right reserved.

UUT DATA :	Model	PFM	Item	AMS02 POWER DISTRIBUTION SYSTEM	C.I.	PDS 18	S/N	FM01

10.3.2.5.6 ESEM 3A-2 SIDE B

STEP n°	TEST SEQUENCE	EXPECTED VALUE	MEASURED VALUE	REMARKS
3A-2-B.1	Click on ESEM3-A-2 button	OK	OK	Button located on left side of software window
3A-2-B.2	Connect to active loads outlet 1, 2, 3, 4, 5, 6, 7 and 8.	OK	OK	
3A-2-B.3	Verify that loads are set to 0A current absorption	OK	OK	
3A-2-B.4	Set Digital I/F Test logic value = 1 in "Commanding" column	1	1	
3A-2-B.5	Click on letter "W" on the right of the "1" value	OK	OK	
3A-2-B.6	Click on the command READ ALL under the column Digital Readout	OK	OK	
3A-2-B.7	Verify that in the column Digital Readout under the voice Digital I/F Test appears "1"	1	1	
3A-2-B.8	Set Digital I/F Test logic value = 0 in "Commanding" column	0	0	
3A-2-B.9	Click on letter "W" on the right of the "0" value	OK	OK	
3A-2-B.10	Click on the command READ ALL under the column Digital Readout	OK	OK	
3A-2-B.11	Verify that in the column Digital Readout under the voice Digital I/F Test appears "0"	0	0	
3A-2-B.12	Set ON in the window All Outlets ON/OFF and push the relative "W" command	OK	OK	
3A-2-B.13	Read on display the voltage on this ESEM 3-A loads: O_1: ER1_N O_2: TPD2 O_3: TPD6 O_4: SPD3_N O_5: MPD_N O_6: UPD1 O_7: SPD2_N O_8: CAB_R	 28,00V±1,00V 28,00V±1,00V 28,00V±1,00V 28,00V±1,00V 28,00V±1,00V 28,00V±1,00V 28,00V±1,00V 28,00V±1,00V	28,0 V (ALL)	
3A-2-B.14	Click on Read All command in Digital Readout column	OK	OK	
3A-2-B.15	Verify the status of the following flags: BOARD STATUS OVT Alarm From O_1 CMD: ER1_N to O_8 CMD: CAB_R From O_1 Status: ER1_N to O_8 Status: CAB_R	 OK OK ON ON	 OK OK ON ON	
3A-2-B.16	Set the CAN BUS board address to 30	30	30	
3A-2-B.17	Select "CAN BUS I/F Side" to A	A	A	
3A-2-B.18	Click on Read All command in Digital Readout column	OK	OK	
3A-2-B.19	Verify the status of the following flags: BOARD STATUS OVT Alarm From O_1 CMD: ER1_N to O_8 CMD: CAB_R From O_1 Status: ER1_N to O_8 Status: CAB_R	 OK OK ON ON	 OK OK ON ON	

DATE:	TEST CONDUCTOR	QA	CUSTOMER
24 /07/2009	Albertin A.	Francini E.	

Questo documento contiene informazioni di proprietà di CARLO GAVAZZI SPACE SpA. Tutti i diritti sono riservati.

All information contained in this document are property of CARLO GAVAZZI SPACE SpA. All right reserved.

UUT DATA : Model PFM Item AMS02 POWER DISTRIBUTION SYSTEM C.I. PDS 18 S/N FM01

STEP n°	TEST SEQUENCE	EXPECTED VALUE	MEASURED VALUE	REMARKS
3A-2-B.20	Generate a short circuit on the passive load keyboards: From O_1: ER1_N to O_8: CAB_R	OK	OK	
3A-2-B.21	Read on display the voltage on this ESEM 3-A loads: O_1: ER1_N O_2: TPD2 O_3: TPD6 O_4: SPD3_N O_5: MPD_N O_6: UPD1 O_7: SPD2_N O_8: CAB_R	0,00V<V<1,00V 0,00V<V<1,00V 0,00V<V<1,00V 0,00V<V<1,00V 0,00V<V<1,00V 0,00V<V<1,00V 0,00V<V<1,00V 0,00V<V<1,00V	0,0 V (ALL)	
3A-2-B.22	Click on Read All command in Digital Readout column	OK	OK	
3A-2-B.23	Verify the status of the following flags: BOARD STATUS OVT Alarm From O_1 CMD: ER1_N to O_8 CMD: CAB_R From O_1 Status: ER1_N to O_8 Status: CAB_R	**NOK** OK ON **OFF**	**NOK** OK ON **OFF**	
3A-2-B.24	Set the CAN BUS board address to 31	31	31	
3A-2-B.25	Select "CAN BUS I/F Side" to B	B	B	
3A-2-B.26	Click on Read All command in Digital Readout column	OK	OK	
3A-2-B.27	Verify the status of the following flags: BOARD STATUS OVT Alarm From O_1 CMD: ER1_N to O_8 CMD: CAB_R From O_1 Status: ER1_N to O_8 Status: CAB_R	**NOK** OK ON **OFF**	**NOK** OK ON **OFF**	
3A-2-B.28	Set OFF in the window All Outlets ON/OFF and push the relative "W" command	OK	OK	
3A-2-B.29	Set ON in the window All Outlets ON/OFF and push the relative "W" command	OK	OK	
3A-2-B.30	Click on Read All command in Digital Readout column	OK	OK	
3A-2-B.31	Verify the status of the following flags: BOARD STATUS OVT Alarm From O_1 CMD: ER1_N to O_8 CMD: CAB_R From O_1 Status: ER1_N to O_8 Status: CAB_R	**OK** OK ON **ON**	**OK** OK ON **ON**	
3A-2-B.32	Set the CAN BUS board address to 30	30	30	
3A-2-B.33	Select "CAN BUS I/F Side" to A	A	A	
3A-2-B.34	Click on Read All command in Digital Readout column	OK	OK	
3A-2-B.35	Verify the status of the following flags: BOARD STATUS	**OK**	**OK**	

DATE:	TEST CONDUCTOR	QA	CUSTOMER
24 /07/2009	Albertin A.	Francini E.	

Questo documento contiene informazioni di proprietà di CARLO GAVAZZI SPACE SpA. Tutti i diritti sono riservati.

All information contained in this document are property of CARLO GAVAZZI SPACE SpA. All right reserved.

UUT DATA : Model PFM Item AMS02 POWER DISTRIBUTION SYSTEM C.I. PDS 18 S/N FM01

STEP n°	TEST SEQUENCE	EXPECTED VALUE	MEASURED VALUE	REMARKS
	OVT Alarm From O_1 CMD: ER1_N to O_8 CMD: CAB_R From O_1 Status: ER1_N to O_8 Status: CAB_R	OK ON ON	OK ON ON	
3A-2-B.36	Using board telemetries set to 2A current absorption all the outlets: From O_1: ER1_N to O_8: CAB_R	OK	OK	Set active loads to constant current mode. Set current on display with 100mA above the desired value with the exception of out8 that is correct.
3A-2-B.37	Push on Read All button in Analog Readout column	OK	OK	
3A-2-B.38	Verify the telemetries: O_1 Current: ER1_N O_2 Current: TPD2 O_3 Current: TPD6 O_4 Current: SPD3_N O_5 Current: MPD_N O_6 Current: UPD1 O_7 Current: SPD2_N O_8 Current: CAB_R Temperature Analog Ref. 3.0V	 2,000A±0,225A 2,000A±0,225A 2,000A±0,225A 2,000A±0,225A 2,000A±0,225A 2,000A±0,225A 2,000A±0,225A 2,00A±0,45A -40°C<T<80C° 3,000V±250mV	 2,03 A 2,16 A 2,04 A 2,08 A 2,10 A 2,13 A 2,14 A 2,16 A 27,0 °C 2,97 V	
3A-2-B.39	Set the CAN BUS board address to 31	31	31	
3A-2-B.40	Select "CAN BUS I/F Side" to B	B	B	
3A-2-B.41	Push on Read All button in Analog Readout column	OK	OK	
3A-2-B.42	Verify the telemetries: O_1 Current: ER1_N O_2 Current: TPD2 O_3 Current: TPD6 O_4 Current: SPD3_N O_5 Current: MPD_N O_6 Current: UPD1 O_7 Current: SPD2_N O_8 Current: CAB_R Temperature Analog Ref. 3.0V	 2,000A±0,225A 2,000A±0,225A 2,000A±0,225A 2,000A±0,225A 2,000A±0,225A 2,000A±0,225A 2,000A±0,225A 2,00A±0,45A -40°C<T<80C° 3,000V±250mV	 2,03 A 2,22 A 2,08 A 2,15 A 2,10 A 2,21 A 2,12 A 2,17 A 28°C 2,98 V	
3A-2-B.43	Set to 0A current absorption all the outlets: From O_1: TPD3 to O_8: TTPD_R	OK	OK	
3A-2-B.44	Set OFF in the window All Outlets ON/OFF and push the relative "W" command	OK	OK	
3A-2-B.45	Click on Raed all to in Digital readout column	OK	OK	
3A-2-B.46	Verify from digital readout column that all outlets are OFF	OK	OK	

DATE:	TEST CONDUCTOR	QA	CUSTOMER
29/07/2009	Albertin A.	Francini E.	

Questo documento contiene informazioni di proprietà di CARLO GAVAZZI SPACE SpA. Tutti i diritti sono riservati.

All information contained in this document are property of CARLO GAVAZZI SPACE SpA. All right reserved.

UUT DATA : Model PFM Item AMS02 POWER DISTRIBUTION SYSTEM C.I. PDS 18 S/N FM01

10.3.2.5.7 PB2-3 SIDE B

STEP n°	TEST SEQUENCE	EXPECTED VALUE	MEASURED VALUE	REMARKS
PB2-3-B.1	Connect BI_120V and BI_120V_RTN power supply signals	OK	OK	
PB2-3-B.2	Verify that all the cables of the section are connected	OK	OK	
PB2-3-B.3	Launch the PDS controller software	Program open	Program open	
PB2-3-B.4	Set to "FM" the window Model	OK	OK	
PB2-3-B.5	Select "PDS Side" to B	B	B	
PB2-3-B.6	Set the CAN BUS board address to 31	31	31	
PB2-3-B.7	Select JMDC = 0	0	0	
PB2-3-B.8	Select TX = A	A	A	
PB2-3-B.9	Select RX = A	A	A	
PB2-3-B.10	Select "CAN BUS I/F Side" to B	B	B	
PB2-3-B.11	Set input bus voltage to 120V	120V±1V	120,0 V	
PB2-3-B.12	Set input bus current limitation to ~~15A~~ 27,5A	27,5A ~~15A~~±1A	27,5 A	See PVS-02
PB2-3-B.13	Enable power supply output	enabled	enabled	
PB2-3-B.14	Verify that green led of "power switch box" is lighted	Green led ligthed	Green led ligthed	
PB2-3-B.15	Switch ON the "power switch "of "power switch box"	Switch ON	Switch ON	
PB2-3-B.16	Verify that red led of "power switch box" is lighted	Red led ligthed	Red led ligthed	
PB2-3-B.17	Take note of power supply output current	1,1A±0,5A	1,2 A	
PB2-3-B.18	Click on Run flash button	OK	OK	
PB2-3-B.19	Set the CAN BUS board address to 30	30	30	
PB2-3-B.20	Select "CAN BUS I/F Side" to A	A	A	
PB2-3-B.21	Click on Run flash button	OK	OK	
PB2-3-B.22	Set the CAN BUS board address to 31	31	31	
PB2-3-B.23	Select "CAN BUS I/F Side" to B	B	B	
PB2-3-B.24	Click on PB2-3 button	OK	OK	This board is default OFF
PB2-3-B.25	Set Digital I/F Test logic value = 1 in "Commanding" column	1	1	Button located on left side of software window
PB2-3-B.26	Click on letter "W" on the right of the "1" value	OK	OK	
PB2-3-B.27	Click on the command READ ALL under the column Digital Readout	OK	OK	
PB2-3-B.28	Verify that in the column Digital Readout under the voice Digital I/F Test appears "1"	1	1	
PB2-3-B.29	Set Digital I/F Test logic value = 0 in "Commanding" column	0	0	
PB2-3-B.30	Click on letter "W" on the right of the "0" value	OK	OK	
PB2-3-B.31	Click on the command READ ALL under the column Digital Readout	OK	OK	
PB2-3-B.32	Verify that in the column Digital Readout under the voice Digital I/F Test appears "0"	0	0	
PB2-3-B.33	Click on the command READ ALL under the column Digital Readout	OK	OK	
PB2-3-B.34	Verify the status of the following flags:			

DATE:	TEST CONDUCTOR	QA	CUSTOMER
24/07/2009	Albertin A.	Francini E.	

Questo documento contiene informazioni di proprietà di CARLO GAVAZZI SPACE SpA. Tutti i diritti sono riservati.

All information contained in this document are property of CARLO GAVAZZI SPACE SpA. All right reserved.

UUT DATA : Model **PFM** Item **AMS02 POWER DISTRIBUTION SYSTEM** C.I. **PDS 18** S/N **FM01**

STEP n°	TEST SEQUENCE	EXPECTED VALUE	MEASURED VALUE	REMARKS
	BOARD STATUS	OK	OK	
	OVT ALARM	OK	OK	
	Input OVC Alarm	OK	OK	
	DCDC ON/OFF	OFF	OFF	
	27V UV	OK	OK	
	29V Trip	OK	OK	
	DCDC OFF/ON CMD	OFF	OFF	
PB2-3-B.35	Click on the command READ ALL under the column Analog Readout	OK	OK	
PB2-3-B.36	Verify the value of the following telemetries: Temperature Analog Ref. 2.0V	 -40°C<T<80C° 2,000V±150mV	 26,0 °C 2,08 V	
PB2-3-B.37	Set the CAN BUS board address to 30	30	30	
PB2-3-B.38	Select "CAN BUS I/F Side" to A	A	A	
PB2-3-B.39	Click on the command READ ALL under the column Digital Readout	OK	OK	
PB2-3-B.40	Verify the status of the following flags: BOARD STATUS OVT ALARM Input OVC Alarm DCDC ON/OFF 27V UNV 29V Trip DCDC OFF/ON CMD	 OK OK OK OFF OK OK OFF	 OK OK OK OFF OK OK OFF	
PB2-3-B.41	Set ON on DCDC OFF/ON command window and send the command	OK	OK	Power cell ON
PB2-3-B.42	Click on the command READ ALL under the column Digital Readout	OK	OK	
PB2-3-B.43	Verify the status of the following flags: BOARD STATUS OVT ALARM Input OVC Alarm DCDC ON/OFF 27V UNV 29V Trip DCDC OFF/ON CMD	 OK OK OK ON OK OK ON	 OK OK OK ON OK OK ON	
PB2-3-B.44	Click on ESEM 3A-3 button	OK	OK	
PB2-3-B.45	Set ON in the window "O_1: TPD0" and push the relative "W" command	OK	OK	
PB2-3-B.46	Read on display the voltage on ESEM 3-A 3 out 1 (Check that load is not connected)	28,00V±1,00V	28,16V	V1
PB2-3-B.47	Click on PB2-3 button	OK	OK	
PB2-3-B.48	Click on the command READ ALL under the column Analog Readout	OK	OK	

DATE:	TEST CONDUCTOR	QA	CUSTOMER
24 /07/2009	Albertin A.	Francini E.	

Questo documento contiene informazioni di proprietà di CARLO GAVAZZI SPACE SpA. Tutti i diritti sono riservati.

All information contained in this document are property of CARLO GAVAZZI SPACE SpA. All right reserved.

UUT DATA : Model PFM Item AMS02 POWER DISTRIBUTION SYSTEM C.I. PDS 18 S/N FM01

STEP n°	TEST SEQUENCE	EXPECTED VALUE	MEASURED VALUE	REMARKS
PB2-3-B.49	Verify the value of the following telemetry: Output Voltage	V1±1.092V	28,22	Click on relative Rbutton
PB2-3-B.50	Set the CAN BUS board address to 31	31	31	
PB2-3-B.51	Select "CAN BUS I/F Side" to B	B	B	
PB2-3-B.52	Click on the command READ ALL under the column Digital Readout	OK	OK	
PB2-3-B.53	Verify the status of the following flags: BOARD STATUS OVT ALARM Input OVC Alarm DCDC ON/OFF 27V UNV 29V Trip DCDC OFF/ON CMD	 OK OK OK ON OK OK ON	 OK OK OK ON OK OK ON	

DATE:	TEST CONDUCTOR	QA	CUSTOMER
24 /07/2009	Albertin A.	Francini E.	

Questo documento contiene informazioni di proprietà di CARLO GAVAZZI SPACE SpA. Tutti i diritti sono riservati.

All information contained in this document are property of CARLO GAVAZZI SPACE SpA. All right reserved.

UUT DATA :	Model	PFM	Item	AMS02 POWER DISTRIBUTION SYSTEM	C.I.	PDS 18	S/N	FM01

10.3.2.5.8 ESEM 3A-3 SIDE B

STEP n°	TEST SEQUENCE	EXPECTED VALUE	MEASURED VALUE	REMARKS
3A-3-B.1	Click on ESEM3-A-3 button	OK	OK	Button located on left side of software window
3A-3-B.2	Connect to active loads outlet 1, 2, 3, 4, 5, 6, 7 and 8.	OK	OK	
3A-3-B.3	Verify that loads are set to 0A current absorption	OK	OK	
3A-3-B.4	Set Digital I/F Test logic value = 1 in "Commanding" column	1	1	
3A-3-B.5	Click on letter "W" on the right of the "1" value	OK	OK	
3A-3-B.6	Click on the command READ ALL under the column Digital Readout	OK	OK	
3A-3-B.7	Verify that in the column Digital Readout under the voice Digital I/F Test appears "1"	1	1	
3A-3-B.8	Set Digital I/F Test logic value = 0 in "Commanding" column	0	0	
3A-3-B.9	Click on letter "W" on the right of the "0" value	OK	OK	
3A-3-B.10	Click on the command READ ALL under the column Digital Readout	OK	OK	
3A-3-B.11	Verify that in the column Digital Readout under the voice Digital I/F Test appears "0"	0	0	
3A-3-B.12	Set ON in the window All Outlets ON/OFF and push the relative "W" command	OK	OK	
3A-3-B.13	Read on display the voltage on this ESEM 3-A loads: O_1: TPD0 O_2: TPD4 O_3: ER0_N O_4: MPD_R O_5: SPD3_R O_6: UGPD_R O_7: SPD2_R O_8: CAB_N	 28,00V±1,00V 28,00V±1,00V 28,00V±1,00V 28,00V±1,00V 28,00V±1,00V 28,00V±1,00V 28,00V±1,00V 28,00V±1,00V	28,0 V (ALL)	
3A-3-B.14	Click on Read All command in Digital Readout column	OK	OK	
3A-3-B.15	Verify the status of the following flags: BOARD STATUS OVT Alarm From O_1 CMD: TPD0 to O_8 CMD: CAB_N From O_1 Status: TPD0 to O_8 Status: CAB_N	 OK OK ON ON	 OK OK ON ON	
3A-3-B.16	Set the CAN BUS board address to 30	30	30	
3A-3-B.17	Select "CAN BUS I/F Side" to A	A	A	
3A-3-B.18	Click on Read All command in Digital Readout column	OK	OK	
3A-3-B.19	Verify the status of the following flags: BOARD STATUS OVT Alarm From O_1 CMD: TPD0 to O_8 CMD: CAB_N From O_1 Status: TPD0 to O_8 Status: CAB_N	 OK OK ON ON	 OK OK ON ON	

DATE:	TEST CONDUCTOR	QA	CUSTOMER
27 /07/2009	Albertin A.	Francini E.	

Questo documento contiene informazioni di proprietà di CARLO GAVAZZI SPACE SpA. Tutti i diritti sono riservati.

All information contained in this document are property of CARLO GAVAZZI SPACE SpA. All right reserved.

UUT DATA : Model PFM Item AMS02 POWER DISTRIBUTION SYSTEM C.I. PDS 18 S/N FM01

STEP n°	TEST SEQUENCE	EXPECTED VALUE	MEASURED VALUE	REMARKS
3A-3-B.20	Generate a short circuit on the passive load keyboards: From O_1: TPD0 to O_8: CAB_N	OK	OK	
3A-3-B.21	Read on display the voltage on this ESEM 3-A loads: O_1: TPD0 O_2: TPD4 O_3: ER0_N O_4: MPD_R O_5: SPD3_R O_6: UGPD_R O_7: SPD2_R O_8: CAB_N	0,00V<V<1,00V 0,00V<V<1,00V 0,00V<V<1,00V 0,00V<V<1,00V 0,00V<V<1,00V 0,00V<V<1,00V 0,00V<V<1,00V 0,00V<V<1,00V	0,0 V (ALL)	
3A-3-B.22	Click on Read All command in Digital Readout column	OK	OK	
3A-3-B.23	Verify the status of the following flags: BOARD STATUS OVT Alarm From O_1 CMD: TPD0 to O_8 CMD: CAB_N From O_1 Status: TPD0 to O_8 Status: CAB_N	**NOK** OK ON **OFF**	**NOK** OK ON **OFF**	
3A-3-B.24	Set the CAN BUS board address to 31	31	31	
3A-3-B.25	Select "CAN BUS I/F Side" to B	B	B	
3A-3-B.26	Click on Read All command in Digital Readout column	OK	OK	
3A-3-B.27	Verify the status of the following flags: BOARD STATUS OVT Alarm From O_1 CMD: TPD0 to O_8 CMD: CAB_N From O_1 Status: TPD0 to O_8 Status: CAB_N	**NOK** OK ON **OFF**	**NOK** OK ON **OFF**	
3A-3-B.28	Set OFF in the window All Outlets ON/OFF and push the relative "W" command	OK	OK	
3A-3-B.29	Set ON in the window All Outlets ON/OFF and push the relative "W" command	OK	OK	
3A-3-B.30	Click on Read All command in Digital Readout column	OK	OK	
3A-3-B.31	Verify the status of the following flags: BOARD STATUS OVT Alarm From O_1 CMD: TPD0 to O_8 CMD: CAB_N From O_1 Status: TPD0 to O_8 Status: CAB_N	**OK** OK ON **ON**	**OK** OK ON **ON**	
3A-3-B.32	Set the CAN BUS board address to 30	30	30	
3A-3-B.33	Select "CAN BUS I/F Side" to A	A	A	
3A-3-B.34	Click on Read All command in Digital Readout column	OK	OK	
3A-3-B.35	Verify the status of the following flags: BOARD STATUS	**OK**	**OK**	

DATE:	TEST CONDUCTOR	QA	CUSTOMER
27/07/2009	Albertin A.	Francini E.	

Questo documento contiene informazioni di proprietà di CARLO GAVAZZI SPACE SpA. Tutti i diritti sono riservati.

All information contained in this document are property of CARLO GAVAZZI SPACE SpA. All right reserved.

UUT DATA : Model PFM Item AMS02 POWER DISTRIBUTION SYSTEM C.I. PDS 18 S/N FM01

STEP n°	TEST SEQUENCE	EXPECTED VALUE	MEASURED VALUE	REMARKS
	OVT Alarm From O_1 CMD: TPD0 to O_8 CMD: CAB_N From O_1 Status: TPD0 to O_8 Status: CAB_N	OK ON ON	OK ON ON	
3A-3-B.36	Using board telemetries set to 2A current absorption all the outlets: From O_1: TPD0 to O_8: CAB_N	OK	OK	Set active loads to constant current mode. Set current on display with 100mA above the desired value with the exception of out8 that is correct.
3A-3-B.37	Push on Read All button in Analog Readout column	OK	OK	
3A-3-B.38	Verify the telemetries: O_1 Current: TPD0 O_2 Current: TPD4 O_3 Current: ER0_N O_4 Current: MPD_R O_5 Current: SPD3_R O_6 Current: UGPD_R O_7 Current: SPD2_R O_8 Current: CAB_N Temperature Analog Ref. 3.0V	 2,000A±0,225A 2,000A±0,225A 2,000A±0,225A 2,000A±0,225A 2,000A±0,225A 2,000A±0,225A 2,000A±0,225A 2,00A±0,45A -40°C<T<80C° 3,000V±250mV	 2,10 A 2,06 A 2,10 A 2,09 A 2,14 A 2,08 A 2,11 A 2,14 A 30 °C 2,98 V	
3A-3-B.39	Set the CAN BUS board address to 31	31	31	
3A-3-B.40	Select "CAN BUS I/F Side" to B	B	B	
3A-3-B.41	Push on Read All button in Analog Readout column	OK	OK	
3A-3-B.42	Verify the telemetries: O_1 Current: TPD0 O_2 Current: TPD4 O_3 Current: ER0_N O_4 Current: MPD_R O_5 Current: SPD3_R O_6 Current: UGPD_R O_7 Current: SPD2_R O_8 Current: CAB_N Temperature Analog Ref. 3.0V	 2,000A±0,225A 2,000A±0,225A 2,000A±0,225A 2,000A±0,225A 2,000A±0,225A 2,000A±0,225A 2,000A±0,225A 2,00A±0,45A -40°C<T<80C° 3,000V±250mV	 2,07 A 2,09 A 2,13 A 2,11 A 2,12 A 2,11 A 2,10 A 2,15 A 31,0 °C 2,97 V	
3A-3-B.43	Set to 0A current absorption all the outlets: From O_1: TPD0 to O_8: CAB_N	OK	OK	
3A-3-B.44	Set OFF in the window All Outlets ON/OFF and push the relative "W" command	OK	OK	
3A-3-B.45	Click on Raed all to in Digital readout column	OK	OK	
3A-3-B.46	Verify from digital readout column that all outlets are OFF	OK	OK	

DATE:	TEST CONDUCTOR	QA	CUSTOMER
27/07/2009	Albertin A.	Francini E.	

Questo documento contiene informazioni di proprietà di CARLO GAVAZZI SPACE SpA. Tutti i diritti sono riservati.

All information contained in this document are property of CARLO GAVAZZI SPACE SpA. All right reserved.

UUT DATA :	Model	PFM	Item	AMS02 POWER DISTRIBUTION SYSTEM	C.I.	PDS 18	S/N	FM01

10.3.2.5.9 PB2-4 SIDE B

STEP n°	TEST SEQUENCE	EXPECTED VALUE	MEASURED VALUE	REMARKS
PB2-4-B.1	Connect BI_120V and BI_120V_RTN power supply signals	OK	OK	
PB2-4-B.2	Verify that all the cables of the section are connected	OK	OK	
PB2-4-B.3	Launch the PDS controller software	Program open	Program open	
PB2-4-B.4	Set to "FM" the window Model	OK	OK	
PB2-4-B.5	Select "PDS Side" to B	B	B	
PB2-4-B.6	Set the CAN BUS board address to 31	31	31	
PB2-4-B.7	Select JMDC = 0	0	0	
PB2-4-B.8	Select TX = A	A	A	
PB2-4-B.9	Select RX = A	A	A	
PB2-4-B.10	Select "CAN BUS I/F Side" to B	B	B	
PB2-4-B.11	Set input bus voltage to 120V	120V±1V	120,0 V	
PB2-4-B.12	Set input bus current limitation to ~~15A~~ 27,5A	27,5A ~~15A~~±1A	27,5 A	See PVS-02
PB2-4-B.13	Enable power supply output	enabled	enabled	
PB2-4-B.14	Verify that green led of "power switch box" is lighted	Green led ligthed	Green led ligthed	
PB2-4-B.15	Switch ON the "power switch "of "power switch box"	Switch ON	Switch ON	
PB2-4-B.16	Verify that red led of "power switch box" is lighted	Red led ligthed	Red led ligthed	
PB2-4-B.17	Take note of power supply output current	1,6A±0,5A	1,43 A	
PB2-4-B.18	Click on Run flash button	OK	OK	
PB2-4-B.19	Set the CAN BUS board address to 30	30	30	
PB2-4-B.20	Select "CAN BUS I/F Side" to A	A	A	
PB2-4-B.21	Click on Run flash button	OK	OK	
PB2-4-B.22	Set the CAN BUS board address to 31	31	31	
PB2-4-B.23	Select "CAN BUS I/F Side" to B	B	B	
PB2-4-B.24	Click on PB2-4 button	OK	OK	This board is default ON
PB2-4-B.25	Set Digital I/F Test logic value = 1 in "Commanding" column	1	1	Button located on left side of software window
PB2-4-B.26	Click on letter "W" on the right of the "1" value	OK	OK	
PB2-4-B.27	Click on the command READ ALL under the column Digital Readout	OK	OK	
PB2-4-B.28	Verify that in the column Digital Readout under the voice Digital I/F Test appears "1"	1	1	
PB2-4-B.29	Set Digital I/F Test logic value = 0 in "Commanding" column	0	0	
PB2-4-B.30	Click on letter "W" on the right of the "0" value	OK	OK	
PB2-4-B.31	Click on the command READ ALL under the column Digital Readout	OK	OK	
PB2-4-B.32	Verify that in the column Digital Readout under the voice Digital I/F Test appears "0"	0	0	
PB2-4-B.33	Click on the command READ ALL under the column Analog Readout	OK	OK	

DATE:	TEST CONDUCTOR	QA	CUSTOMER
27/07/2009	Albertin A.	Francini E.	

Questo documento contiene informazioni di proprietà di CARLO GAVAZZI SPACE SpA. Tutti i diritti sono riservati.

All information contained in this document are property of CARLO GAVAZZI SPACE SpA. All right reserved.

UUT DATA : Model PFM Item AMS02 POWER DISTRIBUTION SYSTEM C.I. PDS 18 S/N FM01

STEP n°	TEST SEQUENCE	EXPECTED VALUE	MEASURED VALUE	REMARKS
PB2-4-B.34	Verify the status of the following flags: BOARD STATUS OVT ALARM Input OVC Alarm DCDC ON/OFF 27V UV 29V Trip DCDC OFF/ON CMD	 OK OK OK ON OK OK ON	 OK OK OK ON OK OK ON	
PB2-4-B.35	Click on the command READ ALL under the column Analog Readout	OK	OK	
PB2-4-B.36	Verify the value of the following telemetries: Temperature Analog Ref. 2.0V	 N.A. ~~-40°C<T<80C°~~ N.A. ~~2,000V±150mV~~	 N.A. N.A.	See PVS-05
PB2-4-B.37	Read on display the voltage on ESEM 3A-4 out 1 (Check that load is not connected)	28,00V±1,00V	28,1 V	V1
PB2-4-B.38	Verify the value of the following telemetry: Output Voltage	V1±1.092V	28,2 V	Click on relative Rbutton
PB2-4-B.39	Set OFF on DCDC ON /OFF command window and send the command	OK	OK	Power cell OFF
PB2-4-B.40	Click on the command READ ALL under the column Digital Readout	OK	OK	
PB2-4-B.41	Verify the status of the following flags: BOARD STATUS OVT ALARM Input OVC Alarm DCDC ON/OFF 27V UNV 29V Trip DCDC OFF/ON CMD	 OK OK OK OFF OK OK OFF	 OK OK OK OFF OK OK OFF	
PB2-4-B.42	Click on the command READ ALL under the column Analog Readout	OK	OK	
PB2-4-B.43	Verify the value of the following telemetries: Temperature Analog Ref. 2.0V	 -40°C<T<80C° 2,000V±150mV	 38,5 °C 2,05 V	
PB2-4-B.44	Verify the following analog monitor: Output Voltage	0,00V±1.092V	0,00 V	
PB2-4-B.45	Read on display the voltage on ESEM 3A-4 out 1 (Check that load is not connected)	0,00V±0,10V	-0,05 V	
PB2-4-B.46	Set the CAN BUS board address to 30	30	30	
PB2-4-B.47	Select "CAN BUS I/F Side" to A	A	A	
PB2-4-B.48	Click on the command READ ALL under the column Digital Readout	OK	OK	
PB2-4-B.49	Verify the status of the following flags: BOARD STATUS OVT ALARM	 OK OK	 OK OK	

DATE:	TEST CONDUCTOR	QA	CUSTOMER
27/07/2009	Albertin A.	Francini E.	

Questo documento contiene informazioni di proprietà di CARLO GAVAZZI SPACE SpA. Tutti i diritti sono riservati.

All information contained in this document are property of CARLO GAVAZZI SPACE SpA. All right reserved.

UUT DATA : Model PFM Item AMS02 POWER DISTRIBUTION SYSTEM C.I. PDS 18 S/N FM01

STEP n°	TEST SEQUENCE	EXPECTED VALUE	MEASURED VALUE	REMARKS
	Input OVC Alarm	OK	OK	
	DCDC ON/OFF	OFF	OFF	
	27V UNV	OK	OK	
	29V Trip	OK	OK	
	DCDC OFF/ON CMD	OFF	OFF	
PB2-4-B.50	Set ON on DCDC OFF/ON command window and send the command	OK	OK	Power cell ON
PB2-4-B.51	Click on the command READ ALL under the column Digital Readout	OK	OK	
PB2-4-B.52	Verify the status of the following flags:			
	BOARD STATUS	OK	OK	
	OVT ALARM	OK	OK	
	Input OVC Alarm	OK	OK	
	DCDC ON/OFF	ON	ON	
	27V UNV	OK	OK	
	29V Trip	OK	OK	
	DCDC OFF/ON CMD	ON	ON	
PB2-4-B.53	Read on display the voltage on ESEM 3A-4 out 1 (Check that load is not connected)	28,00V±1,00V	28,1 V	
PB2-4-B.54	Set the CAN BUS board address to 31	31	31	
PB2-4-B.55	Select "CAN BUS I/F Side" to B	B	B	
PB2-4-B.56	Click on the command READ ALL under the column Digital Readout	OK	OK	
PB2-4-B.57	Verify the status of the following flags:			
	BOARD STATUS	OK	OK	
	OVT ALARM	OK	OK	
	Input OVC Alarm	OK	OK	
	DCDC ON/OFF	ON	ON	
	27V UNV	OK	OK	
	29V Trip	OK	OK	
	DCDC OFF/ON CMD	ON	ON	

DATE:	TEST CONDUCTOR	QA	CUSTOMER
27 /07/2009	Albertin A.	Francini E.	

Questo documento contiene informazioni di proprietà di CARLO GAVAZZI SPACE SpA. Tutti i diritti sono riservati.

All information contained in this document are property of CARLO GAVAZZI SPACE SpA. All right reserved.

UUT DATA :	Model	PFM	Item	AMS02 POWER DISTRIBUTION SYSTEM	C.I.	PDS 18	S/N	FM01

10.3.2.5.10 ESEM 3A-4 SIDE B

STEP n°	TEST SEQUENCE	EXPECTED VALUE	MEASURED VALUE	REMARKS
3A-4-B.1	Click on ESEM 3A-4 button	OK	OK	Button located on left side of software window
3A-4-B.2	Connect to active loads outlet 1, 2, 3, 4, 5, 6, 7 and 8.	OK	OK	
3A-4-B.3	Verify that loads are set to 0A current absorption	OK	OK	
3A-4-B.4	Set Digital I/F Test logic value = 1 in "Commanding" column	1	1	
3A-4-B.5	Click on letter "W" on the right of the "1" value	OK	OK	
3A-4-B.6	Click on the command READ ALL under the column Digital Readout	OK	OK	
3A-4-B.7	Verify that in the column Digital Readout under the voice Digital I/F Test appears "1"	1	1	
3A-4-B.8	Set Digital I/F Test logic value = 0 in "Commanding" column	0	0	
3A-4-B.9	Click on letter "W" on the right of the "0" value	OK	OK	
3A-4-B.10	Click on the command READ ALL under the column Digital Readout	OK	OK	
3A-4-B.11	Verify that in the column Digital Readout under the voice Digital I/F Test appears "0"	0	0	
3A-4-B.12	Set ON in the window All Outlets ON/OFF and push the relative "W" command	OK	OK	
3A-4-B.13	Read on display the voltage on this ESEM 3-A loads: O_1: JPD_R O_2: ER1_R O_3: SPD1_R O_4: ER0_R O_5: UPD0 O_6: SPD0_N O_7: TPD5 O_8: TTPD_N	 28,00V±1,00V 28,00V±1,00V 28,00V±1,00V 28,00V±1,00V 28,00V±1,00V 28,00V±1,00V 28,00V±1,00V 28,00V±1,00V	28,0 V	
3A-4-B.14	Click on Read All command in Digital Readout column	OK	OK	
3A-4-B.15	Verify the status of the following flags: BOARD STATUS OVT Alarm From O_1 CMD: JPD_R to O_8 CMD: TTPD_N From O_1 Status: JPD_R to O_8 Status: TTPD_N	 OK OK ON ON	 OK OK ON ON	
3A-4-B.16	Set the CAN BUS board address to 30	30	30	
3A-4-B.17	Select "CAN BUS I/F Side" to A	A	A	
3A-4-B.18	Click on Read All command in Digital Readout column	OK	OK	
3A-4-B.19	Verify the status of the following flags: BOARD STATUS OVT Alarm From O_1 CMD: JPD_R to O_8 CMD: TTPD_N From O_1 Status: JPD_R to O_8 Status: TTPD_N	 OK OK ON ON	 OK OK ON ON	

DATE:	TEST CONDUCTOR	QA	CUSTOMER
27/07/2009	Albertin A.	Francini E.	

Questo documento contiene informazioni di proprietà di CARLO GAVAZZI SPACE SpA. Tutti i diritti sono riservati.

All information contained in this document are property of CARLO GAVAZZI SPACE SpA. All right reserved.

UUT DATA : Model PFM Item AMS02 POWER DISTRIBUTION SYSTEM C.I. PDS 18 S/N FM01

STEP n°	TEST SEQUENCE	EXPECTED VALUE	MEASURED VALUE	REMARKS
3A-4-B.20	Generate a short circuit on the passive load keyboards: From O_1: JPD_R to O_8: TTPD_N	OK	OK	
3A-4-B.21	Read on display the voltage on this ESEM 3-A loads: O_1: TPD0 O_2: TPD4 O_3: ER0_N O_4: MPD_R O_5: SPD3_R O_6: UGPD_R O_7: SPD2_R O_8: CAB_N	0,00V<V<1,00V 0,00V<V<1,00V 0,00V<V<1,00V 0,00V<V<1,00V 0,00V<V<1,00V 0,00V<V<1,00V 0,00V<V<1,00V 0,00V<V<1,00V	0,0 V (ALL)	
3A-4-B.22	Click on Read All command in Digital Readout column	OK	OK	
3A-4-B.23	Verify the status of the following flags: BOARD STATUS OVT Alarm From O_1 CMD: JPD_R to O_8 CMD: TTPD_N From O_1 Status: JPD_R to O_8 Status: TTPD_N	NOK OK ON OFF	NOK OK ON OFF	
3A-4-B.24	Set the CAN BUS board address to 31	31	31	
3A-4-B.25	Select "CAN BUS I/F Side" to B	B	B	
3A-4-B.26	Click on Read All command in Digital Readout column	OK	OK	
3A-4-B.27	Verify the status of the following flags: BOARD STATUS OVT Alarm From O_1 CMD: JPD_R to O_8 CMD: TTPD_N From O_1 Status: JPD_R to O_8 Status: TTPD_N	NOK OK ON OFF	NOK OK ON OFF	
3A-4-B.28	Set OFF in the window All Outlets ON/OFF and push the relative "W" command	OK	OK	
3A-4-B.29	Set ON in the window All Outlets ON/OFF and push the relative "W" command	OK	OK	
3A-4-B.30	Click on Read All command in Digital Readout column	OK	OK	
3A-4-B.31	Verify the status of the following flags: BOARD STATUS OVT Alarm From O_1 CMD: JPD_R to O_8 CMD: TTPD_N From O_1 Status: JPD_R to O_8 Status: TTPD_N	OK OK ON ON	OK OK ON ON	
3A-4-B.32	Set the CAN BUS board address to 30	30	30	
3A-4-B.33	Select "CAN BUS I/F Side" to A	A	A	
3A-4-B.34	Click on Read All command in Digital Readout column	OK	OK	
3A-4-B.35	Verify the status of the following flags: BOARD STATUS	OK	OK	

DATE:	TEST CONDUCTOR	QA	CUSTOMER
27/07/2009	Albertin A.	Francini E.	

Questo documento contiene informazioni di proprietà di CARLO GAVAZZI SPACE SpA. Tutti i diritti sono riservati.

All information contained in this document are property of CARLO GAVAZZI SPACE SpA. All right reserved.

UUT DATA : Model PFM Item AMS02 POWER DISTRIBUTION SYSTEM C.I. PDS 18 S/N FM01

STEP n°	TEST SEQUENCE	EXPECTED VALUE	MEASURED VALUE	REMARKS
	OVT Alarm From O_1 CMD: JPD_R to O_8 CMD: TTPD_N From O_1 Status: JPD_R to O_8 Status: TTPD_N	OK ON ON	OK ON ON	
3A-4-B.36	Using board telemetries set to 2A current absorption all the outlets: From O_1: JPD_R to O_8: TTPD_N	OK	OK	Set active loads to constant current mode. Set current on display with 100mA above the desired value with the exception of out8 that is correct.
3A-4-B.37	Push on Read All button in Analog Readout column	OK	OK	
3A-4-B.38	Verify the telemetries: O_1 Current: JPD_R O_2 Current: ER1_R O_3 Current: SPD1_R O_4 Current: ER0_R O_5 Current: UPD0 O_6 Current: SPD0_N O_7 Current: TPD5 O_8 Current: TTPD_N Temperature Analog Ref. 3.0VTemperature Analog Ref. 3.0V	 2,000A±0,225A 2,000A±0,225A 2,000A±0,225A 2,000A±0,225A 2,000A±0,225A 2,000A±0,225A 2,000A±0,225A 2,00A±0,45A -40°C<T<80C° 3,000V±250mV	 2,04 A 2,11 A 2,18 A 2,08 A 2,20 A 2,09 A 2,10 A 2,16 A 33 °C 3,1 V	
3A-4-B.39	Set the CAN BUS board address to 31	31	31	
3A-4-B.40	Select "CAN BUS I/F Side" to B	B	B	
3A-4-B.41	Push on Read All button in Analog Readout column	OK	OK	
3A-4-B.42	Verify the current telemetries: O_1 Current: JPD_R O_2 Current: ER1_R O_3 Current: SPD1_R O_4 Current: ER0_R O_5 Current: UPD0 O_6 Current: SPD0_N O_7 Current: TPD5 O_8 Current: TTPD_N Temperature Analog Ref. 3.0V	 2,000A±0,225A 2,000A±0,225A 2,000A±0,225A 2,000A±0,225A 2,000A±0,225A 2,000A±0,225A 2,000A±0,225A 2,00A±0,45A -40°C<T<80C° 3,000V±250mV	 2,12 A 2,11 A 1,99 A 2,04 A 2,18 A 2,15 A 2,18 A 2,19 A 38 °C 2,86 V	
3A-4-B.43	Set to 0A current absorption all the outlets: From O_1: JPD_R to O_8: TTPD_N	OK	OK	
3A-4-B.44	Set OFF in the window All Outlets ON/OFF and push the relative "W" command	OK	OK	
3A-4-B.45	Click on Raed all to in Digital readout column	OK	OK	

DATE:	TEST CONDUCTOR	QA	CUSTOMER
27 /07/2009	Albertin A.	Francini E.	

Questo documento contiene informazioni di proprietà di CARLO GAVAZZI SPACE SpA. Tutti i diritti sono riservati.

All information contained in this document are property of CARLO GAVAZZI SPACE SpA. All right reserved.

UUT DATA :	Model	PFM	Item	AMS02 POWER DISTRIBUTION SYSTEM	C.I.	PDS 18	S/N	FM01

STEP n°	TEST SEQUENCE	EXPECTED VALUE	MEASURED VALUE	REMARKS
3A-4-B.46	Verify from digital readout column that all outlets are OFF	OK	OK	
3A-4-B.47	Switch OFF the "power switch "of "power switch box"	OFF	OFF	See PVS-06

Questo documento contiene informazioni di proprietà di CARLO GAVAZZI SPACE SpA. Tutti i diritti sono riservati.

All information contained in this document are property of CARLO GAVAZZI SPACE SpA. All right reserved.

UUT DATA :	Model	PFM	Item	AMS02 POWER DISTRIBUTION SYSTEM	C.I.	PDS 18	S/N	FM01

STEP n°	TEST SEQUENCE	EXPECTED VALUE	MEASURED VALUE	REMARKS

10.3.2.5.11 ESEM 3-B SIDE B

3B-B.1	Connect all the loads. The following column resumes the currents (with Main bus equal to 120V):	OK	OK	There is no need to check the current absorption of the loads. CCS load not connected
3B-B.2	Set all the loads of the other boards to 0A	OK	OK	
3B-B.3	Set power supply voltage to 120V	120V ± 0.2V	120,0 V	
3B-B.4	Set power supply current limitation to 27.5A	27.5A±0.5A	27,5 A	
3B-B.5	Switch ON the "power switch "of "power switch box"	OK	OK	
3B-B.6	Take note of input current	7,9A±0,5A	7,77 A	
3B-B.7	Select PDS controller software	program open	program open	
3B-B.8	Set the CAN BUS board address to 31	31	31	
3B-B.9	Select JMDC = 0	0	0	
3B-B.10	Select TX = A	A	A	
3B-B.11	Select RX = A	A	A	
3B-B.12	Select "CAN BUS I/F Side" to B	B	B	
3B-B.13	Select "PDS Side" to B	B	B	
3B-B.14	Click on Run flash command	OK	OK	
3B-B.15	Click on ESEM3-B button	OK	OK	Button located on left side of PDS controller software window
3B-B.16	Set Digital I/F Test logic value = 1 in "Commanding" column	1	1	
3B-B.17	Click on letter "W" on the right of the "1" value	OK	OK	
3B-B.18	Click on the command READ ALL under the column Digital Readout	OK	OK	

DATE:	TEST CONDUCTOR	QA	CUSTOMER
27/07/2009	Albertin A.	Francini E.	

Questo documento contiene informazioni di proprietà di CARLO GAVAZZI SPACE SpA. Tutti i diritti sono riservati.

All information contained in this document are property of CARLO GAVAZZI SPACE SpA. All right reserved.

OUTLET	CURRENT [A] SET
1	1,200±100mA
2	3,200±100mA
3	1,200±100mA
4	1,200±100mA
5	2,400±100mA
6	1,200±100mA
7	1,200±100mA
8	1,200±100mA
9	1,200±100mA
10	1,200±100mA
11	1,200±100mA
12	3,520±100mA

UUT DATA : Model PFM Item AMS02 POWER DISTRIBUTION SYSTEM C.I. PDS 18 S/N FM01

STEP n°	TEST SEQUENCE	EXPECTED VALUE	MEASURED VALUE	REMARKS
3B-B.19	Verify that in the column Digital Readout under the voice Digital I/F Test appears "1"	1	1	
3B-B.20	Set Digital I/F Test logic value = 0 in "Commanding" column	0	0	
3B-B.21	Click on letter "W" on the right of the "0" value	OK	OK	
3B-B.22	Click on the command READ ALL under the column Digital Readout	OK	OK	
3B-B.23	Verify that in the column Digital Readout under the voice Digital I/F Test appears "0"	0	0	
3B-B.24	Verify the status of the following flags: BOARD STATUS OVT Alarm O__1 CMD: AH_OUT1 O__2 CMD: AH_OUT2 O__3 CMD: AH_OUT3 O__4 CMD: AH_OUT4 O__5 CMD: AH_OUT5 O__6 CMD: AH_OUT6 O__7 CMD: AH_OUT7 O__8 CMD: AH_OUT8 O__9 CMD: AH_OUT9 O_10 CMD: AH_OUT10 O_11 CMD: AH_OUT11 O_12 CMD: AO_CCEB O__1 Status: AH_OUT1 O__2 Status: AH_OUT2 O__3 Status: AH_OUT3 O__4 Status: AH_OUT4 O__5 Status : AH_OUT5 O__6 Status: AH_OUT6 O__7 Status: AH_OUT7 O__8 Status: AH_OUT8 O__9 Status: AH_OUT9 O_10 Status: AH_OUT10 O_11 Status: AH_OUT11 O_12 Status: AO_CCEB O_12 Trip: AO_CCEB	 OK OK ON ON ON OFF OFF ON OFF OFF OFF OFF OFF OFF ON ON ON OFF OFF ON OFF OFF OFF OFF OFF OFF OFF OK	 OK OK ON ON ON OFF OFF ON OFF OFF OFF OFF OFF OFF ON ON ON OFF OFF ON OFF OFF OFF OFF OFF OFF OFF OK	
3B-B.25	Push on Read All button in Analog Readout column	OK	OK	
3B-B.26	Take note of the following values in "Analog readout" column: Temperature O_12 Current: AO_CCEB Analog Ref. 2.5V	 -40°C<T<80C° 0,00A±0,45A 2,500V±150mV	 28 °C 0,13 A 2,49 V	

DATE:	TEST CONDUCTOR	QA	CUSTOMER
27/07/2009	Albertin A.	Francini E.	

Questo documento contiene informazioni di proprietà di CARLO GAVAZZI SPACE SpA. Tutti i diritti sono riservati.

All information contained in this document are property of CARLO GAVAZZI SPACE SpA. All right reserved.

UUT DATA : Model PFM Item AMS02 POWER DISTRIBUTION SYSTEM C.I. PDS 18 S/N FM01

STEP n°	TEST SEQUENCE	EXPECTED VALUE	MEASURED VALUE	REMARKS
3B-B.27	Set the CAN BUS board address to 30	30	30	
3B-B.28	Select "CAN BUS I/F Side" to A	A	A	
3B-B.29	Click on Run flash button	OK	OK	
3B-B.30	Click on Read All command in Digital Readout column	OK	OK	
3B-B.31	Verify the status of the following flags:			
	BOARD STATUS	OK	OK	
	OVT Alarm	OK	OK	
	O__1 CMD: AH_OUT1	ON	ON	
	O__2 CMD: AH_OUT2	ON	ON	
	O__3 CMD: AH_OUT3	ON	ON	
	O__4 CMD: AH_OUT4	OFF	OFF	
	O__5 CMD: AH_OUT5	OFF	OFF	
	O__6 CMD: AH_OUT6	ON	ON	
	O__7 CMD: AH_OUT7	OFF	OFF	
	O__8 CMD: AH_OUT8	OFF	OFF	
	O__9 CMD: AH_OUT9	OFF	OFF	
	O_10 CMD: AH_OUT10	OFF	OFF	
	O_11 CMD: AH_OUT11	OFF	OFF	
	O_12 CMD: AO_CCEB	OFF	OFF	
	O__1 Status: AH_OUT1	ON	ON	
	O__2 Status: AH_OUT2	ON	ON	
	O__3 Status: AH_OUT3	ON	ON	
	O__4 Status: AH_OUT4	OFF	OFF	
	O__5 Status : AH_OUT5	OFF	OFF	
	O__6 Status: AH_OUT6	ON	ON	
	O__7 Status: AH_OUT7	OFF	OFF	
	O__8 Status: AH_OUT8	OFF	OFF	
	O__9 Status: AH_OUT9	OFF	OFF	
	O_10 Status: AH_OUT10	OFF	OFF	
	O_11 Status: AH_OUT11	OFF	OFF	
	O_12 Status: AO_CCEB	OFF	OFF	
	O_12 Trip: AO_CCEB	OK	OK	
3B-B.32	Push on Read All button in Analog Readout column	OK	OK	
3B-B.33	Take note of the following values in "Analog readout" column:			
	Temperature	-40°C<T<80C°	29,0 °C	
	O_12 Current: AO_CCEB	0,00A±0,45A	0,12 A	
	Analog Ref. 2.5V	2,500V±150mV	2,47 V	
3B-B.34	Set OFF in the window All Outlets ON/OFF and push the relative "W" command	OK	OK	

DATE:	TEST CONDUCTOR	QA	CUSTOMER
27/07/2009	Albertin A.	Francini E.	

Questo documento contiene informazioni di proprietà di CARLO GAVAZZI SPACE SpA. Tutti i diritti sono riservati.

All information contained in this document are property of CARLO GAVAZZI SPACE SpA. All right reserved.

UUT DATA : Model PFM Item AMS02 POWER DISTRIBUTION SYSTEM C.I. PDS 18 S/N FM01

STEP n°	TEST SEQUENCE	EXPECTED VALUE	MEASURED VALUE	REMARKS
3B-B.35	Click on the command READ ALL under the column Digital Readout	OK	OK	
3B-B.36	Verify the status of the following flags: BOARD STATUS OVT Alarm From O__1 CMD: AH_OUT1 to O_11 CMD: AH_OUT11 O_12 CMD: AO_CCEB From O__1 Status: AH_OUT1 to O_11 Status: AH_OUT11 O_12 Status: AO_CCEB O_12 Trip: AO_CCEB	 OK OK OFF OFF OFF OFF OK	 OK OK OFF OFF OFF OFF OK	
3B-B.37	Set the CAN BUS board address to 31	31	31	
3B-B.38	Select "CAN BUS I/F Side" to B	B	B	
3B-B.39	Click on the command READ ALL under the column Digital Readout	OK	OK	
3B-B.40	Verify the status of the following flags: BOARD STATUS OVT Alarm From O__1 CMD: AH_OUT1 to O_11 CMD: AH_OUT11 O_12 CMD: AO_CCEB From O__1 Status: AH_OUT1 to O_11 Status: AH_OUT11 O_12 Status: AO_CCEB O_12 Trip: AO_CCEB	 OK OK OFF OFF OFF OFF OK	 OK OK OFF OFF OFF OFF OK	
3B-B.41	Verify with a multimeter the voltage of the outlets: AH_OUT1 AH_OUT2 AH_OUT3 AH_OUT4 AH_OUT5 AH_OUT6 AH_OUT7 AH_OUT8 AH_OUT9 AH_OUT10 AH_OUT11 AO_CCEB	 V<5,00V V<5,00V V<5,00V V<5,00V V<5,00V V<5,00V V<5,00V V<5,00V V<5,00V V<5,00V V<5,00V V<5,00V	 0,0 V (ALL)	
3B-B.42	Set ON in the window All Outlets ON/OFF and push the relative "W" command	OK	OK	
3B-B.43	Take note of input current	21A±1A	20,1 A	
3B-B.44	Click on the command READ ALL under the column Digital Readout	OK	OK	
3B-B.45	Verify the status of the following flags: BOARD STATUS	 OK	 OK	

DATE:	TEST CONDUCTOR	QA	CUSTOMER
27/07/2009	Albertin A.	Francini E.	

Questo documento contiene informazioni di proprietà di CARLO GAVAZZI SPACE SpA. Tutti i diritti sono riservati.

All information contained in this document are property of CARLO GAVAZZI SPACE SpA. All right reserved.

UUT DATA : Model PFM Item AMS02 POWER DISTRIBUTION SYSTEM C.I. PDS 18 S/N FM01

STEP n°	TEST SEQUENCE	EXPECTED VALUE	MEASURED VALUE	REMARKS
	OVT Alarm From O__1 CMD: AH_OUT1 to O_11 CMD: AH_OUT11 O_12 CMD: AO_CCEB From O__1 Status: AH_OUT1 to O_11 Status: AH_OUT11 O_12 Status: AO_CCEB O_12 Trip: AO_CCEB	OK ON ON ON ON OK	OK ON ON ON ON OK	
3B-B.46	Set the CAN BUS board address to 30	30	30	
3B-B.47	Select "CAN BUS I/F Side" to A	A	A	
3B-B.48	Click on the command READ ALL under the column Digital Readout	OK	OK	
3B-B.49	Verify the status of the following flags: BOARD STATUS OVT Alarm From O__1 CMD: AH_OUT1 to O_11 CMD: AH_OUT11 O_12 CMD: AO_CCEB From O__1 Status: AH_OUT1 to O_11 Status: AH_OUT11 O_12 Status: AO_CCEB O_12 Trip: AO_CCEB	OK OK ON ON ON ON OK	OK OK ON ON ON ON OK	
3B-B.50	Set the CAN BUS board address to 31	31	31	
3B-B.51	Select "CAN BUS I/F Side" to B	B	B	
3B-B.52	Measure the PDS input voltage: connect a multimeter between PIN "bypass thermal interlock" (positive) and "PRI_GND"(negative) on side A of the J300 test box	117,50V±1,00V	117,17 V	See PVS-08
3B-B.53	Verify with a multimeter the voltage of the outlets: AH_OUT1 AH_OUT2 AH_OUT3 AH_OUT4 AH_OUT5 AH_OUT6 AH_OUT7 AH_OUT8 AH_OUT9 AH_OUT10 AH_OUT11 AO_CCEB	115V ~~117V~~<V<120,00V 115V ~~117V~~<V<120,00V 115V ~~117V~~<V<120,00V 115V ~~117V~~<V<120,00V 115V ~~117V~~<V<120,00V 115V ~~117V~~<V<120,00V 115V ~~117V~~<V<120,00V 115V ~~117V~~<V<120,00V 115V ~~117V~~<V<120,00V 115V ~~117V~~<V<120,00V 115V ~~117V~~<V<120,00V 115V ~~117V~~<V<120,00V	115,4 V 115,5 V 115,4 V 115,4 V 115,3 V 115,4 V 115,4 V 115,4 V 115,4 V 115,4 V 115,4 V 116,1 V	Measurement on the load See PVS-09
3B-B.54	Set OFF the command All Outlets ON/OFF in commanding column and click on relative "W"	OK	OK	
3B-B.55	Connect the short circuit simulator in parallel to outlet 12	OK	OK	
3B-B.56	Set the short circuit simulator to 10ms short circuit duration	OK	OK	
3B-B.57	Set "ON" in the window "O_12:AO_CCEB" and push the relative "W" command	OK	OK	

DATE:	TEST CONDUCTOR	QA	CUSTOMER
27/07/2009	Albertin A.	Francini E.	

Questo documento contiene informazioni di proprietà di CARLO GAVAZZI SPACE SpA. Tutti i diritti sono riservati.

All information contained in this document are property of CARLO GAVAZZI SPACE SpA. All right reserved.

UUT DATA : Model PFM Item AMS02 POWER DISTRIBUTION SYSTEM C.I. PDS 18 S/N FM01

STEP n°	TEST SEQUENCE	EXPECTED VALUE	MEASURED VALUE	REMARKS
3B-B.58	Create the short circuit	OK	OK	
3B-B.59	Click on the command READ ALL under the column Digital Readout	OK	OK	
3B-B.60	Verify the status of the following flags: BOARD STATUS OVT Alarm From O__1 Status: AH_OUT1 to O_11 Status: AH_OUT11 O_12 Status: AO_CCEB O_12 Trip: AO_CCEB	NOK OK ON ON OFF TRIP	NOK OK ON ON OFF TRIP	
3B-B.61	Set the CAN BUS board address to 30	30	30	
3B-B.62	Select "CAN BUS I/F Side" to A	A	A	
3B-B.63	Click on the command READ ALL under the column Digital Readout	OK	OK	
3B-B.64	Verify the status of the following flags: BOARD STATUS OVT Alarm From O__1 Status: AH_OUT1 to O_11 Status: AH_OUT11 O_12 Status: AO_CCEB O_12 Trip: AO_CCEB	NOK OK ON ON OFF TRIP	NOK OK ON ON OFF TRIP	
3B-B.65	Set the CAN BUS board address to 31	31	31	
3B-B.66	Select "CAN BUS I/F Side" to B	B	B	
3B-B.67	Disconnect short circuit simulator	OK	OK	
3B-B.68	Set OFF the command O_12:AO_CCEB in commanding column and click on relative "W"	OK	OK	Protection reset
3B-B.69	Set ON the command O_12:AO_CCEB in commanding column and click on relative "W"	OK	OK	
3B-B.70	Click on the command READ ALL under the column Digital Readout	OK	OK	
3B-B.71	Verify the status of the following flags: BOARD STATUS O_12 Status: AO_CCEB O_12 Trip: AO_CCEB	OK ON OK	OK ON OK	
3B-B.72	Set the CAN BUS board address to 30	30	30	
3B-B.73	Select "CAN BUS I/F Side" to A	A	A	
3B-B.74	Click on the command READ ALL under the column Digital Readout	OK	OK	
3B-B.75	Verify the status of the following flags: BOARD STATUS O_12 Status: AO_CCEB O_12 Trip: AO_CCEB	OK ON OK	OK ON OK	
3B-B.76	Set the CAN BUS board address to 31	31	31	
3B-B.77	Select "CAN BUS I/F Side" to B	B	B	
3B-B.78	Set OFF the command All Outlets ON/OFF in commanding column and click on relative "W"	OK	OK	

DATE:	TEST CONDUCTOR	QA	CUSTOMER
22/07/2009	Albertin A.	Francini E.	

Questo documento contiene informazioni di proprietà di CARLO GAVAZZI SPACE SpA. Tutti i diritti sono riservati.

All information contained in this document are property of CARLO GAVAZZI SPACE SpA. All right reserved.

UUT DATA :	Model	PFM	Item	AMS02 POWER DISTRIBUTION SYSTEM	C.I.	PDS 18	S/N	FM01

STEP n°	TEST SEQUENCE	EXPECTED VALUE	MEASURED VALUE	REMARKS
3B-B.79	Switch OFF main power bus	OK	OK	
3B-B.80	Disconnect current probe	OK	OK	
3B-B.81	Switch OFF the "power switch "of "power switch box"	Switch OFF	Switch OFF	

10.3.2.6 SIDE B TELEMETRY VERIFICATION

10.3.2.6.1 INPUT STAGE CURRENT MONITOR

IBUS-B.1	Connect all the ESEM3B loads. The following column resumes the currents (with Main bus equal to 120V):	OK	OK	There is no need to check the current absorption of the loads. CCS load not connected
IBUS-B.2	Set all the loads of the other boards to 0A	OK	OK	
IBUS-B.3	Set power supply voltage to 120V	120V ± 0.2V	120,0 V	
IBUS-B.4	Set power supply current limitation to 27.5A	27.5A±0.5A	27,5 A	
IBUS-B.5	Switch ON the "power switch "of "power switch box"	OK	OK	
IBUS-B.6	Take note of input current	7,9A±0,5A	7,76 A	
IBUS-B.7	Select PDS controller software	program open	program open	
IBUS-B.8	Set the CAN BUS board address to 31	31	31	
IBUS-B.9	Select JMDC = 0	0	0	
IBUS-B.10	Select TX = A	A	A	
IBUS-B.11	Select RX = A	A	A	

OUTLET	CURRENT [A] SET
1	1,200±100mA
2	3,200±100mA
3	1,200±100mA
4	1,200±100mA
5	2,400±100mA
6	1,200±100mA
7	1,200±100mA
8	1,200±100mA
9	1,200±100mA
10	1,200±100mA
11	1,200±100mA
12	3,520±100mA

DATE:	TEST CONDUCTOR	QA	CUSTOMER
21/07/2009	Albertin A.	Francini E.	

Questo documento contiene informazioni di proprietà di CARLO GAVAZZI SPACE SpA. Tutti i diritti sono riservati.
All information contained in this document are property of CARLO GAVAZZI SPACE SpA. All right reserved.

UUT DATA : Model PFM Item AMS02 POWER DISTRIBUTION SYSTEM C.I. PDS 18 S/N FM01

STEP n°	TEST SEQUENCE	EXPECTED VALUE	MEASURED VALUE	REMARKS
IBUS-B.12	Select "CAN BUS I/F Side" to B	B	B	
IBUS-B.13	Select "PDS Side" to B	B	B	
IBUS-B.14	Click on Run flash command	OK	OK	
IBUS-B.15	Set the CAN BUS board address to 30	30	30	
IBUS-B.16	Select "CAN BUS I/F Side" to A	A	A	
IBUS-B.17	Click on Run flash command	OK	OK	
IBUS-B.18	Set the CAN BUS board address to 31	31	31	
IBUS-B.19	Select "CAN BUS I/F Side" to B	B	B	
IBUS-B.20	Click on ESEM3-B button	OK	OK	Button located on left side of PDS controller software window
IBUS-B.21	Verify the status of the following flags:			
	BOARD STATUS	OK	OK	
	OVT Alarm	OK	OK	
	O__1 CMD: AH_OUT1	ON	ON	
	O__2 CMD: AH_OUT2	ON	ON	
	O__3 CMD: AH_OUT3	ON	ON	
	O__4 CMD: AH_OUT4	OFF	OFF	
	O__5 CMD: AH_OUT5	OFF	OFF	
	O__6 CMD: AH_OUT6	ON	ON	
	O__7 CMD: AH_OUT7	OFF	OFF	
	O__8 CMD: AH_OUT8	OFF	OFF	
	O__9 CMD: AH_OUT9	OFF	OFF	
	O_10 CMD: AH_OUT10	OFF	OFF	
	O_11 CMD: AH_OUT11	OFF	OFF	
	O_12 CMD: AO_CCEB	OFF	OFF	
	O__1 Status: AH_OUT1	ON	ON	
	O__2 Status: AH_OUT2	ON	ON	
	O__3 Status: AH_OUT3	ON	ON	
	O__4 Status: AH_OUT4	OFF	OFF	
	O__5 Status : AH_OUT5	OFF	OFF	
	O__6 Status: AH_OUT6	ON	ON	
	O__7 Status: AH_OUT7	OFF	OFF	
	O__8 Status: AH_OUT8	OFF	OFF	
	O__9 Status: AH_OUT9	OFF	OFF	
	O_10 Status: AH_OUT10	OFF	OFF	
	O_11 Status: AH_OUT11	OFF	OFF	
	O_12 Status: AO_CCEB	OFF	OFF	
	O_12 Trip: AO_CCEB	OK	OK	

DATE:	TEST CONDUCTOR	QA	CUSTOMER
21/07/2009	Albertin A.	Francini E.	

Questo documento contiene informazioni di proprietà di CARLO GAVAZZI SPACE SpA. Tutti i diritti sono riservati.

All information contained in this document are property of CARLO GAVAZZI SPACE SpA. All right reserved.

UUT DATA : Model PFM Item AMS02 POWER DISTRIBUTION SYSTEM C.I. PDS 18 S/N FM01

STEP n°	TEST SEQUENCE	EXPECTED VALUE	MEASURED VALUE	REMARKS
IBUS-B.22	Push on Read All button in Analog Readout column	OK	OK	
IBUS-B.23	Take note of the following values in "Analog readout" column: Temperature O_12 Current: AO_CCEB Analog Ref. 2.5V	 -40°C<T<80C° 0,00A±0,45A 2,500V±150mV	 28,6 °C 0,17 A 2,5 V	
IBUS-B.24	Set OFF in the window All Outlets ON/OFF and push the relative "W" command	OK	OK	
IBUS-B.25	Take note of input current	1.1A±0.2A	1,1 A	
IBUS-B.26	Click on the command READ ALL under the column Digital Readout	OK	OK	
IBUS-B.27	Verify the status of the following flags: BOARD STATUS OVT Alarm From O__1 CMD: AH_OUT1 to O_11 CMD: AH_OUT11 O_12 CMD: AO_CCEB From O__1 Status: AH_OUT1 to O_11 Status: AH_OUT11 O_12 Status: AO_CCEB O_12 Trip: AO_CCEB	 OK OK OFF OFF OFF OFF OK	 OK OK OFF OFF OFF OFF OK	
IBUS-B.28	Fill the table at the end of paragraph	OK	OK	
IBUS-B.29	To switch ON the loads Set "ON" in the window "O_x: AH_OUTx" and push the relative "W" command	OK	OK	
IBUS-B.30	To read telemetries change from CAN BUS 30 to CAN BUS 31 using the following parameters: *CAN BUS 30 verification* Set the CAN BUS board address to 30 Select "CAN BUS I/F Side" to A *CAN BUS 31 verification* Set the CAN BUS board address to 31 Select "CAN BUS I/F Side" to B	OK	OK	
IBUS-B.31	Using the table at the end of paragraph verify that Iload-Itlm is lower than 7,6A	OK	OK	Verify that all telemetries are in line with tolerance 20% F.S. see RFW PDS-WV-CGS-002
IBUS-B.32	Set OFF in the window All Outlets ON/OFF and push the relative "W" command	OK	OK	
IBUS-B.33	Switch OFF the "power switch "of "power switch box"	Switch OFF	Switch OFF	
IBUS-B.34	Disconnect all Loads	OK	OK	

DATE:	TEST CONDUCTOR	QA	CUSTOMER
27/07/2009	Albertin A.	Francini E.	

Questo documento contiene informazioni di proprietà di CARLO GAVAZZI SPACE SpA. Tutti i diritti sono riservati.
All information contained in this document are property of CARLO GAVAZZI SPACE SpA. All right reserved.

STEP n°	TEST SEQUENCE	EXPECTED VALUE	MEASURED VALUE	REMARKS

Side B Input Stage - current monitors

	INPUT STAGE	
	CAN BUS 30	CAN BUS 31
Iload ~1,1A [A] – Loads OFF	1,09	1,09
Itlm ~1,1A [A] – Loads OFF	0,53	0,30
Itlm - Iload < 7,6A	-0,560	-0,790
Iload ~4,7A [A] – Switch ON out 1, 5	4,60	4,60
Itlm ~4,7A [A] – Switch ON out 1, 5	4,50	4,18
Itlm - Iload < 7,6A	-0,100	-0,420
Iload ~10,3A [A] – Switch ON out 2, 3 ,4	10,00	10,00
Itlm ~10,3A [A] – Switch ON out 2, 3, 4	10,10	9,76
Itlm - Iload < 7,6A	0,100	-0,240
Iload ~15,1A [A] – Switch ON out 6, 7, 8 ,9	14,60	14,60
Itlm ~15,1A [A] – Switch ON out 6, 7, 8 ,9	14,73	14,30
Itlm - Iload < 7,6A	0,130	-0,300
Iload ~21,1A [A] – Switch ON out 10, 11, 12	20,15	20,15
Itlm ~21,1A [A] – Switch ON out 10, 11, 12	20,23	19,78
Itlm - Iload < 7,6A	0,080	-0,370

Tab. 5: Side B Input Stage current monitors

Questo documento contiene informazioni di proprietà di CARLO GAVAZZI SPACE SpA. Tutti i diritti sono riservati.
All information contained in this document are property of CARLO GAVAZZI SPACE SpA. All right reserved.

10.3.2.6.2 INPUT STAGE – ESEM1A TELEMETRY

STEP n°	TEST SEQUENCE	EXPECTED VALUE	MEASURED VALUE	REMARKS
VBUS-B.1	Connect main power supply between BI_120V (positive) and BI_120V_RTN (negative)	J100 connected	J100	
VBUS-B.2	Set Power supply alim to 120V	120,00V±1,00V	120,0 V	
VBUS-B.3	Set output current limitation to 3A	3A±0,5A	3,0 A	
VBUS-B.4	Enable power supply output	enabled	enabled	
VBUS-B.5	Verify that green led of **"power switch box"** is lighted	Green led ligthed	Green led ligthed	
VBUS-B.6	Switch ON the **"power switch "of "power switch box"**	Switch ON	Switch ON	
VBUS-B.7	Verify that red led of **"power switch box"** is lighted	Red led ligthed	Red led ligthed	
VBUS-B.8	Verify the current absorption from Main Bus	1,10A±0,20A	1,1 A	Note: this current can be read from power supply display or amperometer. In case of power supply reading, verify the correctness of measurements.
VBUS-B.9	Select PDS controller software	program open	program open	
VBUS-B.10	Set the CAN BUS board address to 30	30	30	
VBUS-B.11	Select JMDC = 0	0	0	
VBUS-B.12	Select TX = A	A	A	
VBUS-B.13	Select RX = A	A	A	
VBUS-B.14	Select "CAN BUS I/F Side" to A	A	A	
VBUS-B.15	Select "PDS Side" to A	A	A	
VBUS-B.16	Click on Run flash command	OK	OK	
VBUS-B.17	Set the CAN BUS board address to 31	31	31	
VBUS-B.18	Select "CAN BUS I/F Side" to B	B	B	
VBUS-B.19	Click on Run flash command	OK	OK	
VBUS-B.20	Set the CAN BUS board address to 30	30	30	
VBUS-B.21	Select "CAN BUS I/F Side" to A	A	A	
VBUS-B.22	Fill the table at the end of paragraph	OK	OK	
VBUS-B.23	Connect a multimeter between PIN "bypass thermal interlock" (positive) and "PRI_GND"(negative) on side A of the J300 test box	OK	OK	
VBUS-B.24	To set the Voltage value use the multimeter connected on J300 test box	OK	OK	
VBUS-B.25	To read the telemetry of the ESEM1A board *Click on ESEM1A button and Press button "READ"*	OK	OK	Button located on left side of software window
VBUS-B.26	To read the telemetry of the INPUT STAGE *Click on button "READ" relevant to INPUT STAGE*	OK	OK	Button located on left side of software window
VBUS-B.27	To read telemetries change from CAN BUS 30 to CAN BUS 31 using the following parameters: *CAN BUS 30 verification*	OK	OK	

DATE:	TEST CONDUCTOR	QA	CUSTOMER
27/07/2009	Albertin A.	Francini E.	

Questo documento contiene informazioni di proprietà di CARLO GAVAZZI SPACE SpA. Tutti i diritti sono riservati.

All information contained in this document are property of CARLO GAVAZZI SPACE SpA. All right reserved.

UUT DATA : **Model** **PFM** **Item** **AMS02 POWER DISTRIBUTION SYSTEM** **C.I.** **PDS 18** **S/N** **FM01**

STEP n°	TEST SEQUENCE	EXPECTED VALUE	MEASURED VALUE	REMARKS
	Set the CAN BUS board address to 30 **Select** "CAN BUS I/F Side" to A *CAN BUS 31 verification* Set the CAN BUS board address to 31 Select "CAN BUS I/F Side" to B			
VBUS-B.28	Using the table at the end of paragraph verify that Iload-Itlm is lower than 9.5V	OK	OK	Verify that all telemetries are in line with tolerance 5% F.S.
VBUS-B.29	Switch OFF main power bus	OK	OK	
VBUS-B.30	Switch OFF the "power switch "of "power switch box"	Switch OFF	Switch OFF	

DATE:	TEST CONDUCTOR	QA	CUSTOMER
27/07/2009	Albertin A.	Francini E.	

Questo documento contiene informazioni di proprietà di CARLO GAVAZZI SPACE SpA. Tutti i diritti sono riservati.
All information contained in this document are property of CARLO GAVAZZI SPACE SpA. All right reserved.

STEP n°	TEST SEQUENCE	EXPECTED VALUE	MEASURED VALUE	REMARKS

Side B Input Stage – Esem1A telemetry

	INPUT STAGE		ESEM1A	
	CAN BUS 30	CAN BUS 31	CAN BUS 30	CAN BUS 31
Vbus 90V [V]	90,17	90,17	90,17	90,17
Vtel 90 [V]	90,8	92,3	92,0	89,2
Vtlm - Vbus < 9,5V	0,630	2,130	1,830	-0,970
Vbus 110V [V]	110,44	110,44	110,44	110,44
Vtel 110 [V]	111,7	112,5	112,4	111,0
Vtlm - Vbus < 9,5V	1,260	2,060	1,960	0,560
Vbus 120V [V]	120,04	120,04	120,04	120,04
Vtel 120 [V]	121,1	122,0	121,1	119,6
Vtlm - Vbus < 9,5V	1,060	1,960	1,060	-0,440
Vbus 130V [V]	130,62	130,62	130,62	130,62
Vtel 130 [V]	131,5	132,0	131,4	133,0
Vtlm - Vbus < 9,5V	0,880	1,380	0,780	2,380
Vbus 145V [V]	145,72	145,72	145,72	145,72
Vtel 145 [V]	146,8	148,4	146,5	144,3
Vtlm - Vbus < 9,5V	1,080	2,680	0,780	-1,420

Tab. 6: Side B Input Stage - ESEM 1-A telemetry

Questo documento contiene informazioni di proprietà di CARLO GAVAZZI SPACE SpA. Tutti i diritti sono riservati.
All information contained in this document are property of CARLO GAVAZZI SPACE SpA. All right reserved.

11. ANNEX PVS

PROCEDURE VARIATION SHEET ref. N°: PVS-01		
Test Procedure Ref.: PDS-PR-CGS-020 Is.1	Page Revised: 29	Paragraph Revised: 3.1.5.2

Description of Change:

The Test Sequence was:

Verify that all the cables of the section are connected

The Test Sequence is:

Verify that all the cables of the section are connected and all loads are set to 0A.

Reason for Change:

Unit check must start without current absorption from loads.

CONCURRENCE				
Test Cond. Albertin A.	QA Francini E.	System Eng. Alia S.		Customer
Date 23/07/09	Date 23/07/09	Date 23-7-09		Date

Questo documento contiene informazioni di proprietà di CARLO GAVAZZI SPACE SpA. Tutti i diritti sono riservati.
All information contained in this document are property of CARLO GAVAZZI SPACE SpA. All right reserved.

PROCEDURE VARIATION SHEET ref. N°: PVS-02

Test Procedure Ref.:	Page Revised:	Paragraph Revised:
PDS-PR-CGS-020 Is.1	42, 48, 94, 101, 107, 113	PB2-2-A. 12, PB2-3-A.12, PB2-1-B.12, PB2-2-B.12, PB2-3-B.12, PB2-4-B.12

Description of Change:

The Test Sequence and Expected value were:

Set input bus current limitation to 15A	15A±1A

The Test Sequence and Expected value are:

Set input bus current limitation to 27,5A	27,5A±1A

Reason for Change:

Typing error

CONCURRENCE

Test Cond. Albertin A.	QA Francini E.	System Eng. Alia S.		Customer
Date 24/07/09	Date 24/07/09	Date 24-7-09		Date

Questo documento contiene informazioni di proprietà di CARLO GAVAZZI SPACE SpA. Tutti i diritti sono riservati.
All information contained in this document are property of CARLO GAVAZZI SPACE SpA. All right reserved.

PROCEDURE VARIATION SHEET ref. N°: PVS-03

Test Procedure Ref.:	Page Revised:	Paragraph Revised:
PDS-PR-CGS-020 Is.1	76	3.2.2.1

Description of Change:

The Expected Value was:

J100 connected

The Expected Value is:

J200 connected

Reason for Change:

Typing error

CONCURRENCE

Test Cond. Albertin A.	QA Francini E.	System Eng. Alia S.		Customer
Date 24/7/09	Date 24/07/09	Date 24-7-09		Date

Questo documento contiene informazioni di proprietà di CARLO GAVAZZI SPACE SpA. Tutti i diritti sono riservati.
All information contained in this document are property of CARLO GAVAZZI SPACE SpA. All right reserved.

PROCEDURE VARIATION SHEET ref. N°: PVS-04

Test Procedure Ref.:	Page Revised:	Paragraph Revised:
PDS-PR-CGS-020 Is.1	89	1A-B.2

Description of Change:

The Test Sequence and Expected value were:

Set input bus current limitation to 15A	15A

The Test Sequence and Expected value are:

Set input bus current limitation to 27,5A	27,5A±1A

Reason for Change:

Typing error

CONCURRENCE

Test Cond. Albertin A.	QA Francini E.	System Eng. Alia S.		Customer
Date 24/07/09	Date 24/07/09	Date 24-7-09		Date

Questo documento contiene informazioni di proprietà di CARLO GAVAZZI SPACE SpA. Tutti i diritti sono riservati.
All information contained in this document are property of CARLO GAVAZZI SPACE SpA. All right reserved.

PROCEDURE VARIATION SHEET ref. N°: PVS-05

Test Procedure Ref.:	Page Revised:	Paragraph Revised:
PDS-PR-CGS-020 Is.1	55, 114	PB2-4-A.36, PB2-4-B.36

Description of Change:

The measured value was:

-40°C<T<80C°
2,000V±150mV

The measured value is:

N.A.

Reason for Change:

The test is not necessary because it is performed 7 steps later.

CONCURRENCE

Test Cond. Albertin A.	QA Francini E.	System Eng. Alla S.		Customer
Date 24/07/09	Date 24/07/09	Date 24-7-09		Date

Questo documento contiene informazioni di proprietà di CARLO GAVAZZI SPACE SpA. Tutti i diritti sono riservati.
All information contained in this document are property of CARLO GAVAZZI SPACE SpA. All right reserved.

PROCEDURE VARIATION SHEET ref. N°: PVS-06

Test Procedure Ref.:	Page Revised:	Paragraph Revised:
PDS-PR-CGS-020 Is.1	60, 119	3A-4-A.47, 3A-4-B.47

Description of Change:

The step 3A-4-A.47 and relative 3A-4-B.47 have been added.

Reason for Change:

For safety reasons, the main bus is switched off.

CONCURRENCE

Test Cond. Albertin A.	QA Francini E.	System Eng. Alia S.		Customer
Date 24/07/09	Date 24/07/09	Date 24-7-09		Date

Questo documento contiene informazioni di proprietà di CARLO GAVAZZI SPACE SpA. Tutti i diritti sono riservati.
All information contained in this document are property of CARLO GAVAZZI SPACE SpA. All right reserved.

PROCEDURE VARIATION SHEET ref. N°: PVS-07

Test Procedure Ref.:	Page Revised:	Paragraph Revised:
PDS-PR-CGS-020 Is.1	65	3B-A.52

Description of Change:

The step 3B-A.52 has been added. As consequence the numeration of steps from 3B-A.52 to 3B-A.80 becomes from 3B-A.53 to 3B-A.81.

Reason for Change:

In order to verify the correctness off the voltages of steps 3B-A.53, the main bus voltage must be measured.

CONCURRENCE

Test Cond. Albertin A.	QA Franclni E.	System Eng. Alia S.		Customer
Date 24/07/08	Date 24/07/09	Date 24-7-09		Date

Questo documento contiene informazioni di proprietà di CARLO GAVAZZI SPACE SpA. Tutti i diritti sono riservati.
All information contained in this document are property of CARLO GAVAZZI SPACE SpA. All right reserved.

PROCEDURE VARIATION SHEET ref. N°: PVS-08

Test Procedure Ref.:	Page Revised:	Paragraph Revised:
PDS-PR-CGS-020 Is.1	124	3B-B.52

Description of Change:

The step 3B-B.52 has been added. As consequence the numeration of steps from 3B-B.52 to 3B-B.80 becomes from 3B-B.53 to 3B-B.81.

Reason for Change:

In order to verify the correctness off the voltages of steps 3B-B.53, the main bus voltage must be measured.

CONCURRENCE

Test Cond. Albertin A.	QA Francini E.	System Eng. Alia S.		Customer
Date 27/07/09	Date 27/07/09	Date 27-7-09		Date

Questo documento contiene informazioni di proprietà di CARLO GAVAZZI SPACE SpA. Tutti i diritti sono riservati.
All information contained in this document are property of CARLO GAVAZZI SPACE SpA. All right reserved.

PROCEDURE VARIATION SHEET ref. N°: PVS-09

Test Procedure Ref.:	Page Revised:	Paragraph Revised:
PDS-PR-CGS-020 Is.1	65, 124	3B-A.53, 3B-B.53

Description of Change:

The Expected value was:

117,00V<V<120,00V
117,00V<V<120,00V
117,00V<V<120,00V
117,00V<V<120,00V
117,00V<V<120,00V
117,00V<V<120,00V
117,00V<V<120,00V
117,00V<V<120,00V
117,00V<V<120,00V
117,00V<V<120,00V
117,00V<V<120,00V
117,00V<V<120,00V

The expected value is:

115,00V<V<120,00V
115,00V<V<120,00V
115,00V<V<120,00V
115,00V<V<120,00V
115,00V<V<120,00V
115,00V<V<120,00V
115,00V<V<120,00V
115,00V<V<120,00V
115,00V<V<120,00V
115,00V<V<120,00V
115,00V<V<120,00V
115,00V<V<120,00V

Reason for Change:

Typing error.

CONCURRENCE

Test Cond. Albertin A.	QA Francini E.	System Eng. Alia S.		Customer
Date 24/07/09	Date 24/07/09	Date 24-7-09		Date

Questo documento contiene informazioni di proprietà di CARLO GAVAZZI SPACE SpA. Tutti i diritti sono riservati.
All information contained in this document are property of CARLO GAVAZZI SPACE SpA. All right reserved.

12. CONCLUSION

Test successfully completed.

Questo documento contiene informazioni di proprietà di CARLO GAVAZZI SPACE SpA. Tutti i diritti sono riservati.
All information contained in this document are property of CARLO GAVAZZI SPACE SpA. All right reserved.