


1. PROJECT CODE SA-AMS		2. JPIC CODE AMS		AMS-02 TASK SHEET (ATS)			
3. TYPE	A	CONFIGURATION CHANGE		<input checked="" type="checkbox"/>	4. ATS NO. TCS000001-1-15		5. PAGE 1 OF 16
		PERMANENT	<input checked="" type="checkbox"/>	TEMPORARY	<input type="checkbox"/>	6. MOD SHEET(S) NUMBER(S)	
	B	NONCONFIGURATION CHANGE		<input type="checkbox"/>			
10. PART NAME TCs installation				11. Sub Detector Name Star Tracker Cameras		12. SERIAL/LOT NO. - NA	
14. APPLICABLE DOCUMENTS							
18. ATS TITLE TCs installation on Star Tracker							
20. OPER SEQ. NO.		21. OPERATIONS (Print, Type, or Write Legibly)					VERIFICATION
							22. TECH
							23. QA/DV
		<p align="center"><u>NOTE CAUTION WARNING</u></p> <p align="center">THIS ATS COVERS ALL THE INTEGRATION STEPS NEEDED FOR THE INSTALLATION OF THE FLIGHT OR NON-FLIGHT THERMOCOUPLES;</p> <p align="center">AS A GENERAL REQUIREMENTS ALL THE STEPS SHALL BE DONE:</p> <p align="center">- IN A CONTROLLED ENVIRONMENT (CLEAN ROOM);</p> <p align="center">- BY TECHNICIANS.</p>					
24. ORIGINATOR F.Santarossa (CARSO) 24OCT2009				DATE		25. FINAL ACCEPTANCE STAMP AND DATE	
APPROVALS (Printed or Typed and Signed)							
26. PROJECT ENGINEER Paolo Trampus (CARSO) 24OCT2009				DATE		27. QUALITY ENGINEER	
28. Corrado Gargiulo (INFN)						29. Giovanni Ambrosi (INFN)	
30. Joseph Burger (AMS thermal)						31. Serena Borsini (INFN)	

		5. Page 2 of 16	
AMS-02 TASK SHEET (ATS) CONTINUATION PAGE		4. ATS NO.	TCS000001-1-15
		6. MOD NO.	
20. OPER SEQ. NO.	21. OPERATIONS (Print, Type, or Write Legibly)	VERIFICATION	
		22. TECH	23. QA/DV
	<p>The purpose of this ATS is to describe how and where to fix the flight or non-flight thermocouples on Star tracker.</p>  <p>The TCs are the thermal sensors that will be used during the general AMS02 thermal-vacuum test at ESTEC.</p> <p>Thermocouples accessible after the thermal vacuum test will be removed. These are called non-flight thermocouples.</p> <p>Thermocouples not accessible after the TVTB test are called flight thermocouples. The cables of these sensors will be cut as much as possible near the TCs head, after the thermo-vacuum test at ESTEC.</p> <p>The Project Engineer on site has the option to recorder steps as required .</p> <ol style="list-style-type: none"> 1. Open this ATS 2. HARDWARE AVAILABILITY AND IDENTIFICATION Before starting the installation check the availability of the following hardware and fill the following tables with all the technical information. <p>2.1 TCs sensors list</p>		

5. Page 3 of 16																																																																												
AMS-02 TASK SHEET (ATS) CONTINUATION PAGE				4. ATS NO. 6. MOD NO.	TCS000001-1-15																																																																							
20. OPER SEQ. NO.	21. OPERATIONS (Print, Type, or Write Legibly)				VERIFICATION 22. TECH 23. QA/DV																																																																							
2.2 2.3 2.4 2.5 2.6	<table border="1" style="margin: 20px auto; width: 80%; border-collapse: collapse;"> <thead> <tr> <th>Sensor number</th> <th>Sensor type</th> <th>Part number</th> <th>Cable length (m)</th> <th>Temporary(T)/ Permanent (P)</th> <th>Note</th> </tr> </thead> <tbody> <tr><td>1</td><td>TC</td><td>ST TC #1</td><td>5</td><td>P</td><td></td></tr> <tr><td>2</td><td>TC</td><td>ST TC #2</td><td>5</td><td>P</td><td></td></tr> <tr><td>3</td><td>TC</td><td>ST TC #3</td><td>5</td><td>P</td><td></td></tr> <tr><td>4</td><td>TC</td><td>ST TC #4</td><td>5</td><td>P</td><td></td></tr> <tr><td>5</td><td></td><td>ST TC #5</td><td></td><td>T</td><td></td></tr> <tr><td>6</td><td></td><td>ST TC #6</td><td></td><td>T</td><td></td></tr> <tr><td>7</td><td></td><td>ST TC #7</td><td></td><td>T</td><td></td></tr> <tr><td>8</td><td></td><td>ST TC #8</td><td></td><td>T</td><td></td></tr> </tbody> </table> <div style="margin-bottom: 20px;"> TCs datasheet. </div> <div style="margin-bottom: 20px;"> Reader for TCs verification : Type: Keythley 2000 El Pool 0113 0055 Part Number: 1088916 </div> <div style="margin-bottom: 20px;"> Instruction sheet/manual for use of reader (multimeter) </div> <div style="margin-bottom: 20px;"> Kapton Tape: <table border="1" style="margin: 10px auto; width: 60%; border-collapse: collapse;"> <thead> <tr> <th>Tape P/N</th> <th>Lot Number</th> <th>Expiration Date</th> <th>Note</th> </tr> </thead> <tbody> <tr> <td>3M 1205 25 mm</td> <td>8218-07</td> <td>N/A</td> <td></td> </tr> </tbody> </table> </div> <div> Aluminum tape: <table border="1" style="margin: 10px auto; width: 60%; border-collapse: collapse;"> <thead> <tr> <th>Tape P/N</th> <th>Lot Number</th> <th>Expiration Date</th> <th>Note</th> </tr> </thead> <tbody> <tr> <td>3M 425 50 mm</td> <td>8227-21-68</td> <td>April 24, 2010</td> <td></td> </tr> </tbody> </table> </div>				Sensor number	Sensor type	Part number	Cable length (m)	Temporary(T)/ Permanent (P)	Note	1	TC	ST TC #1	5	P		2	TC	ST TC #2	5	P		3	TC	ST TC #3	5	P		4	TC	ST TC #4	5	P		5		ST TC #5		T		6		ST TC #6		T		7		ST TC #7		T		8		ST TC #8		T		Tape P/N	Lot Number	Expiration Date	Note	3M 1205 25 mm	8218-07	N/A		Tape P/N	Lot Number	Expiration Date	Note	3M 425 50 mm	8227-21-68	April 24, 2010			
Sensor number	Sensor type	Part number	Cable length (m)	Temporary(T)/ Permanent (P)	Note																																																																							
1	TC	ST TC #1	5	P																																																																								
2	TC	ST TC #2	5	P																																																																								
3	TC	ST TC #3	5	P																																																																								
4	TC	ST TC #4	5	P																																																																								
5		ST TC #5		T																																																																								
6		ST TC #6		T																																																																								
7		ST TC #7		T																																																																								
8		ST TC #8		T																																																																								
Tape P/N	Lot Number	Expiration Date	Note																																																																									
3M 1205 25 mm	8218-07	N/A																																																																										
Tape P/N	Lot Number	Expiration Date	Note																																																																									
3M 425 50 mm	8227-21-68	April 24, 2010																																																																										

5. Page 4 of 16																																																						
AMS-02 TASK SHEET (ATS) CONTINUATION PAGE			4. ATS NO.	TCS000001-1-15																																																		
			6. MOD NO.																																																			
20. OPER SEQ. NO.	21. OPERATIONS (Print, Type, or Write Legibly)			VERIFICATION																																																		
				22. TECH 23. QA/DV																																																		
2.7	Tool to clean the Star Tracker mounting surface.																																																					
2.8	Label for cables: use Kapton tape as label and a permanent marker to write the TCs identification number on the tape.																																																					
2.9	Isopropyl alcohol.																																																					
2.10	Antistatic cloth.																																																					
2.11	Camera																																																					
3.	TCs PRE-INSTALLATION VERIFICATION Before to install the TCs on the detector, check their correct functioning using the handheld reader and compare the results with the temperature in the clean room. See instruction sheet for use of a Multimeter for thermocouple readout																																																					
3.1	Take the reader.																																																					
3.2	Take all the available TCs.																																																					
3.3	For each sensor fill the following table (the data logger reads Temperature in °C directly): Note the clean room temperature: 24.3 °C																																																					
	<table border="1" style="width: 100%; border-collapse: collapse; text-align: center;"> <thead> <tr> <th>Part number</th> <th>Measured value (°C)</th> <th>Datasheet value</th> <th>Temperature value (°C)</th> <th>OK</th> </tr> </thead> <tbody> <tr> <td>ST TC #1</td> <td>28.2</td> <td></td> <td>29.3</td> <td>OK</td> </tr> <tr> <td>ST TC #2</td> <td>26.2</td> <td></td> <td>29.1</td> <td>OK</td> </tr> <tr> <td>ST TC #3</td> <td>24.8</td> <td></td> <td>27.8</td> <td>OK</td> </tr> <tr> <td>ST TC #4</td> <td>26.1</td> <td></td> <td>31.8</td> <td>OK</td> </tr> <tr><td> </td><td> </td><td> </td><td> </td><td> </td></tr> <tr><td> </td><td> </td><td> </td><td> </td><td> </td></tr> <tr><td> </td><td> </td><td> </td><td> </td><td> </td></tr> <tr><td> </td><td> </td><td> </td><td> </td><td> </td></tr> <tr><td> </td><td> </td><td> </td><td> </td><td> </td></tr> </tbody> </table>				Part number	Measured value (°C)	Datasheet value	Temperature value (°C)	OK	ST TC #1	28.2		29.3	OK	ST TC #2	26.2		29.1	OK	ST TC #3	24.8		27.8	OK	ST TC #4	26.1		31.8	OK																									
Part number	Measured value (°C)	Datasheet value	Temperature value (°C)		OK																																																	
ST TC #1	28.2		29.3	OK																																																		
ST TC #2	26.2		29.1	OK																																																		
ST TC #3	24.8		27.8	OK																																																		
ST TC #4	26.1		31.8	OK																																																		
4.	ST TC																																																					

		5. Page 5 of 16	
AMS-02 TASK SHEET (ATS) CONTINUATION PAGE		4. ATS NO.	TCS000001-1-15
		6. MOD NO.	
20. OPER SEQ. NO.	21. OPERATIONS (Print, Type, or Write Legibly)	VERIFICATION	
		22. TECH	23. QA/DV
4.1	#1 INSTALLATION		
	SURFACE CLEANING According to the Figure 1, clean the substrate surface (3 cm x 3 cm approximately) for the sensor installation.		
	4.1.1 The location of the thermocouple is shown in Figure 2.		
	4.1.2 Clean the surface using the cloth paper and the Isopropyl alcohol. <div data-bbox="264 719 1107 1048" data-label="Image"> </div>		
	Figure 1 – General TC mounting technique <div data-bbox="296 1149 1126 1935" data-label="Image"> </div>		
	Figure 2 – ST TC #1 position on the electronic frame interface		

5. Page 6 of 16										
AMS-02 TASK SHEET (ATS) CONTINUATION PAGE			4. ATS NO.	TCS000001-1-15						
			6. MOD NO.							
20. OPER SEQ. NO.	21. OPERATIONS (Print, Type, or Write Legibly)			VERIFICATION						
				22. TECH 23. QA/DV						
4.2	SENSOR FIXATION									
4.2.1	Take one of the available TCs and fill the table: <table border="1" data-bbox="274 613 1241 761"> <tr> <td>TC identification number</td> <td>Part number</td> <td>Location of the TC on electronic frame interface</td> </tr> <tr> <td>ST TC #1</td> <td>N/A</td> <td>As in Figure</td> </tr> </table>			TC identification number	Part number	Location of the TC on electronic frame interface	ST TC #1	N/A	As in Figure	
TC identification number	Part number	Location of the TC on electronic frame interface								
ST TC #1	N/A	As in Figure								
4.2.2	Wrap the thermocouple in a small piece of Kapton tape to insulate it and position it on the subdetector OR put a piece of Kapton tape on the subsystem surface, on the clean area, center the thermocouple on this tape, and fix it in place with a larger piece of Kapton tape.									
4.2.3	Take a photo to show the exact configuration.									
4.2.4	Cover the thermocouple and Kapton tape with a larger piece of aluminum tape to fix it firmly in place (recommended AL tape size: ~2.5cmx2.5cm)									
4.2.5	Take a photo									
4.2.6	Record the photos files numbers: ST TC#1, TC fixation photos files numbers STTC#1_sect_4.2.3.jpg STTC#1_sect_4.2.5a.jpg STTC#1_sect_4.2.5b.jpg									
4.2.7	According to the ST installation position, report the cabling layout in the Figure 3. Fix the cable using ALUMINUM tape. Typically one piece of tape every 20 cm.									
WARNING										
BEFORE TO PUT THE ALUMINUM TAPE, CLEAN THE SURFACE WITH ISOPROPYL ALCOHOL										

AMS-02 TASK SHEET (ATS)

CONTINUATION PAGE

4. ATS NO.

TCS000001-1-15

6. MOD NO.

20. OPER
SEQ. NO.21. OPERATIONS
(Print, Type, or Write Legibly)

VERIFICATION

22. TECH

23. QA/DV




Figure 3 – ST TC #1 cable fixation.



- 4.2.8 Take pictures of the cables layout and record the photos files numbers:
ST TC #1, cable fixation photos files numbers: STTC#1_sect_4.2.8a.jpg
STTC#1_sect_4.2.8b.jpg

- 4.3 TC IDENTIFICATION.
Put the TC identification number “ST TC #1” 10 cm far from the cable end using the cable label.
If the thermocouple and cable on AMS will be hidden later, place a second label near where the cable will emerge, if this location is known.

- 4.4 TC VERIFICATION AFTER INSTALLATION
Check the functionality of the TC and fill the table:

TC identification number	Part number	Measured value	Datasheet value	Temperature value (°C)	OK
ST TC #1	N/A	24.0		24.9	OK

- 4.5 Touch TC head with gloved hand to check that temperature rises.

		5. Page 8 of 16	
AMS-02 TASK SHEET (ATS) CONTINUATION PAGE		4. ATS NO.	TCS000001-1-15
		6. MOD NO.	
20. OPER SEQ. NO.	21. OPERATIONS (Print, Type, or Write Legibly)	VERIFICATION	
		22. TECH	23. QA/DV
5.	ST TC #2 INSTALLATION		
5.1	SURFACE CLEANING According to the Figure 4, clean the substrate surface (3 cm x 3 cm approximately) for the sensor installation.		
5.1.1	The location of the thermocouple is shown in Figure 5.		
5.1.2	Clean the surface using the cloth paper and the Isopropyl alcohol.		
			
	Figure 4 – General TC mounting technique		
			
	Figure 5 – ST TC #2 position on the electronic frame interface		
5.2	SENSOR FIXATION		

5. Page 9 of 16									
AMS-02 TASK SHEET (ATS) CONTINUATION PAGE		4. ATS NO.	TCS000001-1-15						
		6. MOD NO.							
20. OPER SEQ. NO.	21. OPERATIONS (Print, Type, or Write Legibly)		VERIFICATION						
			22. TECH 23. QA/DV						
5.2.1	Take one of the available TCs and fill the table: <table border="1" style="margin: 10px auto; width: 60%;"> <tr> <th>TC identification number</th> <th>Part number</th> <th>Location of the TC on electronic frame interface</th> </tr> <tr> <td>ST TC #2</td> <td>N/A</td> <td>As in Figure</td> </tr> </table>		TC identification number	Part number	Location of the TC on electronic frame interface	ST TC #2	N/A	As in Figure	
TC identification number	Part number	Location of the TC on electronic frame interface							
ST TC #2	N/A	As in Figure							
5.2.2	Wrap the thermocouple in a small piece of Kapton tape to insulate it and position it on the subdetector OR put a piece of Kapton tape on the subsystem surface, on the clean area, center the thermocouple on this tape, and fix it in place with a larger piece of Kapton tape.								
5.2.3	Take a photo to show the exact configuration.								
5.2.4	Cover the thermocouple and Kapton tape with a larger piece of aluminum tape to fix it firmly in place (recommended AL tape size: ~2.5cmx2.5cm)								
5.2.5	Take a photo								
5.2.6	Record the photos files numbers: ST TC #2, TC fixation photos files numbers STTC#2_sect_5.2.3.jpg STTC#2_sect_5.2.5a.jpg STTC#2_sect_5.2.5b.jpg								
5.2.7	According to the Star tracker installation position, report the cabling layout in the Figure 6. Fix the cable using ALUMINUM tape. Typically one piece of tape every 20 cm.								
	WARNING BEFORE TO PUT THE ALUMINUM TAPE, CLEAN THE SURFACE WITH ISOPROPYL ALCOHOL								

AMS-02 TASK SHEET (ATS)

CONTINUATION PAGE

4. ATS NO.

TCS000001-1-15

6. MOD NO.

20. OPER
SEQ. NO.21. OPERATIONS
(Print, Type, or Write Legibly)

VERIFICATION

22. TECH

23. QA/DV






Figure 6 – ST TC #2 cable fixation.

- 5.2.8 Take pictures of the cables layout and record the photos files numbers:
ST TC #2, cable fixation photos files numbers: STTC#2_sect_5.2.8a.jpg
STTC#2_sect_5.2.8b.jpg

- 5.3 TC IDENTIFICATION.
Put the TC identification number “ST TC #2” 10 cm far from the cable end using the cable label.
If the thermocouple and cable on AMS will be hidden later, place a second label near where the cable will emerge, if this location is known.

- 5.4 TC VERIFICATION AFTER INSTALLATION
Check the functionality of the TC and fill the table:

TC identification number	Part number	Measured value	Datasheet value	Temperature value (°C)	OK
ST TC #2	N/A	23.8		25.1	OK

		5. Page 11 of 16	
AMS-02 TASK SHEET (ATS) CONTINUATION PAGE		4. ATS NO.	TCS000001-1-15
		6. MOD NO.	
20. OPER SEQ. NO.	21. OPERATIONS (Print, Type, or Write Legibly)	VERIFICATION	
		22. TECH	23. QA/DV
5.5	Touch TC head with gloved hand to check that temperature rises.		
6.	ST TC #3 INSTALLATION		
6.1	SURFACE CLEANING According to the Figure 7, clean the substrate surface (3 cm x 3 cm approximately) for the sensor installation.		
6.1.1	The location of the thermocouple is shown in Figure 8.		
6.1.2	Clean the surface using the cloth paper and the Isopropyl alcohol.		
	 <p>AL Tape (3M 425)</p> <p>Kapton tape (either folded around TC or bottom piece stuck on surface first)</p> <p>AMS</p>		
	Figure 7 – General TC mounting technique  <p>ST1</p> <p>ST TC #3</p> <p>ST TC #4</p>		
	Figure 8 –ST TC #3 position on the electronic frame interface		

5. Page 12 of 16										
AMS-02 TASK SHEET (ATS) CONTINUATION PAGE			4. ATS NO.	TCS000001-1-15						
			6. MOD NO.							
20. OPER SEQ. NO.	21. OPERATIONS (Print, Type, or Write Legibly)			VERIFICATION						
				22. TECH 23. QA/DV						
6.2	SENSOR FIXATION 6.2.1 Take one of the available TCs and fill the table: <table border="1" data-bbox="328 553 1295 701"> <tr> <td>TC identification number</td> <td>Part number</td> <td>Location of the TC on the electronic frame interface</td> </tr> <tr> <td>ST TC #3</td> <td>N/A</td> <td>As in Figure</td> </tr> </table>			TC identification number	Part number	Location of the TC on the electronic frame interface	ST TC #3	N/A	As in Figure	
TC identification number	Part number	Location of the TC on the electronic frame interface								
ST TC #3	N/A	As in Figure								
6.2.2	Wrap the thermocouple in a small piece of Kapton tape (to insulate it and position it on the subdetector OR put a piece of Kapton tape on the subsystem surface, on the clean area, center the thermocouple on this tape, and fix it in place with a larger piece of Kapton tape.									
6.2.3	Take a photo to show the exact configuration.									
6.2.4	Cover the thermocouple and Kapton tape with a larger piece of aluminum tape to fix it firmly in place (recommended AL tape size: ~2.5cmx2.5cm)									
6.2.5	Take a photo									
6.2.6	Record the photos files numbers: ST TC #3 , TC fixation photos files numbers STTC#3_sect_6.2.3.jpg STTC#3_sect_6.2.5a.jpg STTC#3_sect_6.2.5b.jpg									
6.2.7	According to the Star Tracker installation position, report the cabling layout in the Figure 9. Fix the cable using Aluminum tape. Typically one piece of tape every 20 cm.									
<p style="text-align: center;">WARNING</p> <p style="text-align: center;">BEFORE TO PUT THE ALUMINIUM TAPE, CLEAN THE SURFACE WITH ISOPROPYL ALCOHOL</p>										

AMS-02 TASK SHEET (ATS)

CONTINUATION PAGE

4. ATS NO.

TCS000001-1-15

6. MOD NO.

20. OPER
SEQ. NO.21. OPERATIONS
(Print, Type, or Write Legibly)

VERIFICATION

22. TECH

23. QA/DV




Figure 9 – ST TC #3 cable fixation.

6.2.8 Take pictures of the cables layout and record the photos files numbers:
ST TC #3 , cable fixation photos files numbers: STTC#3_sect_6.2.8.jpg

6.3 TC IDENTIFICATION.
Put the TC identification number “ST TC #3 ” 10 cm far from the cable end using the cable label.
If the thermocouple and cable on AMS will be hidden later, place a second label near where the cable will emerge, if this location is known.

6.4 TC VERIFICATION AFTER INSTALLATION
Check the functionality of the TC and fill the table:

TC identification number	Part number	Measured value	Datasheet value	Temperature value (°C)	OK
ST TC #3	N/A	23.6		25.2	OK

6.5 Touch TC head with gloved hand to check that temperature rises.

		5. Page 14 of 16	
AMS-02 TASK SHEET (ATS) CONTINUATION PAGE		4. ATS NO.	TCS000001-1-15
		6. MOD NO.	
20. OPER SEQ. NO.	21. OPERATIONS (Print, Type, or Write Legibly)	VERIFICATION	
		22. TECH	23. QA/DV
7.	ST TC #4 INSTALLATION		
7.1	SURFACE CLEANING According to the Figure 10, clean the substrate surface (3 cm x 3 cm approximately) for the sensor installation.		
7.1.1	The location of the thermocouple is shown in Figure 11.		
7.1.2	Clean the surface using the cloth paper and the Isopropyl alcohol. <div data-bbox="263 750 1109 1086" data-label="Image"> </div>		
	<div data-bbox="470 1108 1045 1153" data-label="Caption"> <p>Figure 10 – General TC mounting technique</p> </div> <div data-bbox="343 1176 1077 1870" data-label="Image"> </div>		
7.2	SENSOR FIXATION		

				5. Page 15 of 16								
AMS-02 TASK SHEET (ATS) CONTINUATION PAGE			4. ATS NO.		TCS000001-1-15							
			6. MOD NO.									
20. OPER SEQ. NO.	21. OPERATIONS (Print, Type, or Write Legibly)				VERIFICATION							
					22. TECH							
					23. QA/DV							
7.2.1	Take one of the available TCs and fill the table: <table border="1" style="margin: 10px auto; width: 60%;"> <tr> <td>TC identification number</td> <td>Part number</td> <td>Location of the TC on the electronic frame interface</td> </tr> <tr> <td>ST TC #4</td> <td>N/A</td> <td>As in Figure</td> </tr> </table>				TC identification number	Part number	Location of the TC on the electronic frame interface	ST TC #4	N/A	As in Figure		
TC identification number	Part number	Location of the TC on the electronic frame interface										
ST TC #4	N/A	As in Figure										
7.2.2	Wrap the thermocouple in a small piece of Kapton tape (to insulate it and position it on the subdetector OR put a piece of Kapton tape on the subsystem surface, on the clean area, center the thermocouple on this tape, and fix it in place with a larger piece of Kapton tape.											
7.2.3	Take a photo to show the exact configuration.											
7.2.4	Cover the thermocouple and Kapton tape with a larger piece of aluminum tape to fix it firmly in place (recommended AL tape size: ~2.5cmx2.5cm)											
7.2.5	Take a photo											
7.2.6	Record the photos files numbers: ST TC #4 , TC fixation photos files numbers STTC#4_sect_7.2.3.jpg STTC#4_sect_7.2.5.jpg											
7.2.7	According to the Star Tracker installation position, report the cabling layout in the Figure 12. Fix the cable using Aluminum tape. Typically one piece of tape every 20 cm.											
	WARNING BEFORE TO PUT THE ALUMINIUM TAPE, CLEAN THE SURFACE WITH ISOPROPYL ALCOHOL											

AMS-02 TASK SHEET (ATS)

CONTINUATION PAGE

4. ATS NO.

TCS000001-1-15

6. MOD NO.

VERIFICATION

20. OPER
SEQ. NO.21. OPERATIONS
(Print, Type, or Write Legibly)

22. TECH

23. QA/DV




Figure 12 – ST TC #4 cable fixation.

7.2.8 Take pictures of the cables layout and record the photos files numbers:
ST TC #4, cable fixation photos files numbers: STTC#4_sect_7.2.8.jpg

7.3 TC IDENTIFICATION.
Put the TC identification number "ST TC #4 " 10 cm far from the cable end using the cable label.
If the thermocouple and cable on AMS will be hidden later, place a second label near where the cable will emerge, if this location is known.

7.4 TC VERIFICATION AFTER INSTALLATION
Check the functionality of the TC and fill the table:

TC identification number	Part number	Measured value	Datasheet value	Temperature value (°C)	OK
ST TC #4	N/A	23.5		25.5	OK

7.5 Touch TC head with gloved hand to check that temperature rises.