



Doc.: RICSYS-ED-CGS-001

Issue: 1 Date: June 2008

ACCEPTANCE DATA PACKAGE

SECTION: 26 PAGE: 1 OF 1

OPERATION AND MAINTENANCE MANUAL

LIST OF DOCUMENTS INCLUDED IN THIS SECTION:

[illegible]

All information contained in this document are property of CARLO GAVAZZI SPACE SpA. All rights reserved.

Mod. N° ADP-SS-03/05 (Instructions: doc. GD-WI-CGS-006)



CARLO GAVAZZI SPACE SpA

RICH System

Tipo Doc.: MANUAL Doc. Type:		N° DRD: NA DRD N°:	
N° Doc.: RICSYS-MA-CGS-001 Doc. N°:	Ediz.: 1 Issue:	Data: 18/06/2008 Date:	Pagina 1 Di 14 Page Of
Titolo : RICH TCS REFLECTOR AND MECHANICAL ASSY HANDLING, STORAGE, OPERATION AND Title : MAINTENANCE MANUAL			

	Nome & Funzione Name & Function	Firma Signature	Data Date	LISTA DI DISTRIBUZIONE DISTRIBUTION LIST	N	A	I
Preparato da: Prepared by:	Duchini G. (DT/MT)		18/6/08	Interna / Internal			
Approvato da: Approved by:	Cinquepalmi C. (PC/CC)		18/06/08				
	Molina M. (DT/MT)		18/6/08				
	X Cremonesi L. (PA/QA)		19/6/08				
Applicazione autorizzata da: Application authorized by:	Olivier M. (DT/MT)		18/06/08	Esterna / External			
				Russo E. (ASI)	1		x
				Laurenti, G. (INFN)	1		x
Customer / Higher Level Contractor							
Accettato da: Accepted by:							
Approvato da: Approved by:							

N=Numero di copie A=Applicazione I=Informazione
N=Number of copy A=Application I=Information

Gestione documenti: Data Management:		18/06/08	File: RICSYS-MA-CGS-001_issue1.doc
	Firma / Signature	Data / Date	



CARLO GAVAZZI SPACE SpA

RICH System

RICH TCS REFLECTOR AND MECHANICAL ASSY HANDLING,
STORAGE, OPERATION AND MAINTENANCE MANUAL

N° Doc: RICSYS-MA-CGS-001
Doc N°:

Ediz.: 1 Data: 18/06/2008
Issue: Date:

Pagina 2 di 14
Page of

REGISTRAZIONE DELLE MODIFICHE / *CHANGE RECORD*

EDIZIONE <i>ISSUE</i>	DATA <i>DATE</i>	AUTORIZZAZIONE <i>CHANGE AUTHORITY</i>	OGGETTO DELLA MODIFICA E SEZIONI AFFETTE <i>REASON FOR CHANGE AND AFFECTED SECTIONS</i>
1	18/06/2008		First Issue



RICH System

N° Doc: RICSYS-MA-CGS-001
Doc N°:

Ediz.: 1 Data: 18/06/2008
/Issue: Date:

Pagina 3 di 14
Page 3 of 14


RICH TCS REFLECTOR AND MECHANICAL ASSY HANDLING, STORAGE, OPERATION AND MAINTENANCE MANUAL

LISTA DELLE PAGINE VALIDE / LIST OF VALID PAGES[illegible]

 CARLO GAVAZZI SPACE SpA	<h1>RICH System</h1>	N° Doc: RICSYS-MA-CGS-001 Doc N°:	
		Ediz.: 1 Issue:	Data: 18/06/2008 Date:
	RICH TCS REFLECTOR AND MECHANICAL ASSY HANDLING, STORAGE, OPERATION AND MAINTENANCE MANUAL	Pagina 4 Page	di 14 of

TABLE OF CONTENT

1.	SCOPE.....	5
2.	DOCUMENTS.....	5
2.1	APPLICABLE DOCUMENTS.....	5
2.2	REFERENCE DOCUMENTS.....	5
3.	ACRONYMS	6
4.	RICH TCS HARDWARE IDENTIFICATION AND DESCRIPTION.....	7
4.1	RICH ASSY MECHANICAL INTERFACES.....	8
4.2	RICH ASSY ELECTRICAL INTERFACES	8
5.	SHIPPING\HANDLING AND STORAGE.....	9
5.1	REFLECTOR UNPAKAGING AND HANDLING PROCEDURES	11
6.	PRODUCT OPERATION (GROUND) AND LIMITATIONS.....	13
7.	MAINTENANCE.....	14

 CARLO GAVAZZI SPACE SpA	<h1>RICH System</h1>	N° Doc: RICSYS-MA-CGS-001 Doc N°:	
	Ediz.: 1 Issue:		Data: 18/06/2008 Date:
	RICH TCS REFLECTOR AND MECHANICAL ASSY HANDLING, STORAGE, OPERATION AND MAINTENANCE MANUAL		Pagina 5 Page

1. SCOPE

The present document contains the information needed to correctly use the RICH TCS and mechanical subsystem hardware developed by CGS in terms of:

- Shipment/handling
- Storage
- Operation
- Maintenance

For technical details on RICH TCS and mechanical subsystem hardware refer to the applicable and reference documentation.


2. DOCUMENTS

2.1 APPLICABLE DOCUMENTS

AD	Document Number	Issue/Date	Rev.	Title/Applicability
1	AMS02-TN-004-CGS	5	02/03/2005	Preliminary Thermal Requirements for AMS02 Internal Interfaces
2	I/020/03/0	n/a	14/05/2003	RICH SYSTEM Contract


2.2 REFERENCE DOCUMENTS

RD	Document Number	Issue/Date	Rev.	Title/Applicability
1	AMS02-TN-CGS-007	Issue 2, 30/11/2005		AMS 120VDC and 28VDC HEATERS DESCRIPTION
2	10-RICSYS-00.001	27/07/2004	/	RICH SYSTEM ICD
3	RICSYS-TN-CGS-003	Issue 1, 21/06/2007		RICH HEATERS AND THERMOSTATS INTEGRATION DESCRIPTION
4	CGS RICH Reflector FM-00102			UNPACKING AND HANDLING PROCEDURES
5	RICSYS-ED-CGS-001	Issue 1, May 2007		ACCEPTANCE DATA PACKAGE RICH SYSYTEM

 CARLO GAVAZZI SPACE SpA	<h1>RICH System</h1>	N° Doc: RICSYS-MA-CGS-001 Doc N°:		
	RICH TCS REFLECTOR AND MECHANICAL ASSY HANDLING, STORAGE, OPERATION AND MAINTENANCE MANUAL	Ediz.: 1 Issue:	Data: 18/06/2008 Date:	Pagina 6 Page
			di 14 of	

3. ACRONYMS

AD	Applicable Documents
AMS	Alpha Magnetic Spectrometer (experiment)
CGS	Carlo Gavazzi Space
ECAL	Electromagnetic Calorimeter (detector)
H/W	Hardware
I/F	Interface
ID	Identification
MLI	Multi Layer Insulation
N.A.	Not Applicable
PDS	Power Distribution System
RD	Reference Documents
RICH	Ring Imaging Cherenkov (Detector)
TCS	Thermal Control System
ToF	Time of Flight (Detector)
VDA	Vacuum Deposited Aluminum

 CARLO GAVAZZI SPACE SpA	<h1>RICH System</h1>		N° Doc: RICSYS-MA-CGS-001 Doc N°:	
	RICH TCS REFLECTOR AND MECHANICAL ASSY HANDLING, STORAGE, OPERATION AND MAINTENANCE MANUAL		Ediz.: 1 Issue:	Data: 18/06/2008 Date:
			Pagina 7 Page	di 14 of

4. RICH TCS HARDWARE IDENTIFICATION AND DESCRIPTION

The RICH thermal and mechanical subsystem hardware is composed of:

- Composite Reflector
- Mechanical structure assy
- Thermostats and Heaters
- MLI blankets

In the following picture the Rich Assy is displayed.





Figure 4-1 RICH detector assembly

 CARLO GAVAZZI SPACE SpA	<h1>RICH System</h1>		N° Doc: RICSYS-MA-CGS-001 Doc N°:	
	RICH TCS REFLECTOR AND MECHANICAL ASSY HANDLING, STORAGE, OPERATION AND MAINTENANCE MANUAL		Ediz.: 1 Issue:	Data: 18/06/2008 Date:
			Pagina 8 Page	di 14 of

4.1 RICH ASSY MECHANICAL INTERFACES

The RICH mechanical interfaces are reported in [AD 2] (10-RICSYS-00.001 Rev. / - RICH SYSTEM ICD) and shown in the following picture:





Figure 4-2 RICH mechanical interfaces to the USS

4.2 RICH ASSY ELECTRICAL INTERFACES

The RICH electrical interface (used to supply power to thermostatically controlled heaters) are reported in [AD 3] (RICSYS-TN-CGS-003 issue 1 – RICH HEATERS AND THERMOSTATS INTEGRATION DESCRIPTION)

 CARLO GAVAZZI SPACE SpA	RICH System	N° Doc: RICSYS-MA-CGS-001 Doc N°:	
	RICH TCS REFLECTOR AND MECHANICAL ASSY HANDLING, STORAGE, OPERATION AND MAINTENANCE MANUAL	Ediz.: 1 Issue:	Data: 18/06/2008 Date:
		Pagina 9 Page	di 14 of

5. SHIPPING\HANDLING AND STORAGE

The shipping of the RICH TCS and mechanical subsystem HW must happen through its own transportation container to prevent excessive mechanical loads, according to standard space hardware transportation loads.



- Prevent damage and shock to the equipment during transportation.

The following environmental conditions shall be kept during the whole period of transportation:

- Temperature: $-20 \div +50^{\circ}\text{C}$
- Humidity: $20 \div 98 \%$
- Pressure: $959 \div 1048 \text{ mbar}$.

The transport container shall not be left for more than 15 minutes when not kept in this type of environment.

The transport container shall not be exposed to direct sunlight or rain.

Desiccants shall be used to preserve the required level of humidity. Silica gel shall be completely enclosed inside its dedicate packet in order to avoid any contamination with flight hardware.

Cushioning material must be used between the units and the outer container. The cushion material:

- Shall avoid the movement of the unit inside the container
- Shall reduce shocks on the unit
- Shall be made of materials which do not deteriorate or disaggregate, avoiding contamination of the unit.
- Shall avoid scratches or physical damage to the unit.

The RICH TCS and mechanical subsystem hardware must be always shipped and stored inside a container able to protect the hardware from unwanted contact with external objects that can damage the surfaces. The container must guarantee sufficient cleanliness and the hardware must be wrapped in antistatic envelope. The same applies if the hardware is temporary stored outside the container. In this case the environmental and cleanliness conditions must be as follows:



- During storage inside or outside container the hardware must be wrapped in antistatic envelope
- Storage temperature in the $20 \pm 10^{\circ}\text{C}$ ($-20 \div +50^{\circ}\text{C}$ during transportation)
- Storage humidity $40-70 \text{ \%RH}$ ($20 \div 98 \%$ during transportation)
- Cleanliness level Visibly clean

The personnel who are in charge of handling and transportation of the hardware shall be skilled personnel for handling of space qualified hardware.



- During installation, and in all following phases, special case must be paid in order not to damage the inner surface of the Mirror. (see dedicated paragraph for Mirror handling)

For handling of the TCS and mechanical subsystem HW outside the transport container apply the following guidelines:

- Extract RICH TSC and mechanical subsystem hardware from the transport container in at least a visibly clean area (Class 100.000 preferred)



CARLO GAVAZZI SPACE SpA

RICH System

RICH TCS REFLECTOR AND MECHANICAL ASSY HANDLING,
STORAGE, OPERATION AND MAINTENANCE MANUAL


N° Doc: RICSYS-MA-CGS-001
Doc N°:

Ediz.: 1 Data: 18/06/2008
Issue: Date:

Pagina 10 di 14
Page of



- Wear gloves
- Wear overall headgear and shoes cover suitable for the cleanliness level of the room and appropriate to avoid ESD
- Utilize wrist lace connected to the ground

 CARLO GAVAZZI SPACE SpA	RICH System	N° Doc: Doc N°:	RICSYS-MA-CGS-001		
	RICH TCS REFLECTOR AND MECHANICAL ASSY HANDLING, STORAGE, OPERATION AND MAINTENANCE MANUAL	Ediz.: Issue:	1	Data: Date:	18/06/2008
		Pagina Page	11	di of	14

5.1 REFLECTOR UNPAKAGING AND HANDLING PROCEDURES

Reflector shall be unpacked and handled following the below instructions (Ref [AD 4])

CGS RICH Reflector

FM-00102

Unpacking and Handling Procedures

Unpacking and Handling Procedures

RICH FM Reflector

Serial Number FM-00102

The following is a set of Handling and Packing Procedures for the RICH FM Mirror and Flight Spares, FS, for the AMS-02.

FM Container


The container for shipping the FM is the original container in which the mandrel was shipped to CMA. The FM is bolted to the conical ring supplied in the container by CGS. It is bolted from the 4 mounting points of the FM to 4 corresponding holes on the conical ring.

Unpacking the FM

1. Remove completely the bolts holding the shipping container halves together.
2. Carefully lift the top of the container straight up until the top has cleared the FM.
3. Remove the FM from the mounting cone at the 4 bolt locations at the base flange of the FM.
4. Remove completely the FM and place on a flat surface.

Handling the EM

1. Once the FM is unbolted, it is to be lifted off of the base by holding the reinforcement ribs on the back of the mirror.
2. **Under no circumstance is the surface of the mirror to be touched**
3. Always place the mirror on a flat level surface for storage.
4. Do not place a cover over the mirror unless the cover is designed so that it does not touch the surface of the mirror.
5. Do not place the mirror face down onto any surface for any reason. However, the mirror can be laid flat with the surface facing upward.
6. Do not attempt to clean the surface of the mirror with any chemicals or wipe the surface with a cloth of any kind. Small dust particles can be removed by either gently wiping with a feather duster or an aero or compressed gas duster.

 CARLO GAVAZZI SPACE SpA	RICH System		N° Doc: Doc N°:	RICSYS-MA-CGS-001	
	RICH TCS REFLECTOR AND MECHANICAL ASSY HANDLING, STORAGE, OPERATION AND MAINTENANCE MANUAL		Ediz.: Issue:	1	Data: Date: 18/06/2008
			Pagina Page	12	di of

Handling the FS

1. Carefully remove top of FS carton with the carton placed "Top" side up.
2. With gloves, carefully lift the FS out of the carton and place down on a table the convex side.
3. Carefully unwrap the FS covering
4. Use no sharp tools on the concave side of the FS to remove wrap.
5. Either place FS on its bottom edge or on its back side down for storage.
6. It is advisable to place a soft cloth over the FS while it is on the bottom edge.


Cleaning FM/FS Optical Surface

While it is not advisable to touch the optical surface of either the FM or FS, the following must be observed if cleaning should become necessary.

1. Using an aero duster or fine feather duster, carefully wipe any visible particulates from the optical surface.
2. Using a white Kleenex, with no lotion, colorant or scent, place a small amount, 10 – 15cc, of Isopropanol, IPA.
3. Carefully and gently wipe away the contaminated area until no streaking is visible. Do not completely wet the Kleenex with IPA as streaking can occur on the mirror surface, which is difficult to detect.
4. Never Dry Wipe the optical surface of the mirrors.
5. After adequately removing the contamination, carefully wipe away any residual lint from the Kleenex with either an aero duster or a fine feather duster.

Cleaning the Carbon Fiber, CF, Mirror Back and Reinforcement Structure

1. Using a soft lint-free cloth and a small amount of IPA, carefully wipe the contaminated areas of the CF structure.
2. After the contamination has been cleaned, carefully remove any residual lint with either an aero duster or fine feather duster.

 CARLO GAVAZZI SPACE SpA	<h1>RICH System</h1>		N° Doc: RICSYS-MA-CGS-001 Doc N°:	
	RICH TCS REFLECTOR AND MECHANICAL ASSY HANDLING, STORAGE, OPERATION AND MAINTENANCE MANUAL		Ediz.: 1 Issue:	Data: 18/06/2008 Date:
			Pagina 13 Page	di 14 of

6. PRODUCT OPERATION (GROUND) AND LIMITATIONS

Units operations for ground activities have to be performed only by skilled personnel and run in a clean room area (class 100000) and at standard ambient operation:

- | | |
|----------------------|----------------|
| 1. Temperature | 22°C ± 3°C |
| 2. Relative Humidity | 50% ± 10% |
| 3. Pressure | Ambient +1mbar |

For operation during test and flight refer to applicable test and flight operation procedures.

Unless otherwise specified apply the following operational limitations:




- Never feed the heaters with a voltage larger than 126VDC



- It is recommended to power the heaters only after they have been connected to their terminal blocks, unless it is strictly necessary to power single patches individually.



- For MLI operation special care must be applied to avoid MLI layers damage.

 CARLO GAVAZZI SPACE SpA	<h1 style="text-align: center;">RICH System</h1> RICH TCS REFLECTOR AND MECHANICAL ASSY HANDLING, STORAGE, OPERATION AND MAINTENANCE MANUAL	N° Doc: RICSYS-MA-CGS-001 Doc N°: Ediz.: 1 Data: 18/06/2008 Issue: Date: Pagina 14 di Page of 14
---	---	--

7. MAINTENANCE

The delivered hardware, once stored and handled according to the present document does not require on ground maintenance.

In case cleaning activity is requested use only isopropyl alcohol and cleaning towels



- Never use on the delivered hardware aggressive cleaning tools.
- Use only isopropyl alcohol for cleaning
- Perform regular visual inspections and in case of detected anomalies contact the supplier.