



---

## AMS Tracker Thermal Control Subsystem TTCB and condenser tube cutting procedure

**AMSTR-NLR-PR-008**  
**ISSUE 2.0**  
**OCTOBER 2007**

---

Sun Yat-Sen University (SYSU)  
National Aerospace Laboratory (NLR)  
Istituto Nazionale di Fisica Nucleare (INFN)  
Aerospace Industrial Development Corporation (AIDC)

	NAME	ORGANISATION/RESPONSIBILITY	SIGNATURE	DATE
PREPARED	J. van Es	NLR		
CHECKED	J. van Es	NLR / AMS SE		
AGREED	L. Timmermans	NLR / AMS PA		
APPROVED	J. van Es	NLR / AMS PM		
AUTHORISED	P. Dieleman	NLR Space Department		

FILENAME	AMSTR-NLR-PR-008_Tube_Cutting_Procedure_iss01.doc	ORDER-/CODENUMBER:	2494047
LAST SAVED	2007.12.10 07:34 by Utente	DIVISION:	AS&A
PRINTED	2009.01.12 16:52	DISTRIBUTION:	Unlimited
PAGES	10	CLASSIFICATION TITLE:	Unclassified

*No part of this document may be reproduced and/or disclosed, in any form or by any means,  
without the prior written permission of NLR.*



# AMS Tracker Thermal Control Subsystem

TTCB and condenser tube cutting

Page

Doc.Id

Issue

Date

2 of 10

AMSTR-NLR-PR-008

issue 3.0

January 2009

## Distribution list

Company	FOR*	Name	Comments
INFN	I	R. Battiston	
		M. Menichelli	
		C. Gargiulo	
		B. Alpat	
		A. Alvino	
		E. Laudi	
AMS	I	M. Capell	
		V. Koutsenko	
		R. Becker	
NLR	I	P. Dieleman	
		J.van Es	
		M. Bardet	
Jacobs Sverdrup	I	T. Martin	
		G. Clark	
AIDC	I	B. Hong	
		B. Hsu	
		W. Min Hsu	
CGS	I	M. Molina	
		C. Vettore	

A = Approval  
R = Review  
I = Input / Information

An electronic version of this document is available on the AMS TTCS website:

<https://ams-ttcs.nlr.nl>



# AMS Tracker Thermal Control Subsystem

TTCB and condenser tube cutting

Page	3 of 10
Doc.Id	AMSTR-NLR-PR-008
Issue	issue 3.0
Date	January 2009

## Document change log

<u>Change Ref.</u>	<u>Section(s)</u>	<u>Issue 1.0</u>
-	All	Initial issue
	<u>Section(s)</u>	<u>Issue 2.0</u>
	all	Reference for QM and FM condenser tube cutting before and after bending
	3.1	Argon instead of N2
		Filter dimension change to 0.45 instead of 10 micron
	<u>Section(s)</u>	<u>Issue 2.0</u>



# AMS Tracker Thermal Control Subsystem

TTCB and condenser tube cutting

Page	4 of 10
Doc.Id	AMSTR-NLR-PR-008
Issue	issue 3.0
Date	January 2009

## Summary

This document describes the tube cutting procedure which can be used for cutting of TTCS box internal and external tube parts and the condenser Inconel tubes after the bending.



# AMS Tracker Thermal Control Subsystem

TTCB and condenser tube cutting

Page	5 of 10
Doc.Id	AMSTR-NLR-PR-008
Issue	issue 3.0
Date	January 2009

## Contents

Document change log	3
Summary	4
1 Scope of the document	6
2 References documents	6
3 Tube cutting procedure	7
3.1 Tube cutting procedure sheets	7
END OF DOCUMENT	10

(10 pages in total)



# AMS Tracker Thermal Control Subsystem

TTCB and condenser tube cutting

Page 6 of 10  
Doc.Id AMSTR-NLR-PR-008  
Issue issue 3.0  
Date January 2009

## 1 Scope of the document

The procedure in this document describes the tube cutting procedure.

## 2 References documents

	Title	Number	Date
RD-1	TTCS Leak rate	AMSTR-NLR-TN-046-Issue 1.0	April 2006



# **AMS Tracker Thermal Control Subsystem**

**TTCB and condenser tube cutting**

Page	7 of 10
Doc.Id	AMSTR-NLR-PR-008
Issue	issue 3.0
Date	January 2009

## **3 Tube cutting procedure**

### **3.1 Tube cutting procedure sheets**

The tube cutting procedure sheets shall be filled in, and shall accompany the box and condenser tubes during its lifetime in order to be able to show what procedure was followed.

To minimise the amount of documentation the form is filled in:

1. The first time the tube cutting takes place
2. Every time the equipment for tube cutting is changed:
  - a. Change of tube cutting equipment
  - b. Changing of filters
  - c. Change of tube diameter (pressure needs to be adjusted)
  - d. Start working on another model (QM Primary, FM Primary, FM Secondary, FM external tubes, QM and FM condenser tubes after bending)

This is done to keep track of change in equipment. Any problems with welds and/or contamination can then be traced.



## AMS Tracker Thermal Control Subsystem

TTCB and condenser tube cutting procedure

Page 8 of 10  
Doc.Id. AMSTR-NLR-PR-008  
Issue issue 3.0  
Date January 2009

	Tube cutting procedure sheet		company:		date:	
	Fill in by hand.		engineer:		location:	
Step	Action	Monitoring	Value	Result	Comment	✓
1	Record model (FM1/FM2/QM) for which the cutting of tubes is performed	Model	-			
2	Record pipe part drawing number					
3	Make picture of part	Record picture time as on photo				
4	Perform visual inspection inlet and outlet tube	Clean/particles/grease				
5	Clean outside tube with IPA and lint-free cloth					
6	Record cutting equipment used	Manufacturer, type/serial number	-			
7	Record filter type	Manufacturer/filter size	0.45 µm			
8	Connect the filter and a clean flexible (silicone) hose to a N <sub>2</sub> -(or Argon )bottle delivering gaseous Argon gas as shown in figure.		-			






# AMS Tracker Thermal Control Subsystem

TTCB and condenser tube cutting procedure

Page 9 of 10  
Doc.Id. AMSTR-NLR-PR-008  
Issue issue 3.0  
Date January 2009

Tube cutting procedure sheet		company:		date:		
Fill in by hand.		engineer:		location:		
Step	Action	Monitoring	Value	Result	Comment	✓
						
9	Limit the pressure of the gaseous nitrogen/argon to a reasonable flow (0-4bar) check the used pressure prior to connecting the tube part	Pressure	0-4 bar			
10	Flow gaseous nitrogen/argon through the hose prior to connect to the tube part		-			
11	Connect the flexible hose to the tube as shown in above figure. Set a fixed gaseous flow	Check flow at outside				
12	Cut tube					
13	Make picture of set-up and record picture time					
14	Disconnect tube, clean outside with IPA and lint free cloth & perform visual inspection of cut surface	Flat square surface				
15	Cover tube end with caps and store in a clean box or clean environment for further integration					
16	End cutting of part (mention part number at comments)					



# **AMS Tracker Thermal Control Subsystem**

TTCB and condenser tube cutting

Page

Doc.Id

Issue

Date

10 of 10

AMSTR-NLR-PR-008

issue 3.0

January 2009

## END OF DOCUMENT