

AMS Tracker Thermal Control Subsystem

TTCB and condenser tube cutting procedure

Tube cutting procedure sheet		company:	date:		
	Fill in by hand.	engineer:	location:		
Step	Action	Monitoring	Value	Result	Comment
1	Record model (FM1/FM2/QM) for which the cutting of tubes is performed	Model <i>FM12</i>	-		
2	Record pipe part drawing number	<i>ET5998-08-19.9</i>	<i>22</i>		<i>405 piece</i> <i>1045 piece</i>
3	Make picture of part	Record picture time as on photo			<i>14:43</i>
4	Perform visual inspection inlet and outlet tube	Clean/particles/grease			
5	Clean outside tube with IPA and lint-free cloth				
6	Record cutting equipment used	Manufacturer, type/serial number	-		<i>Preburn 0227400 equipment</i>
7	Record filter type	Manufacturer/filter size	0.45 µm		<i>Feb 2</i> <i>BSF 12 impairs</i> <i>purge could gas</i> <i>3 LPH</i>
8	Connect the filter and a clean flexible (silicone) hose to a N ₂ -(or Argon) bottle delivering gaseous Argon gas as shown in figure.		-		

De burning with. Quality products technique 14:43. Feb 26. 2009
ser. no. 040681. Cordless driver 14:43 Feb 26. 2009



AMS Tracker Thermal Control Subsystem


TCB and condenser tube cutting procedure

Page 9 of 10

Doc.id. AMSTR-NLR-PR-008

Issue issue 3.0

Date January 2009

Tube cutting procedure sheet				company:	date:
Fill in by hand.				engineer:	location:
Step	Action	Monitoring	Value	Result	Comment
					14:36 28/02/2009
9	Limit the pressure of the gaseous nitrogen/argon to a reasonable flow (0-4bar) check the used pressure prior to connecting the tube part	Pressure	0-4 bar		3 LPH
10	Flow gaseous nitrogen/argon through the hose prior to connect to the tube part		-		
11	Connect the flexible hose to the tube as shown in above figure. Set a fixed gaseous flow	Check flow at outside			Pressure gas
12	Cut tube				
13	Make picture of set-up and record picture time				
14	Disconnect tube, clean outside with IPA and lint free cloth & perform visual inspection of cut surface	Flat square surface			
15	Cover tube end with caps and store in a clean box or clean environment for further integration				
16	End cutting of part (mention part number at comments)				



AMS Tracker Thermal Control Subsystem


TTCB and condenser tube cutting procedure

Page 8 of 10
Doc.id. AMSTR-NLR-PR-008
Issue issue 3.0
Date January 2009

	Tube cutting procedure sheet		company:	<i>NLR</i>	date:	<i>26/04/2009</i>	
	Fill in by hand.		engineer:	<i>J.v.Es</i>	location:	<i>Track the</i>	
Step	Action	Monitoring	Value	Result	Comment		✓
1	Record model (FM1/FM2/QM) for which the cutting of tubes is performed	Model <i>FT12</i>	-				✓
2	Record pipe part drawing number	<i>FT398-08-199</i>			<i>DRS Free</i>		✓
3	Make picture of part	Record picture time as on photo			<i>15:34 just after debarry</i>		
4	Perform visual inspection inlet and outlet tube	Clean/particles/grease					
5	Clean outside tube with IPA and lint-free cloth						
6	Record cutting equipment used	Manufacturer, type/serial number	-		<i>Metabo cutting 0227400</i>		
7	Record filter type	Manufacturer/filter size	0.45 µm				
8	Connect the filter and a clean flexible (silicone) hose to a N ₂ -(or Argon)bottle delivering gaseous Argon gas as shown in figure.		-				

AMS Tracker Thermal Control Subsystem

TTCB and condenser tube cutting procedure

Tube cutting procedure sheet				company:	date:	
	Fill in by hand.			engineer:	location:	
Step	Action	Monitoring	Value	Result	Comment	✓
					15:36 26/02/2009	✓
9	Limit the pressure of the gaseous nitrogen/argon to a reasonable flow (0-4bar) check the used pressure prior to connecting the tube part	Pressure	0-4 bar		5 L PH	✓
10	Flow gaseous nitrogen/argon through the hose prior to connect to the tube part		-			✓
11	Connect the flexible hose to the tube as shown in above figure. Set a fixed gaseous flow	Check flow at outside			5 L PH	✓
12	Cut tube					✓
13	Make picture of set-up and record picture time				15:34	✓
14	Disconnect tube, clean outside with IPA and lint free cloth & perform visual inspection of cut surface	Flat square surface				✓
15	Cover tube end with caps and store in a clean box or clean environment for further integration					✓
16	End cutting of part (mention part number at comments)					✓



AMS Tracker Thermal Control Subsystem

TTCB and condenser tube cutting procedure

Page 8 of 10
Doc.id. AMSTR-NLR-PR-008
Issue issue 3.0
Date January 2009


Tube cutting procedure sheet			company:	date:	
Fill in by hand.			engineer:	location:	
Step	Action	Monitoring	Value	Result	Comment
1	Record model (FM1/FM2/QM) for which the cutting of tubes is performed	Model #172	-		pre heater
2	Record pipe part drawing number		ET8998-124.3a.		
3	Make picture of part	Record picture time as on photo			17:13.
4	Perform visual inspection inlet and outlet tube	Clean/particles/grease			
5	Clean outside tube with IPA and lint-free cloth				
6	Record cutting equipment used	Manufacturer, type/serial number	-		pipe cutter + debur pin 14:143 26/02/2009
7	Record filter type	Manufacturer/filter size	0.45 µm		pruge gas filter
8	Connect the filter and a clean flexible (silicone) hose to a N ₂ -(or Argon)bottle delivering gaseous Argon gas as shown in figure.		-		



AMS Tracker **Thermal Control** **Subsystem**

TCB and condenser tube cutting procedure

Page 9 of 10
 Doc. Id. AMSTR-NLR-PR-008
 Issue issue 3.0
 Date January 2009

Tube cutting procedure sheet		company:		date:	
Fill in by hand.		engineer:		location:	
Step	Action	Monitoring	Value	Result	Comment
					
9	Limit the pressure of the gaseous nitrogen/argon to a reasonable flow (0-4bar) check the used pressure prior to connecting the tube part	Pressure	0-4 bar		
10	Flow gaseous nitrogen/argon through the hose prior to connect to the tube part		-		
11	Connect the flexible hose to the tube as shown in above figure. Set a fixed gaseous flow	Check flow at outside			
12	Cut tube				
13	Make picture of set-up and record picture time				
14	Disconnect tube, clean outside with IPA and lint free cloth & perform visual inspection of cut surface	Flat square surface			
15	Cover tube end with caps and store in a clean box or clean environment for further integration				
16	End cutting of part (mention part number at comments)				

Spool weld together ends, closed



AMS Tracker Thermal Control Subsystem

TCB and condenser tube cutting procedure

Page 8 of 10
Doc.id. AMSTR-NLR-PR-008
Issue issue 3.0
Date January 2009

	Tube cutting procedure sheet		company:	NLK	date:	26/02/2009	
	Fill in by hand.		engineer:	J. v. E.	location:	HT.	
Step	Action	Monitoring	Value	Result	Comment		
1	Record model (FM1/FM2/QM) for which the cutting of tubes is performed	Model FM2	-		pre heater		✓
2	Record pipe part drawing number		ET599 2-12-43 4.8		17.09. 26.2009		✓
3	Make picture of part	Record picture time as on photo					✓
4	Perform visual inspection inlet and outlet tube	Clean/particles/grease					✓
5	Clean outside tube with IPA and lint-free cloth						✓
6	Record cutting equipment used	Manufacturer, type/serial number	-		rip cutters		✓
7	Record filter type	Manufacturer/filter size	0.45 µm		filter purge		
8	Connect the filter and a clean flexible (silicone) hose to a N ₂ -(or Argon)bottle delivering gaseous Argon gas as shown in figure.		-				


see r.no 040681 (debeurgh)
see also 14143 26/02/2009



AMS Tracker Thermal Control Subsystem

TCB and condenser tube cutting procedure

Page 9 of 10
Doc. Id. AMSTR-NLR-PR-008
Issue issue 3.0
Date January 2009

Tube cutting procedure sheet				company:	date:	location:	
Fill in by hand.				engineer:			
Step	Action	Monitoring	Value	Result	Comment		✓
							✓
9	Limit the pressure of the gaseous nitrogen/argon to a reasonable flow (0-4bar) check the used pressure prior to connecting the tube part	Pressure	0-4 bar				
10	Flow gaseous nitrogen/argon through the hose prior to connect to the tube part		-				
11	Connect the flexible hose to the tube as shown in above figure. Set a fixed gaseous flow	Check flow at outside					
12	Cut tube						
13	Make picture of set-up and record picture time						
14	Disconnect tube, clean outside with IPA and lint free cloth & perform visual inspection of cut surface	Flat square surface					
15	Cover tube end with caps and store in a clean box or clean environment for further integration						
16	End cutting of part (mention part number at comments)						

spot welded together
caps added



AMS Tracker Thermal Control Subsystem

TTCB and condenser tube cutting procedure

Page 8 of 10
Doc. Id. AMSTR-NLR-PR-008
Issue issue 3.0
Date January 2009

Tube cutting procedure sheet			company:	date:	
Fill in by hand.			engineer:	location:	
Step	Action	Monitoring	Value	Result	Comment
1	Record model (FM1/FM2/QM) for which the cutting of tubes is performed	Model <i>FM2</i>	-	<i>J.v.Es</i>	<i>Pump inlet tube cutting</i>
2	Record pipe part drawing number			<i>J2</i>	<i>No drawing</i>
3	Make picture of part	Record picture time as on photo			<i>13:36 27 Feb 2009</i>
4	Perform visual inspection inlet and outlet tube	Clean/particles/grease			<i>with thermal additional tapping test</i>
5	Clean outside tube with IPA and lint-free cloth				
6	Record cutting equipment used	Manufacturer, type/serial number	-		<i>13:30</i>
7	Record filter type	Manufacturer/filter size	0.45 µm		<i>Purge welder</i>
8	Connect the filter and a clean flexible (silicone) hose to a N ₂ -(or Argon) bottle delivering gaseous Argon gas as shown in figure.		-		<i>gas during</i>


After cutting and deburring
1. Tapping on white cloth
2. Purge with closed outlet with capillary tube
Additional tapping with white cloth behind → no particles found



AMS Tracker Thermal Control Subsystem

TTCB and condenser tube cutting procedure

Page 9 of 10
Doc. Id. AMSTR-NLR-PR-008
Issue 3.0
Date January 2009

Tube cutting procedure sheet				company:	date:	location:	
Fill in by hand.				engineer:			
Step	Action	Monitoring	Value	Result	Comment		✓
		✓					
9	Limit the pressure of the gaseous nitrogen/argon to a reasonable flow (0-4bar) check the used pressure prior to connecting the tube part	Pressure	0-4 bar			with cap. flow + 5L/min	
10	Flow gaseous nitrogen/argon through the hose prior to connect to the tube part		-				
11	Connect the flexible hose to the tube as shown in above figure. Set a fixed gaseous flow	Check flow at outside					
12	Cut tube						
13	Make picture of set-up and record picture time						
14	Disconnect tube, clean outside with IPA and lint free cloth & perform visual inspection of cut surface	Flat square surface					
15	Cover tube end with caps and store in a clean box or clean environment for further integration					caps	✓
16	End cutting of part (mention part number at comments)						



AMS Tracker Thermal Control Subsystem

TTCB and condenser tube cutting procedure

Page 8 of 10
Doc. Id. AMSTR-NLR-PR-008
Issue 3.0
Date January 2009

Tube cutting procedure sheet				company:	date:	location:	
	Fill in by hand.			engineer:			
Step	Action	Monitoring	Value	Result	Comment		
1	Record model (FM1/FM2/QM) for which the cutting of tubes is performed	Model FM2	-		Pump in place cutting		✓
2	Record pipe part drawing number			51	no drawing		✓
3	Make picture of part	Record picture time as on photo			13:21, 13:25,		
4	Perform visual inspection inlet and outlet tube	Clean/particles/ grease					✓
5	Clean outside tube with IPA and lint-free cloth				13:34		
6	Record cutting equipment used	Manufacturer, type/serial number	-		Deburring with Heraeus 0227400		
7	Record filter type	Manufacturer/filter size	0.45 µm				
8	Connect the filter and a clean flexible (silicone) hose to a N ₂ -(or Argon) bottle delivering gaseous Argon gas as shown in figure.		-		No purging possible verified by cutting		



After cutting & deburring with gravity & tapping or clean cloth. Then a second check with capillary tube. No particles detected.



AMS Tracker Thermal Control Subsystem


TTCB and condenser tube cutting procedure

Page 9 of 10

Doc. Id. AMSTR-NLR-PR-008

Issue issue 3.0

Date January 2009

Tube cutting procedure sheet		company:		date:	
Fill in by hand.		engineer:		location:	
Step	Action	Monitoring	Value	Result	Comment
					
9	Limit the pressure of the gaseous nitrogen/argon to a reasonable flow (0-4bar) check the used pressure prior to connecting the tube part	Pressure	0-4 bar		same as J2 ±5 LPR.
10	Flow gaseous nitrogen/argon through the hose prior to connect to the tube part		-		
11	Connect the flexible hose to the tube as shown in above figure. Set a fixed gaseous flow	Check flow at outside			
12	Cut tube				
13	Make picture of set-up and record picture time				
14	Disconnect tube, clean outside with IPA and lint free cloth & perform visual inspection of cut surface	Flat square surface			
15	Cover tube end with caps and store in a clean box or clean environment for further integration				tape
16	End cutting of part (mention part number at comments)				



AMS Tracker Thermal Control Subsystem

TTCB and condenser tube cutting procedure

Page 8 of 10
Doc. Id. AMSTR-NLR-PR-008
Issue issue 3.0
Date January 2009

Tube cutting procedure sheet		company:	date:	
Fill in by hand.		engineer:	location:	
Step	Action	Monitoring	Value	Result
1	Record model (FM1/FM2/QM) for which the cutting of tubes is performed	Model <i>F172</i>	-	
2	Record pipe part drawing number		<i>pump</i>	<i>J1</i>
3	Make picture of part	Record picture time as on photo		
4	Perform visual inspection inlet and outlet tube	Clean/particles/grease		
5	Clean outside tube with IPA and lint-free cloth			
6	Record cutting equipment used	Manufacturer, type/serial number	-	
7	Record filter type	Manufacturer/filter size	0.45 µm	
8	Connect the filter and a clean flexible (silicone) hose to a N ₂ -(or Argon)bottle delivering gaseous Argon gas as shown in figure.		-	

*delivering gas
through the structure
+ Metabo 0227 400
equipment*



AMS Tracker Thermal Control Subsystem


TTCB and condenser tube cutting procedure

Page 9 of 10

Doc. Id. AMSTR-NLR-PR-008

Issue issue 3.0

Date January 2009

Tube cutting procedure sheet				date:	location:	
Fill in by hand.				company: engineer:		
Step	Action	Monitoring	Value	Result	Comment	✓
					6 LPH	
9	Limit the pressure of the gaseous nitrogen/argon to a reasonable flow (0-4bar) check the used pressure prior to connecting the tube part	Pressure	0-4 bar			
10	Flow gaseous nitrogen/argon through the hose prior to connect to the tube part		-			✓
11	Connect the flexible hose to the tube as shown in above figure. Set a fixed gaseous flow	Check flow at outside				✓
12	Cut tube					✓
13	Make picture of set-up and record picture time					✓
14	Disconnect tube, clean outside with IPA and lint free cloth & perform visual inspection of cut surface	Flat square surface				✓
15	Cover tube end with caps and store in a clean box or clean environment for further integration					✓
16	End cutting of part (mention part number at comments)					✓



AMS Tracker Thermal Control Subsystem

TCB and condenser tube cutting procedure

Page 8 of 10
Doc. Id. AMSTR-NLR-PR-008
Issue issue 3.0
Date January 2009

Tube cutting procedure sheet				company:	date:	
Fill in by hand.				engineer:	location:	
Step	Action	Monitoring	Value	Result	Comment	✓
1	Record model (FM1/FM2/QM) for which the cutting of tubes is performed	Model FM2	-		Pump outlet.	
2	Record pipe part drawing number		Pam	J2.	cut with saw (particles!)	
3	Make picture of part	Record picture time as on photo			11:57 27 Feb 2009	
4	Perform visual inspection inlet and outlet tube	Clean/particles/grease			12:06	
5	Clean outside tube with IPA and lint-free cloth					
6	Record cutting equipment used	Manufacturer, type/serial number	-		Deburring with ser no 040881 condenser driver	
7	Record filter type	Manufacturer/filter size	0.45 µm		purge gas filter	
8	Connect the filter and a clean flexible (silicone) hose to a N ₂ -(or Argon)bottle delivering gaseous Argon gas as shown in figure.		-			

First de burring with the saw 0227400



AMS Tracker Thermal Control Subsystem


TCB and condenser tube cutting procedure

Page 9 of 10

Doc. Id. AMSTR-NLR-PR-008

Issue issue 3.0

Date January 2009

Tube cutting procedure sheet				company:	date:	
Fill in by hand.				engineer:	location:	
Step	Action	Monitoring	Value	Result	Comment	✓
						
9	Limit the pressure of the gaseous nitrogen/argon to a reasonable flow (0-4bar) check the used pressure prior to connecting the tube part	Pressure	0-4 bar			
10	Flow gaseous nitrogen/argon through the hose prior to connect to the tube part		-			
11	Connect the flexible hose to the tube as shown in above figure. Set a fixed gaseous flow	Check flow at outside				
12	Cut tube					
13	Make picture of set-up and record picture time					✓
14	Disconnect tube, clean outside with IPA and lint free cloth & perform visual inspection of cut surface	Flat square surface				✓
15	Cover tube end with caps and store in a clean box or clean environment for further integration					✓
16	End cutting of part (mention part number at comments)					✓

54PR
just a small
blew more.)



AMS Tracker Thermal Control Subsystem

TTCB and condenser tube cutting procedure

Page 8 of 10

Doc. Id. AMSTR-NLR-PR-008

Issue issue 3.0

Date January 2009

Tube cutting procedure sheet		company:		date:	
Fill in by hand.		engineer:	J.V. Es	location:	27/02/2009 HT.
Step	Action	Monitoring	Value	Result	Comment
1	Record model (FM1/FM2/QM) for which the cutting of tubes is performed	Model F172	-		
2	Record pipe part drawing number	ET 5988-08-19-19			top condenser return line
3	Make picture of part	Record picture time as on photo			13:53.
4	Perform visual inspection inlet and outlet tube	Clean/particles/grease			
5	Clean outside tube with IPA and lint-free cloth				
6	Record cutting equipment used	Manufacturer, type/serial number	-		Takebo 0227400/less deburring with cond
7	Record filter type	Manufacturer/filter size	0.45 µm		purge filter
8	Connect the filter and a clean flexible (silicone) hose to a N ₂ -(or Argon) bottle delivering gaseous Argon gas as shown in figure.		-		

040681.



AMS Tracker Thermal Control Subsystem

TTCB and condenser tube cutting procedure

Page 9 of 10
Doc. Id. AMSTR-NLR-PR-008
Issue issue 3.0
Date January 2009

Tube cutting procedure sheet		company: <i>NLR</i>		date: <i>27/02/2009</i>		✓
Fill in by hand.		engineer:	<i>I. v. E.</i>	location:	<i>HT</i>	
Step	Action	Monitoring	Value	Result	Comment	
9	Limit the pressure of the gaseous nitrogen/argon to a reasonable flow (0-4bar) check the used pressure prior to connecting the tube part	Pressure	0-4 bar		<i>16 LPH</i>	<i>✓</i>
10	Flow gaseous nitrogen/argon through the hose prior to connect to the tube part		-			<i>✓</i>
11	Connect the flexible hose to the tube as shown in above figure. Set a fixed gaseous flow	Check flow at outside				<i>✓</i>
12	Cut tube				<i>14:27-14:31</i>	
13	Make picture of set-up and record picture time					
14	Disconnect tube, clean outside with IPA and lint free cloth & perform visual inspection of cut surface	Flat square surface				
15	Cover tube end with caps and store in a clean box or clean environment for further integration					
16	End cutting of part (mention part number at comments)					



AMS Tracker Thermal Control Subsystem

TTCB and condenser tube cutting procedure

Page 8 of 10
Doc. Id. AMSTR-NLR-PR-008
Issue issue 3.0
Date January 2009

Tube cutting procedure sheet				company:	date:	
Fill in by hand.				engineer:	location:	
Step	Action	Monitoring	Value	Result	Comment	✓
1	Record model (FM1/FM2/QM) for which the cutting of tubes is performed	Model FM2	-	OK	27/02/2009	
2	Record pipe part drawing number	ET 5998-8-19.18			bottom condenser return line	
3	Make picture of part	Record picture time as on photo			13:53	
4	Perform visual inspection inlet and outlet tube	Clean/particles/grease				
5	Clean outside tube with IPA and lint-free cloth					
6	Record cutting equipment used	Manufacturer, type/serial number	-		cut Metabo 02740e debber cordless driver 040681.	
7	Record filter type	Manufacturer/filter size	0.45 µm		weld gas filter	
8	Connect the filter and a clean flexible (silicone) hose to a N ₂ -(or Argon)bottle delivering gaseous Argon gas as shown in figure.		-			



AMS Tracker Thermal Control Subsystem


TTCB and condenser tube cutting procedure

Page 9 of 10

Doc. Id. AMSTR-NLR-PR-008

Issue issue 3.0

Date January 2009

Tube cutting procedure sheet			company:		date:	
Fill in by hand.			engineer:		location:	
Step	Action	Monitoring	Value	Result	Comment	
					10 LPR	✓
9	Limit the pressure of the gaseous nitrogen/argon to a reasonable flow (0-4bar) check the used pressure prior to connecting the tube part	Pressure	0-4 bar			✓
10	Flow gaseous nitrogen/argon through the hose prior to connect to the tube part		-			✓
11	Connect the flexible hose to the tube as shown in above figure. Set a fixed gaseous flow	Check flow at outside				✓
12	Cut tube				14.34 14.27	✓
13	Make picture of set-up and record picture time					
14	Disconnect tube, clean outside with IPA and lint free cloth & perform visual inspection of cut surface	Flat square surface				
15	Cover tube end with caps and store in a clean box or clean environment for further integration					
16	End cutting of part (mention part number at comments)					



Page	8 of 10
Doc.id.	AMSTR-NLR-PR-008
Issue	issue 3.0
Date	January 2009

Decorating internally with "vigil"
clean sheet afterwards.



AMS Tracker Thermal Control Subsystem


TTCB and condenser tube cutting procedure

Page 9 of 10

Doc. Id. AMSTR-NLR-PR-008

Issue issue 3.0

Date January 2009

Tube cutting procedure sheet		company:		date: 27/02/2009		
Fill in by hand.		engineer:		location: HTR		
Step	Action	Monitoring	Value	Result	Comment	
						✓
9	Limit the pressure of the gaseous nitrogen/argon to a reasonable flow (0-4bar) check the used pressure prior to connecting the tube part	Pressure	0-4 bar		10 L/min	✓
10	Flow gaseous nitrogen/argon through the hose prior to connect to the tube part		-			✓
11	Connect the flexible hose to the tube as shown in above figure. Set a fixed gaseous flow	Check flow at outside				✓
12	Cut tube					✓
13	Make picture of set-up and record picture time				see fresh page	✓
14	Disconnect tube, clean outside with IPA and lint free cloth & perform visual inspection of cut surface	Flat square surface				✓
15	Cover tube end with caps and store in a clean box or clean environment for further integration					✓
16	End cutting of part (mention part number at comments)					



AMS Tracker Thermal Control Subsystem

TTCB and condenser tube cutting procedure

Page 8 of 10

Doc. Id. AMSTR-NLR-PR-008

Issue issue 3.0

Date January 2009

Tube cutting procedure sheet				company:		date:	
Fill in by hand.				engineer:	J.v. Es	27/02/2009	
Step	Action	Monitoring	Value	Result	Comment		
1	Record model (FM1/FM2/QM) for which the cutting of tubes is performed	Model FM2	-				
2	Record pipe part drawing number		ET 5998-08-19.17		Evaporator line		
3	Make picture of part	Record picture time as on photo			15:23, 27/02/2009		
4	Perform visual inspection inlet and outlet tube	Clean/particles/grease					
5	Clean outside tube with IPA and lint-free cloth						
6	Record cutting equipment used	Manufacturer, type/serial number	-		Heftabo 0227400 + debar 040681		
7	Record filter type	Manufacturer/filter size	0.45 µm		Purge gas seal-off		
8	Connect the filter and a clean flexible (silicone) hose to a N ₂ -(or Argon) bottle delivering gaseous Argon gas as shown in figure.		-				


Removal internal debris with jet
cleanliness check afterwards



AMS Tracker Thermal Control Subsystem

TTCB and condenser tube cutting procedure

Page 9 of 10
Doc. Id. AMSTR-NLR-PR-008
Issue issue 3.0
Date January 2009

Tube cutting procedure sheet				company:	date:	location:	
Fill in by hand.				engineer:			
Step	Action	Monitoring	Value	Result	Comment		
							✓
9	Limit the pressure of the gaseous nitrogen/argon to a reasonable flow (0-4bar) check the used pressure prior to connecting the tube part	Pressure	0-4 bar		10 LPH		✓
10	Flow gaseous nitrogen/argon through the hose prior to connect to the tube part		-				✓
11	Connect the flexible hose to the tube as shown in above figure. Set a fixed gaseous flow	Check flow at outside					✓
12	Cut tube						✓
13	Make picture of set-up and record picture time					see first page	✓
14	Disconnect tube, clean outside with IPA and lint free cloth & perform visual inspection of cut surface	Flat square surface					✓
15	Cover tube end with caps and store in a clean box or clean environment for further integration						✓
16	End cutting of part (mention part number at comments)				closed after welding		✓



AMS Tracker Thermal Control Subsystem

TTCB and condenser tube cutting procedure

Page 8 of 10
Doc. Id. AMSTR-NLR-PR-008
Issue issue 3.0
Date January 2009


Tube cutting procedure sheet			company:	date: 27/02/2009		
Fill in by hand.			engineer:	location: HT.		
Step	Action	Monitoring	Value	Result	Comment	✓
1	Record model (FM1/FM2/QM) for which the cutting of tubes is performed	Model #172	-		Acces Pelting inlet outlet.	
2	Record pipe part drawing number				no drawing, 16.5g.	✓
3	Make picture of part	Record picture time as on photo			16.5g.	✓
4	Perform visual inspection inlet and outlet tube	Clean/particles/grease				✓
5	Clean outside tube with IPA and lint-free cloth					✓
6	Record cutting equipment used	Manufacturer, type/serial number	-		pipe cutter.	✓
7	Record filter type	Manufacturer/filter size	0.45 µm		wet set-up filter	✓
8	Connect the filter and a clean flexible (silicone) hose to a N ₂ -(or Argon) bottle delivering gaseous Argon gas as shown in figure.		-			



AMS Tracker Thermal Control Subsystem

TTCB and condenser tube cutting procedure

Page 9 of 10
Doc. Id. AMSTR-NLR-PR-008
Issue issue 3.0
Date January 2009

Tube cutting procedure sheet				company:	date:	
Fill in by hand.				engineer:	location:	
Step	Action	Monitoring	Value	Result	Comment	
					9 L PR	✓
9	Limit the pressure of the gaseous nitrogen/argon to a reasonable flow (0-4bar) check the used pressure prior to connecting the tube part	Pressure	0-4 bar			✓
10	Flow gaseous nitrogen/argon through the hose prior to connect to the tube part		-			✓
11	Connect the flexible hose to the tube as shown in above figure. Set a fixed gaseous flow	Check flow at outside			16:59	✓
12	Cut tube				17:04 + 17:06	✓
13	Make picture of set-up and record picture time					
14	Disconnect tube, clean outside with IPA and lint free cloth & perform visual inspection of cut surface	Flat square surface				✓
15	Cover tube end with caps and store in a clean box or clean environment for further integration					
16	End cutting of part (mention part number at comments)				After finished.	



AMS Tracker Thermal Control Subsystem

TTCB and condenser tube cutting procedure

Page 8 of 10
Doc. Id. AMSTR-NLR-PR-008
Issue issue 3.0
Date January 2009

Tube cutting procedure sheet			company:	date:	
	Fill in by hand.		engineer:	location:	
Step	Action	Monitoring	Value	Result	Comment
1	Record model (FM1/FM2/QM) for which the cutting of tubes is performed	Model	-		APR Tube cutting
2	Record pipe part drawing number				dead end.
3	Make picture of part	Record picture time as on photo			11:10 Mar. 2. 2009
4	Perform visual inspection inlet and outlet tube	Clean/particles/grease			Atop
5	Clean outside tube with IPA and lint-free cloth				
6	Record cutting equipment used	Manufacturer, type/serial number	-		pipe cutter used
7	Record filter type	Manufacturer/filter size	0.45 µm		Purged of the residuals with capillary.
8	Connect the filter and a clean flexible (silicone) hose to a N ₂ -(or Argon)bottle delivering gaseous Argon gas as shown in figure.		-		

Deburring with Metabo and cordless driver 040681
022700


with
gutter



AMS Tracker Thermal Control Subsystem

TTCB and condenser tube cutting procedure

Page 9 of 10
Doc. Id. AMSTR-NLR-PR-008
Issue issue 3.0
Date January 2009

Tube cutting procedure sheet				company:	date:	
Fill in by hand.				engineer:	location:	
Step	Action	Monitoring	Value	Result	Comment	
						✓
9	Limit the pressure of the gaseous nitrogen/argon to a reasonable flow (0-4bar) check the used pressure prior to connecting the tube part	Pressure	0-4 bar		→ 10 L PH	✓
10	Flow gaseous nitrogen/argon through the hose prior to connect to the tube part		-			✓
11	Connect the flexible hose to the tube as shown in above figure. Set a fixed gaseous flow	Check flow at outside			11:11 11:14	✓
12	Cut tube				11:20	
13	Make picture of set-up and record picture time					
14	Disconnect tube, clean outside with IPA and lint free cloth & perform visual inspection of cut surface	Flat square surface				
15	Cover tube end with caps and store in a clean box or clean environment for further integration					
16	End cutting of part (mention part number at comments)					✓

cleaned with tapping
and checked with
capillary tube
covered by tape.



AMS Tracker Thermal Control Subsystem

TTCB and condenser tube cutting procedure

Tube cutting procedure sheet				company:	date:	
Fill in by hand.				engineer:	location:	
Step	Action	Monitoring	Value	Result	Comment	
1	Record model (FM1/FM2/QM) for which the cutting of tubes is performed	Model FM2	-			✓
2	Record pipe part drawing number	ET5998	-08-19.7		Special bend part as a new feed pipe and fit	✓
3	Make picture of part	Record picture time as on photo			11:06 AM 2.2.2009	✓
4	Perform visual inspection inlet and outlet tube	Clean/particles/grease			See below	
5	Clean outside tube with IPA and lint-free cloth					✓
6	Record cutting equipment used	Manufacturer, type/serial number	-			
7	Record filter type	Manufacturer/filter size	0.45 µm		Purge gas set-up	
8	Connect the filter and a clean flexible (silicone) hose to a N ₂ -(or Argon) bottle delivering gaseous Argon gas as shown in figure.		-			

try 2 N.B re-opened again because of not fit re bending \Rightarrow re-check cleanliness (on parallel section) they in your section removed — check purged with cloth \rightarrow ok 15:30 J.E.

try 1 copy the part check on cleanliness after spot weld



AMS Tracker Thermal Control Subsystem


TTCB and condenser tube cutting procedure

Page 9 of 10

Doc. Id. AMSTR-NLR-PR-008

Issue issue 3.0

Date January 2009

Tube cutting procedure sheet				company:	date:	
Fill in by hand.				engineer:	location:	
Step	Action	Monitoring	Value	Result	Comment	✓
					10 LPH during clean check.	
9	Limit the pressure of the gaseous nitrogen/argon to a reasonable flow (0-4bar) check the used pressure prior to connecting the tube part	Pressure	0-4 bar			✓
10	Flow gaseous nitrogen/argon through the hose prior to connect to the tube part		-			✓
11	Connect the flexible hose to the tube as shown in above figure. Set a fixed gaseous flow	Check flow at outside				✓
12	Cut tube					✓
13	Make picture of set-up and record picture time					
14	Disconnect tube, clean outside with IPA and lint free cloth & perform visual inspection of cut surface	Flat square surface				✓
15	Cover tube end with caps and store in a clean box or clean environment for further integration				See PR 13:42	✓
16	End cutting of part (mention part number at comments)				02/03/2009	



AMS Tracker Thermal Control Subsystem

TCB and condenser tube cutting procedure

Page 8 of 10

Doc.id. AMSTR-NLR-PR-008

Issue issue 3.0


Date January 2009

Tube cutting procedure sheet				company:	date:	
Fill in by hand.				engineer:	location:	
Step	Action	Monitoring	Value	Result	Comment	
1	Record model (FM1/FM2/QM) for which the cutting of tubes is performed	Model F112	-		Pellets pipe inlet cutting	✓
2	Record pipe part drawing number		ET 5998-08-4.3		connections to Enbco 4.3	
3	Make picture of part	Record picture time as on photo			13:07 re-cut	
4	Perform visual inspection inlet and outlet tube	Clean/particles/grease			14:02	✓
5	Clean outside tube with IPA and lint-free cloth					✓
6	Record cutting equipment used	Manufacturer, type/serial number	-		Petabo + 0227400 deburr equipment 040681	
7	Record filter type	Manufacturer/filter size	0.45 µm			
8	Connect the filter and a clean flexible (silicone) hose to a N ₂ -(or Argon)bottle delivering gaseous Argon gas as shown in figure.		-			

3/3/2009
After COA contamination cut tubes
are inspected and they are ok -!
3/3/2009 16:25,

AMS Tracker Thermal Control Subsystem

TTCB and condenser tube cutting procedure

Tube cutting procedure sheet				company:	date:
Fill in by hand.				engineer:	location:
Step	Action	Monitoring	Value	Result	Comment
					
9	Limit the pressure of the gaseous nitrogen/argon to a reasonable flow (0-4bar) check the used pressure prior to connecting the tube part	Pressure	0-4 bar		4 LPH
10	Flow gaseous nitrogen/argon through the hose prior to connect to the tube part		-		
11	Connect the flexible hose to the tube as shown in above figure. Set a fixed gaseous flow	Check flow at outside			
12	Cut tube				
13	Make picture of set-up and record picture time				13:07 Mar 2, 2009
14	Disconnect tube, clean outside with IPA and lint free cloth & perform visual inspection of cut surface	Flat square surface			
15	Cover tube end with caps and store in a clean box or clean environment for further integration				
16	End cutting of part (mention part number at comments)				

14:05
no picture



AMS Tracker Thermal Control Subsystem

TCB and condenser tube cutting procedure

Page 8 of 10

Doc.id. AMSTR-NLR-PR-008

Issue issue 3.0

Date January 2009

Tube cutting procedure sheet				company:	date:	
Fill in by hand.				engineer:	location:	
Step	Action	Monitoring	Value	Result	Comment	
1	Record model (FM1/FM2/QM) for which the cutting of tubes is performed	Model FM2	-		Pre-halter cleanliness check. cat	✓
2	Record pipe part drawing number					
3	Make picture of part	Record picture time as on photo			10:21 after cutting	
4	Perform visual inspection inlet and outlet tube	Clean/particles/grease				
5	Clean outside tube with IPA and lint-free cloth					
6	Record cutting equipment used	Manufacturer, type/serial number	-		pipe cutter	
7	Record filter type	Manufacturer/filter size	0.45 µm		purge filter cover set-up	
8	Connect the filter and a clean flexible (silicone) hose to a N ₂ -(or Argon)bottle delivering gaseous Argon gas as shown in figure.		-			✓



AMS Tracker Thermal Control Subsystem


TCB and condenser tube cutting procedure

Page 9 of 10

Doc. Id. AMSTR-NLR-PR-008

Issue Issue 3.0

Date January 2009

Tube cutting procedure sheet					
	Fill in by hand.				
Step	Action	Monitoring	Value	Result	Comment
					
9	Limit the pressure of the gaseous nitrogen/argon to a reasonable flow (0-4bar) check the used pressure prior to connecting the tube part	Pressure	0-4 bar		5 LPR
10	Flow gaseous nitrogen/argon through the hose prior to connect to the tube part		-		
11	Connect the flexible hose to the tube as shown in above figure. Set a fixed gaseous flow	Check flow at outside			
12	Cut tube				
13	Make picture of set-up and record picture time				
14	Disconnect tube, clean outside with IPA and lint free cloth & perform visual inspection of cut surface	Flat square surface			
15	Cover tube end with caps and store in a clean box or clean environment for further integration				
16	End cutting of part (mention part number at comments)				

checked & clean lines
of sample

10:21 03/03/2009



AMS Tracker
Thermal Control
Subsystem

TCB and condenser tube cutting procedure

COH
contamin-
ation

Tube cutting procedure sheet				company: <i>NLR</i>		date: <i>02/03/2009</i>	
Fill in by hand.				engineer: <i>I.v.E</i>		location: <i>17x</i>	
Step	Action	Monitoring	Value	Result	Comment	✓	
1	Record model (FM1/FM2/QM) for which the cutting of tubes is performed	Model <i>FM2</i>	-		<i>cold growth heater inlet to outlet cutting</i>		
2	Record pipe part drawing number						
3	Make picture of part	Record picture time as on photo			<i>17:07</i>		
4	Perform visual inspection inlet and outlet tube	Clean/particles/grease					
5	Clean outside tube with IPA and lint-free cloth						
6	Record cutting equipment used	Manufacturer, type/serial number	-		<i>pipe cutter + 2 times debris.</i>		
7	Record filter type	Manufacturer/filter size	0.45 µm		<i>large self-cp</i>		
8	Connect the filter and a clean flexible (silicone) hose to a N ₂ -(or Argon)bottle delivering gaseous Argon gas as shown in figure.		-				

022700
Hetebo
+
coodles
driver
040631

Remark: Visual inspection showed. Contamination
Very likely caused by cleaning agent after soldering COH.
The COH is cleaned by pumping IPA through it all night.
Visual inspection showed clean lines in the morning.



AMS Tracker Thermal Control Subsystem

TCB and condenser tube cutting procedure

Page 9 of 10
Doc. Id. AMSTR-NLR-PR-008
Issue issue 3.0
Date January 2009

Tube cutting procedure sheet		company:	date:		
Fill in by hand.		engineer:	location:		
Step	Action	Monitoring	Value	Result	Comment
9	Limit the pressure of the gaseous nitrogen/argon to a reasonable flow (0-4bar) check the used pressure prior to connecting the tube part	Pressure	0-4 bar		10 L/min
10	Flow gaseous nitrogen/argon through the hose prior to connect to the tube part		-		
11	Connect the flexible hose to the tube as shown in above figure. Set a fixed gaseous flow	Check flow at outside			
12	Cut tube				
13	Make picture of set-up and record picture time				
14	Disconnect tube, clean outside with IPA and lint free cloth & perform visual inspection of cut surface	Flat square surface			17.10 02/03/2009
15	Cover tube end with caps and store in a clean box or clean environment for further integration				
16	End cutting of part (mention part number at comments)				



AMS Tracker
Thermal Control
Subsystem

TTCB and condenser tube cutting procedure

Tube cutting procedure sheet				company:	date:	
Fill in by hand.				engineer:	location:	
Step	Action	Monitoring	Value	Result	Comment	✓
1	Record model (FM1/FM2/QM) for which the cutting of tubes is performed	Model <i>FT172</i>	-		<i>DPS prefix to perform</i>	✓
2	Record pipe part drawing number	<i>ET599</i>	<i>0-08.</i>	<i>19.16</i> <i>19.15.</i>	<i>pipe cutting</i>	✓
3	Make picture of part	Record picture time as on photo				✓
4	Perform visual inspection inlet and outlet tube	Clean/particles/grease			<i>cleanliness checked afterwards with white cloth</i>	
5	Clean outside tube with IPA and lint-free cloth					
6	Record cutting equipment used	Manufacturer, type/serial number	-			
7	Record filter type	Manufacturer/filter size	0.45 µm		<i>filtered purge of fresh set-up</i>	
8	Connect the filter and a clean flexible (silicone) hose to a N ₂ -(or Argon) bottle delivering gaseous Argon gas as shown in figure.		-			

*changed
to visual
inspection 3/3/10g
4/2/10g*



AMS Tracker Thermal Control Subsystem


TCB and condenser tube cutting procedure

Page 9 of 10

Doc.id. AMSTR-NLR-PR-008

Issue issue 3.0

Date January 2009

Tube cutting procedure sheet				company:	date:	
Fill in by hand.				engineer:	location:	
Step	Action	Monitoring	Value	Result	Comment	✓
						
9	Limit the pressure of the gaseous nitrogen/argon to a reasonable flow (0-4bar) check the used pressure prior to connecting the tube part	Pressure	0-4 bar		<i>Approx 0.4 bar</i>	<i>✓</i>
10	Flow gaseous nitrogen/argon through the hose prior to connect to the tube part		-			<i>✓</i>
11	Connect the flexible hose to the tube as shown in above figure. Set a fixed gaseous flow	Check flow at outside				<i>✓</i>
12	Cut tube					<i>✓</i>
13	Make picture of set-up and record picture time				<i>N/A</i>	<i>✓</i>
14	Disconnect tube, clean outside with IPA and lint free cloth & perform visual inspection of cut surface	Flat square surface				<i>✓</i>
15	Cover tube end with caps and store in a clean box or clean environment for further integration				<i>clean bag</i>	<i>✓</i>
16	End cutting of part (mention part number at comments)					<i>✓</i>



AMS Tracker Thermal Control Subsystem

TTCB and condenser tube cutting procedure

Page 8 of 10
Doc. Id. AMSTR-NLR-PR-008
Issue issue 3.0
Date January 2009

Tube cutting procedure sheet			company:	date:	
	Fill in by hand.		engineer:	location:	
Step	Action	Monitoring	Value	Result	Comment
1	Record model (FM1/FM2/QM) for which the cutting of tubes is performed	Model FM2	-		
2	Record pipe part drawing number	ET 5998-08-'g:20			Pump to ADS-section
3	Make picture of part	Record picture time as on photo			
4	Perform visual inspection inlet and outlet tube	Clean/particles/grease			
5	Clean outside tube with IPA and lint-free cloth				
6	Record cutting equipment used	Manufacturer, type/serial number	-		
7	Record filter type	Manufacturer/filter size	0.45 µm		
8	Connect the filter and a clean flexible (silicone) hose to a N ₂ -(or Argon) bottle delivering gaseous Argon gas as shown in figure.		-		



AMS Tracker Thermal Control Subsystem


TCB and condenser tube cutting procedure

Page 9 of 10

Doc.id. AMSTR-NLR-PR-008

Issue issue 3.0

Date January 2009

Tube cutting procedure sheet				company:	date:	
Fill in by hand.				engineer:	location:	
Step	Action	Monitoring	Value	Result	Comment	✓
						
9	Limit the pressure of the gaseous nitrogen/argon to a reasonable flow (0-4bar) check the used pressure prior to connecting the tube part	Pressure	0-4 bar			
10	Flow gaseous nitrogen/argon through the hose prior to connect to the tube part		-			
11	Connect the flexible hose to the tube as shown in above figure. Set a fixed gaseous flow	Check flow at outside				
12	Cut tube					
13	Make picture of set-up and record picture time					
14	Disconnect tube, clean outside with IPA and lint free cloth & perform visual inspection of cut surface	Flat square surface				
15	Cover tube end with caps and store in a clean box or clean environment for further integration					
16	End cutting of part (mention part number at comments)					



AMS Tracker Thermal Control Subsystem

TTCB and condenser tube cutting procedure

Page 8 of 10
Doc. Id. AMSTR-NLR-PR-008
Issue 3.0
Date January 2009

Tube cutting procedure sheet		company:	date:	
Fill in by hand.		engineer:	location:	
Step	Action	Monitoring	Value	Result
1	Record model (FM1/FM2/QM) for which the cutting of tubes is performed	Model	-	Comment
2	Record pipe part drawing number	ET 59908-0819.25		
3	Make picture of part	Record picture time as on photo		
4	Perform visual inspection inlet and outlet tube	Clean/particles/grease		
5	Clean outside tube with IPA and lint-free cloth			
6	Record cutting equipment used	Manufacturer, type/serial number	-	
7	Record filter type	Manufacturer/filter size	0.45 µm	
8	Connect the filter and a clean flexible (silicone) hose to a N ₂ -(or Argon) bottle delivering gaseous Argon gas as shown in figure.		-	

Taiwan Shang Yang
Inductor motor
cutting equipment for off line tubes

13:40

13:48. 03 March 2009


Pump to
condenser inlet

Standard cutting
equipment &
purge gas



AMS Tracker Thermal Control Subsystem

TTCB and condenser tube cutting procedure

Tube cutting procedure sheet		company:		date:	
Fill in by hand.		engineer:		location:	
Step	Action	Monitoring	Value	Result	Comment
					
9	Limit the pressure of the gaseous nitrogen/argon to a reasonable flow (0-4bar) check the used pressure prior to connecting the tube part	Pressure	0-4 bar		6 Lp77
10	Flow gaseous nitrogen/argon through the hose prior to connect to the tube part		-		
11	Connect the flexible hose to the tube as shown in above figure. Set a fixed gaseous flow	Check flow at outside			
12	Cut tube				13:48
13	Make picture of set-up and record picture time				
14	Disconnect tube, clean outside with IPA and lint free cloth & perform visual inspection of cut surface	Flat square surface			
15	Cover tube end with caps and store in a clean box or clean environment for further integration				
16	End cutting of part (mention part number at comments)				



AMS Tracker Thermal Control Subsystem

TTCB and condenser tube cutting procedure

Page 8 of 10
Doc. Id. AMSTR-NLR-PR-008
Issue 3.0
Date January 2009

Tube cutting procedure sheet				company:	date:	
Fill in by hand.				engineer:	location:	
Step	Action	Monitoring	Model	Value	Result	Comment
1	Record model (FM1/FM2/QM) for which the cutting of tubes is performed			-		100% AT 5th second after
2	Record pipe part drawing number		ET5998-08-19			
3	Make picture of part		Record picture time as on photo			14:27
4	Perform visual inspection inlet and outlet tube		Clean/particles/grease			No purge possible
5	Clean outside tube with IPA and lint-free cloth					
6	Record cutting equipment used		Manufacturer, type/serial number	-		see x (below)
7	Record filter type		Manufacturer/filter size	0.45 µm		
8	Connect the filter and a clean flexible (silicone) hose to a N ₂ -(or Argon)bottle delivering gaseous Argon gas as shown in figure.			-		

✓ Taisa Sheng Yang equip - picture
16:44 03/03/2009
13:58 03/03/2009
meter spec.



AMS Tracker Thermal Control Subsystem

TCB and condenser tube cutting procedure

Page 9 of 10

Doc. Id. AMSTR-NLR-PR-008

Issue issue 3.0

Date January 2009

Tube cutting procedure sheet				company:	date:	
Fill in by hand.				engineer:	location:	
Step	Action	Monitoring	Value	Result	Comment	✓
					<i>clean checked afterwards with capillary purge</i>	
9	Limit the pressure of the gaseous nitrogen/argon to a reasonable flow (0-4bar) check the used pressure prior to connecting the tube part	Pressure	0-4 bar			
10	Flow gaseous nitrogen/argon through the hose prior to connect to the tube part		-			
11	Connect the flexible hose to the tube as shown in above figure. Set a fixed gaseous flow	Check flow at outside				
12	Cut tube					
13	Make picture of set-up and record picture time					
14	Disconnect tube, clean outside with IPA and lint free cloth & perform visual inspection of cut surface	Flat square surface				
15	Cover tube end with caps and store in a clean box or clean environment for further integration					
16	End cutting of part (mention part number at comments)					

no particles in cloth

capillary



AMS Tracker Thermal Control Subsystem

TTCB and condenser tube cutting procedure

Page 8 of 10
Doc. Id. AMSTR-NLR-PR-008
Issue Issue 3.0
Date January 2009

Tube cutting procedure sheet				company:	date:	location:	
Fill in by hand.				engineer:			
Step	Action	Monitoring	Value	Result	Comment		
1	Record model (FM1/FM2/QM) for which the cutting of tubes is performed	Model FM2	-		COX inlet to HX		
2	Record pipe part drawing number		ET5998-2019.23	19.10	section		
3	Make picture of part	Record picture time as on photo			14.25 result		
4	Perform visual inspection inlet and outlet tube	Clean/particles/grease					
5	Clean outside tube with IPA and lint-free cloth						
6	Record cutting equipment used	Manufacturer, type/serial number	-		4423		
7	Record filter type	Manufacturer/filter size	0.45 µm				
8	Connect the filter and a clean flexible (silicone) hose to a N ₂ -(or Argon) bottle delivering gaseous Argon gas as shown in figure.		-				

Taiwan Yang Shang equipment
prepare 16:44 03/03/2009
18:58 motor spec



AMS Tracker Thermal Control Subsystem


TTCB and condenser tube cutting procedure

Page 9 of 10

Doc.id. AMSTR-NLR-PR-008

Issue issue 3.0

Date January 2009

Tube cutting procedure sheet		company:		date:	
Fill in by hand.		engineer:		location:	
Step	Action	Monitoring	Value	Result	Comment
					
9	Limit the pressure of the gaseous nitrogen/argon to a reasonable flow (0-4bar) check the used pressure prior to connecting the tube part	Pressure	0-4 bar		
10	Flow gaseous nitrogen/argon through the hose prior to connect to the tube part		-		
11	Connect the flexible hose to the tube as shown in above figure. Set a fixed gaseous flow	Check flow at outside			
12	Cut tube				
13	Make picture of set-up and record picture time				
14	Disconnect tube, clean outside with IPA and lint free cloth & perform visual inspection of cut surface	Flat square surface			
15	Cover tube end with caps and store in a clean box or clean environment for further integration				
16	End cutting of part (mention part number at comments)				



AMS Tracker Thermal Control Subsystem

TTCB and condenser tube cutting procedure

Page 8 of 10

DocId: AMSTR-NLR-PR-008

Issue issue 3.0

Date January 2009


Tube cutting procedure sheet		company: <i>NLR</i>		date: <i>3/3/2009</i>	
Fill in by hand.		engineer: <i>J. v. Es</i>		location: <i>HT</i>	
Step	Action	Monitoring	Value	Result	Comment
1	Record model (FM1/FM2/QM) for which the cutting of tubes is performed	Model	- <i>FM2</i>		
2	Record pipe part drawing number		<i>ET 5998-00.19.11.</i>		
3	Make picture of part	Record picture time as on photo			<i>10.16 (cutting)</i>
4	Perform visual inspection inlet and outlet tube	Clean/particles/grease			
5	Clean outside tube with IPA and lint-free cloth				
6	Record cutting equipment used	Manufacturer, type/serial number	-		
7	Record filter type	Manufacturer/filter size	0.45 µm		
8	Connect the filter and a clean flexible (silicone) hose to a N ₂ -(or Argon) bottle delivering gaseous Argon gas as shown in figure.		-		


visual inspected parts after cutting => ok with light.



AMS Tracker Thermal Control Subsystem


TTCB and condenser tube cutting procedure

Tube cutting procedure sheet					
Fill in by hand.					
Step	Action	Monitoring	Value	Result	Comment
					
9	Limit the pressure of the gaseous nitrogen/argon to a reasonable flow (0-4bar) check the used pressure prior to connecting the tube part	Pressure	0-4 bar		
10	Flow gaseous nitrogen/argon through the hose prior to connect to the tube part		-		
11	Connect the flexible hose to the tube as shown in above figure. Set a fixed gaseous flow	Check flow at outside			
12	Cut tube				
13	Make picture of set-up and record picture time				
14	Disconnect tube, clean outside with IPA and lint free cloth & perform visual inspection of cut surface	Flat square surface			
15	Cover tube end with caps and store in a clean box or clean environment for further integration				
16	End cutting of part (mention part number at comments)				



AMS Tracker Thermal Control Subsystem

TTCB and condenser tube cutting procedure



particle direction (if any)

Tube cutting procedure sheet				company:	date:	location:	
Fill in by hand.				engineer:			
Step	Action	Monitoring	Model	Value	Result	Comment	
1	Record model (FM1/FM2/QM) for which the cutting of tubes is performed			- FM2		Fill pipe cutting to check 10 mm dead end weld.	✓
2	Record pipe part drawing number			① First cut with normal metal saw		10:47 04 March 2009.	
3	Make picture of part	Record picture time as on photo		purge via		- 11 Feb 15.	
4	Perform visual inspection inlet and outlet tube	Clean/particles/grease		not pump inlet section + vacuum cleaner		③ Flack cleaning with non-concentric Metabo cutter 14:01 14:02	also purge ✓
5	Clean outside tube with IPA and lint-free cloth						
6	Record cutting equipment used	Manufacturer, type/serial number		-		Metabo 027 00	
7	Record filter type	Manufacturer/filter size		0.45 µm		Purge gas F. K. 47.	✓
8	Connect the filter and a clean flexible (silicone) hose to a N ₂ -(or Argon) bottle delivering gaseous Argon gas as shown in figure.			-			✓

1) Cleaning performed by capillary tube

Cleaning of inside needed with lint-free cloth. Done after APS/APS1 dead end cleaning 05/03/2009

2) Same after with tube to DPS and to purge

Cleaning of inside needed with lint-free cloth. Done after APS/APS1 dead end cleaning 05/03/2009



AMS Tracker Thermal Control Subsystem


TTCB and condenser tube cutting procedure

Page 9 of 10

DocId. AMSTR-NLR-PR-008

Issue issue 3.0

Date January 2009

Tube cutting procedure sheet				company:	date:		location:	
Fill in by hand.				engineer:				
Step	Action	Monitoring	Value	Result	Comment			
								
9	Limit the pressure of the gaseous nitrogen/argon to a reasonable flow (0-4bar) check the used pressure prior to connecting the tube part	Pressure	0-4 bar		<i>declared!</i>			
10	Flow gaseous nitrogen/argon through the hose prior to connect to the tube part		-					<i>✓</i>
11	Connect the flexible hose to the tube as shown in above figure. Set a fixed gaseous flow	Check flow at outside						
12	Cut tube							
13	Make picture of set-up and record picture time				<i>see. 04/03/2009</i>			
14	Disconnect tube, clean outside with IPA and lint free cloth & perform visual inspection of cut surface	Flat square surface						<i>✓</i>
15	Cover tube end with caps and store in a clean box or clean environment for further integration							<i>✓</i>
16	End cutting of part (mention part number at comments)							<i>✓</i>

after cut.



AMS Tracker Thermal Control Subsystem

TTCB and condenser tube cutting procedure

Tube cutting procedure sheet				company:	date:		
Fill in by hand.				engineer:	location:		
Step	Action	Monitoring	Value	Result	Comment		
1	Record model (FM1/FM2/QM) for which the cutting of tubes is performed	Model FM2	-				✓
2	Record pipe part drawing number	ET3908-08	19.21 19.22		Condenser lines to COM.		✓
3	Make picture of part	Record picture time as on photo			14.12.22		
4	Perform visual inspection inlet and outlet tube	Clean/particles/ grease					
5	Clean outside tube with IPA and lint-free cloth						
6	Record cutting equipment used	Manufacturer, type/serial number	-				
7	Record filter type	Manufacturer/filter size	0.45 µm		14.12.22 14.12.22		
8	Connect the filter and a clean flexible (silicone) hose to a N ₂ -(or Argon)bottle delivering gaseous Argon gas as shown in figure.		-				



AMS Tracker Thermal Control Subsystem


TTCB and condenser tube cutting procedure

Page 9 of 10

Doc. Id. AMSTR-NLR-PR-008

Issue issue 3.0

Date January 2009

Tube cutting procedure sheet				company:	date:	
Fill in by hand.				engineer:	location:	
Step	Action	Monitoring	Value	Result	Comment	
						✓
9	Limit the pressure of the gaseous nitrogen/argon to a reasonable flow (0-4bar) check the used pressure prior to connecting the tube part	Pressure	0-4 bar		6 LPM	✓
10	Flow gaseous nitrogen/argon through the hose prior to connect to the tube part		-			
11	Connect the flexible hose to the tube as shown in above figure. Set a fixed gaseous flow	Check flow at outside				✓
12	Cut tube					
13	Make picture of set-up and record picture time				see for 1pg	✓
14	Disconnect tube, clean outside with IPA and lint free cloth & perform visual inspection of cut surface	Flat square surface				✓
15	Cover tube end with caps and store in a clean box or clean environment for further integration					✓
16	End cutting of part (mention part number at comments)					✓



AMS Tracker

Thermal Control Subsystem

TTCB and condenser tube cutting procedure

Page 8 of 10
 Doc. Id. AMSTR-NLR-PR-008
 Issue Issue 3.0
 Date January 2009

	Tube cutting procedure sheet		company:	NLR	date:	05/03/2009	
	Fill in by hand.		engineer:	S. v. Es	location:	HT	
Step	Action	Monitoring	Value	Result	Comment		✓
1	Record model (FM1/FM2/QM) for which the cutting of tubes is performed	Model	-		Pre-heating bottle cutting		
2	Record pipe part drawing number						
3	Make picture of part	Record picture time as on photo					
4	Perform visual inspection inlet and outlet tube	Clean/particles/ grease					
5	Clean outside tube with IPA and lint-free cloth						
6	Record cutting equipment used	Manufacturer, type/serial number	-				
7	Record filter type	Manufacturer/filter size	0.45 µm				
8	Connect the filter and a clean flexible (silicone) hose to a N ₂ -(or Argon)bottle delivering gaseous Argon gas as shown in figure.		-				



AMS Tracker Thermal Control Subsystem


TTCB and condenser tube cutting procedure

Page 9 of 10

Doc.id. AMSTR-NLR-PR-008

Issue issue 3.0

Date January 2009

Tube cutting procedure sheet		company:		date:	
Fill in by hand.		engineer:		location:	
Step	Action	Monitoring	Value	Result	Comment
					
9	Limit the pressure of the gaseous nitrogen/argon to a reasonable flow (0-4bar) check the used pressure prior to connecting the tube part	Pressure	0-4 bar		
10	Flow gaseous nitrogen/argon through the hose prior to connect to the tube part		-		
11	Connect the flexible hose to the tube as shown in above figure. Set a fixed gaseous flow	Check flow at outside			
12	Cut tube				
13	Make picture of set-up and record picture time				
14	Disconnect tube, clean outside with IPA and lint free cloth & perform visual inspection of cut surface	Flat square surface			
15	Cover tube end with caps and store in a clean box or clean environment for further integration				
16	End cutting of part (mention part number at comments)				