



---

## AMS Tracker Thermal Control Subsystem Condenser heaters installation procedure

**AMSTR-NLR-PR-043**  
**ISSUE 5**  
**SEPTEMBER 2009**

---

Sun Yat-Sen University (SYSU)  
National Aerospace Laboratory (NLR)  
Istituto Nazionale di Fisica Nucleare (INFN)  
Aerospace Industrial Development Corporation (AIDC)

	NAME	ORGANISATION/RESPONSIBILITY	SIGNATURE	DATE
PREPARED	E.Laudi	INFN		
CHECKED	J. van Es	NLR / AMS TTCS System Eng.		
AGREED	PA person XYZ	NLR / AMS Company PA		
APPROVED	J. van Es	NLR / AMS TTCS PM		
AUTHORISED				

FILENAME	AMSTR-NLR-PR-043-Condenser heaters installation procedure_draft3.doc	ORDER-/CODENUMBER:	
LAST SAVED	2009.09.11 11:41 by E.L.	DIVISION:	
PRINTED	2009.10.08 23:25	DISTRIBUTION:	Unlimited
PAGES	43	CLASSIFICATION TITLE:	Unclassified

*No part of this document may be reproduced and/or disclosed, in any form or by any means,  
without the prior written permission of NLR.*



# AMS Tracker Thermal Control Subsystem

Condenser heaters installation

procedure

Page 2 of 43  
Doc.Id AMSTR-NLR-PR-043  
Issue draft 5  
Date september 2009

## Distribution list

<i>Company</i>	<i>FOR*</i>	<i>Name</i>	<i>Comments</i>
INFN	I	R. Battiston	
		M. Menichelli	
		C. Gargiulo	
		B. Alpat	
		A. Alvino	
		E. Laudi	
AMS	I	M. Capell	
		V. Koutsenko	
		R. Becker	
NLR	I	P. Dieleman	
		J.van Es	
		M. Bardet	
Jacobs Sverdrup	I	T. Martin	
		G. Clark	
AIDC	I	N.J.Lin	
		B. Hsu	
		W. Min Hsu	
CGS	I	M. Molina	
		C. Vettore	

A = Approval  
R = Review  
I = Input / Information

*An electronic version of this document is available on the AMS TTCS website:*

*<https://ams-ttcs.nlr.nl>*



# AMS Tracker Thermal Control Subsystem

Condenser heaters installation

procedure

Page 3 of 43  
Doc.Id AMSTR-NLR-PR-043  
Issue draft 5  
Date september 2009

## Document change log

<u>Change Ref.</u>	<u>Section(s)</u>	<u>Issue draft</u>
-	All	Initial issue
<u>Change Ref.</u>	<u>Section(s)</u>	<u>Issue draft 3</u>
	7.0	Comments on heaters under strain relief installation
	7.2	Deleted spot gluing on liquid line foil heaters; only spot gluing on the heater cables
	7.3	Deleted spot gluing for heaters under the strain relief side; the spot gluing of the wire will be done at the final step.
<u>Change Ref.</u>	<u>Section(s)</u>	<u>Issue draft 4</u>
	3.0	Updated manufacturing sequence
	7.0	Updated procedure sheets with picture and gluing details
	9.0	Added appendix B with drawing to position the foil heaters
<u>Change Ref.</u>	<u>Section(s)</u>	<u>Issue draft 4</u>
		Added appendix B with drawing to position the foil heaters
<u>Change Ref.</u>	<u>Section(s)</u>	<u>Issue draft 5</u>
	7.5	Added wire heater installation procedure

## Summary

This document presents the process for the installation of self-adhesive heater on QM and FM condensers. The heater installation step is part of the overall production of the condensers.



# AMS Tracker Thermal Control Subsystem

Condenser heaters installation

procedure

Page 4 of 43  
Doc.Id AMSTR-NLR-PR-043  
Issue draft 5  
Date september 2009

## Contents

Document change log	3
Summary	3
1 Scope of the document and test objective	5
2 References documents	5
3 Condenser integration sequence	6
4 Detailed Heater descriptions	8
4.1 Liquid line wire heaters description	8
4.2 Liquid line Inlet/outlet foil heaters description	10
4.3 Condenser 120 V foil heaters description	11
5 Material and tools required	12
6 Installation Procedure in main steps	13
7 Heater installation procedure	13
7.1 Heater installation procedure sheets	13
7.2 Liquid line Inlet/outlet foil heater installation procedure sheet	14
7.3 Condenser 120 V foil heater installation procedure sheet	21
7.4 Wire heater installation procedure sheet	31
8 Appendix A	33
9 Appendix B	40
END OF DOCUMENT	43

(43 pages in total)



# AMS Tracker Thermal Control Subsystem

Condenser heaters installation

procedure

Page 5 of 43  
Doc.Id AMSTR-NLR-PR-043  
Issue draft 5  
Date september 2009

## 1 Scope of the document and test objective

The procedure in this document describes the installation of :

- Liquid line wire heaters
- Inlet/outlet foil heaters
- Condenser foil heaters

on QM and FM condensers.

The objective of the installation of this thermal components is to defrost the TTCS CO2 condenser lines after an AMS complete power down (liquid line heaters and condenser foil heaters), and to compensate the heat leak from the liquid lines into the cold condenser at freezing (inlet/outlet foil heaters)

## 2 References documents

	Title	Number	Date
RD-1	QM-FM Condenser gluing procedure	AMSTR-NLR-PR-038	December 2008
RD-2	TCS Tracker Radiator Panel Heater Installation	TCS-071219	January 2008
RD-3	TTCS Heater Specifications	AMSTR-NLR-TN-043-issue 1.5	July 2007



## AMS Tracker Thermal Control Subsystem

Condenser heaters installation

procedure

Page	6 of 43
Doc.Id	AMSTR-NLR-PR-043
Issue	draft 5
Date	september 2009

### 3 Condenser integration sequence

The heater installation step is part of the overall condenser manufacturing sequence. The bold lines indicate the steps described in this procedure. **(For the most update version of the sequence see RD-1).**

QM and FM condenser will undergo two different heater installation sequence.

1. Bend individual tubes
2. Label tubes
3. He leak test for individual tubes AMSTR-NLR-PR-040
4. Cut tubes to exact length according to the cutting procedure AMSTR-NLR-PR-008-v.2. QM-FM Condenser cutting procedure (to be approved)
5. Clean tubes inside & outside and seal the end: AMSTR\_NLR-039 (to be approved)
6. Manufacture brazing plates
7. Apply stop off agent on brazing component AMSTR-NLR-041
8. Manufacture bottom, top plates and strain relieves in AL 2024 T351
9. Convert to AL 2024 T851 (worksheet by AIDC)
10. Manufacture manifold parts and filters
11. Clean manifold parts and filter AMSTR-NLR-039 (to be approved)
12. Perform nickel plating on tubes side to be brazed
13. Spot weld condenser tubes to manifold and apply solder around tubes
14. Braze tubes and manifolds AMSTR\_NLR-041
15. He leak test on condenser tubing lay-out AMSTR-NLR -040
16. Proof pressure test up to 1.5 MDP =  $1.5 * 160 = 240$  bar AMSTR-NLR -040
- 17. He leak on condenser tubing lay-out AMSTR-NLR –PR 040**

For QM condenser:

18. Install nutplates on top plate AMSTR-NLR-PR -38
19. Surface treatment of condenser plates and tube AMSTR-NLR-PR -38
20. Glue the condenser tubes to the base plate AMSTR-NLR-PR-38
- 21. Glue foil heaters (under the strain relief side) over top plate AMSTR-NLR-PR-43**
22. Glue the top plate to the bottom plate and glue strain reliefs; AMSTR-NLR-PR-38
- 23. Glue the remaining foil heaters on top plate; AMSTR-NLR-PR-043**
24. Clean outside tubes, manifold and condenser plates according to : AMSTR-NLR-PR.039 (to be approved)
25. Do a mass check/measurement on the condenser and condenser bolts



## AMS Tracker Thermal Control Subsystem

Condenser heaters installation

procedure

Page	7 of 43
Doc.Id	AMSTR-NLR-PR-043
Issue	draft 5
Date	september 2009

26. Fix condenser with bolts to transport jig AMSTR-NLR-PR-044-Condenser assembly to Transport and brazing jig (to be updated)
27. Perform thermal cycling test according TTCS-SYSU-TEST-TPR-013-3.0

For FM condensers:

18. Surface treatment of bottom plate and tube AMSTR-NLR-PR -38
19. Glue the tubes to the bottom plate AMSTR-NLR-PR-38
20. Surface treatment of top plate AMSTR-NLR-PR -38
21. Install nutplates on top plate
- 22. Glue foil heaters (under the strain relief side) over the top plate AMSTR-NLR-PR-43**
23. Glue the top plate to the bottom plate
24. Surface treatment of top and bottom strain relief AMSTR-NLR-PR -38
25. Install nutplates on top strain relief
26. Glue strain reliefs; AMSTR-NLR-PR-38
- 27. Glue the remaining foil heaters on top plate; AMSTR-NLR-PR-043**
28. Clean outside tubes, manifold and condenser plates according to : AMSTR-NLR-PR.039 (to be approved)
- 29. Apply wire heater according to AMSTR-NLR-PR-043**
30. Do a mass check/measurement on the condenser and condenser bolts
31. Fix condenser with bolts to transport jig AMSTR-NLR-PR-044-Condenser assembly to Transport and brazing jig (to be updated)
32. Perform an outgoing inspection (visual and electrical) according to ATS N° ( to be written)
33. Apply TS according to ATS N° ( to be written)
34. Integrate the condenser to radiator according to ATS N° ( to be written)



# AMS Tracker Thermal Control Subsystem

Condenser heaters installation

procedure

Page 8 of 43  
Doc.Id AMSTR-NLR-PR-043  
Issue draft 5  
Date september 2009

## 4 Detailed Heater descriptions


### 4.1 Liquid line wire heaters description

The liquid line wire heater are :

Thermocoax wire heaters:

- **ZUZ : single core with cold ends**
- **Ac15 : austenitic stainless steel sheat**
- **Hot length:336cm +-10%**
- **Cold parts: 4cm**
- **Connector: CM15**


Plastic connection



Type Code	For heating element Ø (mm)	Max. working temperature	Max. current (A)*	Power supply
CM 10	1		8	Cable : length: 20 cm Section: 2 mm <sup>2</sup>
CM 15	1.5	200°C	12	
CM 20	2		16	

- **cement8**
- **E2219white wire**
- **200mm**
- 1.5 mm diameter 3,36 m long one with roughly 10 windings around the tubes


Option 1	Heater type and spec	ZUZ/15/4-336-4/HcAc 12.4 Ohm/m
	Heater wire selection line resistance [Ohm/m]	12.4000
	Cold end resistance [0.3 Ohm/m] [Ohm]	0.0240
	Diameter wire [m]	0.0015
	Calculated length [m]	3.3600
	Calculated number of turns [-]	10.0000



No part of this document may be reproduced and/or disclosed, in any form or by any means, without the prior written permission of NLR.



For each FM condenser 2 wire heaters are wrapped along the tubes from the condenser plate down to the manifolds: one side needs to be connected to the foil heater FHK 203 and the other side to the TB (as shown in the following picture). The connection to TB side will done at CERN.





## AMS Tracker Thermal Control Subsystem

Condenser heaters installation

procedure

Page

Doc.Id

Issue

Date

10 of 43

AMSTR-NLR-PR-043

draft 5

september 2009

### 4.2 Liquid line Inlet/outlet foil heaters description

The inlet/outlet foil heaters are Minco heater with the following description:

FHK203

Kapton Thermofoil heater

Dimensions 10.7 x 58.4 mm

$R = 7.3 \text{ Ohm}$


Leads AWG-26, 760 mm long TF insulated

lead exit type #1


tested to NASA S-311-P-079 Table II

Foil Element Tophet A (non magnetic)

PSA 10 backing




Each condenser will be equipped with two of them at the inlet/outlet position of the top plate as shown in the figure 4.1. The lead wire direction is described in the same figure.



**Figura 4-1. .Lead wire direction on the liquid line foil heaters**

### 4.3 Condenser 120 V foil heaters description

The condenser foil heaters are HNK5203R48.4L12B

Size (in)		Size (mm)		Type	Resistance options- ohms*						Effective area in <sup>2</sup> (cm <sup>2</sup> )	Lead AWG	Insu- lation	Model number
X	Y	X	Y		R(0°C) [May be used with Heaterstat] →				NiFe	Ni				
0.25	10.40	6.4	264.2	5- 	160	80.1	48.4	23.3	24.8	5.7	1.55 (10.00)	26	K, R	5203

Conditioning test per NASA S311-P-079 Table II done at 2.50 W/sq in (13 volts)

PSA 10 backing

With the following custom property:

Lead: 22 AWG wires 12" long minimum

On each condenser, 8 pairs (16 : A+B) heaters will be installed:

- 7 pairs on top plate
- 1 pairs on top strain relief



# AMS Tracker Thermal Control Subsystem

Condenser heaters installation

procedure

Page 12 of 43  
Doc.Id AMSTR-NLR-PR-043  
Issue draft 5  
Date september 2009



## 5 Material and tools required

The following tools are required for this procedure.

- a) Power supply
- b) Multi-meter; capable of measuring in the 1000 Ohm range or equivalent.
- c) Heater ID Label

The materials used for heater installation shall be vacuum compatible. The following material needs to be available during installation:

- a) Minco Foil Heater HK27565 with Pressure sensitive adhesive 10
- b) Minco foil heaters: FHK 203 with Pressure sensitive adhesive 10
- c) Thermocoax wire heaters: ZUZ Ac 15/4cm-336cm-4cm/2xCM15/cement8/2219white/200mm
- d) EC 2216 B/A Gray.
- e) K-Dry tissues
- f) IPA
- g) Aluminum tape

**NOTE: Use IPA to clean all tools or equipment prior to use in clean room**



## AMS Tracker Thermal Control Subsystem

Condenser heaters installation

procedure

Page	13 of 43
Doc.Id	AMSTR-NLR-PR-043
Issue	draft 5
Date	september 2009

## 6 Installation Procedure in main steps

The major steps of installation of the heaters is:

- Inspection of the heater
- Surface preparation
- Heater tape installation
- Electrical check out and record
- Gluing heater tape (only for foil heaters)
- Curing (only for foil heaters)

## 7 Heater installation procedure

### 7.1 Heater installation procedure sheets

The installation procedure sheets shall be filled in, and shall accompany foil and wire heaters during their lifetime in order to be able to show the procedure was followed.

The two foil heaters condenser under the strain relief side will undergo the electrical check out only during the installation of the remaining 7 pair of heaters ( final step of the gluing procedure).

The 4 foil heaters under the strain reliefs will not be spot glued with 3M2216; only the cables of the Minco FK203 will be spot glued, of that heaters, during the last gluing step.



## AMS Tracker Thermal Control Subsystem

Condenser heaters installation procedure

Page 14 of 43

Doc.Id. AMSTR-NLR-PR-043

Issue draft 5

Date september 2009

### 7.2 Liquid line Inlet/outlet foil heater installation procedure sheet


	Inlet/outlet foil heater installation procedure		company:		date:	
	Fill in by hand.		engineer:		location:	
Step	Action	Monitoring	Value	Result	Comment	√
1.	Record condenser model (P-ram, P-wake, S-ram, S-wake)	T.I. description	-			
2.	Record model ( EM / QM / FM )	model	-			
	Visual and electrical inspection					
3.	Record test equipment used	manufacturer, type				
4.	Visual inspection on the heaters to be installed		-			
5.	Label the lead wire near the heater that it can be clearly identified when for check. Report in the table (Appendix A) the part number correspondent.	Part number TTCS heater ID	A or B			



# AMS Tracker Thermal Control Subsystem

Condenser heaters installation procedure

Page 15 of 43  
Doc.Id. AMSTR-NLR-PR-043  
Issue draft 5  
Date september 2009


Inlet/outlet foil heater installation procedure		company:		date:		
Fill in by hand.		engineer:		location:		
Step	Action	Monitoring	Value	Result	Comment	✓
						
6.	label the lead wire near the heater that it can be clearly identified when for check. Report in the table (appendix A) the part number correspondent	Part number TTCS heater ID	A or B			
7.	Check the resistance and record	resistance	7.3 Ohm +/- 10%			
	<b>Surface preparation</b>					
8.	Wipe the bonding surface area with K-Dry tissues or equivalent dampened with isopropyl alcohol.					
9.	Determine the required position of the heater and mark reference points with Aluminum tape. Close out all gaps around the edge of heaters					



# AMS Tracker Thermal Control Subsystem

Condenser heaters installation procedure

Page 16 of 43  
Doc.Id. AMSTR-NLR-PR-043  
Issue draft 5  
Date september 2009

Inlet/outlet foil heater installation procedure		company:		date:		
Fill in by hand.		engineer:		location:		
Step	Action	Monitoring	Value	Result	Comment	✓
						
10.	Prepare the location and dimension of MINCO heater according to. Drawing ET5998-09-DR-001-A-KW-CONDENSOR ASSEMBLY or ET5998-10-DR-001-0-KW-CONDENSOR ASSEMBLY ( and figure in Appendix A)					
11.	Strip the adhesive backing from the heater and lay the heater on the top plate per the reference drawing and gently press it into place per figure in <b>appendix A</b>					





## AMS Tracker Thermal Control Subsystem



Condenser heaters installation procedure

Page 17 of 43

Doc.Id. AMSTR-NLR-PR-043

Issue draft 5

Date september 2009


Inlet/outlet foil heater installation procedure		company:		date:		
Fill in by hand.		engineer:		location:		
Step	Action	Monitoring	Value	Result	Comment	✓
						
12.	Use a rubber roller (or equivalent tool) to press the heater onto the top plate. Roll from the centre toward the edges.					
13.	Repeats step 12, make sure no trapped air under the heaters.					
14.	Repeat step 11 to 13 for the second heater 					



# AMS Tracker Thermal Control Subsystem

Condenser heaters installation procedure

Page 18 of 43  
Doc.Id. AMSTR-NLR-PR-043  
Issue draft 5  
Date september 2009


	Inlet/outlet foil heater installation procedure		company:		date:	
	Fill in by hand.		engineer:		location:	
Step	Action	Monitoring	Value	Result	Comment	√
15.	For QM check resistance after gluing per heater individually For FM check resistance after gluing per heater individually		7.3 Ohm +/- 10%	A= B=		
16.	For QM/FM: Power on A & B heater parallel to a <b>4.2 V</b> power supply. Rolling while warm and repeat several times 					
	<b>Electric Checkouts and Record</b>					
17.	Record Multimeter used	Type; S/N; cal. Valid date				
18.	Record power supply used	Type; S/N; cal. Valid date				
19.	Check the heaters are electrically isolated with the panel by using Multi-meter.					
20.	For QM/FM: Power on heater A to a <b>4.2 V</b> power supply.. Record the voltage and current values of the heater For QM/FM: Power on heater B to a <b>4.2 V</b> power supply..	Voltage current	4.2 V 0.57 A	V <sub>A</sub> = I <sub>A</sub> = V <sub>b</sub> =		



# AMS Tracker Thermal Control Subsystem

Condenser heaters installation procedure

Page 19 of 43  
Doc.Id. AMSTR-NLR-PR-043  
Issue draft 5  
Date september 2009


	<b>Inlet/outlet foil heater installation procedure</b>		company:		date:	
	Fill in by hand.		engineer:		location:	
Step	Action	Monitoring	Value	Result	Comment	√
	Record the voltage and current values of the heater			Ib=		
21.	Recorded the derived resistance	Resistance	V/I	RA <sub>dev</sub> = RB <sub>dev</sub> =		
22.	Check the derived resistance with the measured one (step 7)	Resistance	From step 7	RA <sub>mes</sub> = RB <sub>mes</sub> =		
	<b>Heater tape installation</b>					
23.	Record glue 3M 2216 data and mixing ratio	Expiring date Mixing ratio				
24.	<div>Put glue on the wire leads (3 mm diameter or more, as needed)</div> <div></div> <div>NOTE: <u>this wire fixing has to be performed during the final gluing step (together with the installation of all the remaining top plate foil heaters)</u></div>					



# AMS Tracker Thermal Control Subsystem

Condenser heaters installation procedure

Page 20 of 43  
Doc.Id. AMSTR-NLR-PR-043  
Issue draft 5  
Date september 2009

	Inlet/outlet foil heater installation procedure		company:		date:	
	Fill in by hand.		engineer:		location:	
Step	Action	Monitoring	Value	Result	Comment	√
	<div><p>(no spot on the edge of the heaters!)</p></div>					
25.	7 days for fully curing					
26.	End					



## AMS Tracker Thermal Control Subsystem

Condenser heaters installation procedure

Page 21 of 43  
Doc.Id. AMSTR-NLR-PR-043  
Issue draft 5  
Date september 2009

### 7.3 Condenser 120 V foil heater installation procedure sheet


	Condenser 120 V foil heater installation procedure		company:		date:	
	Fill in by hand.		engineer:		location:	
Step	Action	Monitoring	Value	Result	Comment	√
1.	Record condenser model (P-ram, P-wake, S-ram, S-wake)	T.I. description	-			
2.	Record model ( EM / QM / FM )	model	-			
	<b>Visual and electical inspection</b>					
3.	Record test equipment used	manufacturer, type				
4.	Visual inspection on the heaters to be installed		-			
5.	Label the lead wire near the heater that it can be clearly identified when for check. Report in the table on appendix A the part number correspondent.	Part number TTCS heater ID	A or B			
6.	label the lead wire near the heater that it can be clearly identified when for check. Report in the table on appendix A the part number correspondent	Part number TTCS heater ID	A or B			
7.	Repeat step 5 and 6 for the remaining pairs of heaters					
8.	Check the resistance and record ( in table in Appendix A)	resistance	48.4 Ohm +/- 10%			



# AMS Tracker Thermal Control Subsystem

Condenser heaters installation procedure

Page 22 of 43  
Doc.Id. AMSTR-NLR-PR-043  
Issue draft 5  
Date september 2009


Condenser 120 V foil heater installation procedure		company:		date:		
Fill in by hand.		engineer:		location:		
Step	Action	Monitoring	Value	Result	Comment	✓
						
	Surface preparation					
9.	Wipe the bonding surface area with K-Dry tissues or equivalent dampened with isopropyl alcohol.					
10.	Determine the required position of the heater and mark reference points with Aluminum tape. Close out all gaps around the edge of heaters					



## AMS Tracker Thermal Control Subsystem

Condenser heaters installation procedure

Page 23 of 43  
Doc.Id. AMSTR-NLR-PR-043  
Issue draft 5  
Date september 2009


Condenser 120 V foil heater installation procedure		company:		date:		
Fill in by hand.		engineer:		location:		
Step	Action	Monitoring	Value	Result	Comment	✓
						
11.	Prepare the location and dimension of MINCO heater according to Appendix B and drawing ET5998-09-DR-001-A-KW-CONDENSOR ASSEMBLY or ET5998-10-DR-001-0-KW-CONDENSOR ASSEMBLY (figure in Appendix A)					
12.	Strip the adhesive backing from the heater and lay the heater on the top plate per the reference drawing and gently press it into place per figure in appendix A					



# AMS Tracker Thermal Control Subsystem

Condenser heaters installation procedure

Page 24 of 43  
Doc.Id. AMSTR-NLR-PR-043  
Issue draft 5  
Date september 2009

Condenser 120 V foil heater installation procedure		company:		date:		
Fill in by hand.		engineer:		location:		
Step	Action	Monitoring	Value	Result	Comment	✓
13.	<p>Use a rubber roller (or equivalent tool) to press the heater onto the top plate. Roll from the centre toward the edges.</p> 					
14.	Repeats step 13, make sure no trapped air under the heaters.					
15.	For QM/FM: Power on A heater parallel to a <b>50 V</b> power supply. Rolling while warm and repeat several times					





# AMS Tracker Thermal Control Subsystem

Condenser heaters installation procedure

Page 25 of 43

Doc.Id. AMSTR-NLR-PR-043

Issue draft 5

Date september 2009



	Condenser 120 V foil heater installation procedure		company:		date:	
	Fill in by hand.		engineer:		location:	
Step	Action	Monitoring	Value	Result	Comment	✓
16.	Repeat step15 for heaters B					
	<b>Electric Checkouts and Record</b>					
17.	Record Multimeter used	Type; S/N; cal. Valid date				
18.	Record power supply used	Type; S/N; cal. Valid date				
19.	Check the heaters are electrically isolated by using Multi-meter.					
20.	Connect all heaters A in series(red), using a bread-board					



# AMS Tracker Thermal Control Subsystem

Condenser heaters installation procedure

Page 26 of 43  
Doc.Id. AMSTR-NLR-PR-043  
Issue draft 5  
Date september 2009


Condenser 120 V foil heater installation procedure		company:		date:		
Fill in by hand.		engineer:		location:		
Step	Action	Monitoring	Value	Result	Comment	✓
						
21.	<p>For QM/FM: Power on heaters A to a <b>50 V</b> power supply.. Record the voltage and current values of the heater group</p> 	Voltage current		Va Ia		



# AMS Tracker Thermal Control Subsystem

Condenser heaters installation procedure

Page 27 of 43  
Doc.Id. AMSTR-NLR-PR-043  
Issue draft 5  
Date september 2009


Condenser 120 V foil heater installation procedure		company:		date:		
Fill in by hand.		engineer:		location:		
Step	Action	Monitoring	Value	Result	Comment	✓
22.	Check the derived resistance with the measured one for heaters A(step8)	Resistance	Design: $8 \times 48,4 = 387,2 \text{ Ohm}$ From step 8(measured): $8 \times R_{\text{step8}} = \text{ Ohm}$	<b>Derived Resistance (V/A)(<math>\Omega</math>) Ra=</b>		
23.	Connect all heater B in series ( orange)  					
24.	For QM/FM: Power on heaters B to a <b>50 V</b> power supply. Record the voltage and current values of the heaters	Voltage current		Vb= Ib=		



# AMS Tracker Thermal Control Subsystem

Condenser heaters installation procedure

Page 28 of 43  
Doc.Id. AMSTR-NLR-PR-043  
Issue draft 5  
Date september 2009



Condenser 120 V foil heater installation procedure			company:		date:	
Fill in by hand.			engineer:		location:	
Step	Action	Monitoring	Value	Result	Comment	✓
25.	Check the derived resistance with the measured one for heaters B(step8)	Resistance	Design: $8 \times 48,4 = 387,2 \text{ Ohm}$ From step 8: $8 \times R_{\text{step8}} = \text{ Ohm}$	<b>Derived Resistance</b> (V/A)( $\Omega$ ) <b>Rb=</b>		
<b>Heater Tape Installation</b>						
26.	Record glue 3M 2216 data and mixing ratio	Expiring date Mixing ratio				
27.	Put 4 spots of glue on the heater patch corners (3 mm diameter) ( <b>DON'T SPOT GLUE THE HEATERS UNDER STRAIN RELIEF SIDE</b> ) 					



# AMS Tracker Thermal Control Subsystem

Condenser heaters installation procedure

Page 29 of 43  
Doc.Id. AMSTR-NLR-PR-043  
Issue draft 5  
Date september 2009

Condenser 120 V foil heater installation procedure		company:		date:		
Fill in by hand.		engineer:		location:		
Step	Action	Monitoring	Value	Result	Comment	✓
28.	Put glue on the wire leads (3 mm diameter or more, as needed)  					
29.	Put glue on the edges : every 50 mm put a spot of glue of this size: 2 to 3 mm wide (i.e.: across the edge), enough to bridge the heater and the surface underneath 5 mm long (i.e.: along the edge) ( <b>DON'T SPOT GLUE THE HEATERS UNDER STRAIN RELIEF SIDE</b> )  					
30.	Repeat step 26 to 29 for all the remaining heaters.					



## AMS Tracker Thermal Control Subsystem

Condenser heaters installation procedure

Page 30 of 43

Doc.Id. AMSTR-NLR-PR-043

Issue draft 5

Date september 2009

	Condenser 120 V foil heater installation procedure		company:		date:	
	Fill in by hand.		engineer:		location:	
Step	Action	Monitoring	Value	Result	Comment	√
31.	7 days for fully curing					
32.	End					



## AMS Tracker Thermal Control Subsystem

Condenser heaters installation procedure

Page 31 of 43  
Doc.Id. AMSTR-NLR-PR-043  
Issue draft 5  
Date september 2009

### 7.4 Wire heater installation procedure sheet

Wire heater installation procedure		company:		date:		
Fill in by hand.		engineer:		location:		
Step	Action	Monitoring	Value	Result	Comment	✓
1.	Record condenser model (P-ram, P-wake, S-ram, S-wake)					
2.	Verify condenser tube brackets are mounted and positioned in correct place					
3.	Record lock wire used				Cessna Aircr. comp. B08/026	
4.	Visual inspection on the 2 heaters to be installed	Part number				
5.	Label the lead wires of each heater HTR_A and HTR_B.					
6.	Check the resistances and record resistance wire heater and insulation resistance	Resistance heater Insulation	49 ohm > 1 Mohm	. . . .		
7.	Check the length between connectors and record	cm	336 cm	. .		
8.	Create 'fit-wire' with correct length					
9.	Bend 'fit-wire' in the middle, using 10 mm OD tube					



## AMS Tracker Thermal Control Subsystem

Condenser heaters installation procedure

Page 32 of 43  
Doc.Id. AMSTR-NLR-PR-043  
Issue draft 5  
Date september 2009

Wire heater installation procedure		company:		date:		
Fill in by hand.		engineer:		location:		
Step	Action	Monitoring	Value	Result	Comment	✓
10.	Wrap 'fit-wire' around condenser tube according to drawing ET5998-09-DR-001-B-KW-CONDENSOR ASSEMBLY 20081118					
11.	Remind bend radius $R > 3$ mm, do not twist / kink wire					
12.	Take pictures, record typical values like threads between brackets, number of bends etc.					
13.	Bend wire heaters in the middle, using 10 mm OD tube					
14.	Wrap 'fit-wire' around condenser tube according to drawing ET5998-09-DR-001-B-KW-CONDENSOR ASSEMBLY 20081118 and results obtained in previous steps					
	Fasten wire heater with lock wire 0.032''					
15.	Fasten connectors on 4 mm tubes with ty-raps					
16.	Check the resistances and record resistance wire heater and insulation resistance	Resistance heater Insulation	49 ohm > 1 Mohm			
17.	Take pictures of result.					
18.	End					





# AMS Tracker Thermal Control Subsystem

Condenser heaters installation

Page

Doc.Id

Issue

Date

33 of 43

AMSTR-NLR-PR-043

draft 5

september 2009

## 8 Appendix A

In the following tables are described the correspondence between the ID heater on TTCS loop are related to the heater P/N provided by the supplier:

Location/	Condenser	ID heater	P/N
Inlet/outlet foil heater	QM	HHLL1aPW_f	
		HHLL1bPW_f	
	PW	HHLL1aPWAK_f	
		HHLL1bPWAK_f	
	SR	HHLL1aSRAM_f	
		HHLL1bSRAM_f	
	PR	HHLL1aPRAM_f	
		HHLL1bPRAM_f	
	SW	HHLL1aSWAK_f	
		HHLL1bSWAK_f	
Condenser foil heater	QM	HHCONWP7a	
		HHCONWP7b	
	PW	HHCONWAKEP1a	
		HHCONWAKEP1b	
		HHCONWAKEP2a	
		HHCONWAKEP2b	
		HHCONWAKEP3a	
		HHCONWAKEP3b	
		HHCONWAKEP4a	
		HHCONWAKEP5a	
		HHCONWAKEP5b	
		HHCONWAKEP6a	
		HHCONWAKEP6b	
		HHCONWAKEP7a	
		HHCONWAKEP7b	
		HHCONWAKEP8b	
		HHCONWAKEP8a	



# AMS Tracker Thermal Control Subsystem

Condenser heaters installation

Page

Doc.Id

Issue

Date

34 of 43

AMSTR-NLR-PR-043

draft 5

september 2009

SR	HHCONRAMS1a
	HHCONRAMS1b
	HHCONRAMS2a
	HHCONRAMS2b
	HHCONRAMS3a
	HHCONRAMS3b
	HHCONRAMS4a
	HHCONRAMS5a
	HHCONRAMS5b
	HHCONRAMS6a
	HHCONRAMS6b
	HHCONRAMS7a
	HHCONRAMS7b
	HHCONRAMS8b
	HHCONRAMS8a
PR	HHCONRAMP1a
	HHCONRAMP1b
	HHCONRAMP2a
	HHCONRAMP2b
	HHCONRAMP3a
	HHCONRAMP3b
	HHCONRAMP4a
	HHCONRAMP5a
	HHCONRAMP5b
	HHCONRAMP6a
	HHCONRAMP6b
	HHCONRAMP7a
	HHCONRAMP7b
	HHCONRAMP8b
	HHCONRAMP8a
SW	HHCONWAKES1a
	HHCONWAKES1b
	HHCONWAKES2a
	HHCONWAKES2b
	HHCONWAKES3a



# AMS Tracker Thermal Control Subsystem

Condenser heaters installation

Page

Doc.Id

Issue

Date

35 of 43

AMSTR-NLR-PR-043

draft 5

september 2009

HHCONWAKES3b		
HHCONWAKES4a		
HHCONWAKES5a		
HHCONWAKES5b		
HHCONWAKES6a		
HHCONWAKES6b		
HHCONWAKES7a		
HHCONWAKES7b		
HHCONWAKES8b		
HHCONWAKES8a		
Liquid line wire heater	QM	HHLL1aPW_w HHLL1bPW_w
	PW	HHLL1aPWAK_w HHLL1bPWAK_w
	SR	HHLL1aSRAM_w HHLL1bSRAM_w
	PR	HHLL1aPRAM_w HHLL1bPRAM_w
	SW	HHLL1aSWAK_w HHLL1bSWAK_w



# AMS Tracker Thermal Control Subsystem

Condenser heaters installation

Page

Doc.Id

Issue



Date

36 of 43

AMSTR-NLR-PR-043

draft 5

september 2009





# AMS Tracker Thermal Control Subsystem

Condenser heaters installation

Page

37 of 43

Doc.Id



AMSTR-NLR-PR-043

Issue

draft 5

Date

september 2009





# AMS Tracker Thermal Control Subsystem

Condenser heaters installation

Page

Doc.Id

Issue



Date

38 of 43

AMSTR-NLR-PR-043

draft 5

september 2009





# AMS Tracker Thermal Control Subsystem

Condenser heaters installation

Page

Doc.Id

Issue



Date

39 of 43

AMSTR-NLR-PR-043


draft 5

september 2009



## 9 Appendix B

### Foil heater positioning on top plate







# AMS Tracker Thermal Control Subsystem

Condenser heaters installation

Page

Doc.Id

Issue


Date

41 of 43

AMSTR-NLR-PR-043

draft 5

september 2009





# AMS Tracker Thermal Control Subsystem

Condenser heaters installation

Page

Doc.Id

Issue


Date

42 of 43


AMSTR-NLR-PR-043

draft 5

september 2009



Foil heater positioning on top strain relief





# **AMS Tracker Thermal Control Subsystem**

Condenser heaters installation

Page	43 of 43
Doc.Id	AMSTR-NLR-PR-043
Issue	draft 5
Date	september 2009

**END OF DOCUMENT**