



Doc. #	(TTCS-SYSU-GS-TN-002-5.0) AMSTR-SYSU-PR-024		
Project	AMS-TTCS		
Title	FM TTCB FILLING AND VENTING PROCEDURE		
Create Date	2009-10-8 9:45	Save date	2009-10-8 9:47
File name	AMSTR-SYSU-PR-024 FM_TTCB_Filling_and_ventin g_procedure 2.0.doc	Issue	2.0
Distribution	Unlimited	Pages	64

	Name	Signature	Date	Department/Organization
Prepared by	Xihui Sun/ Zhan Zhang			
Checked by	Zhenhui He			
Approved by	Zhenhui He			
Distribution List				
Internal		External		
Name	Department	Name	Organization	

AMS-TTCS AMSTR-SYSU-PR-024		Page	2	
		OF	64	
Title	FM TTCB Filling and venting procedure	ISSUE	2.0	

CHANGE TAKE BY HAND			
<i>ISSUE</i>	<i>DATE</i>	<i>AUTHOR</i>	<i>REASON FOR CHANGE AND AFFECTED SECTIONS</i>
<i>Issue 1</i>		<i>XH.SUN</i>	<i>Created for TTCB functional check</i>
<i>Issue 2</i>	<i>2009-10-08</i>	<i>XH Sun/ Z Zhang</i>	<i>Modified for TTCS FM final filling after integration</i>

No part of this document may be reproduced and/or disclosed, in any form or by any means, without the prior written permission of SUN YAT-SEN UNIVERSITY.



AMS-TTCS AMSTR-SYSU-PR-024		Page	3	
		OF	64	
Title	FM TTCS Filling and venting procedure	ISSUE	2.0	

TABLE OF CONTENT

1. SCOPE.....	5
2. DOCUMENTS.....	5
2.1	5
3. AMS TTCS FILLING SYSTEM.....	6
3.1 Principle of the TTCS filling system.....	6
3.2 Structure of the portable TTCS filling system.....	6
4. MAIN TERM COMMENTARY OF THE TTCS FILLING PROCEDURE	8
5. PRINCIPLE OF VOLUME DETERMINATION	10
5.1 Volume determination by gas mass	10
5.2 Volume determination of the TTCS loop	10
6. TTCS FILL PROCEDURE	12
6.1 Preparation procedures.....	13
6.2 Leak rate of the TTCS loop	14
6.3 Determination TTCS volume and CO ₂ mass to be filled.....	16
6.4 Fill a standard vessel with CO ₂ from a Gas bottle.....	19
6.5 Calibration of the filled mass	20
6.6 Fill TTCS loop with CO ₂ from SV1.5	22
6.7 Venting CO ₂ from the TTCS loop	24
6.8 Temporary sealing the TTCS loop (FM)	26
7. FILLING PROCEDURE DATA SHEET	27
7.1 Preparation procedures.....	27
7.2 Filling system leak rate examination	28
7.3 Determination of filling system volume.....	30
7.4 Determination of TTCS volume	34
7.5 Fill a standard vessel with CO ₂ from a Gas bottle.....	38
7.6 Calibration of the filled mass	43
7.7 Fill TTCS loop with CO ₂ from SV1.5	47
7.8 Venting CO ₂ from the TTCS loop	53

No part of this document may be reproduced and/or disclosed, in any form or by any means, without the prior written permission of SUN YAT-SEN UNIVERSITY.

AMS-TTCS AMSTR-SYSU-PR-024		Page	4	
		OF	64	
Title	FM TTCB Filling and venting procedure	ISSUE	2.0	

8. APPENDIX	55
8.1 Error analysis of volume determination of a vessel by weighting the gas mass inside 55	
8.2 Error analysis of volume determination of TTCS loop by indirectly measuring the Nitrogen mass inside the loop	56
8.3 Error analysis of the total filled mass of TTCS loop	57
8.4 Calculation of the required filling mass into the SV1.5.....	59
8.5 Calculation example	60

LIST OF TABLES

Table 2-1 Reference	5
Table 2 Commentary about main term of the TTCS filling procedure	8
Table 3 Preparation procedures	13
Table 4 Procedures for leak rate examination	14
Table 5 Procedure of determination of the volume of the TTCS loop V_{loop} and the CO_2 mass to be filled	16
Table 6 Procedure of determination of filling a standard vessel with CO_2 from a gas bottle	19
Table 7 Procedure of Calibration of the filled mass	20
Table 8 Procedure of filling TTCS loop with CO_2 from SV1.5.....	22
Table 9 Procedures for venting CO_2 from TTCS loop	25
Table 10 saturated properties of CO_2 from 15°C to 29°C with interval of 1°C	62

LIST OF FIGURES

Figure 3-1 Portable filling system	6
Figure 3-2 Schematic TTCS filling system	7
Figure 5-1 Weight of gas mass of the filled standard vessel before filling TTCS, to determine the volume of TTCS LOOP	11
Figure 5-2 Weight of gas mass of the filled standard vessel after filling TTCS to determine the volume of TTCS FM	11

No part of this document may be reproduced and/or disclosed, in any form or by any means, without the prior written permission of SUN YAT-SEN UNIVERSITY.


AMS-TTCS AMSTR-SYSU-PR-024		Page	5	
		OF	64	
Title	FM TTCS Filling and venting procedure	ISSUE	2.0	

Figure 6-1 Schematic of venting CO ₂ from TTCS loop	25
Figure 8-1 CO ₂ initial state and mass distribution between the filling system and the TTCS loop before starting filling	59
Figure 8-2 CO ₂ final state and mass distribution between the filling system and the TTCS loop after finishing filling	59
Figure 8-3 CO ₂ mass distribution between the filling system and the TTCS loop after finishing filling	60

1. SCOPE

This document describes the AMS Tracker Thermal Control System (TTCS) filling system, and the CO₂ filling procedure for TTCS FM after integration, based on this filling system.


2. DOCUMENTS

2.1

Table 2-1 Reference

RD-1	TTCS Filling System and Accuracy, by G. van Donk/J. van Es	NLR-Memorandum AMSTR-NLR-TN-019-Issue 02	
RD-2	Cleaning of 316L tubes and components, by WJ Xiao	TTCS-SYSU-GS-TN-001-1.0	
RD-3	Leak detection for TTCS EM by He mass spectrography, JF Ding	TTCS-SYSU-GS-RP-003-1.0	

No part of this document may be reproduced and/or disclosed, in any form or by any means, without the prior written permission of SUN YAT-SEN UNIVERSITY.

AMS-TTCS AMSTR-SYSU-PR-024		Page	6	
		OF	64	
Title	FM TTCS Filling and venting procedure	ISSUE	2.0	

3. AMS TTCS FILLING SYSTEM

3.1 Principle of the TTCS filling system

The TTCS filling system is designed to fill the required CO₂ into the TTCS loop with mass accuracy of 4%. The filling system is capable to measure the TTCS loop volume, which allows the determination of the fill mass of CO₂.

The requirement details and the filling principle can be referred to RD1 “TTCS Filling System and Accuracy”.


3.2 Structure of the portable TTCS filling system



Figure 3-1 Portable filling system

Figure 3-1 and figure 3-2 shows the structure and the principle of the TTCS filling system. The filling system consists of three standard vessels with about volume of 1.5 liters (labeled as: VS_A, VS_B, and VS_C, respectively), a filling box (see Figure 3-1, the photo above, and Figure 3-2), a vacuum pump, and an electronic balance (locally supplied for the last two), a digital pressure

No part of this document may be reproduced and/or disclosed, in any form or by any means, without the prior written permission of SUN YAT-SEN UNIVERSITY.

AMS-TTCS AMSTR-SYSU-PR-024		Page	7	
		OF	64	
Title	FM TTCB Filling and venting procedure	ISSUE	2.0	

gauge, and flexible extension filling tubes. The filling box consists of a vacuum valve and valve 4 that connect to the vacuum connector, a vacuum gauge to measure the vacuum, valve 1 that connects to the TTCS loop through connector 1, valve 2 that connects to the gas bottle through connector 2, valve 3 that connects to a standard vessel through connector 3, a digital pressure gauge to measure filling pressure, a finer gauge mount on the front panel measures outlet pressure of pressure regulator and these two pressure gauges can measure pressure of TTCS indirectly during filling. And two filters that prevent micro-particles from entering the filling system (including standard vessels) and the TTCS loop.





Figure 3-2 Schematic TTCS filling system


AMS-TTCS AMSTR-SYSU-PR-024		Page	8	
		OF	64	
Title	FM TTCSB Filling and venting procedure	ISSUE	2.0	

4. MAIN TERM COMMENTARY OF THE TTCS FILLING PROCEDURE

Table 2 Commentary about main term of the TTCS filling procedure


Nomenclature	
T	Temperature
M	Mass
V	Volume
ρ_G	Density of gas
Subscript	
C	Calculated
E	Empty
F	Filled
FT	Filling tube and box
FR	Fill rate (g/L)
Filled_VS	The filled standard vessel
Filled_L	The filled loop
L	The TTCS Loop
O	Obtained
R	Retained
VS	Standard vessel with volume of 1.5L

No part of this document may be reproduced and/or disclosed, in any form or by any means, without the prior written permission of SUN YAT-SEN UNIVERSITY.

AMS-TTCS AMSTR-SYSU-PR-024		Page	9	
		OF	64	
Title	FM TTCB Filling and venting procedure	ISSUE	2.0	

T_{room}	Clean room temperature
M_{C_L}	$=V_{\text{Loop}} \times FR$ Calculated CO ₂ mass to be filled into the TTCS LOOP
ρ_G (T, P)	CO ₂ density inside the standard vessel determined by the chosen final temperature of the standard vessel and the final saturated pressure of the TTCS loop during filling
M_{C_R_VS}	$=V_{\text{VS}} \times \rho_G (T)$ The calculated CO ₂ mass to be retained in the SV1.5 after filling
M_{C_R_FT}	$=V_{\text{FT}} \times \rho_G (T)$ The calculated CO ₂ mass to be retained in the filling box and the extend tube after filling
M_{C_R}	$=M_{\text{C_R_VS}} + M_{\text{C_R_FT}}$
M_{E_VS}	Net mass of the SV1.5 in 15Pa.
M_{C_VS}	$= M_{\text{E_VS}} + M_{\text{C_L}} + M_{\text{C_R}};$ Total calculated mass of the filled SV1.5 before filling to the TTCS Loop
M_{Filled_VS}	The obtained gross mass of CO ₂ in the SV1.5 before filling
M_{O_VS}	$= M_{\text{Filled_VS}} - M_{\text{E_VS}}$ The obtained net mass of CO ₂ to be filled into the SV1.5 before filling
M_{O_R_VS}	The obtained CO ₂ mass retained in the SV1.5 after filling
M_{O_R_FT}	The obtained CO ₂ mass retained in the filling tube after filling
M_{Filled_L}	$= M_{\text{O_VS}} - M_{\text{O_R_VS}} - M_{\text{O_R_FT}}$ The obtained CO ₂ mass filled into the TTCS Loop

No part of this document may be reproduced and/or disclosed, in any form or by any means, without the prior written permission of SUN YAT-SEN UNIVERSITY.

AMS-TTCS AMSTR-SYSU-PR-024		Page	10	
		OF	64	
Title	FM TTCSB Filling and venting procedure	ISSUE	2.0	

5. PRINCIPLE OF VOLUME DETERMINATION

5.1 Volume determination by gas mass

Assumption: There is no leakage of the measuring system, including the containers (here components and couplings), during the period of measurement; and the temperature can be controlled with uniformity within 2.0K; no nitrogen absorption on the inner surface of the system (here TTCS loop) that made of stainless steel.

A container, with mass of M_E and filled N_2 of M_{N_2} , is connected to another container with unknown volume V_2 , after measuring the N_2 mass filled into V_2 by weighting, and the final pressure by employing the filling system with high precision pressure sensor, and the temperatures of the containers, the unknown volume of V_2 can be determined by using the ideal gas equation.

5.2 Volume determination of the TTCS loop


Fill nitrogen with the volumes of the known container to a pressure of 4.5MPa; weight the mass of the container $M_{\text{nitrogen1}}$. Connect the container to a vacuumed loop and release nitrogen to the loop. Weight the mass of the container again $M_{\text{nitrogen2}}$, the nitrogen mass filled into the loop can then be calculated: $M_{\text{nitrogen}} = M_{\text{nitrogen1}} - M_{\text{nitrogen2}}$,

$$V_{\text{Loop}} = \frac{M_{\text{nitrogen}} RT_2}{P_2 m_{\text{nitrogen}}}$$

Here m_{nitrogen} is molecular weight of nitrogen.

$$\Delta M_B = \pm 0.1 \text{g}, \text{ and } \Delta T_{\text{loop}} = \pm 2 \text{K}, \text{ the error } \frac{\Delta V_{\text{loop}}}{V_{\text{loop}}} = \frac{\Delta P_{\text{loop}}}{P_{\text{loop}}} + 2 \frac{\Delta M_B}{M_{He}} + \frac{\Delta T_{\text{loop}}}{T_{\text{loop}}} \text{ is about } 2.4\%.$$

Please refers to 8.2 for details.

AMS-TTCS AMSTR-SYSU-PR-024		Page	11	
		OF	64	
Title	FM TTCB Filling and venting procedure	ISSUE	2.0	




Figure 5-1 Weight of gas mass of the filled standard vessel before filling TTCS, to determine the volume of TTCS LOOP





Figure 5-2 Weight of gas mass of the filled standard vessel after filling TTCS to determine the volume of TTCS FM

AMS-TTCS AMSTR-SYSU-PR-024		Page	12	
		OF	64	
Title	FM TTCSB Filling and venting procedure	ISSUE	2.0	

6. TTCS FILL PROCEDURE


The fill procedure consists of the following major steps:

1. Determination of the exact TTCS-loop volume, including that of the accumulator
2. Filling of the TTCS-loop with the exact CO₂ mass

Main implication of the filled TTCS is that TTCS-loop below 60°C (the maximum design temperature) is below 160bar, the maximum design pressure. We use a CO₂ filling system to fill the TTCS loop (including all the components), which can reach the required filling accuracy.

In general, the filling procedures include:

1. Preparation;
2. Leak test of the filling system, including extend tubes, and the TTCS loop;
3. Filling a standard vessel and the calibration of the filled mass before loop filling
4. Determination of the volume of the TTCS loop and the CO₂ mass to be filled.
5. Filling a standard vessel and then Filling a TTCS loop
6. Verify the fill mass of CO₂ into the loop (by weighting the mass of the standard vessel)
7. Temporary Sealing of the TTCS loop
8. If refilling is required, CO₂ venting from the TTCS.


AMS-TTCS AMSTR-SYSU-PR-024		Page	13	
		OF	64	
Title	FM TTCB Filling and venting procedure	ISSUE	2.0	

6.1 Preparation procedures

Table 3 Preparation procedures

Step	Action
1.	
2.	Calibrate the volume of the filling box, the two connecting tubes and valves; ($V_{FT}= 0.042$ liter, if no additional extend tube is required)
3.	Select filling environmental temperature, e.g., 22°C;
4.	Wrap a heating tape around the filling tube outside the box;
5.	Prepare an electronic balance, with full scale of XXg and accuracy of 0.1g;
6.	Prepare a He-mass spectrometer to perform leak test
7.	Prepare a high precision APS (0.1%FS with FS=10MPa) for volume determination;
8.	Prepare pure N ₂ gas bottle for volume calibration
9.	Prepare high purity (99.99%) CO ₂ bottle for filling;
10.	Prepare a barrel with ice water mixture for cooling the vessel;
11.	Prepare a fan for cooling TTCS accumulator during filling;
12.	Connect a dry mechanical pump to the vacuum connector;

list of components to be prepared

AMS-TTCS AMSTR-SYSU-PR-024		Page	14	
		OF	64	
Title	FM TTCSB Filling and venting procedure	ISSUE	2.0	


6.2 Leak rate of the TTCS loop

In order to ensure the filling accuracy, the leak rate of the filling system need to be satisfied by the requirements below $5 \times 10^{-5} \text{ mbar}\cdot\text{l/s}$. Since the filling system had been used for several times, leak might be happened at the connectors of the filling system. Using equipment “He mass spectrometer” to check these connectors. If some connecting parts have a detectable leak, replace them with new ones.

To avoid the helium remaining in the filling system after the leak test, a flash operation is needed. N₂ could be taken to flash the filling system.

Table 4 Procedures for leak rate examination


Step	Action
1.	Seal the filling system with the extend tubes
2.	Measure the background leak rate of the “He mass spectrometer”
3.	Connect the He mass spectrometer to the vacuum connector
4.	Vacuum the filling system
5.	Measure the leak rate of the filling system without helium gas.
6.	Using <i>negative</i> method, blowing helium gas, to measure the leak rate of these connectors, connector 1, 2 and 3. Leak rate for each connector should be below $5 \times 10^{-5} \text{ mbar}\cdot\text{l/s}$.
7.	Disconnect the vacuum pump and measure the background leak rate of the equipment.
8.	Flush the filling system
9.	Connect the N ₂ bottle to the connector 2
10.	Pressurize the filling system to 40bar

AMS-TTCS AMSTR-SYSU-PR-024		Page	15	
		OF	64	
Title	FM TTCB Filling and venting procedure	ISSUE	2.0	

11.	Release the N2 from the system
12.	Repeat above steps 10 Error! Reference source not found. and Error! Reference source not found. 11

If the leak rate of the filling system, which reaches $5.0 \times 10^{-5} \text{ mbar l/s}$, are detected with a He-mass spectrometer, this gives a leak rate of $7.7 \times 10^{-3} \text{ g/day/connector}$, which is neglectable as compared to 850g fill mass of CO₂.

NOTE: As the portable filling system is disconnected and reconnected before being used, the leak rate of the system must be detected again.

AMS-TTCS AMSTR-SYSU-PR-024		Page	16	
		OF	64	
Title	FM TTCB Filling and venting procedure	ISSUE	2.0	

6.3 Determination TTCS volume and CO₂ mass to be filled


In Figure 4-1 and Figure 4-2 the set-up for the volume determination is shown. The principle of volume determination is to measure mass of a standard vessel before and after filling the TTCS-loop. The mass difference gives (in)-directly the TTCS loop-volume.

Note:


1. Because of assembly, pressure regulator does not function compatibly to control the filling speed, we decide to so by turning on and off valves, to replace operating the pressure regulator. Monitoring the DPS by TTCE at the same time (**not higher than 0.5 bar**).
2. Three temperature sensors of Pt-1000 of new filling system should be mounted at the top, the middle, and the bottom of the standard vessel's side face, which is enveloped by the heater as a jacket (No.1 PT1000 for control, No.2 PT1000 and No.3 PT1000 for monitor. During filling CO₂ from the standard vessel to the TTCS loop, No.1 PT1000 should be paste on the middle of the standard vessel's side face, the rest PT1000 should be paste on the top and bottom of the standard vessel's side face).

Table 5 Procedure of determination of the volume of the TTCS loop V_{loop} and the CO₂ mass to be filled


Step	Action
1.	Take clean room temperature as T_{room}
2.	Connect the SV1.5 (anyone of stand vessel can be used) to connector 3; <u>Note: Longer extend tube may be used, and height difference may exist between the SV1.5 and connector 3.</u> <u>The extend tube between connectors and valves must be mechanically supported to reduce strain.</u>
3.	Connect a N ₂ bottle to connector 2;

AMS-TTCS AMSTR-SYSU-PR-024		Page	17	
		OF	64	
Title	FM TTCSB Filling and venting procedure	ISSUE	2.0	

4.	<p>Connect the TTCS Loop to connector 1;</p> <p><u>Note: Longer extend tube may be used, and height difference may exist between the TTCS loop and connector 1.</u></p> <p><u>The extend tube between connectors and valves must be mechanically supported to reduce strain.</u></p>
5.	Close valve 1, valve 4 and the N ₂ bottle valve, open valve 2, valve 3, SV1.5 valve, pressure regulator the vacuum valve and the TTCS valve slowly, to pump SV1.5 down to 30Pa;
6.	Close the vacuum valve, open the valve of the N ₂ bottle;
7.	<p>Fill the SV1.5 with N₂ up to 4.5MPa, then close valve 2; waiting for 0.5~1hours until pressure and temperature of the standard vessel is stable. Take the N₂ pressure by hand as P₁.</p> <p>Take by hand average reading of three PT1000s in the filling system as T₁.</p> <p>(here T₁ is compared T_{room} with range of $\pm 1^{\circ}\text{C}$);</p>
8.	Close the SV1.5 valve, valve 3, and the N ₂ bottle valve, disconnect SV1.5 from connector 3;
9.	Weight the SV1.5 with an electronic balance (0.1g in precision or better), as M _{nitrogen1} ;
10.	Connect the filled SV1.5 back to the connector 3;
11.	Open valve 3, valve 1, valve 4 and the vacuum valve; open pressure regulator to pump the filling box and TTCS loop down to 30Pa;
12.	<p>Close the vacuum valve, valve 1 and valve 4, and switch off the pump.</p> <p>Open the SV1.5 valve, then close SV1.5 valve, slowly turn on valve 1 to fill the N₂ into the TTCS loop to prevent pressure spike to the sensors.</p> <p>Repeating on and off SV1.5 valve and valve 1 in turn until pressure of TTCS loop is up to 1.5MPa, then open SV5.0 valve and valve 1 slowly at the same time.</p>
13.	Wait a period of time (0.5~1hours), take by hand the loop pressure as P ₂ and average reading of three PT1000s in the filling system as T ₂ .

AMS-TTCS AMSTR-SYSU-PR-024		Page	18	
		OF	64	
Title	FM TTCSB Filling and venting procedure	ISSUE	2.0	


	(here T_2 is compared T_{room} with range of $\pm 1^\circ\text{C}$); NOTE: Take by hand the highest and the lowest measurable temperature of the TTCS loop, the temperature difference should be less than 2°C
14.	Close valve 1, valve 3, SV1.5 valve and the TTCS valve;
15.	Disconnect SV1.5 from the connector 3;
16.	Weight the SV1.5 with the electronic balance again, as $M_{\text{nitrogen2}}$;
17.	The nitrogen mass inside the loop is $M_{\text{nitrogen}} = M_{\text{nitrogen1}} - M_{\text{nitrogen2}} - M_{\text{filling system}}$, where
18.	The volume of the loop is determined by the ideal gas equation , where $m_{\text{nitrogen}} = 28\text{g/mol}$ for nitrogen, and R is the gas constant;
19.	Determine the fill mass by $M_{\text{C_L}} = V_{\text{Loop}} \cdot \text{FR}$ (where $\text{FR} = 569.60 \text{ g/l}$).
20.	<p>Calculate the filled mass for the standard vessel</p> <p>Set $M_{\text{C_VS}} = M_{\text{E_VS}} + M_{\text{C_L}} + M_{\text{C_R}}$;</p> <p>NOTE: $M_{\text{C_R}} = M_{\text{C_R_VS}} + M_{\text{C_R_FT}} = V_{\text{VS}} \times \rho_{\text{G}}(T, P) + V_{\text{FT}} \times \rho_{\text{G}}(T, P)$</p> <p>Here $\rho_{\text{G}}(T, P)$ is determined by the chosen final temperature of the standard vessel and the final saturated pressure of the TTCS loop.</p> <p><u>see appendix 8.5 For details.</u></p>

AMS-TTCS AMSTR-SYSU-PR-024		Page	19	
		OF	64	
Title	FM TTCB Filling and venting procedure	ISSUE	2.0	

6.4 Fill a standard vessel with CO₂ from a Gas bottle

Table 6 Procedure of determination of filling a standard vessel with CO₂ from a gas bottle

Step	Action
1.	Connect the SV1.5 (here anyone of the two SV1.5 can be used) to connector 3; <u>Note: Longer extend tube may be used, and height difference may exist between the SV1.5 and connector 3.</u> <u>The extend tube between connectors and valves must be mechanically supported to reduce strain.</u>
2.	Connect a high purity CO ₂ gas bottle to connector 2;
3.	Close valve 1 ,valve 4 and the gas bottle valve, open valve 3, valve 2, pressure regulator, the vacuum valve and the SV1.5 valve;
4.	Open valve 3 until the pressure drop to 30Pa; Close the vacuum valve, open the bottle valve slowly, until the pressure up to 1MPa; Close the bottle valve and open the vacuum valve slowly, pump the SV1.5 until the pressure drop to 30Pa; Repeat such operations and flush with CO ₂ twice.
5.	Place the vacuumed SV1.5 to a barrel with ice water mixture, switch off the pump;
6.	Open valve 2 and regulate the outlet pressure of gas bottle valve slowly until higher than 4MPa;
7.	After a period of time(2 hours~3 hours), close the SV1.5 valve, valve 2, valve 3 and the gas bottle valve; <u>Estimate weight by electronic balance without disconnect, check whether it meets required mass in the SV1.5. If CO₂ filled into the SV1.5 is less than the required mass, then put the SV1.5 to a barrel with ice water mixture again, open valve 2, valve 3 and the SV1.5 valve.</u> <u>During the estimation of the weight without disconnection, the extend tube between the SV1.5 and filling box should be put up slightly in order to get a real weight of the filled SV1.5 as possible as we can, and even do that the extend tube still account for about 200g in total estimating weight.</u>

AMS-TTCS AMSTR-SYSU-PR-024		Page	20	
		OF	64	
Title	FM TTCB Filling and venting procedure	ISSUE	2.0	

8.	Disconnect SV1.5 from the filling box;
9.	Dry and clean the SV1.5 surface;
10.	Weight the filled SV1.5 with a electronic balance, as $M_{\text{Filled_VS}}$;
11.	Take by hand the filled CO ₂ mass $M_{\text{O_VS}} = M_{\text{Filled_VS}} - M_{\text{E_VS}}$
12.	If $M_{\text{O_VS}}$ above what required ($M_{\text{C_L}} + M_{\text{C_R}}$), open SV1.5 valve very slightly to release a little CO ₂ gas, close SV1.5valve;
13.	Weight SV1.5again; repeats step 12 until m_{CO_2} value meets the requirement ($M_{\text{C_L}} + M_{\text{C_R}}$).
14.	Seal the extended tube and the filled SV1.5.


Note : According to previous experiments data, under 3.9MPa~4.2MPa filling mass rate of SV1.5 is about 300g ~ 350g per hour near 0°C (mixture of ice and water)

6.5 Calibration of the filled mass

Table 7 Procedure of Calibration of the filled mass


Step	Action
1.	Set the filling environment temperature as 22°C
2.	Connect another standard vessel (VS_B) to connector 1 with the same extension filling tube for filling the TTCS loop; <u>Note: Longer extend tube may be used, and height difference may exist between the TTCS loop and connector 1.</u>

No part of this document may be reproduced and/or disclosed, in any form or by any means, without the prior written permission of SUN YAT-SEN UNIVERSITY.

AMS-TTCS AMSTR-SYSU-PR-024		Page	21	
		OF	64	
Title	FM TTCB Filling and venting procedure	ISSUE	2.0	

	<u>The extend tube between connectors and valves must be mechanically supported to reduce strain.</u>
3.	Connect a dry mechanical pump
4.	Close valve 2 and open the vacuum valve, valve 3, pressure regulator, valve 1, valve 4 and the VS_B valve;
5.	Pump VS_B until the pressure down to 30Pa;
6.	Connect the filled SV1.5 as the VS_A to connector 3;
7.	Wrap VS_A with heating tape and affix three PT1000 to the top, the middle, and the bottom of the VS_A , respectively.
8.	Open the vacuum valve slowly, and then valve 1, and valve 4 ;
9.	Pump the extension filling tube until the pressure down to 30Pa;
10.	Close the vacuum valve and valve 4;
11.	Open the VS_A valve slowly;
12.	After 5 minutes, switch on the filling box heater and the heating tape (to control the box temperature above 30°C);
13.	Watch the reading of the pressure sensor;
14.	When the pressure drops to 6MPa , close the VS_B valve, the pressure regulator, valve3, the VS_A valve, and valve 1, respectively;
15.	Switch off the filling box heater and the heating tape;
16.	unwrap VS_A ;
17.	Disconnect VS_A and VS_B , respectively;
18.	Weight VS_A and VS_B , as $M_{O_R_VSA}$ and $M_{Filled_VS_B}$, respectively
19.	From $(M_{Filled_VS} - M_{O_R_VS_A})$, we have the mass of CO ₂ out of SV1.5; from $(M_{Filled_VS_B} - M_{E_VS_B})$, we have the mass of CO ₂ into VS_B ;
20.	Obtain the mass loss $M_{loss} = (M_{Filled_VS} - M_{O_R_VS_A}) - (M_{Filled_VSB} - M_{E_VS_B})$;

No part of this document may be reproduced and/or disclosed, in any form or by any means, without the prior written permission of SUN YAT-SEN UNIVERSITY.


AMS-TTCS AMSTR-SYSU-PR-024		Page	22	
		OF	64	
Title	FM TTCS Filling and venting procedure	ISSUE	2.0	

21.	Calculate the mass loss based on the filling tube volume $M_{C_R_FT} = V_{FT} \times \rho_{CO_2}(T)$;
22.	Obtain fill loss range of the filling tube by comparing M_{loss} and $M_{C_R_FT}$ to determine performance of the current filling system
23.	Switch off the pump


6.6 Fill TTCS loop with CO₂ from SV1.5

Table 8 Procedure of filling TTCS loop with CO₂ from SV1.5

Step	Action
1.	Set the filling environment temperature as 22°C
2.	Connect the TTCS loop to connector 1 with an extended filling tube. <u>Note: Longer extend tube may be used, and height difference may exist between the TTCS loop and connector 1.</u> <u>The extend tube between connectors and valves must be mechanically supported to reduce strain.</u>
3.	Connect a high purity CO₂ gas bottle to connector 2;
4.	Put three PT1000 vertically by using adhesive tape in turn onto the side surface of the SV1.5, then wrap the SV1.5 with heater with Pt1000 in the joint of the heater. <u>Note: No.1 PT1000 for control, No.2 PT1000 and No.3 PT1000 for monitor.</u> <u>During the filling CO₂ from the standard vessel to the TTCS loop, No.1 PT1000 should be paste on the middle of the standard vessel's side face; the other two PT1000s should be paste on the top and bottom of the standard vessel's side face.</u>
5.	Connect the filled SV1.5 to connector 3;

AMS-TTCS AMSTR-SYSU-PR-024		Page	23	
		OF	64	
Title	FM TTCB Filling and venting procedure	ISSUE	2.0	

	<p><u>Note: Longer extend tube may be used, and height difference may exist between the SV1.5 and connector 3.</u></p> <p><u>The extend tube between connectors and valves must be supported to reduce strain.</u></p>
6.	<p>Use the He-mass spectrometer to perform leak test before filling.</p> <p>If leak rate more than 5×10^{-5} mbar-l/s somewhere, reconnect it until the leak rate less than 5×10^{-5} mbar-l/s</p>
7.	Switch off the He-mass spectrometer and replace it with a dry mechanical pump.
8.	Insulate the filled vessel and connect the SV heater with socket in the filling box.
9.	Open the vacuum valve, valve 1, valve2, valve 3, valve 4 , the TTCS loop valve and pressure regulator
10.	Pump until pressure of the TTCS loop and the filling box down to 30Pa, close valve4, the vacuum valve and then open the gas bottle valve slowly to fill the loop with high purity CO ₂ from the bottle, until the pressure up to 1MPa (to flush the loop)
11.	Close the gas bottle valve , open valve 1, valve 4 and the vacuum valve slowly;
12.	Pump the TTCS loop until the pressure down to 30Pa;
13.	repeat step 11 and 12 twice;
14.	Close valve 4, valve 2 and the vacuum valve; switch off the pump.
15.	Open the SV1.5 valve slowly, then close the SV1.5 valve, slowly open valve 1 to fill the CO ₂ into the TTCS loop to prevent pressure spike to the sensors. Repeating on and off the SV1.5 valve and valve 1 in turn until pressure of the TTCS loop is up to 3MPa, and then slowly open the SV1.5 valve and valve 1 in turn.
16.	Switch on the filling box heater and the standard vessel heater (to control the box temperature step by step to 30°C);
17.	Using the small fans to cool the temperature of the accumulator to accelerate the filling
18.	Watch the reading of the digital pressure gauge;

AMS-TTCS AMSTR-SYSU-PR-024		Page	24	
		OF	64	
Title	FM TTCB Filling and venting procedure	ISSUE	2.0	

19.	When the pressure drops down to 5.995MPa , close the TTCS loop valve, valve 1, the SV1.5 valve, and valve 3, respectively; <u>Note: here the pressure of 5.995MPa corresponds to CO₂ saturated temperature of 22°C</u>
20.	Switch off the filling box heater and the standard vessel heater;
21.	unwrap the heating tape from the SV1.5;
22.	Disconnect the SV1.5 from the filling box;
23.	Weight the SV1.5 and compare it with ($M_{C_R_VS} + M_{E_VS}$)
24.	After filling finished, the two extended filling tubes, the SV1.5 and the filling system must be carefully disconnect and seal.
25.	Carefully packing the two extended filling tubes, the SV1.5 and the filling system.


6.7 Venting CO₂ from the TTCS loop

Measures shall be taken to avoid damage or contamination arising from water condenses. Usually, below 15°C, the condensing dropwise is visible. The ground accumulator heater (GAC in TTCE) is used to heat the accumulator.

The TTCE communication terminal is used to inspect the accumulator temperature while venting CO₂ from the TTCS loop. PT03 is taken as a detecting point. As soon as the temperature is below 18 °C, stop releasing operation.

A valve (TTCB valve) is connected to the filling port with a filter next to it. And then an exhaust stainless tube is connected to the filter and extended to the outside of the clean room. At the exit of the stainless tube, frost might be encountered because of throttle, thus, a hot air gun is also needed to suppress this phenomenon.

No part of this document may be reproduced and/or disclosed, in any form or by any means, without the prior written permission of SUN YAT-SEN UNIVERSITY.

AMS-TTCS AMSTR-SYSU-PR-024		Page	25	
		OF	64	
Title	FM TTCB Filling and venting procedure	ISSUE	2.0	

Monitor the loop pressure by TTCE terminal, stop venting until 1.5 bar.





Figure 6-1 Schematic of venting CO₂ from TTCS loop

Table 9 Procedures for venting CO₂ from TTCS loop

1.	Switch on TTCE Terminal and go to the interface TTCE-2
2.	Write down the PT01 and PT03 temperatures
3.	Connect the TTCB valve, filter, stainless tube and extended tube
4.	Open the TTCB valve a little to release CO ₂ gas slowly while switch on the ground accumulator heater (GAC) with 30% Monitor the PT01 and PT 03, once one temperature is below 18 °C, stop venting.
5.	Use a hot air gun to heat up the exit of the stainless tube
6.	Repeat steps 0 and 0, until the pressure is down to 1.5 bar
7.	Check the reading of the TTCB' APS. Close the TTCB valve when the pressure is low down 1.5 Bar.

AMS-TTCS AMSTR-SYSU-PR-024		Page	26	
		OF	64	
Title	FM TTCB Filling and venting procedure	ISSUE	2.0	


8.	Switch off TTCE Terminal
----	--------------------------

6.8 Temporary sealing the TTCS loop (FM)

1. Close the fill valve to for further sealing the TTCS FM loop;
2. Clap the tube to the TTCS loop.

Note:

The volume of the filling tube from the box to the TTCS loop may differ from that to SV1.5. In this case, an estimation of this tube volume can be made: Taking a filling tube of one meter in length, 3mm in inner diameter as an example, the volume is 14 ml. The pressure is 6MPa at the filling temperature of 32°C is chosen as final thermodynamics state. Therefore, the mass loss in the filling is about 0.78g/m. This should be taken into account for the calculation of m_{loss} .


AMS-TTCS AMSTR-SYSU-PR-024		Page	27	
		OF	64	
Title	FM TTCB Filling and venting procedure	ISSUE	2.0	

7. FILLING PROCEDURE DATA SHEET

7.1 Preparation procedures

Preparation procedures								
Date:			Company:		Location:		Engineer:	
Step No.	Action and Description			Monitoring	Value	Result	Comment	Time
1.	Take by hand environment conditions							
2.	Temperature: □	Humidity: %RH	Pressure: MPa					
3.	Calibrate the volume of the filling box;(Vbox= 0.021 liter)							
4.	Calculate the volume of the two connecting tubes and valves;							
5.	Select filling environmental temperature, e.g., 22°C;			T _{room}				
6.	Wrap a heating tape around the filling tube outside the box;							
7.	Prepare an electronic balance with full scale more than 4200g and accuracy of 0.1g;							
8.	Prepare a bottle of pure N ₂ gas for volume calibration							
9.	Prepare high purity (99.99%)CO ₂ bottle for filling;							
10.	Prepare a barrel with ice water mixture for cooling the vessel;							
11.	Prepare a fan for cooling TTCS accumulator during filling;							
12.	Connect a dry mechanical pump to the vacuum connector;							


No part of this document may be reproduced and/or disclosed, in any form or by any means, without the prior written permission of SUN YAT-SEN UNIVERSITY.

AMS-TTCS AMSTR-SYSU-PR-024		Page	28	
		OF	64	
Title	FM TTCB Filling and venting procedure	ISSUE	2.0	

7.2 Filling system leak rate examination


Filling system leak rate examination								
Date:			Company:		Location:		Engineer:	
Step No.	Action and Description			Monitoring	Value	Result	Comment	Time
1.	Take by hand environment conditions							
2.	Temperature: □	Humidity: %RH	Pressure: MPa					
3.	Connect the two SV 1.5s to connector 1 and connector 3, respectively. Close valve 2.							
4.	Measure the background leak rate of the “He mass spectrometer”				$<5\times10^{-10} \text{ mbar l/s.}$			
5.	Connect the He mass spectrometer to the vacuum connector							
6.	Open valve1, valve 3 and valve 4 Vacuum the filling system							
7.	Measure the leak rate of the filling system without helium gas.				$<5\times10^{-8} \text{ mbar l/s.}$			
8.	Using negative method, blowing helium gas, to measure the leak rate of these connectors, valves. Leak rate for each connector should be below $5\times10^{-5} \text{ mbar l/s.}$				$<5\times10^{-5} \text{ mbar l/s.}$			
9.	Disconnect the He mass spectrometer and measure the background leak rate of the equipment.				$<5\times10^{-10} \text{ mbar l/s.}$			

No part of this document may be reproduced and/or disclosed, in any form or by any means, without the prior written permission of SUN YAT-SEN UNIVERSITY.

AMS-TTCS AMSTR-SYSU-PR-024		Page	29	
		OF	64	
Title	FM TTCB Filling and venting procedure	ISSUE	2.0	


Filling system leak rate examination						
Date:		Company:		Location:		Engineer:
Step No.	Action and Description	Monitoring	Value	Result	Comment	Time
10.	Flash the filling system					
11.	Connect the N ₂ bottle to the connector 2					
12.	Open the bottle valve and valve 2 Pressurize the filling system slowly		40±1bar			
13.	Close valve 2 and open vacuum valve Release the N ₂ from the system slowly		2±0.5bar			
14.	Open the bottle valve and valve 2 Pressurize the filling system slowly		40±1bar			
15.	Close valve 2 and open vacuum valve Release the N ₂ from the system slowly		2±0.5bar			
16.	Open the bottle valve and valve 2 Pressurize the filling system slowly		40±1bar			
17.	Close valve 2 and open vacuum valve Release the N ₂ from the system slowly		2±0.5bar			

No part of this document may be reproduced and/or disclosed, in any form or by any means, without the prior written permission of SUN YAT-SEN UNIVERSITY.

AMS-TTCS AMSTR-SYSU-PR-024		Page	30	
		OF	64	
Title	FM TTCB Filling and venting procedure	ISSUE	2.0	


7.3 Determination of filling system volume

Filling system volume determination								
Date:		Company:		Location:		Engineer:		
Step No.	Action and Description			Monitoring	Value	Result	Comment	Time
1.	Take by hand environment conditions							
2.	Temperature: <input type="checkbox"/>	Humidity: %RH	Pressure: MPa					
3.	Affix any two of the three PT1000s on the side surface of the SV1.5. and leave the rest one to monitor environmental temperature.							
4.	Connect the SV1.5 (any of the three stand vessels can be used) to connector 3; Note: Longer extend tube may be used and height difference may exist between the SV1.5 and connector 3. <u>Note: The extend tube between connectors and valves must be supported to reduce strain.</u> (For the new connectors, wrench screw nuts with one and quarter circles. For the used connectors, wrench the screw nuts further tightly.)							
5.	Connect the N ₂ bottle to connector 2;							
6.	Connect a dry mechanical pump to vacuum connector							

AMS-TTCS AMSTR-SYSU-PR-024		Page	31	
		OF	64	
Title	FM TTCB Filling and venting procedure	ISSUE	2.0	


Filling system volume determination						
Date:		Company:		Location:		Engineer:
Step No.	Action and Description	Monitoring	Value	Result	Comment	Time
7.	<p>seal the extend filling tube with the other end connected to connector 1 of the filling box;</p> <p>Note: the need of redetermination of the filling system is due to the use of additional extend filling tubes, therefore, the extend filling must be connected to the filling box with the other end sealed.</p> <p>On the other hand, we could skip this procedure if we can rely on the calculation of the volume of the additional extend filling tubes. Then :</p> $V_{FT}=V_{\text{filling_system}}+V_{C_extend\ tubes}$		s			
8.	Close valve 1, valve 4 and the N ₂ bottle valve, open valve 2, valve 3, the SV1.5 valve, pressure regulator and the vacuum valve slowly, pump the SV1.5 and the filling box down to 30Pa;	Evacuate Time Vacuum gauge reading	1~2 hours ≤30Pa			
9.	Close the vacuum valve open the valve of the N ₂ bottle					

No part of this document may be reproduced and/or disclosed, in any form or by any means, without the prior written permission of SUN YAT-SEN UNIVERSITY.


AMS-TTCS AMSTR-SYSU-PR-024		Page	32	
		OF	64	
Title	FM TTCB Filling and venting procedure	ISSUE	2.0	

Filling system volume determination						
Date:		Company:	Location:		Engineer:	
Step No.	Action and Description	Monitoring	Value	Result	Comment	Time
10.	Fill the SV1.5 with N ₂ up to 4.5MPa, then close valve 2; wait until pressure and temperature of the standard vessel is stable. Take by hand the pressure as P1' . Take by hand the average reading of the three PT1000s in the filling system as T ₁ ' . (here T ₁ ' is comparable to T _{room} with range of $\pm 1^{\circ}\text{C}$);	Evacuate Time P1' No.1 Pt1000 No.2 Pt1000 No.3 Pt1000	0.5~1hours T _{room} $\pm 1^{\circ}\text{C}$ T _{room} $\pm 1^{\circ}\text{C}$ T _{room} $\pm 1^{\circ}\text{C}$			
11.	Close the filled SV1.5 valve, valve 3, and the N ₂ bottle valve, disconnect the filled SV1.5 from connector 3;					
12.	Weight the filled SV1.5 with an electronic balance (0.1g precision or better), as M' _{nitrogen1} ;					
13.	Connect the filled SV1.5 back to the connector 3;					
14.	Open valve 3, valve 1,vale 4 and the vacuum valve; open pressure regulator to pump the filling box down to 30Pa;					
15.	Close the vacuum valve, valve 1 and valve 4, switch off the pump. Open the SV1.5 valve and close SV1.5 valve, slowly open valve 1 to fill the N ₂ into the filling box and tubes.	DPS reading of the TTCS loop	$\leq 0.5\text{Bar}$			

No part of this document may be reproduced and/or disclosed, in any form or by any means, without the prior written permission of SUN YAT-SEN UNIVERSITY.


AMS-TTCS AMSTR-SYSU-PR-024		Page	33	
		OF	64	
Title	FM TTCB Filling and venting procedure	ISSUE	2.0	

Filling system volume determination						
Date:		Company:		Location:		Engineer:
Step No.	Action and Description	Monitoring	Value	Result	Comment	Time
16.	Wait about ten mins, take by hand the pressure as P2' and the average reading of the three PT1000s in the filling system as T_2' . (here T_2' is comparable to T_{room} with range of $\pm 1^\circ\text{C}$);	P2' No.1 Pt1000 No.2 Pt1000 No.3 Pt1000	$T_{room} \pm 1^\circ\text{C}$ $T_{room} \pm 1^\circ\text{C}$ $T_{room} \pm 1^\circ\text{C}$			
17.	Close valve 1, valve 3, SV1.5 valve;					
18.	Disconnect SV1.5 from the connector 3;					
19.	Weight the SV1.5 with the electronic balance again, as $M'_{nitrogen2}$;					
20.	The nitrogen mass inside the filling system including tubes is: $M_{FT} = M'_{nitrogen1} - M'_{nitrogen2}$;					
21.	The volume of the filling system including tubes is determined by the ideal gas equation , where $V_{FT} = \frac{M_{FT} R T_2'}{m_{nitrogen} P_2'}$ $m_{nitrogen} = 28\text{g/mol}$ for nitrogen, and R is the gas constant;					

AMS-TTCS AMSTR-SYSU-PR-024		Page	34	
		OF	64	
Title	FM TTCB Filling and venting procedure	ISSUE	2.0	


7.4 Determination of TTCS volume

TTCS volume determination								
Date:		Company:		Location:		Engineer:		
Step No.	Action and Description			Monitoring	Value	Result	Comment	Time
22.	Take by hand environment conditions							
23.	Temperature: <input type="checkbox"/>	Humidity: %RH	Pressure: MPa					
24.	Affix any two of the three PT1000s on the side surface of the SV1.5. and leave the rest one to monitor environmental temperature.							
25.	Connect the SV1.5 (any of the three stand vessels can be used) to connector 3; Note: Longer extend tube may be used and height difference may exist between the SV1.5 and connector 3. <u>Note: The extend tube between connectors and valves must be supported to reduce strain.</u> (For the new connectors, wrench screw nuts with one and quarter circles. For the used connectors, wrench the screw nuts further tightly.)							
26.	Connect the N ₂ bottle to connector 2;							

AMS-TTCS AMSTR-SYSU-PR-024		Page	35	
		OF	64	
Title	FM TTCSB Filling and venting procedure	ISSUE	2.0	


TTCS volume determination						
Date:		Company:		Location:		Engineer:
Step No.	Action and Description	Monitoring	Value	Result	Comment	Time
27.	Connect a dry mechanical pump to vacuum connector					
28.	Connect the TTCS loop to connector 1; Longer extend tubes may be used and height difference may exist between the TTCS loop and connector 1. <u>Note: The extend tube between connectors and valves must be supported to reduce strain.</u>					
29.	Close valve 1, valve 4 and the N ₂ bottle valve, open valve 2, valve 3, the SV1.5 valve, pressure regulator and the vacuum valve slowly, pump the SV1.5 and the filling box down to 30Pa;	Evacuate Time Vacuum gauge reading	1~2 hours ≤30Pa			
30.	Close the vacuum valve open the valve of the N ₂ bottle					
31.	Fill the SV1.5 with N ₂ up to 4.5MPa, then close valve 2; waiting until pressure and temperature of the standard vessel is stable. Take by hand the pressure as P1 . Take by hand the average reading of the three PT1000s in the filling system as T ₁ . (here T ₁ is comparable to T _{room} with range of ±1°C);	Evacuate Time P1 No.1 Pt1000 No.2 Pt1000 No.3 Pt1000	0.5~1hours T _{room} ±1°C T _{room} ±1°C T _{room} ±1°C			

No part of this document may be reproduced and/or disclosed, in any form or by any means, without the prior written permission of SUN YAT-SEN UNIVERSITY.

AMS-TTCS AMSTR-SYSU-PR-024		Page	36	
		OF	64	
Title	FM TTCSB Filling and venting procedure	ISSUE	2.0	


TTCS volume determination						
Date:		Company:		Location:		Engineer:
Step No.	Action and Description	Monitoring	Value	Result	Comment	Time
32.	Close the filled SV1.5 valve, valve 3, and the N ₂ bottle valve, disconnect the filled SV1.5 from connector 3;					
33.	Weight the filled SV1.5 with an electronic balance (0.1g precision or better), as M _{nitrogen1} ;					
34.	Connect the filled SV1.5 back to the connector 3;					
35.	Open valve 3, valve 1, valve 4 and the vacuum valve; open pressure regulator to pump the filling box and TTCS loop down to 30Pa;					
36.	Close the vacuum valve, valve 1 and valve 4, switch off the pump. Open the SV1.5 valve and close SV1.5 valve, slowly open valve 1 to fill the N ₂ into the TTCS loop to prevent pressure spike to the sensors. Repeating on and off the SV1.5 valve and valve 1 in turn until pressure of the TTCS loop is up 1.5MPa, and then slowly open the SV1.5 valve and valve.	DPS reading of the TTCS loop	≤0.5Bar			

No part of this document may be reproduced and/or disclosed, in any form or by any means, without the prior written permission of SUN YAT-SEN UNIVERSITY.

AMS-TTCS AMSTR-SYSU-PR-024		Page	37	
		OF	64	
Title	FM TTCB Filling and venting procedure	ISSUE	2.0	

TTCS volume determination						
Date:		Company:		Location:		Engineer:
Step No.	Action and Description	Monitoring	Value	Result	Comment	Time
37.	Wait a period of time (0.5~1hours), take by hand the loop pressure as P2 and the average reading of the three PT1000s in the filling system as T_2 . (here T_2 is comparable to T_{room} with range of $\pm 1^\circ\text{C}$);	P2 No.1 Pt1000 No.2 Pt1000 No.3 Pt1000	$T_{room} \pm 1^\circ\text{C}$ $T_{room} \pm 1^\circ\text{C}$ $T_{room} \pm 1^\circ\text{C}$			
38.	Close valve 1, valve 3, SV1.5 valve and the TTCS valve;					
39.	Disconnect SV1.5 from the connector 3;					
40.	Weight the SV1.5 with the electronic balance again, as $M_{nitrogen2}$;					
41.	The nitrogen mass inside the loop and the filling system is: $M_{nitrogen} = M_{nitrogen1} - M_{nitrogen2}$;					
42.	The volume of the loop is determined by the ideal gas equation , where $V_{Loop} = \frac{M_{nitrogen} RT_2}{m_{nitrogen} P_2} - V_{FT}$ $m_{nitrogen} = 28\text{g/mol}$ for nitrogen, and R is the gas constant;					
43.	Determine the fill mass by $M_{C-L} = V_{Loop} FR$ (where $FR = 569.60 \text{ g/l}$).					

No part of this document may be reproduced and/or disclosed, in any form or by any means, without the prior written permission of SUN YAT-SEN UNIVERSITY.


AMS-TTCS AMSTR-SYSU-PR-024		Page	38	
		OF	64	
Title	FM TTCSB Filling and venting procedure	ISSUE	2.0	

TTCS volume determination						
Date:		Company:		Location:		Engineer:
Step No.	Action and Description	Monitoring	Value	Result	Comment	Time
44.	Calculate the filled mass for the standard vessel Set $M_{C_VS} = M_{E_VS} + M_{C_L} + M_{C_R}$; NOTE: $M_{C_R} = M_{C_R_VS} + M_{C_R_FT} = V_{VS} \times \rho_G(T, P) + V_{FT} \times \rho_G(T, P)$ Here $\rho_G(T, P)$ is determined by the chosen final temperature of the standard vessel and the final saturated pressure of the TTCS loop.					
45.	Repeat the above procedure of TTCS volume determination again for confirmation					

7.5 Fill a standard vessel with CO₂ from a Gas bottle


Fill a standard vessel with CO ₂ from a Gas bottle								
Date:		Company:		Location:		Engineer:		
Step No.	Action and Description			Monitoring	Value	Result	Comment	Time
1.	Take by hand environment conditions							
2.	Temperature: <div><input type="checkbox"/></div>	Humidity: %RH	Pressure: <div>MPa</div>					

No part of this document may be reproduced and/or disclosed, in any form or by any means, without the prior written permission of SUN YAT-SEN UNIVERSITY.

AMS-TTCS AMSTR-SYSU-PR-024		Page	39	
		OF	64	
Title	FM TTCB Filling and venting procedure	ISSUE	2.0	


Fill a standard vessel with CO ₂ from a Gas bottle						
Date:		Company:		Location:		Engineer:
Step No.	Action and Description	Monitoring	Value	Result	Comment	Time
3.	<p>Connect the SV1.5 (here anyone of the two SV1.5 can be used) to connector 3;</p> <p>Note: Longer extend tube may be used and height difference may exist between the SV1.5 and connector 3.</p> <p><u>Note: The extend tube between connectors and valves must be supported to reduce strain.</u></p> <p>(For the new connectors, wrench screw nuts with one and quarter circles. For the used connectors, wrench the screw nuts further tightly.)</p>					
4.	Connect a high purity CO ₂ gas bottle to connector 2;					
5.	Connect a dry mechanical pump to vacuum connector					
6.	Close valve 1 ,valve 4 and the gas bottle valve, open valve 3, valve 2 , pressure regulator, the vacuum valve and the SV1.5 valve;					

No part of this document may be reproduced and/or disclosed, in any form or by any means, without the prior written permission of SUN YAT-SEN UNIVERSITY.

AMS-TTCS AMSTR-SYSU-PR-024		Page	40	
		OF	64	
Title	FM TTCB Filling and venting procedure	ISSUE	2.0	


Fill a standard vessel with CO ₂ from a Gas bottle						
Date:		Company:		Location:		Engineer:
Step No.	Action and Description	Monitoring	Value	Result	Comment	Time
7.	Open valve 3 until the pressure drop to 30Pa; Close the vacuum valve, open the bottle valve slowly, until the pressure up to 1MPa; Close the bottle valve and open the vacuum valve slowly, pump the SV1.5 until the pressure drop to 30Pa; <u>Repeat such operations and flush with CO₂ twice (totally three times).</u>	Evacuate Time Vacuum gauge reading	1~2 hours ≤30Pa ≤30Pa ≤30Pa			
8.	Place the vacuumed SV1.5 to a barrel with ice water mixture, switch off the pump;					
9.	Open valve 2 and regulate outlet pressure of gas bottle valve slowly until higher than 4MPa;	Outlet pressure of gas bottle	≥ 4MPa			

No part of this document may be reproduced and/or disclosed, in any form or by any means, without the prior written permission of SUN YAT-SEN UNIVERSITY.

AMS-TTCS AMSTR-SYSU-PR-024		Page	42	
		OF	64	
Title	FM TTCB Filling and venting procedure	ISSUE	2.0	

Fill a standard vessel with CO ₂ from a Gas bottle						
Date:		Company:		Location:		Engineer:
Step No.	Action and Description	Monitoring	Value	Result	Comment	Time
15.	Weight the SV1.5 again; repeats step 12 to 14 until M_{O_VS} value meets the requirement ($=M_{C_VS} - M_{E_VS}$).	M_{O_VS}	$(M_{C_VS} - M_{E_VS})$ $\pm 1g$			
16.	Seal the filled SV1.5 valve for cleanness					


No part of this document may be reproduced and/or disclosed, in any form or by any means, without the prior written permission of SUN YAT-SEN UNIVERSITY.

AMS-TTCS AMSTR-SYSU-PR-024		Page	43	
		OF	64	
Title	FM TTCB Filling and venting procedure	ISSUE	2.0	

7.6 Calibration of the filled mass


Calibration of the filled mass								
Date:		Company:		Location:		Engineer:		
Step No.	Action and Description			Monitoring	Value	Result	Comment	Time
1.	Take by hand environment conditions							
2.	Temperature: <input type="checkbox"/>	Humidity: %RH	Pressure: MPa					
3.	Set the filling environment temperature as 22°C							
4.	Connect the filled SV1.5 (the SV1.5 _{new1}) to connector 3; Note: Longer extend tube may be used and height difference may exist between the SV1.5 and connector 3. <u>Note: The extend tube between connectors and valves must be supported to reduce strain.</u> (For the new connectors, wrench screw nuts with one and quarter circles. For the used connectors, wrench the screw nuts further tightly.)							
5.	Connect another standard vessel (VS_B) to connector 1 with the same extension filling tube for filling the TTCS loop;							
6.	Connect a dry mechanical pump to vacuum connector							

No part of this document may be reproduced and/or disclosed, in any form or by any means, without the prior written permission of SUN YAT-SEN UNIVERSITY.

AMS-TTCS AMSTR-SYSU-PR-024		Page	44	
		OF	64	
Title	FM TTCB Filling and venting procedure	ISSUE	2.0	


Calibration of the filled mass						
Date:		Company:		Location:		Engineer:
Step No.	Action and Description	Monitoring	Value	Result	Comment	Time
7.	Close valve 2 and open the vacuum valve, valve 3, pressure regulator, valve 1, valve 4 and the VS_B valve;					
8.	Pump the VS_B until the pressure down to 30Pa;	Vacuum gauge reading	≤30Pa			
9.	Close the vacuum valve and valve 4;					
10.	Open the VS_A valve slowly;					
11.	Switch on the filling box heater with and the standard vessel heater (to control the box temperature to 25°C step by step); If possible, the standard vessel heater should increase the temperature with an interval of 5~10°C. If heat power of the filling box heater is not enough, using additional heat gun to warm up the VS_A	No.1 Pt1000 No.2 Pt1000 No.3 Pt1000	≤30°C ≤30°C ≤30°C			
12.	Using the fans to cool the VS_B					

No part of this document may be reproduced and/or disclosed, in any form or by any means, without the prior written permission of SUN YAT-SEN UNIVERSITY.

AMS-TTCS AMSTR-SYSU-PR-024		Page	45	
		OF	64	
Title	FM TTCB Filling and venting procedure	ISSUE	2.0	


Calibration of the filled mass						
Date:		Company:		Location:		Engineer:
Step No.	Action and Description	Monitoring	Value	Result	Comment	Time
13.	Watch the reading of the digital pressure gauge. When the pressure and temperature is close to the set value, switch on the heating tape on the filling tubes. When the pressure is equal to 5.995MPa , close the TTCS loop valve, valve 1, the SV1.5 valve, and valve 3, respectively;	APS reading of the filling system Temperatures of the filling box and tubes	$5.995 \pm 0.1 \text{ MPa}$ 25°C			
14.	Switch off the filling box heater and the heating tape;					
15.	Unwrap the VS_A ;					
16.	Disconnect the VS_A and the VS_B respectively;					
17.	Weight the VS_A and the VS_B , as $M_{O_R_VSA}$ and $M_{Filled_VS_B}$, respectively					
18.	From $(M_{Filled_VS} - M_{O_R_VS_A})$, we have the mass of CO ₂ out of SV1.5; from $(M_{Filled_VS_B} - M_{E_VS_B})$, we have the mass of CO ₂ into VS_B ;	$(M_{Filled_VS} - M_{O_R_VS_A})$ $(M_{Filled_VS_B} - M_{E_VS_B})$				
19.	Obtain the mass loss $M_{loss} = (M_{Filled_VS} - M_{O_R_VS_A}) - (M_{Filled_VS_B} - M_{E_VS_B})$;	M_{loss}				

No part of this document may be reproduced and/or disclosed, in any form or by any means, without the prior written permission of SUN YAT-SEN UNIVERSITY.

AMS-TTCS AMSTR-SYSU-PR-024		Page	46	
		OF	64	
Title	FM TTCB Filling and venting procedure	ISSUE	2.0	


Calibration of the filled mass						
Date:		Company:		Location:		Engineer:
Step No.	Action and Description	Monitoring	Value	Result	Comment	Time
20.	Calculate the mass loss based on the filling tube volume $M_{C_R_FT}$ $=V_{FT} \times \rho_G(T)$; where $T=25^\circ C$	$M_{C_R_FT}$				
21.	Obtain fill loss range of the filling tube by comparing M_{loss} and $M_{C_R_FT}$ to determine performance of the current filling system					
22.	Switch off the pump.					
23.	Seal the filled SV1.5 valve for cleanness					

No part of this document may be reproduced and/or disclosed, in any form or by any means, without the prior written permission of SUN YAT-SEN UNIVERSITY.

AMS-TTCS AMSTR-SYSU-PR-024		Page	47	
		OF	64	
Title	FM TTCS Filling and venting procedure	ISSUE	2.0	


7.7 Fill TTCS loop with CO₂ from SV1.5

Fill TTCS loop with CO ₂ from SV1.5								
Date:		Company:		Location:		Engineer:		
Step No.	Action and Description			Monitoring	Value	Result	Comment	Time
1.	Take by hand environment conditions							
2.	Temperature: <div></div>	Humidity: %RH	Pressure: <div>MPa</div>					
3.	Set the filling environment temperature as 22°C							
4.	<div>Connect the TTCS loop to connector 1 with an extended filling tube.</div> <div><u>Note: Longer extend tubes may be used and height difference may exist between the TTCS loop and connector 1.</u></div> <div><u>The extend tube between connectors and valves must be mechanically supported to reduce strain.</u></div>							
5.	Connect a high purity CO ₂ gas bottle to connector 2;							

AMS-TTCS AMSTR-SYSU-PR-024		Page	48	
		OF	64	
Title	FM TTCS Filling and venting procedure	ISSUE	2.0	


Fill TTCS loop with CO ₂ from SV1.5						
Date:		Company:		Location:		Engineer:
Step No.	Action and Description	Monitoring	Value	Result	Comment	Time
6.	Put three PT1000 vertically by using adhesive tape in turn on the side surface of the SV1.5, then wrap the SV1.5 with heater with Pt1000 in the joint of the heater. <u>(Note: No.1 PT1000 for control, No.2 PT1000 and No.3 PT1000 for monitor.</u> <u>During filling CO₂ from the standard vessel to the TTCS loop, No.1 PT1000 should be paste on the middle of the standard vessel's side face; the other two PT1000s should be pasted on the top and bottom of the standard vessel's side face).</u>					
7.	Connect the filled SV1.5 to connector 3; <u>Note: Longer extend tubes may be used and height difference may exist between the TTCS loop and connector 1.</u> <u>The extend tube between connectors and valves must be mechanically supported to reduce strain.</u>					
8.	Use the He-mass spectrometer to perform leak test before filling. If leak rate more than $5 \times 10^{-5} \text{ mbar l/s}$ somewhere, reconnect it until the leak rate is less than $5 \times 10^{-5} \text{ mbar l/s}$	LR	$< 5 \times 10^{-5} \text{ mbar l/s}$			

No part of this document may be reproduced and/or disclosed, in any form or by any means, without the prior written permission of SUN YAT-SEN UNIVERSITY.

AMS-TTCS AMSTR-SYSU-PR-024		Page	49	
		OF	64	
Title	FM TTCS Filling and venting procedure	ISSUE	2.0	


Fill TTCS loop with CO ₂ from SV1.5								
Date:		Company:		Location:		Engineer:		
Step No.	Action and Description		Monitoring		Value	Result	Comment	Time
9.	Stop the He-mass spectrometer and replace it with a dry mechanical pump.							
10.	Follow the section of 7.5 (fill a standard vessel with CO ₂ to from a Gas bottle) to fill SV1.5 to M _{filled_SV} ;		M _{filled_SV}					
11.	Put three PT1000 vertically on the side surface of the SV1.5 by using adhesive tape. Then wrap the SV1.5 with heater with Pt1000 in the joint of the heater. Note: check them can work or not (No.1 PT1000 for control, No.2 PT1000 and No.3PT1000 for monitor. During the filling CO2 from the standard vessel to the TTCS loop No.1 PT1000 should be paste on the middle of the standard vessel’s side face; the other two PT1000s should be paste on the top and bottom of the standard vessel’s side face).		NO.1 reading	Pt1000	Ok or not			
		NO.2 reading	Pt1000	Ok or not				
		NO.3 reading	Pt1000	Ok or not				
12.	Insulate the filled vessel and connect the SV heater with the socket in the filling box.							
13.	Open the vacuum valve, valve 1, valve2, valve 3, valve 4 , the TTCS loop valve and the pressure regulator							

No part of this document may be reproduced and/or disclosed, in any form or by any means, without the prior written permission of SUN YAT-SEN UNIVERSITY.


AMS-TTCS AMSTR-SYSU-PR-024		Page	50	
		OF	64	
Title	FM TTCS Filling and venting procedure	ISSUE	2.0	

Fill TTCS loop with CO ₂ from SV1.5						
Date:		Company:		Location:		Engineer:
Step No.	Action and Description	Monitoring	Value	Result	Comment	Time
14.	Wait until pressure of the TTCS loop, the filling box and two extend tubes down to 30Pa or lower. Close valve4, the vacuum valve, and valve 1. then open the gas bottle valve slowly and valve 1 to fill the loop with high purity CO ₂ from the gas bottle, until the pressure up to 1MPa (flush the loop)	Evacuate Time Vacuum gauge reading	1~2hours ≤30Pa ≥1MPa			
15.	Close the gas bottle valve , open valve 1, valve 4 and the vacuum valve slowly;					
16.	Pump the TTCS loop, the filling box and two extend tubes until the pressure down to 30Pa or lower; Close valve4, the vacuum valve, and valve 1. then open the gas bottle valve slowly and valve 1 to fill the loop with high purity CO ₂ from the gas bottle, until the pressure up to 1MPa (flush the loop)	Evacuate Time Vacuum gauge reading	0.6 hour ≤30Pa ≥1MPa			
17.	Pump the TTCS loop, the filling box and two extend tubes until the pressure down to 30Pa or lower;	Evacuate Time Vacuum gauge reading	0.6 hour ≤30Pa			
18.	Close valve 4, the vacuum valve; switch off the pump.					

No part of this document may be reproduced and/or disclosed, in any form or by any means, without the prior written permission of SUN YAT-SEN UNIVERSITY.


AMS-TTCS AMSTR-SYSU-PR-024		Page	51	
		OF	64	
Title	FM TTCSB Filling and venting procedure	ISSUE	2.0	

Fill TTCS loop with CO ₂ from SV1.5						
Date:		Company:		Location:		Engineer:
Step No.	Action and Description	Monitoring	Value	Result	Comment	Time
19.	Put the SV1.5 with the connected tube on the electronic balance. Open the SV1.5 valve slowly, then close the SV1.5 valve, slowly open valve 1 to fill the CO ₂ into the TTCS loop to prevent pressure spike to the sensors. Repeating on and off the SV1.5 valve and valve 1 in turn until pressure of the TTCS loop is up to 3MPa, and then slowly open the SV1.5 valve and valve 1.	DPS reading of the TTCS loop	≤0.5bar			
20.	Switch on the filling box heater and the standard vessel heater (to control the box temperature to 25°C step by step); If possible, the standard vessel should be heated with a temperature interval of 5~10°C. If heat power of the filling box heater is not enough, using additional heat gun to warm up the SV1.5	NO.1 Pt1000 reading NO.2 Pt1000 reading NO.3 Pt1000 reading	30±0.5°C 30±1°C 30±1°C			
21.	Use the fan to cool the accumulator					

AMS-TTCS AMSTR-SYSU-PR-024		Page	52	
		OF	64	
Title	FM TTCB Filling and venting procedure	ISSUE	2.0	

Fill TTCS loop with CO ₂ from SV1.5						
Date:		Company:		Location:		Engineer:
Step No.	Action and Description	Monitoring	Value	Result	Comment	Time
22.	Watch the reading of the digital pressure gauge. When the pressure and temperature is close to the set-value, switch on the heating tape of the filling tubes. When the pressure is equal to 5.995MPa , close the TTCS loop valve, valve 1, the SV1.5 valve, and valve 3, respectively;	Waiting time APS reading of the TTCS loop (P _{TTCB}) APS reading of the filling system (P _{filling system})	3~4 hours 5.995±0.1MPa 5.995±0.1MPa			
23.	Switch off the filling box heater and the standard vessel heater;					
24.	Unwrap the heating tape from the SV1.5;					
25.	Disconnect the SV1.5 from the filling box, clean surface of the SV1.5					
26.	Weight the SV1.5 as (M _{O_R_VS} + M _{E_VS}), compared (M _{O_R_VS} + M _{E_VS}) with (M _{C_R_VS} + M _{E_VS})	(M _{O_R_VS} +M _{E_VS})	(M _{C_R_VS} +M _{E_VS}) ±5g			
27.	Filling finished.					
28.	After the filling is finished, the two extended filling tubes, the SV1.5 valve and the filling system must be carefully disconnected and sealed.					
29.	Carefully packing the two extended filling tubes, the SV1.5 and the filling system.					


No part of this document may be reproduced and/or disclosed, in any form or by any means, without the prior written permission of SUN YAT-SEN UNIVERSITY.

AMS-TTCS AMSTR-SYSU-PR-024		Page	53	
		OF	64	
Title	FM TTCB Filling and venting procedure	ISSUE	2.0	

7.8 Venting CO₂ from the TTCS loop


Venting CO2 from the TTCS loop								
Date:		Company:		Location:		Engineer:		
Step No.	Action and Description			Monitoring	Value	Result	Comment	Time
1.	Take by hand environment conditions							
2.	Temperature: °C	Humidity: %RH	Pressure: MPa					
3.	Switch on TTCE Terminal and go to the interface TTCE-2							
4.	Write down the PT01 and PT03 temperatures			PT01 and PT03	>22°C			
5.	Connect the TTCB valve, filter, stainless tube and extended tube							
6.	Open the TTCB valve a little to release CO ₂ gas slowly while switch on the ground accumulator heater (GAC) with 30% Monitor PT01 and PT 03, once either temperature is below 18 °C, stop venting by closing TTCB valve.			PT01 and PT03	>17°C			
7.	Use a hot air gun, or hot water bath, to heat up the exit of the stainless exhaust tube							
8.	Repeat steps 6 and 7, until the pressure is down to 1.5 bar			APS reading	1.5±0.1bar			

No part of this document may be reproduced and/or disclosed, in any form or by any means, without the prior written permission of SUN YAT-SEN UNIVERSITY.

AMS-TTCS AMSTR-SYSU-PR-024		Page	54	
		OF	64	
Title	FM TTCB Filling and venting procedure	ISSUE	2.0	

Venting CO2 from the TTCS loop						
Date:		Company:		Location:		Engineer:
Step No.	Action and Description	Monitoring	Value	Result	Comment	Time
9.	Close the TTCB valve.	APS reading	1.5±0.1bar			
10.	Switch off TTCE Terminal					

No part of this document may be reproduced and/or disclosed, in any form or by any means, without the prior written permission of SUN YAT-SEN UNIVERSITY.

AMS-TTCS AMSTR-SYSU-PR-024		Page	55	
		OF	64	
Title	FM TTCB Filling and venting procedure	ISSUE	2.0	

8. APPENDIX

8.1 Error analysis of volume determination of a vessel by weighting the gas mass inside

Assumption: no leakage of measuring system, including the container, during the period of measurement; the electronic balance employed has the best accuracy of 0.1g; and the temperature be controlled within 0.5K.

According to the ideal gas equation:


$$PV = \frac{M}{m} RT \quad (A1.1)$$

Where m is the mole mass of the gas in use (in g/mole), M is the net gas mass to be measured, and R is the gas constant, T is temperature of 22°C in thermal bath respectively. For nitrogen, m=28g/mole, and a vessel of about 1.5liters, M≈76.3g. From (A1.1), we have

$$\frac{\Delta V}{V} = \frac{\Delta P}{P} + \frac{\Delta M}{M} + \frac{\Delta T}{T} = \frac{\Delta P}{P} + 2 \frac{\Delta M}{M} + \frac{\Delta T}{T} \quad (A1.2)$$

As ΔP is limited by the pressure sensor, with the pressure sensor available with accuracy of $\pm 0.2\%$ FS, by setting P to the FS of the pressure sensor, (e.g., 10MPa), we have the lowest error of 0.44% for $\Delta P/P$. For using nitrogen as an ideal gas, $\Delta V/V$ is about 0.89 %.

Gas used	N ₂
m (g/mole)	28
M(g)	76.3
$\Delta M/M(\%)$	0.26
$\Delta T/T(\%)$	0.17
$\Delta P/P(\%)$	0.44
$\Delta V/V(\%)$	0.89

AMS-TTCS AMSTR-SYSU-PR-024		Page	56	
		OF	64	
Title	FM TTCS Filling and venting procedure	ISSUE	2.0	

8.2 Error analysis of volume determination of TTCS loop by indirectly measuring the Nitrogen mass inside the loop

Assumption: no leakage to the measuring system, including the TTCS loop and the filling system, during the filling; and the temperature and its uniformity be controlled within $\pm 2K$; the volumes of the standard vessel to fill to loop (V_{VS}) is about 1.5 liter, and the volume of the loop is about 1.5 liter ($V_{loop} \approx V_{VS}$); the accuracy of the electronic balance is 0.1g (ΔM_B); no nitrogen absorption on the inner surface of the TTCS loop that made of stainless steel.

1) Error analysis for the measured volume the filling system including the filling tubes.

Fill nitrogen with the SV1.5 to a pressure of 4.5MPa; weight the mass of the filled SV1.5 $M'_{nitrogen1}$. Connect the vessel to the filling system and release the nitrogen slowly. Weight the mass of the SV1.5 again $M'_{nitrogen2}$, the nitrogen mass filled into the filling system can then be calculated: $M_{FT} = M'_{nitrogen1} - M'_{nitrogen2}$, and $\Delta M_{nitrogen} = \Delta M_1 + \Delta M_2 \approx 2\Delta M_B$. To the volume of the filling tube of the filling system is about 0.042 liter. Even with additional tube of 5m long and 3mm in inner diameter, which is about 0.035 liter, the nitrogen mass inside filling tube is about a few percentages of that in the SV1.5 and the pressure inside is about the same as the initial pressure of SV1.5. The estimated N_2 mass is:

$$M_{FT} \approx \frac{1}{20} \frac{P_0 V_{VS} m_{nitrogen}}{RT_0};$$

Assuming $P_{FT} \approx P_0$, the error of V_{FT}


$$\begin{aligned} \frac{\Delta V_{FT}}{V_{FT}} &= \frac{\Delta P_{FT}}{P_{FT}} + 2 \frac{\Delta M_B}{M_{FT}} + \frac{\Delta T_{FT}}{T_{FT}} \\ &= \frac{0.1\% FS}{P_0} + 40 \frac{\Delta M_B RT_0}{P_0 V_{VS} m_{nitrogen}} + \frac{\Delta T_{FT}}{T_{FT}} \end{aligned}$$

is about 6.3%

2) Error analysis for the measured volume of the loop and filling tube

Similarly, connect the filled vessel to a vacuumed loop and release the nitrogen inside the filled VS1.5 slowly until equilibrium is established. Weight the mass of the SV1.5 again $M_{nitrogen2}$, the

No part of this document may be reproduced and/or disclosed, in any form or by any means, without the prior written permission of SUN YAT-SEN UNIVERSITY.

AMS-TTCS AMSTR-SYSU-PR-024		Page	57	
		OF	64	
Title	FM TTCS Filling and venting procedure	ISSUE	2.0	

nitrogen mass filled into the loop can then be calculated: $M_{loop+FT} = M_{nitrogen1} - M_{nitrogen2}$, and $\Delta M_{loop+FT} = \Delta M_1 + \Delta M_2 \approx 2\Delta M_B$. As V_{VS} is about half of the total volume, the nitrogen mass inside the loop and filling tube is about half of the initial filled mass of nitrogen in the SV1.5, and the pressure inside the loop and filling tube is about half of the initial pressure of SV1.5.

$$M_{loop+FT} = \frac{1}{2} \frac{P_0 V_{VS} m_{nitrogen}}{RT_0} \quad \text{And } P_1 \approx \frac{1}{2} P_0 ;$$

Assuming $T_0 = T_{loop}$, and ΔT_{loop} is about $\pm 2K$

The error of $V_{loop+FT}$:

$$\begin{aligned} \frac{\Delta V_{loop+FT}}{V_{loop+FT}} &= \frac{\Delta P_1}{P_1} + 2 \frac{\Delta M_B}{M_{loop+FT}} + \frac{\Delta T_{loop}}{T_{loop}} \\ &= 2 \frac{0.2\% FS}{P_0} + 4 \frac{\Delta M_B RT_0}{P_0 V_{VS} m_{nitrogen}} + \frac{\Delta T_{loop}}{T_{loop}} \end{aligned}$$

is about 2.1%.

3) Error analysis for the measured volume of the loop

The error of V_{loop} :

$$\frac{\Delta V_{loop}}{V_{loop}} = \frac{2.1\% \times 1.5 + 6.3\% \times (0.042 + 0.035)}{1.5}$$


is about 2.4%

In the assumption, no absorption of nitrogen is considered. This is achieved by performing the measurement for at least twice. Let the nitrogen absorption, if there is any, reach its saturated value during the first measurement, so for the following measurement, there should not be additional nitrogen absorption happen.

8.3 Error analysis of the total filled mass of TTCS loop

Assumption: There is no leakage for the filling system, and the TTCS loop during the period of filling and measurement; the temperature is controlled within $\pm 2.0K$ for filling procedure without thermal bath; and the volume of the loop is about 1.5 liter; the electronic balance employed has the

No part of this document may be reproduced and/or disclosed, in any form or by any means, without the prior written permission of SUN YAT-SEN UNIVERSITY.

AMS-TTCS AMSTR-SYSU-PR-024		Page	58	
		OF	64	
Title	FM TTCB Filling and venting procedure	ISSUE	2.0	

best accuracy of $\pm 0.1\text{g}$ (ΔM_B). (Based on our experiments), any mass loss is less than 1g.

According to Annex 8.2, the error of the loop volume is about 2.4%, so the calculated filled mass $m_{cal} = FrV_{loop}$ ($\approx 860\text{g}$) has also the error of $\pm 2.4\%$.

(1) The error from weighting CO_2 mass is

$$\Delta M = \Delta M_2 - \Delta M_1 = 2 \Delta M_B = \pm 0.2\text{g}.$$

(2) The error from the filling loss in the filling system, the CO_2 mass remained the filling tube of filling system plus additional tube with length of 5m (0.077L) is about 12.75g based on NIST refrigerant properties database.

The error of total filled mass of TTCS is


$$\frac{\Delta M_{\text{CO}_2, \text{loop}}}{M_{\text{CO}_2, \text{loop}}} = \frac{\Delta V_{\text{loop}}}{V_{\text{loop}}} + \frac{2M_B + M_{\text{loss}}}{V_{\text{loop}} \times \text{FR}} \approx 2.4\% + 1.2 / 1.5 / 569.6 \approx 2.6\%$$

Therefore, we have total CO_2 mass accuracy of $\pm 2.6\%$, which meets the requirement of $\pm 4\%$.

Conclusion:

Although the volume error is larger than 2% (required in Ref.1), the mass error (2.6%) is still within that required (4% in the Ref.1)

The impact of using electronic balance with accuracy of 0.1g other than 0.01g is that, the error of loop volume determination is obviously increased, which will be transferred to corresponding mass error. The impact on weighting itself is little.

AMS-TTCS AMSTR-SYSU-PR-024		Page	59	
		OF	64	
Title	FM TTCB Filling and venting procedure	ISSUE	2.0	

8.4 Calculation of the required filling mass into the SV1.5




Figure 8-1 CO₂ initial state and mass distribution between the filling system and the TTCS loop before starting filling





Figure 8-2 CO₂ final state and mass distribution between the filling system and the TTCS loop after finishing filling

It can be concluded from Figure 8-1 and Figure 8-2 that CO₂ final mass distribution would exist in the SV1.5, the filling tube of the filling system and the TTCS loop just like shown in Figure 8-3 with ignoring leak mass during filling process.

No part of this document may be reproduced and/or disclosed, in any form or by any means, without the prior written permission of SUN YAT-SEN UNIVERSITY.

AMS-TTCS AMSTR-SYSU-PR-024		Page	60	
		OF	64	
Title	FM TTCB Filling and venting procedure	ISSUE	2.0	




Figure 8-3 CO₂ mass distribution between the filling system and the TTCS loop after finishing filling

8.5 Calculation example

1) Calculation of M_{C_L}

Assumed : $V_{Loop} = 1.55L$

So

$$\underline{M_{C_L} = FR \times V_{Loop}}$$

$$\underline{= 569.6g/L \times 1.55L}$$

$$\underline{= 882.88g}$$


The above calculated CO₂ must be filled into the TTCS regardless of what temperature you choose for the filling.

2) Calculation of M_{C_R}

If we choose 25°C for the filling, so the retained mass of CO₂ in the filling system including filling box, two extended tube and the stand vessel can be calculated as below:

Known conditions: $T_{Loop}(\text{chosen}) = 22^\circ\text{C}$, $P(\text{corresponds to } T_{accu}(\text{chosen})) = 5.995\text{MPa}$,

No part of this document may be reproduced and/or disclosed, in any form or by any means, without the prior written permission of SUN YAT-SEN UNIVERSITY.

AMS-TTCS AMSTR-SYSU-PR-024		Page	61	
		OF	64	
Title	FM TTCB Filling and venting procedure	ISSUE	2.0	

$T_{vs}(\text{controlled})=30^{\circ}\text{C}$,

Once $T_{\text{Loop}}(\text{chosen})$ is fixed, the final pressure in the filling system and the TTCS loop is also fixed. If the chosen T of CO_2 is 22°C , the corresponding saturated pressure is 5.995MPa_s

And in the filling box, the SV1.5 and twos extend tubes

$\rho_G(30^{\circ}\text{C}, 5.995\text{MPa}) = 170.8\text{g/ L}$

Solution:

And if volume of the used SV1.5 V_{vs} is 1.485L , and filling tube of the filling system V_{FT} is 0.042Liter, so the CO_2 retained in the SV1.5, the filling box and two filling tubes can be calculated as:

$$\begin{aligned}
 M_{C_R} &= M_{C_R_VS} + M_{C_R_FT} \\
 &= V_{vs} \times \rho_G(30^{\circ}\text{C}, 5.995\text{MPa}) + V_{FE} \times \rho_G(30^{\circ}\text{C}, 5.995\text{MPa}) \\
 &= (1.485\text{L} + 0.042\text{L}) \times 170.8\text{g/ L} \\
 &= 260.82\text{g}
 \end{aligned}$$

According to the above calculation, the temperature chosen for filling will influence the retained mass of CO_2 M_{C_R} in the filling system, not influence the mass of CO_2 to be filled into TTCB.

3) Calculation of the total mass

By ignoring the leak mass, the CO_2 mass must filled into the used SV1.5 is

$$M_{C_L} + M_{C_R} = 882.88\text{g} + 260.82\text{g} = 1143.7\text{g}$$

And it pluses net mass of the used SV1.5 M_{E_VS} is

$$\begin{aligned}
 M_{C_VS} &= M_{E_VS} + M_{C_L} + M_{C_R} \\
 &= 2747.23\text{g} + 882.88\text{g} + 260.82\text{g} = 3890.83\text{g}
 \end{aligned}$$

Finally, shown by electronic balance, the total mass should be 3890.83g.




AMS-TTCS AMSTR-SYSU-PR-024		Page	62	
		OF	64	
Title	FM TTCB Filling and venting procedure	ISSUE	2.0	

Table 10 saturated properties of CO2 from 15°C to 29°C with interval of 1°C

Temp [°C]	Pressure[MPa]	Density (L) [kg/m ³]	Density (V) [kg/m ³]	Enthalpy (L) [kJ/kg]	Enthalpy (V) [kJ/kg]	Entropy (L) [kJ/K-kg]	Entropy (V) [kJ/K-kg]
15.00	5.081	821.8	159.6	240.1	418.0	1.136	1.754
16.00	5.204	813.0	165.4	243.1	416.6	1.146	1.746
17.00	5.330	803.9	171.5	246.2	415.0	1.156	1.738
18.00	5.458	794.4	178.0	249.4	413.4	1.167	1.730
19.00	5.589	784.5	184.9	252.6	411.6	1.177	1.721
20.00	5.722	774.2	192.3	256.0	409.7	1.188	1.712
21.00	5.857	763.3	200.2	259.5	407.6	1.199	1.703
22.00	5.995	751.8	208.8	263.0	405.3	1.211	1.693
23.00	6.136	739.5	218.1	266.8	402.8	1.223	1.682
24.00	6.279	726.3	228.3	270.7	400.0	1.236	1.670
25.00	6.425	712.0	239.6	274.9	396.8	1.249	1.658
26.00	6.574	696.2	252.4	279.3	393.2	1.263	1.644

AMS-TTCS AMSTR-SYSU-PR-024		Page	63	
		OF	64	
Title	FM TTCB Filling and venting procedure	ISSUE	2.0	

27.00	6.727	678.4	267.3	284.2	389.0	1.279	1.628
28.00	6.882	657.5	285.1	289.7	384.0	1.296	1.609
29.00	7.042	631.7	307.8	296.3	377.5	1.317	1.586

AMS-TTCS AMSTR-SYSU-PR-024		Page	64	
		OF	64	
Title	FM TTCB Filling and venting procedure	ISSUE	2.0	

===== END OF THE DOCUMENT =====