



AMS Tracker Thermal Control Subsystem
TTCB FM Vibration test procedure
Secondary.


AMSTR-NLR-PR-030
ISSUE 3.0
MAY 14 2009

Sun Yat-Sen University (SYSU)
 National Aerospace Laboratory (NLR)
 Instituto Nazionale di Fisica Nucleare (INFN)

	NAME	ORGANISATION/RESPONSIBILITY	SIGNATURE	DATE
PREPARED	J. van Es/A. Alvino	NLR/INFN		14/05/09
CHECKED	J. van Es	NLR / AMS TTCS System Eng.		14/05/09
AGREED	A. Pauw	NLR / AMS Company PA		15/05/09
APPROVED	J. van Es	NLR / AMS TTCS PM		14/05/09
AUTHORISED				

FILENAME	AMSTR-NLR-PR-30_3_0_TTCB_FM_Vibration_test_procedure.doc	ORDER-/CODENUMBER:	
LAST SAVED	2009.05.14 18:20 by jvanes	DIVISION:	
PRINTED	2009.05.14 18:23	DISTRIBUTION:	Unlimited
PAGES	34	CLASSIFICATION TITLE:	Unclassified

No part of this document may be reproduced and/or disclosed, in any form or by any means,
 without the prior written permission of NLR.



**AMS Tracker
Thermal Control
Subsystem**

TTCB FM Vibration test procedure

Page 2 of 34
Doc.Id AMSTR-NLR-PR-030
Issue 3.0
Date May 14 2009

Distribution list


Company	FOR*	Name	Comments
INFN	I	R. Battiston	
		M. Menichelli	
		C. Gargiulo	
	I	B. Alpat	
		A. Alvino	
		E. Laudi	
AMS	I	M. Capell	
		V. Koutsenko	
		R. Becker	
NLR	I	P. Dieleman	
		J.van Es	
		M. Bardet	
Jacobs Sverdrup	I	T. Martin	
		G. Clark	
AIDC	I	K.M. Sun/	
		B. Hsu	
		W. Min Hsu	
CGS	I	M. Molina	
		C. Vettore	

A = Approval
R = Review
I = Input / Information

An electronic version of this document is available on the AMS TTCS website:

<https://ams-ttcs.nlr.nl>

No part of this document may be reproduced and/or disclosed, in any form or by any means, without the prior written permission of NLR.




**AMS Tracker
Thermal Control
Subsystem**

TTCB FM Vibration test procedure

Page	3 of 34
Doc.Id	AMSTR-NLR-PR-030
Issue	3.0
Date	May 14 2009

Document change log

<u>Change Ref.</u>	<u>Section(s)</u>	<u>Issue 1.0</u>
-	All	Initial issue
<u>Change Ref.</u>	<u>Section(s)</u>	<u>Issue 2.0</u>
4.1		Modified location and name of the accelerometer
5.0		Step 3-4-5 and 10-11-12 deleted: test is performed in Teri and not in Rome
5.0		Modified test sequence for TTCBP & TTCBS
7.1		Related steps to ENEA facility deleted
7.2		Related steps to ENEA facility deleted
7.3		Related steps to ENEA facility deleted
<u>Change Ref.</u>	<u>Section(s)</u>	<u>Issue 3.0</u>
4.1		Modified location on pump and changed to a 3-axis type



AMS Tracker Thermal Control Subsystem

TTCB FM Vibration test procedure

Page	4 of 34
Doc.Id	AMSTR-NLR-PR-030
Issue	3.0
Date	May 14 2009

Contents

Document change log	3
1 Scope of the document and test objective	5
2 Hardware under test	5
3 Test Requirements and success criteria	7
4 Test facility description and measurement equipment	7
4.1 Location of accelerometers	8
5 Test Procedure in main steps	11
6 References documents	12
7 TTCB Vibration overall test procedure	13
7.1 TTCB vibration pre-test procedure sheets	14
7.2 TTCB vibration test sheets	17
7.3 TTCB vibration post-test procedure sheets	26
Appendix A: Vibration profiles and levels	28
Appendix B: Temperature fill table during vibration test	30
Appendix C: I/F plate mechanical lay-out instructions	32
Error! Objects cannot be created from editing field codes.	32
Error! Objects cannot be created from editing field codes.	33
Error! Objects cannot be created from editing field codes.	33
END OF DOCUMENT	34

(34 pages in total)

No part of this document may be reproduced and/or disclosed, in any form or by any means, without the prior written permission of NLR.

AMSTR-NLR-PR-30_3_0_TTCB_FM_Vibration_test_procedure.doc · Saved: 2009.05.14 08:23, Printed: 2009.05.14 18:23

1 Scope of the document and test objective

This document contains the vibration test procedure for the TTCB-P FM and the TTCB-S FM. The objective of the test is to demonstrate the TTCB's can withstand Minimum Workmanship Level Vibrations. Before and after the test functional checks are performed to compare the system health prior and after tests.

2 Hardware under test

The hardware subjected to the vibration test are the TTCB-P FM , TTCB-S FM. Both models are flight hardware. A TTCB consists of completely integrated unit with the following components: 1 pump electronics box connected by an electrical cable to 2 pumps, accumulator, HX, 2 x APS, 2 x DPS, several heaters, Pt1000's and Dallas DS18s20 temperature sensors, and integrated TTCB start-up radiators.

The items are shown in Figure 2-1 to Figure 2-3.





Figure 2-1: TTCB-Primary Box (3D-Model)



**AMS Tracker
Thermal Control
Subsystem**

TTCB FM Vibration test procedure

Page 6 of 34
Doc.Id AMSTR-NLR-PR-030
Issue 3.0
Date May 14 2009




Figure 2-2: Picture of TTCB-Primary FM





Figure 2-3: Picture of TTCB-Secondary FM

No part of this document may be reproduced and/or disclosed, in any form or by any means, without the prior written permission of NLR.

AMSTR-NLR-PR-30_3_0_TTCB_FM_Vibration_test_procedure.doc - Saved: 2009.05.14 06:23, Printed: 2009.05.14 18:23



**AMS Tracker
Thermal Control
Subsystem**

TTCB FM Vibration test procedure

Page	7 of 34
Doc.Id	AMSTR-NLR-PR-030
Issue	3.0
Date	May 14 2009

3 Test Requirements and success criteria

The test is successful when the following requirements are fulfilled.

- No visual damage of the test article is found
- No significant discrepancies between pre- and post sine sweep curve response
- All mechanics frequencies are above 50Hz
- Functional check before and after show no discrepancies

4 Test facility description and measurement equipment

The test is performed at in Terni.

The following equipment will be used:

- Vibration test facility
- Digital camera for documentation of visual inspection
- Accelerometers to monitor and control the vibration
- Additional 3-axis accelerometer to monitor the pump vibrations




Figure 4-1: Vibration table @ SERMS

4.1 Location of accelerometers

The accelerometer to control the table will always be located on the interface plate with the vibration table. The position will be changed according to the test axis to be performed.




Figure 4-2: Location of the control sensor on the I/F plate (first axis)





Figure 4-3: Location of the control sensor on the I/F plate (second axis)



AMS Tracker Thermal Control Subsystem

TTCB FM Vibration test procedure

Page 9 of 34
Doc.Id AMSTR-NLR-PR-030
Issue 3.0
Date May 14 2009




Figure 4-4: Location of the control sensor on the I/F plate (third axis)

Two other sensors will be applied to measure the response in the orthogonal directions. As the base plate is the most representative part the locations proposed are as close to the base plate as possible.





Figure 4-5: Location of the response accelerometers 1 on the TTCB



**AMS Tracker
Thermal Control
Subsystem**

TTCB FM Vibration test procedure

Page	13 of 34
Doc.Id	AMSTR-NLR-PR-030
Issue	3.0
Date	May 14 2009

7 TTCB Vibration overall test procedure

The TTCB vibration test procedure sheets consist of 3 parts.

1. TTCB vibration pre-test vibration sheets
2. TTCB vibration vibration sheets
3. TTCB vibration post-test vibration sheets

No part of this document may be reproduced and/or disclosed, in any form or by any means, without the prior written permission of NLR.




AMS Tracker Thermal Control Subsystem

TTCB FM Vibration test procedure

Page 14 of 34
Doc.Id. AMSTR-NLR-PR-030
Issue 3.0
Date May 14 2009

7.1 TTCB vibration pre-test procedure sheets


TTCB Box pre-test vibration sheets				company:	date: 27/05/2009
Step	Action	Monitoring	engineer: NLP	location: CENOS	Comment: ✓
1.	Record model type	P/S	✓		
2.	Perform filling of the vibration test loop according to AMSTR-SYSU-PR-024 FM TTCB Filling and venting procedure				
3.	Copy the measured volume of the TTCB (total volume- volume external loop parts)	(Litre)	1.241 L.		
4.	Copy the filling rate here	(g/litre)	559.2	max with checked by no molar diagram	
5.	Define maximum allowed temperature during vibration test	(°C)	62°C	Copy to Appendix B table	
6.	Perform functional test according to AMSTR-NLR-PR-028			See separate procedure	
7.					
8.	Close the valves connecting the loop				
	Monitor Test Environmental Temperature during testing	(°C)		Automatic or table app B.	




AMS Tracker
Thermal Control
Subsystem

TTCB FM Vibration test procedure

Page 15 of 34
Doc. Id. AMSTR-NLR-PR-030
Issue 3.0
Date May 14 2009

Step	Action	Monitoring	Value	Result	Comment
9. Install accelerometers					
10.	Install the accelerometer to the Vibration I/F plate (figure 4.2)	Type/location	/	/	
11.	Install the accelerometer 1 to the TTCB sides (see section 4.1)	Type/location	/	/	
12.	Install the accelerometer 2 to the TTCB sides (see section 4.1)	Type/location	/	/	
13.	Install accelerometer close to the pumps (see section 4.1)	Type/location	/	/	
14.	Install the TTCB on the vibration table in first direction			Z-Axis	
 Fasten flight bolts according to ATS of TTCB and fill forms Fasten non-flight bolts fill forms					
15.	Perform visual inspection prior to test			/	
16.	Visual inspection, unaided eye, look at outer surface for - scratches - dents - cleanliness	scratches Dents Particles/grease		/	performed by MS CLEAN 2009



AMS Tracker
Thermal Control
Subsystem

TTCB FM Vibration test procedure

Page 16 of 34
Doc.Id. AMSTR-NLR-PR-030
Issue 3.0
Date May 14 2009

Step	Action	Monitoring	Value	Result	Comment	Date:
17.	Look inside box for -Loose particles due to shaving -Loose cables/harnesses -Loose bolts/nuts -Loose shaving protection of rivnuts			✓ ✓ ✓ ✓		
18.	Attachment of glued components	PT1000 heaters DS18s20		✓ ✓ ✓		
19.	Cable harness	Chafing/mounting		✓		
20.	Take pictures of TTCB from all sides			✓		
21.	End of sheet					



AMS Tracker
Thermal Control
Subsystem

TTCB FM Vibration test procedure

Page 17 of 34
 Doc.Id. AMSTR-NLR-PR-030
 Issue 3.0
 Date May 14 2009

7.2 TTCB vibration test sheets

TTCB Vibration test sheets				company:	date: 23 - May - 2009
Step	Action	Monitoring	Value	Result	Comment
1.	Record model type	P/S	S		
2.	Scanning test to check loose parts and characterise			✓	Loose Check
3.	Perform one PRE sine sweep from 5 to 1000 Hz 0,2 G – scan rate 1 oct/min	Check loose parts		✓	If any loose parts are detected stop test
4.	If loose parts are detected improve attachments			✓	
5.	Check that the frequencies of the mechanics are well above 50Hz Document “response” curves			✓	
6.	Repeat step 2-5 until no loose parts detected			✓	
7.	Document the last characterisation “response curve”	Write down file name	V		The losses will be at first off
8.	Perform Random Vibration test first axis according to spectrum in Appendix A.			✓	
9.	Perform one POST sine sweep from 5 to 1000 Hz 0,2 G – scan rate 1 oct/min			✓	



AMS Tracker Thermal Control Subsystem

TTCB FM Vibration test procedure

Page 18 of 34
Doc.Id. AMSTR-NLR-PR-030
Issue 3.0
Date May 14 2009

TTCB Vibration test sheets		company:	date:
Step	Action	engineer:	location:
10.	Check that the frequencies of the mechanics are well above 50Hz Document "response" curves	Monitoring	✓
11.	Document the last characterisation "response curve"	Value	✓
12.	Perform visual inspection after test	Result	Comment
13.	Visual inspection, unaided eye, look at outer surface for - scratches - dents - cleanliness	file name	✓
14.	Look inside box for -Loose particles due to shaving -Loose cables/harnesses -Loose bolts/nuts -Loose shaving protection of rivnuts	scratches Dents Particles/grease	✓
15.	Attachment of glued components	PT1000 heaters DS18s20	
16.	Cable harness	Chafing/mounting	✓
17.	Take pictures of TTCB from all sides		✓




AMS Tracker
Thermal Control
Subsystem

TTCB FM Vibration test procedure

Page 19 of 34
 Doc.Id. AMSTR-NLR-PR-030
 Issue 3.0
 Date May 14 2009

Step	Action	Monitoring	Value	Result	Comment	date:
18.	End of first axis vibration					
19.	Second axis Vibration test					
20.	Install the TTCB on the vibration table in second direction					
21.	Install accelerometers					
22.	Install the accelerometer to the Vibration I/F plate (figure 4.3)	Type/location			Indicate location/orientation change	
23.	Perform visual inspection prior to test					
24.	Visual inspection, unaided eye, look at outer surface for	scratches				
	- scratches	Dents				
	- dents	Particles/grease				
	- cleanliness					




AMS Tracker
Thermal Control
Subsystem

TTCB FM Vibration test procedure

Page 20 of 34
 Doc. Id. AMSTR-NLR-PR-030
 Issue 3.0
 Date May 14 2009

TTCB Vibration test sheets					
Step	Action	Monitoring	Value	Result	Comment
25.	Look inside box for -Loose particles due to shaving - Loose cables/harnesses - Loose bolts/nuts -Loose shaving protection of rivnuts				
26.	Attachment of glued components	PT1000 heaters DS18s20			
27.	Cable harness	Chafing/mounting			
28.	Take pictures of TTCB from all sides			✓	
29.	Perform one PRE sine sweep from 5 to 1000 Hz 0.2 G – scan rate 1 oct/min	Check loose parts		✓	If any loose parts are detected stop test
30.	Check that the frequencies of the mechanics are well above 50Hz Document “response” curves			✓	
31.	Document the last characterisation “response curve”	file name			
32.	Perform Random Vibration test second axis according to spectrum in Appendix A.			✓	



AMS Tracker
Thermal Control
Subsystem

TTCB FM Vibration test procedure

Page 21 of 34
Doc. Id. AMSTR-NLR-PR-030
Issue 3.0
Date May 14 2009

Step	Action	Monitoring	Value	Result	Comment	Date:
		engineer:	company:	engineer:	location:	
33.	Perform one POST sine sweep from 5 to 1000 Hz 0,2 G - scan rate 1 oct/min					✓
34.	Check that the frequencies of the mechanics are well above 50Hz Document "response" curves					
35.	Document the last characterisation "response curve"				file name	
36.	Perform visual inspection after test					
37.	Visual inspection, unaided eye, look at outer surface for - scratches - dents - cleanliness	scratches Dents Particles/grease			✓ ✓ ✓	
38.	Look inside box for -Loose particles due to shaving -Loose cables/harnesses - Loose bolts/nuts - Loose shaving protection of rivnuts					✓
39.	Attachment of glued components	PT1000				✓