



---

## AMS Tracker Thermal Control Subsystem TTCS Condenser High Pressure Test Report

**AMSTR-NLR-TR-007**  
**ISSUE 1.0**  
**DECEMBER 2007**

---

Sun Yat-Sen University (SYSU)  
National Aerospace Laboratory (NLR)  
Istituto Nazionale di Fisica Nucleare (INFN)

	NAME	ORGANISATION/RESPONSIBILITY	SIGNATURE	DATE
PREPARED	A. Pauw	NLR		
CHECKED	J. van Es	NLR / AMS SE		
AGREED	L. Timmermans	NLR / AMS PA		
APPROVED	J. van Es	NLR / AMS PM		
AUTHORISED	P. Dieleman	NLR Space Department		

FILENAME	AMSTR-NLR-PR-007_TTCS_High_Press_Sample_Test_procedure_Iss01.doc	ORDER-/CODENUMBER:	2494047
LAST SAVED	2007.12.21 14:40 by J. van Es	DIVISION:	AS&A
PRINTED	2007.12.21 19:11	DISTRIBUTION:	Unlimited
PAGES	18	CLASSIFICATION TITLE:	Unclassified

*No part of this document may be reproduced and/or disclosed, in any form or by any means,  
without the prior written permission of NLR.*



# AMS Tracker Thermal Control Subsystem

TTCS Condenser High Pressure Test

Page 2 of 18  
Doc.Id AMSTR-NLR-TR-007  
Issue 1.0  
Date December 2007

## Distribution list

<i>Company</i>	<i>FOR*</i>	<i>Name</i>	<i>Comments</i>
INFN	I	R. Battiston	
		M. Menichelli	
		C. Gargiulo	
		B. Alpat	
		A. Alvino	
		E. Laudi	
AMS	I	M. Capell	
		V. Koutsenko	
		R. Becker	
NLR	I	P. Dieleman	
		J. van Es	
		M. Bardet	
Jacobs Sverdrup	I	T. Martin	
		G. Clark	
AIDC	I	B. Hong	
		B. Hsu	
		W. Min Hsu	
CGS	I	M. Molina	
		C. Vettore	

A = Approval  
R = Review  
I = Input / Information

An electronic version of this document is available on the AMS TTCS website:

<https://ams-ttcs.nlr.nl>

No part of this document may be reproduced and/or disclosed, in any form or by any means, without the prior written permission of NLR.



**AMS Tracker  
Thermal Control  
Subsystem**

TTCS Condenser High Pressure Test

Page 3 of 18  
Doc.Id AMSTR-NLR-TR-007  
Issue 1.0  
Date December 2007

**Document change log**

<u>Change Ref.</u>	<u>Section(s)</u>	<u>Issue 1.0</u>
-	All	Initial issue



# AMS Tracker Thermal Control Subsystem

TTCS Condenser High Pressure Test

Page	4 of 18
Doc.Id	AMSTR-NLR-TR-007
Issue	1.0
Date	December 2007

## Summary

For the AMS experiment onboard the International Space Station a thermal control system, known as the Tracker Thermal Control System (TTCS) is being developed. The TTCS basically consists of a mechanically pumped two-phase loop, where heat is collected at two evaporators and rejected at two radiators. The loop contains carbon dioxide. Critical parts of the loop are protected against freezing, using thermostats and heaters. However, during (accidental) total power down of the experiment, some parts may freeze.

This document describes the proof (460 MPa/4,600 bar) and high pressure (1,000 MPa/10,000 bar) test conducted on test samples of the TTCS Inconel 718 condenser tube.



# AMS Tracker Thermal Control Subsystem

TTCS Condenser High Pressure Test

Page 5 of 18  
Doc.Id AMSTR-NLR-TR-007  
Issue 1.0  
Date December 2007

## Contents

Document change log	3
Summary	4
1 Scope of the document	6
2 References documents	6
3 Test Objective and background	7
3.1 Objective	7
3.2 Background	7
3.2.1 Maximum Design Pressure	7
4 Test Sample Description	8
5 Proof and high pressure test execution	9
6 Result	11
END OF DOCUMENT	18

(18 pages in total)



# AMS Tracker Thermal Control Subsystem

TTCS Condenser High Pressure Test

Page 6 of 18  
Doc.Id AMSTR-NLR-TR-007  
Issue 1.0  
Date December 2007

## 1 Scope of the document

This document describes the proof (460 MPa/4,600 bar) and high pressure (1,000 MPa/10,000 bar) test carried out on test samples of the TTCS Inconel condenser tube.

## 2 References documents

	Title	Number	Date
RD-1	AMS02 TTCS Condenser Freezing Test Plan and Procedure	AMSTR-NLR-TN-022 Iss 2.1	26-08-2005
RD-2	TTCS Condenser Freezing Test Report	AMSTR-NLR-TN-039 Iss 3.0	23-08-2005
RD-3	TTCS Condenser Design	AMSTR-NLR-TN-045 Iss 1.1	Febr-2006
RD-4	Condenser Manifold Brazing Procedure	AMSTR-NLR-PR-004 Iss 1.0	May 2007
RD-5	High Press Sample Test procedure	AMSTR-NLR-PR-007 Iss 1.0	May 2007



# AMS Tracker Thermal Control Subsystem

TTCS Condenser High Pressure Test

Page	7 of 18
Doc.Id	AMSTR-NLR-TR-007
Issue	1.0
Date	December 2007

## 3 Test Objective and background

### 3.1 Objective

The objective of the test is to verify by test the condenser tubes can withstand the MDP pressure of the condenser section with the safety factors for yield and burst as documented in RD-2.

### 3.2 Background

#### 3.2.1 Maximum Design Pressure


In the condenser the extreme MDP of 3009 bar can occur by uncontrolled thawing of the CO<sub>2</sub> in the condenser tubes after freezing.

This event however, may occur only in the unlikely event the AMS02 experiment will have a total power down. Uncontrolled thawing in the condenser lines in the radiator can occur in between frozen parts. The thawing will start at a temperature of -55°C and can continue upto a maximum, calculated by thermal modelling, of -5°C. This will induce a maximum pressure of 300,9 MPa (3009 bar, see also RD-1 and RD-2).

## 4 Test Sample Description

The test sample consists of: 3 identical high pressure bended test samples (Inconel 718). The bends are representative to the FM condenser design

The 3 test samples are made from Inconel 718 and are bended with the same radii as the condenser design. Six representative bends are present in all three test samples.



**Figure 4-1: TTCS Condenser high pressure test samples (Inconel 718)**





## AMS Tracker Thermal Control Subsystem

TTCS Condenser High Pressure Test

Page	9 of 18
Doc.Id	AMSTR-NLR-TR-007
Issue	1.0
Date	December 2007

### 5 Proof and high pressure test execution

The pressure tests are performed by using high pressure equipment of Resato International BV, a manufacturer in the field of high pressure technology, developing high pressure components and systems. The test samples are connected to a high pressure unit (figure 5-1) which is capable to pressurize test units up to 10,000 bar, using IPA as working fluid. The samples (figure 5-2) are pressure tested according to the procedure RD-5. Pressure control is done by manual control of valves and the pressure is electronically logged by a pressure transducer and pc (figure 5-3).

The pressure test has been conducted twice, the first attempt (May 30, 2007) however, was unsuccessful due to leakage of the high pressure fitting connection which was brazed to the tube. Due to the temperature cycle required for solution heat treatment, a non optimal vacuum brazed connection was made. The brazed connections started to leak at a test pressure around 4000 bars, so the test pressure test was aborted. The problem was solved by modifying the high pressure fittings.

The modified fitting on the tube is used for pulling the butt-end of the Inconel tube to the counter part of the high pressure fitting. Now the high pressure seal consists of the tube butt-end tightly pulled on to a flat surface and the brazed connection is no longer part of the pressurized system.

The second pressure test (July-12-2007) was successful, however some minor problems occurred. Internal leakage of the high pressure unit caused the necessity of re-testing samples 2 and 3. Due to the internal leakage the 5 minutes at 10,000 bar requirement was not met and we were obliged to re-test the samples.



# AMS Tracker Thermal Control Subsystem

TTCS Condenser High Pressure Test

Page 10 of 18  
Doc.Id AMSTR-NLR-TR-007  
Issue 1.0  
Date December 2007



Figure 5-1: High pressure unit



Figure 5-2: Test sample in one half of protective enclosure.

No part of this document may be reproduced and/or disclosed, in any form or by any means, without the prior written permission of NLR.



# AMS Tracker Thermal Control Subsystem

TTCS Condenser High Pressure Test

Page 11 of 18  
Doc.Id AMSTR-NLR-TR-007  
Issue 1.0  
Date December 2007




Figure 5-3 control panel of high pressure unit during test.

## 6 Result

All 3 samples passed the high pressure test. No burst, leakage or deterioration of the test samples were found after visual inspection.



## AMS Tracker Thermal Control Subsystem

TTCS Condenser High Pressure Test Report

Page 12 of 18  
Doc.Id. AMSTR-NLR-TR-007  
Issue 1.0  
Date December 2007

### Appendix A: Logsheets



## AMS Tracker Thermal Control Subsystem

Condenser High Pressure Test Procedure

Page 15 of 19  
Doc.Id. AMSTR-NLR-PR-007  
Issue 1.1  
Date 12/7/07 May 2007

### 5.4 TTCS High pressure test procedure sheet

Test sample indication: <u>1</u>		Test engineer: <u>A.P.</u>	Test Date: <u>12/7/2007</u>
Step	Action to be taken	Result	
1.	Type Condenser high pressure test sample numbers		
2.	Connect sample number n (n=1,2 or 3) to the pressure system	<u>1</u>	
3.	Install safety measures (protective metal enclosure, test inside bunker)	<u>✓</u>	
4.	Increase pressure upto 460 MPa (4,600 bar)	<u>5400 bar</u>	
5.	After a dwell time of 5 minutes (TBC) note pressure	<u>5490</u>	
6.	Increase pressure upto 1,000 MPa (10,000 bar)	<u>✓</u>	
7.	After a dwell time of 5 minutes note pressure	<u>10100 bar / 9500 bar</u>	
8.	Release pressure with a steep DP/dt gradient	<u>✓</u>	
9.	Perform steps 1-8 for sample 2 and 3		
10.	General remarks and notes	<u>@ high pressure zone</u> <u>leakage at fittings, so difficult</u> <u>to maintain pressure</u>	

No part of this document may be reproduced and/or disclosed, in any form or by any means, without the prior written permission of NLR.





## AMS Tracker Thermal Control Subsystem

TTCS Condenser High Pressure Test Report

Page 13 of 18  
Doc.Id. AMSTR-NLR-TR-007  
Issue 1.0  
Date December 2007



## AMS Tracker Thermal Control Subsystem

Condenser High Pressure Test Procedure

Page 15 of 19  
Doc.Id. AMSTR-NLR-PR-007  
Issue 1.1  
Date 12/12/07 May 2007

### 5.4 TTCS High pressure test procedure sheet

Test sample indication: 2		Test engineer: A. V	Test Date: 12/02/2007
Step	Action to be taken	Result	
1.	Type Condenser high pressure test sample numbers		
2.	Connect sample number n (n=1,2 or 3) to the pressure system	2	
3.	Install safety measures (protective metal enclosure, test inside bunker)	✓	
4.	Increase pressure upto 460 MPa (4,600 bar)	4,600	
5.	After a dwell time of 5 minutes (TBC) note pressure	4,700	
6.	Increase pressure upto 1,000 MPa (10,000 bar)	✓	
7.	After a dwell time of 5 minutes note pressure	10,000*	
8.	Release pressure with a steep DP/dt gradient	✓	
9.	Perform steps 1-8 for sample 2 and 3		
10.	General remarks and notes		

\* after ca 3 min failure of pressure system

No part of this document may be reproduced and/or disclosed, in any form or by any means, without the prior written permission of NLR.



## AMS Tracker Thermal Control Subsystem

TTCS Condenser High Pressure Test Report

Page 14 of 18  
Doc.Id. AMSTR-NLR-TR-007  
Issue 1.0  
Date December 2007



## AMS Tracker Thermal Control Subsystem

Condenser High Pressure Test Procedure

Page 15 of 19  
Doc.Id. AMSTR-NLR-PR-007  
Issue 1.1  
Date May 2007

### 5.4 TTCS High pressure test procedure sheet

Test sample indication: 2 RE-RLN		Test engineer: A.P	Test Date: 12/02/2007
Step	Action to be taken	Result	
1.	Type Condenser high pressure test sample numbers		
2.	Connect sample number n (n=1,2 or 3) to the pressure system	3	
3.	Install safety measures (protective metal enclosure, test inside bunker)	✓	
4.	Increase pressure upto 460 MPa (4,600 bar)	4640 bar	
5.	After a dwell time of 5 minutes (TBC) note pressure	4760 bar	
6.	Increase pressure upto 1,000 MPa (10,000 bar)	10340 bar	
7.	After a dwell time of 5 minutes note pressure	10000	
8.	Release pressure with a steep DP/dt gradient	✓	
9.	Perform steps 1-8 for sample 2 and 3		
10.	General remarks and notes	RE-RLN	

No part of this document may be reproduced and/or disclosed, in any form or by any means, without the prior written permission of NLR.



## AMS Tracker Thermal Control Subsystem

TTCS Condenser High Pressure Test Report

Page 15 of 18  
Doc.Id. AMSTR-NLR-TR-007  
Issue 1.0  
Date December 2007



## AMS Tracker Thermal Control Subsystem

Condenser High Pressure Test Procedure

Page 15 of 19  
Doc.Id. AMSTR-NLR-PR-007  
Issue 1.1  
Date May 2007

### 5.4 TTCS High pressure test procedure sheet

Test sample indication: 3		Test engineer: Aswin Pauw		Test Date: 12/7/2002	
Step	Action to be taken	Result			
1.	Type Condenser high pressure test sample numbers	3	RE-RUN		
2.	Connect sample number n (n=1,2 or 3) to the pressure system	✓	✓		
3.	Install safety measures (protective metal enclosure, test inside bunker)	✓	✓		
4. ✕	Increase pressure upto 460 MPa (4,600 bar)	4700	4700		
5.	After a dwell time of 5 minutes (TBC) note pressure	4740	4890		
6.	Increase pressure upto 1,000 MPa (10,000 bar)	10030	✓ 10000		
7.	After a dwell time of 5 minutes note pressure	⊗	10270		
8.	Release pressure with a steep DP/dt gradient	✓	✓		
9.	Perform steps 1-8 for sample 2 and 3				
10.	General remarks and notes	RE-RUN			

\* increase : steps + 100 bar / 5 sec  
⊗ leakage pressure system after 3 min





# AMS Tracker Thermal Control Subsystem

TTCS Condenser High Pressure

Page 16 of 18  
Doc.Id AMSTR-NLR-TR-007  
Issue 1.0  
Date December 2007

## Pressure charts.







# AMS Tracker Thermal Control Subsystem

TTCS Condenser High Pressure

Page

Doc.Id

Issue



Date

17 of 18

AMSTR-NLR-TR-007

1.0

December 2007





# AMS Tracker Thermal Control Subsystem

TTCS Condenser High Pressure

Page

18 of 18

Doc.Id


AMSTR-NLR-TR-007

Issue

1.0

Date

December 2007



END OF DOCUMENT