

AMS-TTCS	Page	27
AMSTR-SYSU-PR-024	OF	64
FM TTCB Filling and venting procedure	ISSUE	2.0
SYNTHETIC UNIVERSITY		

7. FILLING PROCEDURE DATA SHEET

7.1 Preparation procedures

Preparation procedures						
Step No.	Action and Description		Location:	Value	Result	Comment
1.	Take by hand environment conditions		CEPRN			
2.	Temperature: <input type="checkbox"/>	Humidity: %RH	Pressure: MPa			
3.	Calibrate the volume of the filling box;(Vbox= 0.021 liter)					
4.	Calculate the volume of the two connecting tubes and valves;					
5.	Select filling environmental temperature, e.g., 22°C;		T _{room}			
6.	Wrap a heating tape around the filling tube outside the box;					✓
7.	Prepare an electronic balance with full scale more than 4200g and accuracy of 0.1g;					✓
8.	Prepare a bottle of pure N ₂ gas for volume calibration					
9.	Prepare high purity (99.99%)CO ₂ bottle for filling;					✓
10.	Prepare a barrel with ice water mixture for cooling the vessel;					✓
11.	Prepare a fan for cooling TTCS accumulator during filling;					✓
12.	Connect a dry mechanical pump to the vacuum connector;					✓

AMSTR-SYSU-PR-024		Page OF	28 64
Title	FM TTCB Filling and venting procedure	ISSUE	2.0

7.2 Filling system leak rate examination — Done on 20/10/2019.

Filling system leak rate examination

Date: 20/10/2019		Company: SYSU		Location: CTRV - CMSEN		Engineer: SXH/22	
Step No.	Action and Description	Monitoring	Value	Result	Comment	Time	
1.	Take by hand environment conditions						
2.	Temperature: <input type="checkbox"/> Humidity: %RH	Pressure:	MPa				
3.	Connect the two SV 1.5s to connector 1 and connector 3, respectively. Close valve 2.						
4.	Measure the background leak rate of the "He mass spectrometer"	<math><5 \times 10^{-10} \text{ mbar l/s.}</math>	$\approx 1.0 \times 10^{-10} \text{ mbar l/s.}$	1.2 ± 0.2			
5.	Connect the He mass spectrometer to the vacuum connector						
6.	Open valve1, valve 3 and valve 4 Vacuum the filling system						
7.	Measure the leak rate of the filling system without helium gas.	<math><5 \times 10^{-8} \text{ mbar l/s.}</math>	3.4×10^{-9}	15 ± 15			
8.	Using negative method, blowing helium gas, to measure the leak rate of these connectors, valves. Leak rate for each connector should be below 5×10^{-5} mbar l/s.	<math><5 \times 10^{-5} \text{ mbar l/s.}</math>	5.7×10^{-9}	values on filling system: $L_{Rmax} = 5.7 \times 10^{-9}$			
9.	Disconnect the He mass spectrometer and measure the background leak rate of the equipment.	<math><5 \times 10^{-10} \text{ mbar l/s.}</math>	$SV1.5(\cos) Value L_R = 5.7 \times 10^{-8}$	$SV1.5(\cos) Value L_R = 6.0 \times 10^{-9}$	leak test again. $L_R = 1.2 \times 10^{-8}$ mbar l/s.		

replace the value on $SV1.5(\cos)$.

No part of this document may be reproduced and/or disclosed, in any form or by any means, without the prior written permission of SUN YAT-SEN UNIVERSITY.

AMS-TTCS	Page	29
AMSTR-SYSU-PR-024	OF	64
FM TTCB Filling and venting procedure	ISSUE	2.0



Filling system leak rate examination					
Step No.	Action and Description	Monitoring	Value	Result	Comment / Time
10.	Flash the filling system				
11.	Connect the N ₂ bottle to the connector 2				
12.	Open the bottle valve and valve 2		40±1bar	10 bar	10:53
13.	Pressurize the filling system slowly				
14.	Close valve 2 and open vacuum valve		2±0.5bar		
15.	Release the N ₂ from the system slowly				
16.	Open the bottle valve and valve 2		40±1bar	10 bar	10:57
17.	Pressurize the filling system slowly		2±0.5bar		11:04
	Close valve 2 and open vacuum valve				
	Release the N ₂ from the system slowly				

pressure regulator max is 10bar

AMS-TTCS		Page	30
AMSTR-SYSU-PR-024		OF	64
Title		ISSUE	2.0
			

7.3 Determination of filling system volume

Done with TTCS Volume determination

Filling system volume determination

Step No.	Date:	Action and Description	Company:	Location:	Monitoring	Value	Result	Comment	Engineer:	Time
1.	Take by hand environment conditions									
2.	Temperature: <input type="checkbox"/> 22 °C.	Humidity: <input type="checkbox"/> %RH	Pressure: MPa							
3.	Affix any two of the three PT1000s on the side surface of the SV1.5.									
	and leave the rest one to monitor environmental temperature.									
4.	Connect the SV1.5 (any of the three stand vessels can be used) to connector 3;									
	Note: Longer extend tube may be used and height difference may exist between the SV1.5 and connector 3.									
	<u>Note: The extend tube between connectors and valves must be supported to reduce strain.</u>									
	(For the new connectors, wrench screw nuts with one and quarter circles. For the used connectors, wrench the screw nuts further tightly.)									
5.	Connect the N ₂ bottle to connector 2;									
6.	Connect a dry mechanical pump to vacuum connector									

AMS-TTCS AMSTR-SYSU-PR-024	Page OF	31 64	ISSUE	2.0	
--------------------------------------	------------	----------	-------	-----	---

Filling system volume determination

Step No.	Date:	Company:	Location:	Engineer:
Step No.	Action and Description	Monitoring	Value	Result
7.	seal the extend filling tube with the other end connected to connector 1 of the filling box;	S	Done with TTCS loop Volume determination.	Comment
	Note: the need of redetermination of the filling system is due to the use of additional extend filling tubes, therefore, the extend filling must be connected to the filling box with the other end sealed. On the other hand, we could skip this procedure if we can rely on the calculation of the volume of the additional extend filling tubes. Then : $V_{FT} = V_{\text{filling_system}} + V_{C,\text{extend tubes}}$			Time
8.	Close valve 1, valve 4 and the N ₂ bottle valve, open valve 2, valve 3, the SV1.5 valve, pressure regulator and the vacuum valve slowly, pump the SV1.5 and the filling box down to 30Pa;	Evacuate Time	1~2 hours	
9.	Close the vacuum valve open the valve of the N ₂ bottle	Vacuum gauge reading	≤30Pa	

AMS-TTCS	Page	32
AMSTR-SYSU-PR-024	OF	64
Title	FM TTCB Filling and venting procedure	ISSUE
		2.0



Filling system volume determination

Step No.	Date:	Company:	Location:		Engineer:	
	Action and Description	Monitoring	Value	Result	Comment	Time
10.	Fill the SV1.5 with N ₂ up to 4.5MPa, then close valve 2; wait until pressure and temperature of the standard vessel is stable. Take by hand the pressure as P1'. Take by hand the average reading of the three PT1000s in the filling system as T ₁ '. (here T ₁ ' is comparable to T _{room} with range of ±1°C);	Evacuate Time P1'	0.5~1hours			
	No.1 Pt1000 No.2 Pt1000 No.3 Pt1000	T _{room} ±1°C T _{room} ±1°C T _{room} ±1°C				
11.	Close the filled SV1.5 valve, valve 3, and the N ₂ bottle valve, disconnect the filled SV1.5 from connector 3;					
12.	Weight the filled SV1.5 with an electronic balance (0.1g precision or better), as M' nitrogen;					
13.	Connect the filled SV1.5 back to the connector 3;					
14.	Open valve 3, valve 1, valve 4 and the vacuum valve; open pressure regulator to pump the filling box down to 30Pa;					
15.	Close the vacuum valve, valve 1 and valve 4, switch off the pump. Open the SV1.5 valve and close SV1.5 valve, slowly open valve 1 to fill the N ₂ into the filling box and tubes.	DPS reading of the TTCS loop	≤0.5Bar			

AMS-TTCS AMSTR-SYSU-PR-024	Page 33	OF 64	ISSUE 2.0	
--------------------------------------	------------	----------	--------------	---

Filling system volume determination						
Step No.	Date: Action and Description	Company:	Location:	Value	Result	Engineer: Comment
16.	Wait about ten mins, take by hand the pressure as P2' and the average reading of the three PT1000s in the filling system as T2'. (here T2' is comparable to T _{room} with range of ±1°C);	P2'	Monitoring	T _{room} ±1°C	No.1 Pt1000 No.2 Pt1000 No.3 Pt1000	T _{room} ±1°C
17.	Close valve 1, valve 3, SV1.5 valve;			T _{room} ±1°C		
18.	Disconnect SV1.5 from the connector 3;					
19.	Weight the SV1.5 with the electronic balance again, as M' nitrogen2;					
20.	The nitrogen mass inside the filling system including tubes is: M _{FT} = M' nitrogen1 - M' nitrogen2,					
21.	The volume of the filling system including tubes is determined by the ideal gas equation , where $V_{FT} = \frac{M_{FT} RT_2'}{m_{\text{nitrogen}} P_2'}$			$V_{\text{external}} = 0.026L$		
	m _{nitrogen} = 28g/mol for nitrogen, and R is the gas constant;					

AMS-TTCS	Page	34
AMSTR-SYSU-PR-024	OF	64
Title	ISSUE	2.0
FM TTCB Filling and venting procedure		

7.4 Determination of TTCS volume



TTCS volume determination						
Step No.	Date: 27/10/2009	Company: SYSU	Location: CERN	Monitoring	Value	Result
	Action and Description			Time	Comment	Engineer: XHS/22
22.	Take by hand environment conditions					
23.	Temperature: <input type="checkbox"/> 22°C	Humidity: %RH	Pressure: MPA			
24.	Affix any two of the three PT1000s on the side surface of the SV1.5 and leave the rest one to monitor environmental temperature.				Connectors leak rate: 1. Vacuum the filling system and connected tubes. Background HR = 5.0 x 10^-9 mbar/s.	
25.	Connect the SV1.5 (any of the three stand vessels can be used) to connector 3; Note: Longer extend tube may be used and height difference may exist between the SV1.5 and connector 3.				2. LR = 4.9 x 10^-9 mbar/s. B:55.	
	<u>Note: The extend tube between connectors and valves must be supported to reduce strain.</u> (For the new connectors, wrench screw nuts with one and quarter circles. For the used connectors, wrench the screw nuts further tightly.)					
26.	Connect the N ₂ bottle to connector 2;					✓

No part of this document may be reproduced and/or disclosed, in any form or by any means, without the prior written permission of SUN YAT-SEN UNIVERSITY.

AMS-TTCS	Page OF	35 64
AMSTR-SYSU-PR-024	ISSUE	2.0



TTCS volume determination						
Step No.	Action and Description	Location:	Engineer:	Time	Value	Result
27.	Connect a dry mechanical pump to vacuum connector	Monitoring	SXH / 22			✓
28.	Connect the TTCS loop to connector 1; Longer extend tubes may be used and height difference may exist between the TTCS loop and connector 1. <u>Note: The extend tube between connectors and valves must be supported to reduce strain.</u>	N_2 bottle with N_2 inside, no flush for it.				✓
29.	Close valve 1, valve 4 and the N_2 bottle valve, open valve 2, valve 3, the SV1.5 valve, pressure regulator and the vacuum valve slowly, pump the SV1.5 and the filling box down to 30Pa;	Evacuate Time Vacuum gauge reading	1~2 hours Vacuum: 18pa. flush 1mpa. vacuum: 29pa		14:213 14:14 14:18	
30.	Close the vacuum valve open the valve of the N_2 bottle					
31.	Fill the SV1.5 with N_2 up to 4.5MPa, then close valve 2; waiting until pressure and temperature of the standard vessel is stable. Take by hand the pressure as P1. Take by hand the average reading of the three PT1000s in the filling system as T_1 . (here T_1 is comparable to T_{room} with range of $\pm 1^\circ C$);	Evacuate Time P1 No.1 Pt1000 No.2 Pt1000 No.3 Pt1000 $T_{room} \pm 1^\circ C$ Start room temp $T_{room} \pm 1^\circ C$ $T_{room} \pm 1^\circ C$	0.5~1hours vacuum 29pa $T_1 = 22.9$ $T_2 = 22.1$ $T_3 = 23.0$ pressurize 14:27		14:19 14:25	
			pressurize to 54mpa		14:30	

$$\begin{cases} T_1 = 25.7 \\ T_2 = 22.0 \\ T_3 = 23.6 \end{cases} \quad \begin{matrix} N_2 \text{ bottle} \\ \text{room.} \\ N_2 \text{ bottle} \end{matrix}$$

	AMS-TTCS	Page	36
	AMSTR-SYSU-PR-024	OF	64
Title	FM TTCS Filling and venting procedure	ISSUE	2.0



TTCS volume determination

Step No.	Date: 27/10/2009	Action and Description	Company: SYSU	Monitoring	Location: CTRW	Result	Comment	Time
32.		Close the filled SV1.5 valve, valve 3, and the N ₂ bottle valve, disconnect the filled SV1.5 from connector 3;				$T_1 = 23.2$ $T_2 = 22.4$ $T_3 = 23.2$.		14:59.
33.		Weight the filled SV1.5 with an electronic balance (0.1g precision or better), as M _{nitrogen} ;				$M_{nitrogen} = 28.503g$.		
34.		Connect the filled SV1.5 back to the connector 3;			Check leak rate of connector to SV1.5.			
35.	1	Open valve 3, valve 1, valve 4 and the vacuum valve; open pressure regulator to pump the filling box and TTCS loop down to 30Pa;			$BG = 7.9 \times 10^{-9} \text{ mbar/s}$ $HR = 7.6 \times 10^{-9} \text{ mbar/s}$.			15:16.
36.		Close the vacuum valve, valve 1 and valve 4, switch off the pump. Open the SV1.5 valve and close SV1.5 valve, slowly open valve 1 to fill the N ₂ into the TTCS loop to prevent pressure spike to the sensors. Repeating on and off the SV1.5 valve and valve 1 in turn until pressure of the TTCS loop is up 1.5MPa, and then slowly open the SV1.5 valve and valve.		DPS reading of the TTCS loop $\leq 0.5\text{Bar}$	Vacuum flush. 1.5mpa. Vacuum. 14pa	15pa.		15:25
					extended tube volume determination.	15:37		
				stable state:	$T_{room} = 22.5^\circ\text{C}$.			

Thermocouple = 22-2 °C.

P_{final} = 5.096mpa. 15:42.

P_{nitrogen} = 2846.3g.

check. leak rate of connector to SV1.5. $BG = 1.0 \times 10^{-8} \text{ mbar/s}$

$R = 9.5 \times 10^{-9} \text{ mbar/s}$.

23pa. 16:35

Vacuum TTCS loop. 15:59. 23pa.



No part of this document may be reproduced and/or disclosed, in any form or by any means, without the prior written permission of SUN YAT-SEN UNIVERSITY.

Page	37
OF	64
ISSUE	2.0



Vacuum TTCS loop
 $P_a = .19 \text{ Pa}$
 17:24
 pressurize N_2 from SV1.5 to TTCSloop 7:36

TTCS volume determination

Step No.	Action and Description	Location:	Engineer:
		Company:	Date: 27/10/2009
37.	Wait a period of time (0.5~1hours), take by hand the loop pressure as P_2 and the average reading of the three PT1000s in the filling system as T_2 . (here T_2 is comparable to T_{room} with range of $\pm 1^\circ\text{C}$);	P2 No.1 Pt1000 No.2 Pt1000 No.3 Pt1000 $T_{room} \pm 1^\circ\text{C}$ $T_{room} \pm 1^\circ\text{C}$ $T_{room} \pm 1^\circ\text{C}$	Monitoring All Pt1000 = 22~23°C. All Dallas = 22.19~22.5°C. on filling system $T_1 = 22.9^\circ\text{C}$ $T_2 = 22.4^\circ\text{C}$ $T_3 = 23.0^\circ\text{C}$
38.	Close valve 1, valve 3, SV1.5 valve and the TTCS valve;		$M_{nitrogen2} = 2802.69$
39.	Disconnect SV1.5 from the connector 3;		
40.	Weight the SV1.5 with the electronic balance again, as $M_{nitrogen2}$;		
41.	The nitrogen mass inside the loop and the filling system is: $M_{nitrogen} = M_{nitrogen1} - M_{nitrogen2}$,	<u>External tube volume</u> = Nitrogen ₁ - Nitrogen ₂ = 2850.3 - 2846.3 = 4g $P_f = \frac{M}{m \cdot RT}$	$5.096 \cdot V = \frac{4}{28} \times 8.314 \times 295.6$ $\therefore V_{ext + filling system} = 0.068 \text{ L. } (\cancel{0.0781 \text{ L.}}$
42.	The volume of the loop is determined by the ideal gas equation , where	$V_{Loop} = \frac{M_{nitrogen} RT_2}{m_{nitrogen} P_2}$ $m_{nitrogen} = 28 \text{ g/mol}$ for nitrogen, and R is the gas constant;	$\therefore V_{fillsys} = 0.042 \text{ L.}$ $\therefore V_{ext} = 0.068 - 0.042 = 0.026 \text{ L.}$
43.	Determine the fill mass by $M_{L_1} = V_{Loop} FR$ (where $FR = 569.60 \text{ g/l}$).		

$$\begin{aligned} \text{Determine max fill mass } M_{L_max} &= V_{Loop} \cdot FR_{max} & (FR_{max} = 592.39 \frac{\text{g}}{\text{L}}) \\ \text{Determine min fill mass } M_{L_min} &= V_{Loop} \cdot FR_{min} & (FR_{min} = 546.32 \frac{\text{g}}{\text{L}}) \end{aligned}$$

$$\text{Bottle + CO}_2 = 2832.3 \text{ g.}$$

AMS-TTCS		Page	38
AMSTR-SYSU-PR-024		OF	64
Title		ISSUE	2.0



TTCS volume determination

Step No.	Action and Description	Company:	Location:	Result	Comment	Time
44.	Calculate the filled mass for the standard vessel Set $M_{C_VS} = M_{C_R_VS} + M_{C_L} + M_{C_R}$;	SYSU	Monitoring	Value		Date: 27/10/2029
	NOTE: $M_{C_R} = M_{C_R_VS} + M_{C_R_FT} = V_{VS} \times \rho_G(T, P) + V_{FT} \times \rho_G(T, P)$ Here $\rho_G(T, P)$ is determined by the chosen final temperature of the TTCS loop standard vessel and the final saturated pressure of the TTCS loop.			$T_{FT} = 24^\circ C$. $T_{Total} = 37^\circ C$. $M_{C_R_FT} = 3823.8 g$. $M_{C_R_FT} = M_{CO_2} - M_{Nitrogen_2}$ $M_{CO_2} = 43.7 g$. $M_{CO_2} = 43.7 g$.	$P_s = 6.279 \text{ MPa}$. $P = 1676$.	Date: 27/10/2029
45.	Repeat the above procedure of TTCS volume determination again for confirmation		$PV = \frac{M_{CO_2} \times RT}{m}$	$2.353 \times 10^3 \cdot V = \frac{43.7}{28} \times 8.314 \times 293.65$		

$$\Rightarrow V_{TTCS} = 1.5015 L$$

$$\therefore V_{TTCS} = 1.5015 - 0.068 = 1.433 L (\pm 1.615\%)$$

$$\begin{aligned} &\text{Remaining: } (0.068 + 1.485) \times 167.6 = 260.4 g. \\ &TTCS_{new}: 569.6 \times 1.433 = 816.2 g. \quad \therefore \text{The total: } 260.4 + 816.2 \\ &\quad + 2747.2 = 3823.9 g \end{aligned}$$

Fill a standard vessel with CO₂ from a Gas bottle

Step No.	Action and Description	Company:	Location:	Result	Comment	Time
1.	Take by hand environment conditions	SYSU	Monitoring	Value		Date: 25/10/2029
2.	Temperature: $\square 27^\circ C (Cms.)$	Humidity: %RH	Pressure: MPa			

AMS-TTCS	Page	39
AMSTR-SYSU-PR-024	OF	64
FM TTCB Filling and venting procedure	ISSUE	2.0



Fill a standard vessel with CO₂ from a Gas bottle

Step No.	Action and Description	Location:	Engineer:
		Monitoring	Comment
		Value	Time
3.	<p>Connect the SV1.5 (here anyone of the two SV1.5 can be used) to connector 3;</p> <p>Note: Longer extend tube may be used and height difference may exist between the SV1.5 and connector 3.</p> <p><u>Note: The extend tube between connectors and valves must be supported to reduce strain.</u></p> <p>(For the new connectors, wrench screw nuts with one and quarter circles. For the used connectors, wrench the screw nuts further tightly.)</p>		✓
4.	Connect a high purity CO ₂ gas bottle to connector 2;		✓
5.	Connect a dry mechanical pump to vacuum connector		✓
6.	Close valve 1 ,valve 4 and the gas bottle valve, open valve 3, valve 2 , pressure regulator, the vacuum valve and the SV1.5 valve;		✓

AMS-TTCS AMSTR-SYSU-PR-024	
Title	FM TTCB Filling and venting procedure
Page OF	40 64

Done before volume determination,
Put much more and the release based on
volume determination.



Fill a standard vessel with CO₂ from a Gas bottle

Step No.	Action and Description	Company:	Location:	Monitoring	Value	Result	Comment	Time
7.	Open valve 3 until the pressure drop to 30Pa; Close the vacuum valve, open the bottle valve slowly, until the pressure up to 1MPa; Close the bottle valve and open the vacuum valve slowly, pump the SV1.5 until the pressure drop to 30Pa; Repeat such operations and flush with CO₂ twice (totally three times).	SY SV	OTKN - CMS	Evacuate Time	1~2 hours	vacuum flush >9mpa.		12:08
8.	Place the vacuumed SV1.5 to a barrel with ice water mixture, switch off the pump;			Vacuum gauge	≤30Pa	vacuum ≥8pa.		12:10
9.	Open valve 2 and regulate outlet pressure of gas bottle valve slowly until higher than 4MPa;			Outlet pressure of gas bottle	≥4MPa	flush >9mpa. vacuum ≥8pa.	✓	12:39

Title	FM TTCB Filling and venting procedure	Page	41
		OF	64

ISSUE	2.0
-------	-----

Fill a standard vessel with CO₂ from a Gas bottle

Step No.	Action and Description	Location:	Engineer:
10.	After a period of time (2 hours~3 hours), close the SV1.5 valve, valve 2 and valve 3; Estimate weight by electronic balance without disconnecting SV1.5, check whether it meets required mass in the SV1.5. If CO ₂ filled into the SV1.5 is less than the required mass, then put the SV1.5 back to the barrel, and open valve 2, valve 3 and the SV1.5 valve. During the estimation of weight without disconnecting SV1.5, the extend tube between the SV1.5 and filling box should be put up slightly in order to get real weight of the filled SV1.5 as possible as we can, and even though, the extend tube still account for about 200g in total estimating weight.	Waiting time	2 hours~3 hours
11.	Disconnect the SV1.5 from the filling box, and dry the SV1.5 surface; Seal the extended tube.	Dry and clean the SV1.5 surface	✓
12.	Weight the filled SV1.5 with a electronic balance, as M _{filled_vs} ;	M _{filled_vs}	
13.	Take by hand the filled CO ₂ mass M _{o_vs} = M _{filled_vs} - M _{E_vs} ;	M _{o_vs}	
14.	If M _{o_vs} > (M _{C_vs} - M _{E_vs}), open the SV1.5 valve very slightly to release a little CO ₂ gas, close SV1.5 valve;		

AMS-TTCS AMSTR-SYSU-PR-024	
Title	FM TTCB Filling and venting procedure
Page OF	42 64
ISSUE	2.0



Fill a standard vessel with CO₂ from a Gas bottle

Fill a standard vessel with CO ₂ from a Gas bottle						
Date:	Company:	Location:	Engineer:			
Step No.	Action and Description	Monitoring	Value	Result	Comment	Time
15.	Weight the SV1.5 again; repeats step 12 to 14 until M _{O_vs} value meets the requirement (=M _{C_vs} – M _{E_vs}).	M _{O_vs}	(M _{C_vs} –M _{E_vs}) ±1g			
16.	Seal the filled SV1.5 valve for cleanness					

AMS-TTCS AMSTR-SYSU-PR-024	Page OF	43 64
Title FM TTCB Filling and venting procedure	ISSUE	2.0



7.6 Calibration of the filled mass

✓/R

Calibration of the filled mass						
Step No.	Date:	Company:	Location:	Engineer:	Monitoring	Value
	Action and Description			Result	Comment	Time
1.	Take by hand environment conditions					
2.	Temperature: <input type="checkbox"/> %RH	Humidity: <input type="checkbox"/> %RH	Pressure: MPa			
3.	Set the filling environment temperature as 22°C					
4.	Connect the filled SV1.5 (the SV1.5 _{new1}) to connector 3; Note: Longer extend tube may be used and height difference may exist between the SV1.5 and connector 3.					
<u>Note: The extend tube between connectors and valves must be supported to reduce strain.</u>						
(For the new connectors, wrench screw nuts with one and quarter circles. For the used connectors, wrench the screw nuts further tightly.)						
5.	Connect another standard vessel (VS_B) to connector 1 with the same extension filling tube for filling the TTCS loop;					
6.	Connect a dry mechanical pump to vacuum connector					

	AMS-TTCS AMSTR-SYSU-PR-024	Page 44
	OF 64	
Title	FM TTCB Filling and venting procedure	ISSUE 2.0



Calibration of the filled mass						
Step No.	Date:	Company:	Location:	Monitoring	Value	Result
						Engineer: Comment Time
7.	Close valve 2 and open the vacuum valve, valve 3, pressure regulator, valve 1, valve 4 and the VS_B valve;					
8.	Pump the VS_B until the pressure down to 30Pa;		Vacuum gauge reading	≤30Pa		
9.	Close the vacuum valve and valve 4;					
10.	Open the VS_A valve slowly;					
11.	Switch on the filling box heater with and the standard vessel heater (to control the box temperature to 25°C step by step); If possible, the standard vessel heater should increase the temperature with an interval of 5~10°C. If heat power of the filling box heater is not enough, using additional heat gun to warm up the VS_A		No.1 Pt1000 No.2 Pt1000 No.3 Pt1000	≤30°C ≤30°C ≤30°C		
12.	Using the fans to cool the VS_B					

No part of this document may be reproduced and/or disclosed, in any form or by any means, without the prior written permission of SUN YAT-SEN UNIVERSITY.

Title	FM TTCB Filling and venting procedure
-------	---------------------------------------



Page 45
OF 64

ISSUE 2.0

Calibration of the filled mass

Calibration of the filled mass							
	Date:	Company:	Monitoring	Value	Result	Comment	Time
13.	Watch the reading of the digital pressure gauge. When the pressure and temperature is close to the set value, switch on the heating tape on the filling tubes.		APS reading of the filling system	$5.995 \pm 0.1 MPa$			
	When the pressure is equal to 5.995MPa, close the TTCS loop valve, valve 1, the SV1.5 valve, and valve 3, respectively;		Temperatures of the filling box and tubes	25°C			
14.	Switch off the filling box heater and the heating tape;						
15.	Unwrap the VS_A;						
16.	Disconnect the VS_A and the VS_B respectively;						
17.	Weight the VS_A and the VS_B, as M _{O_R_vsA} and M _{Filled_vsB} , respectively						
18.	From (M _{Filled_vs - M_{O_R_vsA}}), we have the mass of CO ₂ out of SV1.5; from (M _{Filled_vs_B - M_{E_vs_B}}), we have the mass of CO ₂ into VS_B;	(M _{Filled_vs - M_{O_R_vsA}}) (M _{Filled_vs_B - M_{E_vs_B}})					
19.	Obtain the mass loss M _{loss} =(M _{Filled_vs - M_{O_R_vsA}})-(M _{Filled_vs_B - M_{E_vs_B}});	M _{loss}					

N/A

AMS-TTCS	Page	46
AMSTR-SYSU-PR-024	OF	64
Title	FM TTCB Filling and venting procedure	ISSUE
2.0		



Calibration of the filled mass

Step No.	Date:	Action and Description	Company:	Location:	Engineer:
				Monitoring	Value
20.		Calculate the mass loss based on the filling tube volume $M_{C_R_FT}$ $= V_{FT} \times \rho_G(T)$; where $T=25^\circ C$		$M_{C_R_FT}$	
21.		Obtain fill loss range of the filling tube by comparing M_{loss} and $M_{C_R_FT}$ to determine performance of the current filling system			
22.		Switch off the pump.			
23.		Seal the filled SV1.5 valve for cleanliness			

AMS-TTCS AMSTR-SYSU-PR-024	Page OF	47 64
FM TTCB Filling and venting procedure	ISSUE	2.0



7.7 Fill TTCS loop with CO₂ from SV1.5

Fill TTCS loop with CO ₂ from SV1.5						
Step No.	Action and Description	Location:	Value	Result	Comment	Time
1.	Take by hand environment conditions	Monitoring				
2.	Temperature: <input type="checkbox"/> %RH	Humidity: <input type="checkbox"/>	Pressure: MPa			
3.	Set the filling environment temperature as 22°C				Before: $\text{bottle mass} + \text{CO}_2 \text{ mass} = 38.32-39$	
4.	Connect the TTCS loop to connector 1 with an extended filling tube.					
Note: Longer extend tubes may be used and height difference may exist between the TTCS loop and connector 1.						
The extend tube between connectors and valves must be mechanically supported to reduce strain.						
5.	Connect a high purity CO ₂ gas bottle to connector 2;					✓

AMS-TTCS	Page	48
OF	64	
ISSUE	2.0	
Title		FM TTCB Filling and venting procedure



Fill TTCS loop with CO ₂ from SV1.5						
Step No.	Date: 28/10/2009	Action and Description	Company: SYSEN	Location: CERN	Result	Engineer: SXH/ZZ Comment /Time
6.	Put three PT1000 vertically by using adhesive tape in turn on the side surface of the SV1.5, then wrap the SV1.5 with heater with Pt1000 in the joint of the heater.				V	
	(Note: No.1 PT1000 for control, No.2 PT1000 and No.3 PT1000 for monitor.)					
	During filling CO ₂ from the standard vessel to the TTCS loop, No.1 PT1000 should be paste on the middle of the standard vessel's side face; the other two PT1000s should be pasted on the top and bottom of the standard vessel's side face).					
7.	Connect the filled SV1.5 to connector 3;					
	Note: Longer extend tubes may be used and height difference may exist between the TTCS loop and connector 1. The extend tube between connectors and valves must be mechanically supported to reduce strain.				V	
8.	Use the He-mass spectrometer to perform leak test before filling. If leak rate more than 5×10^{-5} mbar·l/s somewhere, reconnect it until the leak rate is less than 5×10^{-5} mbar·l/s	LR	$5 \times 10^{-5}\text{ mbar}\cdot\text{l/s}$	$\beta G = 5.2 \times 10^{-8} \text{ mbar/s}$ all connectors. $LR = 2.6 \times 10^{-8} \text{ mbar l/s}$		10:20.

AMS-TTCS
AMSTR-SYSU-PR-024

Title	FM TTCB Filling and venting procedure	Page OF	49 64	Issue	2.0
-------	---------------------------------------	------------	------------------------	-------	-----



Fill TTCS loop with CO₂ from SV1.5

Step No.	Action and Description	Date:	Company:	Location:	Engineer:
					Time
9.	Stop the He-mass spectrometer and replace it with a dry mechanical pump.			Monitoring	
10.	Follow the section of 7.5 (fill a standard vessel with CO ₂ to from a Gas bottle) to fill SV1.5 to M _{filled_SV} ;				
11.	Put three PT1000 vertically on the side surface of the SV1.5 by using adhesive tape. Then wrap the SV1.5 with heater with Pt1000 in the joint of the heater. Note: check them can work or not (No.1 PT1000 for control, No.2 PT1000 and No.3PT1000 for monitor. During the filling CO ₂ from the standard vessel to the TTCS loop No.1 PT1000 should be paste on the middle of the standard vessel's side face; the other two PT1000s should be paste on the top and bottom of the standard vessel's side face).				
12.	Insulate the filled vessel and connect the SV heater with the socket in the filling box.				
13.	Open the vacuum valve, valve 1, valve2, valve 3, valve 4 , the TTCS loop valve and the pressure regulator			Vacuum TTCS Loop.	g:oo.

AMSTR-SYSU-PR-024		Page OF	50 64
Title	FM TTCS Filling and venting procedure	ISSUE	2.0



Fill TTCS loop with CO₂ from SV1.5

Step No.	Action and Description	Company: SYU	Location: CERN	Engineer: SXYU/22
		Monitoring	Value	Result
14.	Wait until pressure of the TTCS loop, the filling box and two extend tubes down to 30Pa or lower. Close valve4, the vacuum valve, and valve 1. then open the gas bottle valve slowly and valve 1 to fill the loop with high purity CO ₂ from the gas bottle, until the pressure up to 1MPa (flush the loop)	Evacuate Time	1~2hours	22Pa. 10:23.
15.	Close the gas bottle valve , open valve 1, valve 4 and the vacuum valve slowly;	Vacuum gauge	≤30Pa ≥1MPa	1~1mpa. 10:24.
16.	Pump the TTCS loop, the filling box and two extend tubes until the pressure down to 30Pa or lower; Close valve4, the vacuum valve, and valve 1. then open the gas bottle valve slowly and valve 1 to fill the loop with high purity CO ₂ from the gas bottle, until the pressure up to 1MPa (flush the loop)	Evacuate Time	0.6 hour	Vacuum. 10:28.
17.	Pump the TTCS loop, the filling box and two extend tubes until the pressure down to 30Pa or lower;	Vacuum gauge	≤30Pa ≥1MPa	30Pa. 11:15.
18.	Close valve 4, the vacuum valve; switch off the pump.	Vacuum reading	≤30Pa	Vacuum. 11:20. 27Pa. 12:13.

AMS-TTCS		Page	51
AMSTR-SYSU-PR-024		OF	64
Title	FM TTCB Filling and venting procedure	ISSUE	2.0
			

Fill TTCS loop with CO ₂ from SV1.5						
Step No.	Action and Description	Location:	Engineer:	Time	Comment	Result
19.	Put the SV1.5 with the connected tube on the electronic balance. Open the SV1.5 valve slowly, then close the SV1.5 valve, slowly open valve 1 to fill the CO ₂ into the TTCS loop to prevent pressure spike to the sensors. Repeating on and off the SV1.5 valve and valve 1 in turn until pressure of the TTCS loop is up to 3MPa, and then slowly open the SV1.5 valve and valve 1.	Monitoring DPS reading of the TTCS loop	SXh/ZB	/		✓
20.	Switch on the filling box heater and the standard vessel heater (to control the box temperature to 25°C step by step); If possible, the standard vessel should be heated with a temperature interval of 5~10°C. If heat power of the filling box heater is not enough, using additional heat gun to warm up the SV1.5	NO.1 Pt1000 reading NO.2 Pt1000 reading NO.3 Pt1000 reading	30±0.5°C 30±1°C 37°C			
21.	Use the fan to cool the accumulator					✓

AMS-TTCS AMSTR-SYSU-PR-024		Page OF	52 64
Title	FM TTCB Filling and venting procedure	ISSUE	2.0



Fill TTCS loop with CO₂ from SV1.5

Step No.	Date: 28/10/2009	Action and Description	Company: SYSU	Monitoring	Location: CBRN.	Value	Result	Comment	Engineer: SH/ZZ Time: 16:05
22.	Watch the reading of the digital pressure gauge. When the pressure and temperature is close to the set-value, switch on the heating tape of the filling tubes. When the pressure is equal to 5.995MPa, close the TTCS loop valve, valve 1, the SV1.5 valve, and valve 3, respectively;			Waiting time APS reading of the TTCS loop (P _{TTCS})	3~4 hours 5.995±0.1MPa				
23.	Switch off the filling box heater and the standard vessel heater;			APS reading of the filling system (P _{filling})	5.995±0.1MPa				
24.	Unwrap the heating tape from the SV1.5;						✓		
25.	Disconnect the SV1.5 from the filling box, clean surface of the SV1.5						✓		
26.	Weight the SV1.5 as (M _{O_R_vs} +M _{E_vs}), compared (M _{O_R_vs} +M _{E_vs}) with (M _{C_R_vs} +M _{E_vs}) ±5g		(M _{O_R_vs} +M _{E_vs}) ±5g	(M _{C_R_vs} +M _{E_vs}) ±5g	2934.4 g				
27.	Filling finished.								
28.	After the filling is finished, the two extended filling tubes, the SV1.5 valve and the filling system must be carefully disconnected and sealed.			TTCS loop 00, mass: 3832.3 - 2934.4 = 11.6 remaining in tubes			✓		
29.	Carefully packing the two extended filling tubes, the SV1.5 and the filling system.		V _{loop} = 1.433L = 826.3 g	filling rate = 576.6 g/L	576.6 g/L	filling rate = 576.6 g/L	✓		

Including error higher L $\rho = FR \cdot error = 576.69/L \times 1.0762 = 586.769/L$

No part of this document may be reproduced and/or disclosed, in any form or by any means, without the prior written permission of SUN YAT-SEN UNIVERSITY.

$$including error lower L = 576.69/L \times 0.9828 = 566.449/L$$

AMS-TTCS AMSTR-SYSU-PR-024	Page OF	53 64	
Title FM TTCB Filling and venting procedure	ISSUE	2.0	

7.8 Venting CO₂ from the TTCS loop

Venting CO ₂ from the TTCS loop						
Step No.	Date:	Company:	Location:	Engineer:	Result	Comment
		Action and Description	Monitoring	Value	Time	
1.		Take by hand environment conditions				
2.	Temperature: °C	Humidity: %RH	Pressure: MPa			
3.		Switch on TTCE Terminal and go to the interface TTCE-2				
4.		Write down the PT01 and PT03 temperatures	PT01 and PT03	>22°C		
5.		Connect the TTCB valve, filter, stainless tube and extended tube				
6.		Open the TTCB valve a little to release CO ₂ gas slowly while switch on the ground accumulator heater (GAC) with 30% Monitor PT01 and PT 03, once either temperature is below 18 °C, stop venting by closing TTCB valve.	PT01 and PT03	>17°C		
7.		Use a hot air gun, or hot water bath, to heat up the exit of the stainless exhaust tube				
8.		Repeat steps 6 and 7, until the pressure is down to 1.5 bar	APS reading	1.5±0.1bar		

AMS-TTCS		Page	54
AMSTR-SYSU-PR-024		OF	64
Title		ISSUE	2.0
FM TTCB Filling and venting procedure			



Venting CO2 from the TTCS loop

Date:	Action and Description	Company:	Location:	Engineer:		
Step No.		Monitoring	Value	Result	Comment	Time
9.	Close the TTCB valve.	APS reading	1.5±0.1bar			
10.	Switch off TTCE Terminal					

No part of this document may be reproduced and/or disclosed, in any form or by any means, without the prior written permission of SUN YAT-SEN UNIVERSITY.

Gas used	N ₂
ΔV/V(%)	0.89
ΔP/P(%)	0.44
ΔT/T(%)	0.17
ΔM/M(%)	0.26
M(g)	76.3
m(g/mole)	28

for ΔP/P. For using nitrogen as an ideal gas, ΔV/V is about 0.89 %.

As ΔP is limited by the pressure sensor, with the pressure sensor available with accuracy of ±0.2%, FS, by setting P to the FS of the pressure sensor, (e.g., 10MPa), we have the lowest error of 0.44%.

$$\frac{\Delta V}{V} = \frac{P}{\Delta P} + \frac{M}{\Delta M} + \frac{T}{\Delta T} = \frac{P}{\Delta P} + 2 \frac{M}{\Delta M} + \frac{T}{\Delta T} \quad (\text{A1.2})$$

Where m is the mole mass of the gas in use (in g/mole), M is the net gas mass to be measured, and R is the gas constant, T is temperature of 22°C in thermal bath respectively. For nitrogen, m=28g/mole, and a vessel of about 1.5liters, M≈76.3g. From (A1.1), we have

$$PV = \frac{m}{M} RT \quad (\text{A1.1})$$

According to the ideal gas equation:

be controlled within 0.5K.

Assumption: no leakage of measuring system, including the container, during the period of measurement; the electronic balance employed has the best accuracy of 0.1g; and the temperature

vessel by weighing the gas mass inside

8.1 Error analysis of volume determination of a

8. APPENDIX

Title	FM TCB Filling and Venting procedure	ISSUE	2.0
AMS-TCS	AMSTR-SYSU-PR-024	OF	64
AMS-TCS	Page	55	
AMSTERDAM UNIVERSITY SUN YAT-SEN UNIVERSITY			

AMS-TTCS AMSTR-SYSU-PR-024		Page	56	
OF	64			
Title	FM TTCB Filling and venting procedure		ISSUE	2.0

8.2 Error analysis of volume determination of TTCS loop by indirectly measuring the Nitrogen mass inside the loop

Assumption: no leakage to the measuring system, including the TTCS loop and the filling system, during the filling; and the temperature and its uniformity be controlled within $\pm 2K$; the volumes of the standard vessel to fill to loop (V_{VS}) is about 1.5 liter, and the volume of the loop is about 1.5 liter ($V_{loop} \approx V_{VS}$); the accuracy of the electronic balance is 0.1g (ΔM_B); no nitrogen absorption on the inner surface of the TTCS loop that made of stainless steel.

1) Error analysis for the measured volume the filling system including the filling tubes.

Fill nitrogen with the SV1.5 to a pressure of 4.5MPa; weight the mass of the filled SV1.5 $M'_{nitrogen1}$. Connect the vessel to the filling system and release the nitrogen slowly. Weight the mass of the SV1.5 again $M'_{nitrogen2}$, the nitrogen mass filled into the filling system can then be calculated: $M_{FT} = M'_{nitrogen1} - M'_{nitrogen2}$, and $\Delta M_{nitrogen} = \Delta M_1 + \Delta M_2 \approx 2\Delta M_B$. To the volume of the filling tube of the filling system is about 0.042 liter. Even with additional tube of 5m long and 3mm in inner diameter, which is about 0.035 liter, the nitrogen mass inside filling tube is about a few percentages of that in the SV1.5 and the pressure inside is about the same as the initial pressure of SV1.5. The estimated N₂ mass is:

$$M_{FT} \approx \frac{1}{20} \frac{P_0 V_{VS} m_{nitrogen}}{RT_0};$$

Assuming $P_{FT} \approx P_0$, the error of V_{FT}

$$\begin{aligned} \frac{\Delta V_{FT}}{V_{FT}} &= \frac{\Delta P_{FT}}{P_{FT}} + 2 \frac{\Delta M_B}{M_{FT}} + \frac{\Delta T_{FT}}{T_{FT}} \\ &= \frac{0.1\%FS}{P_0} + 40 \frac{\Delta M_B RT_0}{P_0 V_{VS} m_{nitrogen}} + \frac{\Delta T_{FT}}{T_{FT}} \end{aligned}$$

is about 6.3%

2) Error analysis for the measured volume of the loop and filling tube

Similarly, connect the filled vessel to a vacuumed loop and release the nitrogen inside the filled VS1.5 slowly until equilibrium is established. Weight the mass of the SV1.5 again $M_{nitrogen2}$, the

thermal bath; and the volume of the loop is about 1.5 liter; the electronic balance employed has the filling and measurement; the temperature is controlled within $\pm 2.0\text{K}$ for filling procedure without filling and measurement.

Assumption: There is no leakage for the filling system, and the TCS loop during the period of

loop

8.3 Error analysis of the total filled mass of TCS

additional nitrogen absorption happen.

value during the first measurement, so for the following measurement, there should not be measurement for at least twice. Let the nitrogen absorption, if there is any, reach its saturated In the assumption, no absorption of nitrogen is considered. This is achieved by performing the

is about 2.4%.

$$\Delta V_{\text{loop}} = \frac{V_{\text{loop}}}{2.1\% \times 1.5 + 6.3\% \times (0.042 + 0.035)} - 1.5$$

The error of V_{loop} :

3) Error analysis for the measured volume of the loop

is about 2.1%.

$$= 2 \frac{P_0}{0.2\%FS} + 4 \frac{P_0 V_{\text{S}} m_{\text{nitrogen}}}{\Delta M^B RT_0} + \frac{\Delta T_{\text{loop}}}{T_{\text{loop}}}$$

$$\Delta V_{\text{loop+FT}} = \frac{V_{\text{loop+FT}}}{P_1} + 2 \frac{M_{\text{loop+FT}}}{\Delta M^B} + \frac{\Delta T_{\text{loop}}}{T_{\text{loop}}}$$

The error of $V_{\text{loop+FT}}$:

Assuming $T_0 = T_{\text{loop}}$, and ΔT_{loop} is about $\pm 2\text{K}$

$$M_{\text{loop+FT}} = \frac{1}{2} \frac{RT_0}{P_0 V_{\text{S}} m_{\text{nitrogen}}} \quad \text{And } P_1 \approx \frac{1}{2} P_0;$$

pressure inside the loop and filling tube is about half of the initial pressure of SV1.5. the loop and filling tube is about half of the initial filled mass of nitrogen in the SV1.5, and the $\Delta M_{\text{loop+FT}} = \Delta M_1 + \Delta M_2 \approx 2\Delta M^B$. As V_{S} is about half of the total volume, the nitrogen mass inside nitrogen mass filled into the loop can then be calculated: $M_{\text{loop+FT}} = M_{\text{nitrogen1}} - M_{\text{nitrogen2}}$, and

AMS-TCS	AMSTR-SYSU-PR-024	Title	FM TCB Filling and Venting procedure	ISSUE	2.0
		Page	57	OF	64

AMS-TTCS AMSTR-SYSU-PR-024		Page	58	
OF		64		
Title	FM TTCB Filling and venting procedure		ISSUE	2.0

best accuracy of $\pm 0.1\text{g}$ (ΔM_B). (Based on our experiments), any mass loss is less than 1g.

According to Annex 8.2, the error of the loop volume is about 2.4%, so the calculated filled mass $m_{cal} = FrV_{loop}$ ($\approx 860\text{g}$) has also the error of=2.4%.

(1) The error from weighting CO₂ mass is

$$\Delta M = \Delta M_2 - \Delta M_1 = 2 \quad \Delta M_B = \pm 0.2\text{g}.$$

(2) The error from the filling loss in the filling system, the CO₂ mass remained the filling tube of filling system plus additional tube with length of 5m (0.077L) is about 12.75g based on NIST refrigerant properties database.

The error of total filled mass of TTCS is

$$\frac{\Delta M_{CO_2_loop}}{M_{CO_2_loop}} = \frac{\Delta V_{loop}}{V_{loop}} + \frac{2M_B + M_{loss}}{V_{loop} \times FR} \approx 2.4\% + 1.2/1.5/569.6 \approx 2.6\%$$

Therefore, we have total CO₂ mass accuracy of $\pm 2.6\%$, which meets the requirement of $\pm 4\%$.

Conclusion:

Although the volume error is larger than 2% (required in Ref.1), the mass error (2.6%) is still within that required (4% in the Ref.1)


The impact of using electronic balance with accuracy of 0.1g other than 0.01g is that, the error of loop volume determination is obviously increased, which will be transferred to corresponding mass error. The impact on weighting itself is little.

8-3 with ignoring leak mass during filling process.

in the SV1.5, the filling tube of the filling system and the TTCS loop just like shown in Figure it can be concluded from Figure 8-1 and Figure 8-2 that CO₂ initial mass distribution would exist


loop after finishing filling

Figure 8-2 CO₂ initial state and mass distribution between the filling system and the TTCS



loop before starting filling

Figure 8-1 CO₂ initial state and mass distribution between the filling system and the TTCS



SV1.5

8.4 Calculation of the required filling mass into the

	AMS-TTCS	AMSTR-SYSU-PR-024	Page	59	OF	64	Title	FM TTCS Filling and venting procedure	ISSUE	2.0
--	----------	-------------------	------	----	----	----	-------	---------------------------------------	-------	-----

AMS-TTCS AMSTR-SYSU-PR-024		Page OF	60 64	
Title	FM TTCB Filling and venting procedure	ISSUE	2.0	




Figure 8-3 CO₂ mass distribution between the filling system and the TTCS loop after finishing filling

8.5 Calculation example

1) Calculation of M_{C_L}

Assumed : $V_{Loop} = 1.55L$

So

$$M_{C_L} = FR \times V_{Loop}$$

$$= 569.6g/L \times 1.55L$$

$$= 882.88g$$

The above calculated CO₂ must be filled into the TTCS regardless of what temperature you choose for the filling.

2) Calculation of M_{C_R}

If we choose 25°C for the filling, so the retained mass of CO₂ in the filling system including filling box, two extended tube and the stand vessel can be calculated as below:

Known conditions: $T_{Loop}(chosen) = 22^\circ\text{C}$, $P(\text{corresponds to } T_{accu}(chosen)) = 5.995\text{ MPa}$,

Finally, shown by electronic balance, the total mass should be 3890.83g.

$$= 2747.23g + 882.88g + 260.82g = 3890.83g$$

$$M_{C-VS} = M_{E-VS} + M_{C-L} + M_{C-R}$$

And it pluses net mass of the used SV1.5 M_{E-VS} is

$$M_{C-L} + M_{C-R} = 882.88g + 260.82g = 1143.7g$$

By ignoring the leak mass, the CO_2 mass must filled into the used SV1.5 is

3) Calculation of the total mass

be filled into TTCS.

According to the above calculation, the temperature chosen for filling will influence the retained mass of CO_2 . In the filling system, not influence the mass of CO_2 to

$$= 260.82g$$

$$= (1.485L + 0.042L) * 170.8g/L$$

$$= V_{VS} \times p_g (30^\circ C, 5.995 MPa) + V_{FE} \times p_g (30^\circ C, 5.995 MPa)$$

$$M_{C-R} = M_{C-R-VS} + M_{C-R-FT}$$

calculated as:

And if volume of the used SV1.5 V_{VS} is 1.485L, and filling tube of the filling system V_{FT} is 0.042Liter, so the CO_2 retained in the SV1.5, the filling box and two filling tubes can be

Solution:

$$p_g (30^\circ C, 5.995 MPa) = 170.8g/L$$

And in the filling box, the SV1.5 and two extend tubes

5.995MPa.

also fixed. If the chosen T of CO_2 is $22^\circ C$, the corresponding saturated pressure is

Once T_{loop} (chosen) is fixed, the final pressure in the filling system and the TTCS loop is

$$TV_{S(\text{controlled})} = 30^\circ C,$$

AMS-TTCS	AMSTR-SYSU-PR-024	Page	61	Title	FM TTCS Filling and venting procedure
		OF	64	ISSUE	2.0

AMS-TTCS AMSTR-SYSU-PR-024		Page OF	62 64
Title	FM TTCB Filling and venting procedure	ISSUE	2.0



Table 10 saturated properties of CO₂ from 15°C to 29°C with interval of 1°C

Temp [°C]	Pressure[MPa]	Density (L) [kg/m^3]	Density (V) [kg/m^3]	Enthalpy (L) [kJ/kg]	Enthalpy (V) [kJ/kg]	Entropy (L) [kJ/K-kg]	Entropy (V) [kJ/K-kg]
15.00	5.081	821.8	159.6	240.1	418.0	1.136	1.754
16.00	5.204	813.0	165.4	243.1	416.6	1.146	1.746
17.00	5.330	803.9	171.5	246.2	415.0	1.156	1.738
18.00	5.458	794.4	178.0	249.4	413.4	1.167	1.730
19.00	5.589	784.5	184.9	252.6	411.6	1.177	1.721
20.00	5.722	774.2	192.3	256.0	409.7	1.188	1.712
21.00	5.857	763.3	200.2	259.5	407.6	1.199	1.703
22.00	5.995	751.8	208.8	263.0	405.3	1.211	1.693
23.00	6.136	739.5	218.1	266.8	402.8	1.223	1.682
24.00	6.279	726.3	228.3	270.7	400.0	1.236	1.670
25.00	6.425	712.0	239.6	274.9	396.8	1.249	1.658
26.00	6.574	696.2	252.4	279.3	393.2	1.263	1.644

AMS-TTCS	Page	63
AMSTR-SYSU-PR-024	OF	64
	ISSUE	2.0
FM TTCB Filling and venting procedure		

27.00	6.727	678.4	267.3	284.2	389.0	1.279	1.628
28.00	6.882	657.5	285.1	289.7	384.0	1.296	1.609
29.00	7.042	631.7	307.8	296.3	377.5	1.317	1.586

AMS-STR-SYSU-PR-024		Page OF 64	Page 64
Title	FM TTCB Filling and venting procedure	ISSUE 2.0	



===== END OF THE DOCUMENT =====

1) error of external tube.

$$\frac{\Delta V_f}{V_f} = \frac{\Delta P_f}{P_f} + 2 \frac{\Delta M_B}{M_B} + \frac{\Delta T_f}{T_f}$$

$$= \frac{0.1\% \times 10 \text{ MPa}}{5.4 \text{ MPa}} + 2 \frac{0.1\%}{2850.39 - 2846.39} + \frac{2k}{295k}$$

$$= 5.678\% \quad 5.874\%$$

3) error of the loop

$$\frac{\Delta V_{loop}}{V_{loop}} = \frac{1.332\% \times 1.433L}{1.433L} \quad 5.874\% \times 0.0692$$

$$= 1.615\%$$

4) The error of total filled mass of TTCS primary loop.

$$\frac{\Delta m_{loop}}{m_{loop}} = \frac{\Delta V_{loop}}{V_{loop}} + \frac{2m_B + m_{loop}}{V_{loop} \times FR}$$

$$= \frac{1.615\% + \frac{2 \times 0.9 + 1.9}{295k}}{1.433L \times \frac{569.691}{569.691}} = 1.762\%$$

$$= 1.332\%$$