


Prepared
4 August, 2008

AMS Payload Overview


Prepared by
Trent Martin
NASA AMS Project Manager
281-483-3296
trent.d.martin@nasa.gov





Major AMS Detectors
















Superconducting Cryogenic Magnetic (Cryomag)






- When charged, the coils develop mutual magnetic loads which are reacted internally. The magnetic loads are considerably larger than inertial forces.
- The coils are cooled to a temperature of 1.8 K by a system of pipes...








- ...connected to a 2500 litre superfluid helium tank.
- The cold mass is suspended from a system of 16 composite straps.
- The coils and helium vessel are enclosed in radiation shields and multi-layer superinsulation.








All
 components
 are
 suspended
 within a
 vacuum
 case.









Trent Martin (281) 483-3296

AMS-02 Payload Overview

Superfluid Helium Tank





Trent Martin (281) 483-3296

AMS-02 Payload Overview

Page 11


GSR Phase II, Sept. 8, 2008





























AMS-02 Payload Overview

Page 16

















Trent Martin (281) 483-3296

AMS-02 Payload Overview









Trent Martin (281) 483-3296


AMS-02 Payload Overview

Page 20

GSR Phase II, Sept. 8, 2008







Transition Radiation Detector (TRD)



Transition Radiation Detector (TRD)



- TRD distinguishes positrons form protons, measure particle velocity and energy.
- TRD above the Upper TOF on the experiment stack
 - Octagonal shape max. size 2.31 m x 0.62 m
 - Mounts to USS-02 at four locations via the Aluminum M-Structure
- TRD Gas Supply mount to wake side of USS-02
 - Include Supply Box, Circulation Box, Gas Manifold and Plumbing System
 - TRD uses a gas system with Xe:CO₂ (80:20)




TRD (Cont.)





- Octagonal Support Structure and Bulkheads
- Aluminum M Structure
- 5248 proportional tubes
 - Multi-layer wound composite structure (outer diameter of 6 mm (0.24 in), wall thickness = 70 μ (.003 inches)
 - Gold plated tungsten wire (30 μ (.001 in) diameter) runs thru the center of the tube
 - Total of 20 tube layers high with a radiator material gap between each layer
- Gas Supply System (Details Covered in Another Presentation)
 - 2 Composite Over-wrapped Stainless Steel Pressure Vessels
 - 1 Stainless Steel Mixing Tank Pressure Vessel
 - 1 Stainless Steel Box C Cylinder Pressurized Component
 - Plumbing system Pressurized Components
 - System covered by Meteoroid and Orbital Debris Shield


TRD Structure




TRD Structure










TRD Gas Supply System







TRD Gas Supply Pressure Vessels




Xenon Tank



CO₂ Tank



Mixing Tank



	Xenon Tank	CO ₂ Tank	Mixing Tank
Model	D4815	D4816	SKC 13181
OD (in.)	15.37	12.42	
Volume (in. ³)	1680	813	61
Tank Weight (lbs)	17	9.5	
Gas Weight	109	11	
	Composite over-	Composite over-	
Material	wrapped stainless	wrapped stainless	Stainless steel
	steel	steel	
Arde qualification	EG10330,	EG10331,	EG 10348,
documents	July 6, 2001	July 6, 2001	Nov. 6, 2001















Time of Flight (TOF)





Time of Flight (TOF)



- TOF measures magnitude and direction of particle velocity and the charge magnitude.
 Also serves as a trigger for entire experiment
- TOF systems are being developed by the same groups that developed the STS-91 TOFs
- Size, Location, and Description
 - Two ~1.5 m diameter honeycomb structures
 - Support scintillator detectors and photomultipliers
 - Located above and below the outer most planes of the Tracker











Lower Time of Flight Integration














Anti-Coincidence Counter (ACC)





Anti-Coincidence Counter (ACC)





Notes:


- Identical carbon fiber cylindrical structure to the ACC that was flown successfully on STS-91
- Size, Location, and Description
 - Mounts to inside diameter of VC Conical Flange
 - Carbon Fiber (Tenax) / Epoxy Resin (Araldite LY556) Composite System for Support Tubes
 - Scintallator Panels
 - Surrounded by Photomultiplier Tubes which are contained in support structure


















Tracker



Tracker



- The Tracker measures the trajectory of the particles as it bends in the magnetic field, determines the charge sign and magnitude and the resulting momentum.
- Location and Size
 - Tracker is located inside the inner cylinder of the vacuum case
 - Mounts at 8 attach locations to the vacuum case flanges (changes made to Tracker Feet for AMS-02)
 - 3 Inner planes approximately 1.1 meters in diameter (were 4 on STS-91)
 - 2 Outer planes approximately 1.5 meters in diameter
 - Tracker Support Plates, Cylindrical Shell, & Conical Flange M55J Fiber / Cyanate Ester Composite facesheet and Hexcell Composite Honeycomb Core
 - Tracker Ladders Carbon Fiber / Cyanate Ester Composite for Ladder reenforcement, 7075 Al. Legs, Airex Foam
 - Support Feet Titanium Ti6AIV4
 - System includes Tracker Alignment System Laser




Silicon Tracker

All 8 planes (200,000 channels) have been produced





























Trent Martin (28




Tracker





Tracker Silicon & Hybrids

Tracker Support Structure










Trent Martin (281) 483-32

R Phase II, Sept. 8, 2008









Ring Imaging Cherenkov Counter (RICH)



RICH




Description


- RICH measures particle charge magnitude and velocity magnitude to a high degree of accuracy
- RICH is located near the bottom of the experiment stack
- Approximately 140 x 140 x 57 cm
- Al. 7075 T7351 for mechanical parts
- Reflector CFC K1352U/EX-1515
- Radiator Silica Aerogel and Sodium Fluoride
- 680 Photomultipliers Hamamatsu R7600 M16


















Electromagnetic Calorimeter (ECAL)




Electromagnetic Calorimeter (ECAL)



- ECAL measure particle energy
- Size, Location, and Description
 - ECAL is located at the bottom of the experiment stack
 - 658 X 658 X 250 mm
 - Mounts at 4 attach locations to USS-02 (radially slotted holes)
 - Aluminum Housing & Brackets
 - Aluminum Honeycomb top and bottom plate
 - Lead Foil 'pancake' layers
 - Scintillating Fibers
 - BC 600 Epoxy
 - Surrounded by Photomultiplier Tubes










Electromagnetic Calorimeter (ECAL)















Electronic Crates



Electronics Crates



Size, Location

- 44 crates mounted at various points on the USS that form the support structure for the Ram & Wake Radiators
 - 24 crates are 195x293x(180-546) mm (8x12x(7-21) in)
 - 20 crates are 210x183x(145-295) mm (8x7x(6-12) in)
- Altogether these crates contain ~600 printed circuit boards of 70 different designs
- 7075-T7351 Series Aluminum alloy for electronic crate structures
- Solithane 113 for Conformal Coating
- XL-ETFE insulated cables



Electronic Crates




Wake

Radiator and

Electronic

Crates

Ram Radiator and Electronic Crates




ECAL and RICH Electronic Crates



Electronics Crates








Star Tracker



- 2 small subcomponents mounted to upper Tracker Plane and Conical Flange
- Total Weight = 3.3x2 Kg (15 lbs)
- Sharp Edge issue for baffle

Star Tracker

The baffle mass is 560 gr (+ attachment)
Baffle material : Al 6061











- Radiator Systems
 - Ram/Wake Radiators
 - Zenith (Cryocooler) Radiator
 - Tracker Ram/Wake Radiators
- Tracker Thermal Control System (TTCS)







- Ram & Wake Radiator System
 - Aluminum Honeycomb
 - Electronic Crates provide stiffness to large flat plates
 - Aluminum Heat Pipes filled with Ammonia
 - Small amounts of Ammonia needed
 - Completely sealed system
- Fixation to USS-02
 - Fixed at upper USS-02 via Electronic Crates
 - Fixed in center of Radiator via mounting bracket
 - Pin Ended Strut to bottom of radiator via Electronic Crates









Zenith Radiator for Cryocoolers














Zenith Radiator

- Propylene filled heat pipes
- Rohacell foam sandwich panel
- Aluminum tubes (3 mm OD, 2 mm ID)
- Tubes soldered to upper face sheet
- Bimetallic interface where aluminum tubes transition to stainless steel tubes before running down the structure and attaching to the Cryocoolers
- Supported in the Z direction by 10 thermally isolating spokes on each quadrant that are 3 mm diameter and 35 mm long
- Also supported by 2 aluminum brackets 1 fixed in all directions & located at edge 1 in center fixed in tangential direction (relative to outer support) & flexible in radial direction

TTCS











Lower Unique Support Structure Integration



