


AMS TRD-GAS





Xenon/CO₂ Supply/Mixing/Circulation System for the AMS TRD

Collaboration of:	RWTH Aachen	(TRD)
	MIT LNS	(TRD-GAS System)
	Univ. Roma	(TRD-GAS Electronics)

for the collaboration: Th.Siedenburger, MIT

TRD INTERNALS

Closed Gas System for 5248 Strawtubes filled with Xe/CO₂:
 328 Strawmodules (16 Kapton-Tubes) Gastight to the diffusion Level (230l: 2l CO₂/d, 0.5l Xe/d) TRD-GAS



TRD Octagon CF/Honeycomb Structure




2 Layer Wall




Module


TRD-GAS Schematics



Box-S Diagram



Box-C Diagram




Relief Valve
Swagelok
SS-CHS4-25


Valve
Marotta
MV100


Flow
Restrictor


Pressure Sensor
GP50


Pump
NMP830

Massachusetts Institute of Technology


2008-JUL-30

TS

CgF

TRD-GAS GSE System II

Supply-Vessel Filling




Tested successfully for 100% CO₂ transfer at MIT

OPTIONAL USE AT KSC ONLY

TRD-GAS GSE II Operation

- Supply Vessel Filling only as **EMERGENCY RECOVERY**
- Emergency: Pressure Loss in Box-S Supply Vessels
 detected during Pre-Launch Wait
- Operation: As part of Payload Preparation
 Always manned (by two persons)
 Manually controlled Valves
 Define Maximum Bottle Pressure before connecting
 Three manual pressure gauges on GSE
 Four PC recorded pressure gauges on GSE & TRD-GAS
 Heated bottle is caged against accidental touching
 to allow weight measurement

CO₂ NIST ISOTHERMALS



Xenon NIST ISOTHERMALS

